



System Manual  
PDM360smart monitor

**ecomat100**


**CR1070**

**CR1071**



CoDeSys® V2.3  
Target V05

English



# Contents

<b>1</b>	<b>About this manual</b>	<b>7</b>
1.1	What do the symbols and formats mean? .....	7
1.2	How is this manual structured? .....	8
<b>2</b>	<b>Safety instructions</b>	<b>9</b>
2.1	Important! .....	9
2.2	What previous knowledge is required? .....	10
<b>3</b>	<b>System description</b>	<b>11</b>
3.1	Information concerning the device .....	11
3.2	Information concerning the software .....	11
3.3	PLC configuration .....	12
<b>4</b>	<b>Configurations</b>	<b>13</b>
4.1	Set device parameters (setup) .....	13
4.1.1	Start set-up .....	14
4.1.2	Show the current device settings .....	15
4.1.3	Change device settings .....	16
4.1.4	Set the brightness / contrast of the display .....	21
4.1.5	Check function of keys and LEDs .....	21
4.1.6	Exit PDM setup, restart device .....	22
4.2	Programming interfaces .....	23
4.2.1	Programming via the serial interface RS232 .....	23
4.2.2	Programming via the CAN interface .....	24
4.3	Set up programming system .....	26
4.3.1	Set up programming system manually .....	26
4.3.2	Set up programming system via templates .....	30
4.3.3	ifm demo programs .....	40
4.4	Hints to wiring diagrams .....	44
4.5	First steps .....	46
4.5.1	Add missing libraries .....	46
4.5.2	Create visualisation .....	48
4.5.3	Create PLC program .....	50
4.6	Device update to new software version .....	51
4.6.1	What is required? .....	51
4.6.2	Adopt application program? .....	51
4.6.3	Device update with the downloader .....	52
4.6.4	Load the application program into the controller .....	52
<b>5</b>	<b>Limitations and programming notes</b>	<b>53</b>
5.1	Limits of the device .....	53
5.1.1	CPU frequency .....	53
5.1.2	Watchdog behaviour .....	54
5.1.3	Limitations for PDM360smart .....	55
5.1.4	Available memory .....	55
5.1.5	Visualisation limits .....	56

# Contents

5.2	Programming notes for CoDeSys projects .....	59
5.2.1	FB, FUN, PRG in CoDeSys .....	59
5.2.2	Note the cycle time! .....	60
5.2.3	Libraries .....	61
5.2.4	Operating sequence .....	62
5.2.5	Creating application program .....	63
5.2.6	Using ifm downloader .....	64
<b>6</b>	<b>Using CAN</b>	<b>65</b>
6.1	General about CAN.....	65
6.1.1	Topology .....	65
6.1.2	CAN interfaces.....	66
6.1.3	Available CAN interfaces and CAN protocols .....	67
6.1.4	System configuration .....	68
6.2	Physical connection of CAN .....	69
6.2.1	Network structure.....	69
6.2.2	CAN bus level .....	70
6.2.3	CAN bus level according to ISO 11992-1.....	70
6.2.4	Bus cable length .....	71
6.2.5	Wire cross-sections .....	72
6.3	Exchange of CAN data .....	73
6.3.1	Hints.....	74
6.3.2	Data reception .....	76
6.3.3	Data transmission .....	76
6.4	Description of the CAN standard program units .....	77
6.4.1	CAN1_BAUDRATE.....	79
6.4.2	CAN1_DOWNLOADID .....	81
6.4.3	CANx_ERRORHANDLER .....	82
6.4.4	CANx_RECEIVE.....	84
6.4.5	CANx_RECEIVE_RANGE.....	86
6.4.6	CANx_TRANSMIT .....	89
6.4.7	CAN1_EXT .....	91
6.4.8	CAN1_EXT_ERRORHANDLER.....	92
6.4.9	CAN1_EXT_RECEIVE .....	93
6.4.10	CANx_EXT_RECEIVE_ALL .....	95
6.4.11	CAN1_EXT_TRANSMIT.....	97
6.5	CAN units acc. to SAE J1939 .....	99
6.5.1	CAN for the drive engineering .....	99
6.5.2	Units for SAE J1939 .....	103
6.6	ifm CANopen libraries.....	116
6.6.1	Technical about CANopen.....	117
6.6.2	Libraries for CANopen .....	155
6.7	CAN errors and error handling.....	181
6.7.1	CAN errors.....	181
6.7.2	Structure of an EMCY message .....	184
6.7.3	Overview CANopen error codes .....	186
<b>7</b>	<b>Input/output functions</b>	<b>189</b>
7.1	Processing input values.....	189
7.1.1	ANALOG_RAW .....	190
7.1.2	TOGGLE.....	191

## Contents

7.2	Adapting analogue values .....	192
7.2.1	NORM.....	193
7.2.2	NORM_DINT .....	195
7.2.3	NORM_REAL .....	197
7.3	Counter functions for frequency and period measurement .....	199
7.3.1	Applications .....	199
7.3.2	Use as digital inputs.....	200
7.4	PWM functions.....	214
7.4.1	Availability of PWM .....	214
7.4.2	PWM signal processing .....	215
7.5	Controller functions.....	227
7.5.1	General .....	227
7.5.2	Setting rule for a controller .....	229
7.5.3	Functions for controllers .....	230
<b>8</b>	<b>Communication via interfaces</b>	<b>240</b>
8.1	Use of the serial interface .....	240
8.1.1	SERIAL_SETUP .....	241
8.1.2	SERIAL_TX .....	243
8.1.3	SERIAL_RX .....	244
8.1.4	SERIAL_PENDING.....	246
<b>9</b>	<b>Managing the data</b>	<b>247</b>
9.1	Software reset.....	247
9.1.1	SOFTRESET .....	248
9.2	Reading / writing the system time.....	249
9.2.1	TIMER_READ.....	250
9.2.2	TIMER_READ_US.....	251
9.3	Reading of the device temperature.....	252
9.3.1	TEMPERATURE.....	253
9.4	Saving, reading and converting data in the memory .....	254
9.4.1	Manual data storage .....	254
9.5	Data access and data check.....	266
9.5.1	SET_IDENTITY .....	267
9.5.2	GET_IDENTITY .....	269
9.5.3	SET_PASSWORD.....	271
9.5.4	CHECK_DATA.....	272
<b>10</b>	<b>Optimising the PLC cycle</b>	<b>274</b>
10.1	Processing interrupts .....	274
10.1.1	SET_INTERRUPT_XMS .....	275
10.1.2	SET_INTERRUPT_I .....	278
10.2	Controlling the cycle time.....	281
10.2.1	PLCPRGTC .....	282
<b>11</b>	<b>LED, buzzer, visualisation</b>	<b>284</b>
11.1	Manage visualisation .....	284
11.1.1	PDMsmart_MAIN.....	285
11.1.2	PDMsmart_MAIN_MAPPER .....	287
11.1.3	PDM_PAGECONTROL .....	289
11.1.4	Library Instrumente.....	291

<b>12</b>	<b>Annex</b>	<b>298</b>
12.1	Error and diagnosis.....	298
12.1.1	Rectify faults and errors.....	298
12.1.2	System messages and operating states.....	299
12.2	Address assignment and I/O operating modes .....	299
12.2.1	Addresses / variables of the I/Os.....	300
12.2.2	Possible operating modes of inputs / outputs.....	301
12.2.3	Address assignment inputs / outputs.....	302
12.3	System flags .....	303
12.4	CANopen tables.....	304
12.4.1	IDs (addresses) in CANopen.....	304
12.4.2	Structure of CANopen messages .....	305
12.4.3	Bootup message .....	309
12.4.4	Network management (NMT) .....	309
12.4.5	CANopen error code.....	313
12.5	Visualisations in the device.....	316
12.5.1	General .....	316
12.5.2	Recommendations for user interfaces.....	317
12.5.3	Basic information about bitmap graphics.....	331
12.6	Overview of the files and libraries used .....	334
12.6.1	Installation of the files and libraries .....	334
12.6.2	General overview .....	335
12.6.3	What are the individual files and libraries used for? .....	337
<b>13</b>	<b>Glossary of Terms</b>	<b>343</b>
<b>14</b>	<b>Index</b>	<b>358</b>
<b>15</b>	<b>ifm weltweit • ifm worldwide • ifm à l'échelle internationale</b>	<b>363</b>

© ifm electronic gmbh

# 1 About this manual

## Contents

What do the symbols and formats mean? .....	7
How is this manual structured? .....	8

202

In the additional "Programming Manual for CoDeSys V2.3" you will obtain more details about the use of the programming system "CoDeSys for Automation Alliance". This manual can be downloaded free of charge from **ifm's** website:

- a) → [www.ifm.com](http://www.ifm.com) > select your country > [Service] > [Download] > [Control systems]
- b) → **ecomatmobile** DVD "Software, tools and documentation"

Nobody is perfect. Send us your suggestions for improvements to this manual and you will receive a little gift from us to thank you.

© All rights reserved by **ifm electronic gmbh**. No part of this manual may be reproduced and used without the consent of **ifm electronic gmbh**.

All product names, pictures, companies or other brands used on our pages are the property of the respective rights owners:

- AS-i is the property of the AS-International Association, (→ [www.as-interface.net](http://www.as-interface.net))
- CAN is the property of the CiA (CAN in Automation e.V.), Germany (→ [www.can-cia.org](http://www.can-cia.org))
- CoDeSys™ is the property of the 3S – Smart Software Solutions GmbH, Germany (→ [www.3s-software.com](http://www.3s-software.com))
- DeviceNet™ is the property of the ODVA™ (Open DeviceNet Vendor Association), USA (→ [www.odva.org](http://www.odva.org))
- IO-Link® (→ [www.io-link.com](http://www.io-link.com)) is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- Microsoft® is the property of the Microsoft Corporation, USA (→ [www.microsoft.com](http://www.microsoft.com))
- PROFIBUS® is the property of the PROFIBUS Nutzerorganisation e.V., Germany (→ [www.profibus.com](http://www.profibus.com))
- PROFINET® is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- Windows® is the property of the →Microsoft Corporation, USA

## 1.1 What do the symbols and formats mean?

2979  
203

The following symbols or pictograms depict different kinds of remarks in our manuals:

### **WARNING**

Death or serious irreversible injuries are possible.




### **CAUTION**

Slight reversible injuries are possible.

### **NOTICE**

Property damage is to be expected or possible.

	Important notes on faults and errors
	Further hints
► ...	Required action
> ...	Response, effect
→ ...	"see"

<a href="#">abc</a>	Cross references (links)
[...]	Designations of keys, buttons or display
	PDM encoder: turn rotary button
	PDM encoder: press rotary button PMD scroll key: press the central key
	Scroll key: direction keys

## 1.2 How is this manual structured?

204

This documentation is a combination of different types of manuals. It is for beginners and also a reference for advanced users.

How to use this documentation:

- Refer to the table of contents to select a specific subject.
- The print version of the manual contains a search index in the annex.
- At the beginning of a chapter we will give you a brief overview of its contents.
- Abbreviations and technical terms are listed in the glossary.

In case of malfunctions or uncertainties please contact the manufacturer at:

→ [www.ifm.com](http://www.ifm.com) > select your country > [Contact].

We want to become even better! Each separate section has an identification number in the top right corner. If you want to inform us about any inconsistencies, please indicate this number with the title and the language of this documentation. Thank you for your support.

We reserve the right to make alterations which can result in a change of contents of the documentation. You can find the current version on **ifm's** website at:

→ [www.ifm.com](http://www.ifm.com) > select your country > [Service] > [Download] > [Control systems]

⇒ Our online help is mostly updated without delay.

⇒ The pdf manuals are only updated at long intervals.



## 2 Safety instructions

### Contents

Important! .....	9
What previous knowledge is required? .....	10


213

### 2.1 Important!

9884

No characteristics are warranted with the information, notes and examples provided in this manual. The drawings, representations and examples imply no responsibility for the system and no application-specific particularities.

The manufacturer of the machine/equipment is responsible for the safety of the machine/equipment.

** WARNING**

Property damage or bodily injury are possible when the notes in this manual are not adhered to! **ifm electronic gmbh** does not assume any liability in this regard.

- ▶ The acting person must have read and understood the safety instructions and the corresponding chapters of this manual before performing any work on or with this device.
- ▶ The acting person must be authorised to work on the machine/equipment.
- ▶ Adhere to the technical data of the devices!  
You can find the current data sheet on **ifm's** homepage at:  
→ [www.ifm.com](http://www.ifm.com) > select your country > [Data sheet search] > (Article no.) > [Technical data in PDF format]
- ▶ Note the installation and wiring information as well as the functions and features of the devices!  
→ supplied installation instructions or on **ifm's** homepage:  
→ [www.ifm.com](http://www.ifm.com) > select your country > [Data sheet search] > (Article no.) > [Operating instructions]

**NOTICE**

The driver module of the serial interface can be damaged!

Disconnecting the serial interface while live can cause undefined states which damage the driver module.

- ▶ Do not disconnect the serial interface while live.

#### Start-up behaviour of the controller

The manufacturer of the machine/equipment must ensure with his application program that when the controller starts or restarts no dangerous movements can be triggered.

A restart can, for example, be caused by:

- voltage restoration after power failure
- reset after watchdog response because of too long a cycle time

## 2.2 What previous knowledge is required?

215

This document is intended for people with knowledge of control technology and PLC programming with IEC 61131-3.

If this device contains a PLC, in addition these persons should know the CoDeSys® software.

The document is intended for specialists. These specialists are people who are qualified by their training and their experience to see risks and to avoid possible hazards that may be caused during operation or maintenance of a product. The document contains information about the correct handling of the product.

Read this document before use to familiarise yourself with operating conditions, installation and operation. Keep the document during the entire duration of use of the device.

Adhere to the safety instructions.

## 3 System description

### Contents

Information concerning the device .....	11
Information concerning the software .....	11
PLC configuration.....	12

975

### 3.1 Information concerning the device

1320

This manual describes the PDM360 monitor family of **ifm electronic gmbh** with a 16-bit microcontroller for mobile vehicles:

- PDM360smart: CR1070, CR1071

### 3.2 Information concerning the software

1796

In this manual we refer to the CoDeSys version 2.3.

In the "programming manual CoDeSys 2.3" you will find more details about how to use the programming system "CoDeSys for Automation Alliance". This manual can be downloaded free of charge from **ifm's** website at:

→ [www.ifm.com](http://www.ifm.com) > select your country > [Service] > [Download] > [Control systems]

→ **ecomatmobile** DVD "Software, tools and documentation"

The application software conforming to IEC 61131-3 can be easily designed by the user with the programming system CoDeSys. Before using this software on the PC please note the following minimal system requirements:

- CPU Pentium II, 500 MHz
- Memory (RAM) 128 MB, recommended: 256 MB
- Free hard disc required (HD) 100 MB
- Runtime system platform Windows 2000 or higher
- CD ROM drive

For more details on the current CoDeSys software:

DE: → [http://www.3s-software.com/index.shtml?de\\_oem1](http://www.3s-software.com/index.shtml?de_oem1)

UK: → [http://www.3s-software.com/index.shtml?en\\_oem1](http://www.3s-software.com/index.shtml?en_oem1)

FR: → [http://www.3s-software.com/index.shtml?fr\\_oem1](http://www.3s-software.com/index.shtml?fr_oem1)

Moreover the user must take into account which software version is used (in particular for the operating system and the function libraries).

**NOTE**

The software versions suitable for the selected target must always be used:

- operating system (*ifm\_CRnnnn\_Vxyyyzz.H86*),
- PLC configuration (*ifm\_CRnnnn\_Vxyyyzz.CFG*),
- the device library (*ifm\_CRnnnn\_Vxyyyzz.LIB*) and
- further files (→ chapter **Overview of the files and libraries used** (→ page [333](#))).

CRnnnn	device article number
Vxx: 00...99	target version number
yy: 00...99	release number
zz: 00...99	patch number

The basic file name (e.g. "CR0020") and the software version number "xx" (e.g. "04") must always have the same value! Otherwise the device goes to the STOP mode.

The values for "yy" (release number) and "zz" (patch number) need **not** match.

**!** The following files must also be loaded:

- the internal libraries (created in IEC 1131) required for the project,
- the configuration files (*\*.CFG*) and
- the target files (*\*.TRG*).

**!** It may happen that the target system cannot or only partly be programmed with your currently installed version of CoDeSys. In such a case, please contact the technical support department of **ifm electronic gmbh**.

**WARNING**

The user is responsible for the reliable function of the application programs he designed. If necessary, he must additionally carry out an approval test by corresponding supervisory and test organisations according to the national regulations.

### 3.3 PLC configuration

1797

The control system **ecomatmobile** is a device concept for series use. This means that the devices can be configured in an optimum manner for the applications.

The current version of the **ecomatmobile** software can be downloaded from our website at:

[www.ifm.com](http://www.ifm.com).

**!** → **Setup the target** (→ page [27](#))

Before using the devices it must be checked whether certain functions, hardware options, inputs and outputs described in the documentation are available in the hardware.

## 4 Configurations

### Contents

Set device parameters (setup) .....	13
Programming interfaces .....	23
Set up programming system .....	26
Hints to wiring diagrams .....	44
First steps .....	46
Device update to new software version .....	51

3615

### 4.1 Set device parameters (setup)

#### Contents

Start set-up .....	14
Show the current device settings .....	15
Change device settings .....	16
Set the brightness / contrast of the display .....	21
Check function of keys and LEDs .....	21
Exit PDM setup, restart device .....	22

7306

In this section you will learn how to set the device via the internal device setup.

**i** Representation and possible functions of the setup depend on the device and may be different from the version described in this manual for customer-specific devices.

## 4.1.1 Start set-up

9863

**!** When the device is in the setup menu no communication is possible via the interfaces (CAN and RS232).

The setup menu is accessed as follows:

- ▶ Press the key combination [F1]+[F5] for approx. 1 s when the supply voltage is applied.




Photo: Setup start page

- > A dark bar with inverted font marks the selected menu item.
- ▶ Select the requested setup menu item with [▼]/[▲] and activate it with [OK].
- > The PDM changes to the selected setup menu.

- ▶ When the setup menu screen has been updated:  
Change to the higher menu level with [esc].
- ▶ When the setup start page has been updated:  
Exit the setup menu with [esc].  
→ **Exit PDM setup, restart device** (→ page [22](#))


### Description of the setup menu items:

Setup field	Meaning
System Information	Show the current settings of the device → <b>Show the current device settings</b> (→ page <a href="#">15</a> )
Change Settings	Change the settings of the device → <b>Change device settings</b> (→ page <a href="#">16</a> ) <ul style="list-style-type: none"> <li>• Show or change the node ID of the CAN interface → <b>Set CAN download ID</b> (→ page <a href="#">17</a>)</li> <li>• Show or change the transmission rate of the CAN interface → <b>Set CAN baud rate</b> (→ page <a href="#">17</a>)</li> <li>• Show or change the transmission rate of the serial interface → <b>Set serial interface</b> (→ page <a href="#">18</a>)</li> <li>• Change password → <b>Change password</b> (→ page <a href="#">19</a>)</li> <li>• Reset device to factory settings → <b>Reset device to factory settings</b> (→ page <a href="#">20</a>)</li> </ul>
LCD Contrast	Set the brightness / contrast of the display → <b>Set the brightness / contrast of the display</b> (→ page <a href="#">21</a> )
Key Test	Test keys and LEDs → <b>Check function of keys and LEDs</b> (→ page <a href="#">21</a> )

## 4.1.2 Show the current device settings

9864

- In the setup start screen switch to the menu screen [System Information] with [OK].

 Settings are not possible in this menu screen.

### System Information

Download ID 127

CAN 125k

RS232 57600

Contrast 15

OS V05.01.01

Application yes

Menu screen [System Information] (example)

- > Download ID = Download identifier for CoDeSys
- > CAN = transmission rate of the CAN interface
- > RS232 = transmission rate of the serial interface
- > Contrast = contrast setting for the display
- > OS = version of the loaded runtime system  
If no runtime system has been loaded: OS = no
- > Application = yes, if the application has been loaded,  
otherwise = no

- Return to the setup start screen with [esc].

## 4.1.3 Change device settings

### Contents

Set CAN download ID .....	17
Set CAN baud rate .....	17
Set serial interface.....	18
Change password .....	19
Reset device to factory settings .....	20


9866

### NOTE

In this menu the device can be reset and the password can be changed.  
For safety reasons we thus recommend:

- ▶ Select a password in the IEC application with the function block **SET\_PASSWORD** (→ page [270](#)).
- > This password is activated when the application is started for the first time.
- > The password protects the following accesses to the device:
  - access to the menu [Change Settings],
  - access to the **ifm** downloader

- ▶ In the setup start screen switch to the menu screen [Change Settings] with [OK].



Menu screen [Change Settings]

- Download ID:  
set download identifier for CoDeSys
- CAN baud rate:  
set the transmission rate of the CAN interface
- RS232 baud rate:  
set the transmission rate of the serial interface
- Change Password
- Factory Settings:  
reset device to factory settings

- ▶ Return to the setup start screen with [esc].



## Set CAN download ID


9868

### **NOTE**

The CAN download ID of the device must match the CAN download ID set in CoDeSys!

In the CAN network the CAN download IDs must be unique!

- In the menu screen [Change Settings] change to the menu screen [Download ID] with [OK].



Menu screen [Download ID]

The identifier is used for the communication with the programming system and the **ifm** downloader. The identifier is set independently of the CAN node ID.  
Preset = 127

- > The digit to be edited is displayed invertedly.
- With [◀]/[▶] select the digit to be changed.
- With [▼]/[▲] change the digit (1...127).
- Save the changed value with [OK].

OR:

- Exit the menu screen without any changes with [esc].


- Return to the menu screen [Change Settings] with [esc].

- > After a reboot (power off/on) the device works with the new settings.

## Set CAN baud rate

9869

- In the menu screen [Change Settings] change to the menu screen [CAN Baudrate] with [OK].



Menu screen [CAN Baudrate]

- > The preset value is displayed invertedly.
- Select the requested value with [▼]/[▲].
- Save the changed value with [OK].

OR:

- Exit the menu screen without any changes with [esc].


- Return to the menu screen [Change Settings] with [esc].

- > After a reboot (power off/on) the device works with the new settings.

## Set serial interface

9871

- ▶ In the menu screen [Change Settings] change to the menu screen [RS232 Baudrate] with [OK].



Menu screen [RS232 Baudrate]

> The preset value is displayed invertedly.

- ▶ Select the requested value with [▼]/[▲].

- ▶ Save the changed value with [OK].

OR:

- ▶ Exit the menu screen without any changes with [esc].

- ▶ Return to the menu screen [Change Settings] with [esc].

> After a reboot (power off/on) the device works with the new settings.

## Change password

9872

In this menu screen the password can be changed.

- > The password protects the following accesses to the device:
  - access to the menu [Change Settings],
  - access to the **ifm** downloader.

The password can have max. 16 characters, however no blanks.  
A distinction between capitals and lowercase letters is made.

### NOTICE

The password is displayed in clear text in the menu screen!

- ▶ Please ensure that no unauthorised person can read the password when entered!

- ▶ In the menu screen [Change Settings] change to the menu screen [Change Password] with [OK].



Menu screen [Change Password]

- > The position to be edited is displayed invertedly.
  - ▶ Select the requested character in the internal list with [▼]/[▲].
  - ▶ With [◀]/[▶] select the next position to be changed.
  - ▶ etc.
  - ▶ Store the password with [OK].
  - > The change is effective immediately.
- OR:
- ▶ Exit the menu screen without any changes with [esc].
  - ▶ Return to the menu screen [Change Settings] with [esc].

### NOTE

Is the password (additionally) to be set in the IEC application (by means of **SET\_PASSWORD** (→ page 270))?

- ▶ The function block can only be called when the application is started for the first time.
- > Otherwise the password modified in the Setup menu is overwritten by the password in the function block when the application is started the next time.


## Reset device to factory settings

9874

When the device is reset to the factory settings the following values are set:

- download ID = 127
- CAN baud rate = 125 kBaud
- RS232 baud rate = 9600 Baud
- contrast = 10
- runtime system is deleted
- application is deleted
- password is deleted

- In the menu screen [Change Settings] change to the menu screen [Factory Settings] with [OK].



Menu screen [Factory Settings]

- Select the entry [yes] with [▲].
- Reset the device to the factory settings with [OK].

OR:


- Exit the menu screen without any changes with [esc].

- Return to the menu screen [Change Settings] with [esc].

## 4.1.4 Set the brightness / contrast of the display

9876

- In the setup start screen switch to the menu screen [LCD Contrast] with [OK].



Menu screen [LCD Contrast]

In this menu screen the functioning of the keys and LEDs is checked.

When one button is pressed, the respective key illumination is activated.


- Press any key.
- The corresponding LED is lit.

- Return to the setup start screen with [esc].

## 4.1.5 Check function of keys and LEDs

9877

- In the setup start screen switch to the menu screen [Key Test] with [OK].



Menu screen [Key Test]

The contrast of the display can only be modified in the device setup. The settings made here are stored non volatily. Preset = 10

- > The digit to be edited is displayed invertedly.
- With [◀]/[▶] select the digit to be changed.
- With [▼]/[▲] change the digit (1...25).
- Save the changed value with [OK].
- > The change is effective immediately.

OR:

- Exit the menu screen without any changes with [esc].

- Return to the setup start screen with [esc].

## 4.1.6 Exit PDM setup, restart device

9878

In this menu you can select whether and how you want to exit the PDM setup.


- ▶ Press the [esc] key in the setup start screen.

If a valid application is stored:

- > The PDM is restarted and then starts the application.

If no valid application is stored:

- > The PDM is restarted and then indicates the message
  - "Bootloader..." or
  - "No Application..."

 In principle, you can access the setup menu via the key combination [F1]+[F5] (press for approx. 1 s) for every device restart.

## 4.2 Programming interfaces

### Contents

Programming via the serial interface RS232 .....	23
Programming via the CAN interface.....	24

9880

For programming the following interfaces are at present available in the PDM:

- programming via the serial interface RS232,
- programming via the CAN interface.

### 4.2.1 Programming via the serial interface RS232

9827


There is one serial interface at connector 2 on the back of the device (technical details → data sheet).

Via a null modem cable (cross-over cables) the PDM can be connected to the serial interface on the computer.


### Set CoDeSys communication parameters for the serial interface

3074

- In CoDeSys click on [Online] > [Communication Parameters...].
- Click on [New...]
- The window "Communication Parameters: New Channel" appears.
- Enter a self-explanatory name, e.g. "ifm\_RS232".
- Select the entry "Serial (RS232)" (→ screenshot):



- Enter the following communication parameters for the new channel (→ screenshot):
  - [Baudrate] = 115200
  - [Motorola byteorder] = yes (for all PDMs except for CR107n)
  - [Motorola byteorder] = no (for all *ecomatmobile* controllers and CR107n devices)
 (Double-click to change the value step by step)



- ▶ Adopt communication parameters with [OK].
- > CoDeSys and the device should now be able to communicate via the serial interface.

## 4.2.2 Programming via the CAN interface

3028

**[i]** Due to the low transmission speed and the large data volumes programming PDMs via the CAN interface is not recommended.

### Prerequisites:

- ▶ Connect the CAN adapter (optional, e.g. article no. EC2112) to the PC.

Connect the CAN adapter to the PDM using a cable. To do so, a terminating resistor (120 ohms) must be available between CAN-H and CAN-L on both sides of the cable connection.

### Configure CAN interface:

- ▶ Please find the configuration of the CAN adapter on the PC in the documentation which belongs to the adapter.

### **[i] NOTE**


The CAN download ID of the device must match the CAN download ID set in CoDeSys!  
In the CAN network the CAN download IDs must be unique!



## Set CoDeSys communication parameters for the CAN interface

3073


- In CoDeSys click on [Online] > [Communication Parameters...].
- Click on [New...]
- The window "Communication Parameters: New Channel" appears.
- Enter a self-explanatory name, e.g. "ifm\_CANopen".
- Select the entry "CANopen DSP302" (→ screenshot):



- Adopt new parameters with [OK].

E.g. enter the following communication parameters for the new channel (→ screenshot):

- [NodeID] = enter 127 (default setting for all *ecomatmobile* controllers and PDM360 devices)
- [CAN card driver] = enter the name of the DLL driver (e.g. *Sie\_usb*; here: *ifmCAN*)



- Adopt communication parameters with [OK].
- > CoDeSys and the device should now be able to communicate via the CAN interface.

## 4.3 Set up programming system

### Contents

Set up programming system manually .....	26
Set up programming system via templates .....	30
ifm demo programs .....	40

3968

### 4.3.1 Set up programming system manually

#### Contents

Setup the target .....	27
Activating the PLC configuration (e.g. CR0020) .....	28

3963

## Setup the target

2687  
11379

When creating a new project in CoDeSys the target file corresponding to the device must be loaded.

- Select the desired target file in the dialogue window (→ screenshot).




Figure: Target system settings (example)

- > The target file constitutes the interface to the hardware for the programming system.
- > At the same time, several important libraries and the PLC configuration are loaded when selecting the target.
- If necessary, remove the loaded libraries or complement them by further libraries.
- Always complement the appropriate device library `ifm_CRnnnn_Vxxyzz.LIB` manually!

### NOTE

The software versions suitable for the selected target must always be used:

- operating system (`ifm_CRnnnn_Vxxyzz.H86` / `ifm_CRnnnn_Vxxyzz.RESX`),
- PLC configuration (`ifm_CRnnnn_Vxx.CFG`),
- device library (`ifm_CRnnnn_Vxxyzz.LIB`) and
- the further files (→ chapter [Overview of the files and libraries used](#) (→ page [333](#)))

CRnnnn	device article number
Vxx: 00...99	target version number
yy: 00...99	release number
zz: 00...99	patch number

The basic file name (e.g. "CR0032") and the software version number "xx" (e.g. "02") must always have the same value! Otherwise the device goes to the STOP mode.

The values for "yy" (release number) and "zz" (patch number) do **not** have to match.

! The following files must also be loaded:

- the internal libraries (created in IEC 1131) required for the project,
- the configuration files (`*.CFG`) and
- the target files (`*.TRG`).

! It may happen that the target system cannot or only partly be programmed with your currently installed version of CoDeSys. In such a case, please contact the technical support department of **ifm electronic gmbh**.


## Activating the PLC configuration (e.g. CR0020)

2688


During the configuration of the programming system (→ previous section) automatically also the PLC configuration was carried out.

The point [PLC Configuration] is reached via the tab [Resources]. Double-click on [PLC Configuration] to open the corresponding window.

- Click on the tab [Resources] in CoDeSys:




- Double-click on [PLC Configuration] in the left column.
- > Display of the current PLC configuration (⇒ following figure):



Based on the configuration the following is available in the program environment for the user:

- All important system and error flags  
Depending on the application and the application program, these flags must be processed and evaluated. Access is made via their symbolic names.
- The structure of the inputs and outputs  
These can be directly symbolically designated (highly recommended!) in the window [PLC Configuration] (example → figure below) and are available in the whole project as [Global Variables].



## 4.3.2 Set up programming system via templates

### Contents

About the ifm templates .....	33
Supplement project with further functions .....	37

3977

**ifm** offers ready-to-use templates (program templates) for a fast, simple, and complete setting up of the programming system.


**i** When installing the *ecomatmobile* DVD "Software, tools and documentation", projects with templates have been stored in the program directory of your PC:

...\\ifm electronic\\CoDeSys V...\\Projects\\Template\_CDVxxxyzz


- ▶ Open the requested template in CoDeSys via:  
[File] > [New from template...]
- > CoDeSys creates a new project which shows the basic program structure. It is strongly recommended to follow the shown procedure.  
→ chapter [Set up programming system via templates](#) (→ page [30](#))

### How do you set up the programming system fast and simply? (e.g. CR2500)

- ▶ In the CoDeSys menu select: [File] > [New from template...]
- ▶ Select directory of the current CD, e.g. ...\\Projects\\TEMPLATE\_CDV010500:



- Find article number of the unit in the list, e.g. CR2500 as CANopen master:




- Mind the correct program version!
- How is the CAN network organised?  
Do you want to work on layer 2 basis or is there a master with several slaves (for CANopen)?
- Confirm the selection with [Open].
- > A new CoDeSys project is generated with the following folder structure (left):


Example for CR2500 as CANopen master:	Another example for CR1051 as CANopen slave:

(via the folder structures in templates → section **About the ifm templates** (→ page [33](#))).

- Save the new project with [file] > [Save as...], and define suitable directory and project name.
- Configuration of the CAN network in the project:  
Double click the element [PLC configuration] above the tabulator [resources] in the CoDeSys project.
- **Right** mouse click in the entry [CR2500, CANopen Master]
- Click in the context menu [Append subelement]:



- > A list of all available EDS files appears in the extended context menu.
- ▶ Select requested element, e.g. "System R360": I/O CompactModule CR2011 (EDS)". The EDS files are in directory C:\...\CoDeSys V...\Library\PLCConf\.
- > The window [PLC configuration] changes as follows:



- ▶ Set CAN parameters, PDO mapping and SDOs for the entered slave according to the requirements.  
**!** Better deselect [Create all SDOs].
- ▶ With further slaves proceed as described above.
- ▶ Save the project!

This should be a sufficient description of your project. You want to supplement this project with further elements and functions?

→ chapter **Supplement project with further functions** (→ page [37](#))



## About the ifm templates

### Contents

Folder structure in general .....	33
Programs and functions in the folders of the templates .....	34
Structure of the visualisations in the templates .....	36

3981

As a rule the following templates are offered for each unit:

- `ifm_template_CRnnnnLayer2_Vxxyyzz.pro`  
for the operation of the unit with CAN layer 2
- `ifm_template_CRnnnnMaster_Vxxyyzz.pro`  
for the operation of the unit as CANopen master
- `ifm_template_CRnnnnSlave_Vxxyyzz.pro`  
for the operation of the unit as CANopen slave

The templates described here are for:

- CoDeSys from version 2.3.9.6
- on the *ecomatmobile* DVD "Software, tools and documentation" from version 010500

The templates all have the same structures.

The selection of this program template for CAN operation already is an important basis for a functioning program.

## Folder structure in general

3978

The POU's are sorted in the following folders:

Folder	Description
CAN_OPEN	for Controller and PDM, CAN operation as master or slave:  contains the FBs for CANopen.
I_O_CONFIGURATION	for Controller, CAN operation with layer 2 or as master or slave:  FBs for parameter setting of the operating modes of the inputs and outputs.
PDM_COM_LAYER2	for Controller, CAN operation as layer 2 or as slave:  FBs for basis communication via layer 2 between PLC and PDM.
CONTROL_CR10nn	for PDM, CAN operation with layer 2 or as master or slave:  Contains FBs for image and key control during operation.
PDM_DISPLAY_SETTINGS	for PDM, CAN operation with layer 2 or as master or slave:  Contains FBs for adjusting the monitor.

## Programs and functions in the folders of the templates

3980

The above folders contain the following programs and function blocks (all = POU):

POUs in the folder CAN_OPEN	Description
CANopen	for Controller and PDM, CAN operation as master:  Contains the following parameterised POU: - CAN1_MASTER_EMCY_HANDLER (→ <i>CANx_MASTER_EMCY_HANDLER</i> (→ page 155)), - CAN1_MASTER_STATUS (→ <i>CANx_MASTER_STATUS</i> (→ page 160)), - SELECT_NODESTATE (→ down).
CANopen	for Controller and PDM, CAN operation as slave:  Contains the following parameterised POU: - CAN1_SLAVE_EMCY_HANDLER (→ <i>CANx_SLAVE_EMCY_HANDLER</i> (→ page 167)), - CAN1_SLAVE_STATUS (→ <i>CANx_SLAVE_STATUS</i> (→ page 172)), - SELECT_NODESTATE (→ down).
Objekt1xxxh	for Controller and PDM, CAN operation as slave:  Contains the values [STRING] for the following parameters: - ManufacturerDeviceName, e.g.: 'CR1051' - ManufacturerHardwareVersion, e.g.: 'HW_Ver 1.0' - ManufacturerSoftwareVersion, e.g.: 'SW_Ver 1.0'
SELECT_NODESTATE	for PDM, CAN operation as master or slave:  Converts the value of the node status [BYTE] into the corresponding text [STRING]: 4 → 'STOPPED' 5 → 'OPERATIONAL' 127 → 'PRE-OPERATIONAL'
POUs in the folder I_O_CONFIGURATION	Description
CONF_IO_CRnnnn	for Controller, CAN operation with layer 2 or as master or slave:  Parameterises the operating modes of the inputs and outputs.
POUs in the folder PDM_COM_LAYER2	Description
PLC_TO_PDM	for Controller, CAN operation with layer 2 or as slave:  Organises the communication from the Controller to the PDM: - monitors the transmission time, - transmits control data for image change, input values etc.
TO_PDM	for Controller, CAN operation with layer 2 or as slave:  Organises the signals for LEDs and keys between Controller and PDM.  Contains the following parameterised POU: - PACK (→ 3S), - PLC_TO_PDM (→ up), - UNPACK (→ 3S).

POUs in the folder CONTROL_CR10nn	Description
CONTROL_PDM	<p>for PDM, CAN operation with layer 2 or as master or slave:</p> <p>Organises the image control in the PDM.</p> <p>Contains the following parameterised POU's:</p> <ul style="list-style-type: none"> <li>- PACK (→ 3S),</li> <li>- PDM_MAIN_MAPPER,</li> <li>- PDM_PAGECONTROL (→ <b>PDM_PAGECONTROL</b> (→ page <a href="#">288</a>)),</li> <li>- PDM_TO_PLC (→ down),</li> <li>- SELECT_PAGE (→ down).</li> </ul>
PDM_TO_PLC	<p>for PDM, CAN operation with layer 2:</p> <p>Organises the communication from the PDM to the Controller:</p> <ul style="list-style-type: none"> <li>- monitors the transmission time,</li> <li>- transmits control data for image change, input values etc.</li> </ul> <p>Contains the following parameterised POU's:</p> <ul style="list-style-type: none"> <li>- CAN_1_TRANSMIT,</li> <li>- CAN_1_RECEIVE.</li> </ul>
RT_SOFT_KEYS	<p>for PDM, CAN operation with layer 2 or as master or slave:</p> <p>Provides the rising edges of the (virtual) key signals in the PDM. As many variables as desired (as virtual keys) can be mapped on the global variable SoftKeyGlobal when e.g. a program part is to be copied from a CR1050 to a CR1055. It contains only the keys F1...F3:</p> <p>→ For the virtual keys F4...F6 variables have to be created. Map these self-created variables on the global softkeys. Work only with the global softkeys in the program. Advantage: Adaptations are only required in <b>one</b> place.</p>
SELECT_PAGE	<p>for PDM, CAN operation with layer 2 or as master or slave:</p> <p>Organises the selection of the visualisations.</p> <p>Contains the following parameterised POU's:</p> <ul style="list-style-type: none"> <li>- RT_SOFT_KEYS (→ up).</li> </ul>
POUs in the folder PDM_DISPLAY_SETTINGS	Description
CHANGE_BRIGHTNESS	<p>for PDM, CAN operation with layer 2 or as master or slave:</p> <p>Organises brightness / contrast of the monitor.</p>
DISPLAY_SETTINGS	<p>for PDM, CAN operation with layer 2 or as master or slave:</p> <p>Sets the real-time clock, controls brightness / contrast of the monitor, shows the software version.</p> <p>Contains the following parameterised POU's:</p> <ul style="list-style-type: none"> <li>- CHANGE_BRIGHTNESS (→ up),</li> <li>- CurTimeEx (→ 3S),</li> <li>- PDM_SET_RTC,</li> <li>- READ_SOFTWARE_VERS (→ down),</li> <li>(→ 3S).</li> </ul>
READ_SOFTWARE_VERS	<p>for PDM, CAN operation with layer 2 or as master or slave:</p> <p>Shows the software version.</p> <p>Contains the following parameterised POU's:</p> <ul style="list-style-type: none"> <li>- DEVICE_KERNEL_VERSION1,</li> <li>- DEVICE_RUNTIME_VERSION,</li> <li>- LEFT (→ 3S).</li> </ul>

POUs in the root directory	Description
PLC_CYCLE	for Controller, CAN operation with layer 2 or as master or slave: Determines the cycle time of the PLC in the unit.
PDM_CYCLE_MS	for PDM, CAN operation with layer 2 or as master or slave: Determines the cycle time of the PLC in the unit.
PLC_PRG	for Controller and PDM, CAN operation with layer 2 or as master or slave: Main program This is where further program elements are included.

## Structure of the visualisations in the templates

3979

Available for the following devices:

- BasicDisplay: CR0451
- PDM: CR10nn

The visualisations are structured in folders as follows:

Folder	Image no.	Description contents
START_PAGE	P00001	Setting / display of... - node ID - CAN baud rate - status - GuardErrorNode - PLC cycle time
__MAIN_MENUES	P00010	Menu screen: - Display setup
___MAIN_MENUE_1		
_____DISPLAY_SETUP		
_____1_DISPLAY_SETUP1	P65000	Menu screen: - Software version - brightness / contrast - display / set real-time clock
_____1_SOFTWARE_VERSION	P65010	Display of the software version.
_____2_BRIGHTNESS	P65020	Adjustment of brightness / contrast
_____3_SET_RTC	P65030	Display / set real-time clock

In the templates we have organised the image numbers in steps of 10. This way you can switch into different language versions of the visualisations by means of an image number offset.

## Supplement project with further functions

3987

You have created a project using an **ifm** template and you have defined the CAN network. Now you want to add further functions to this project.


For the example we take a CabinetController CR2500 as CAN open Master to which an I/O CabinetModule CR2012 and an I/O CompactModule are connected as slaves:




Example: PLC configuration

A joystick is connected to the CR2012 which is to trigger a PWM output on the CR2032. How is that achieved in a fast and simple way?


- ▶ Save CoDeSys project!
- ▶ In CoDeSys use [Project] > [Copy...] to open the project containing the requested function:  
e.g. CR2500demo\_cr2012\_02.pro from directory DEMO\_PLC\_CDV... under C:\...\CoDeSys V...\Projects\:



- ▶ Confirm the selection with [Open].
- ▶ The message "Error when loading the PLC configuration" can be ignored.
- > Window [Copy objects] appears:



- Highlight the elements which contain only the requested function, in this case e.g.:




In other cases libraries and/or visualisations might be required.

- Confirm the selection with [OK].
- > In our example project the elements selected in the demo project have been added:

POUs:	Resources:
<ul style="list-style-type: none"> <li>CAN_OPEN <ul style="list-style-type: none"> <li>CANOPEN (PRG)</li> </ul> </li> <li>DEMO_CR2012 <ul style="list-style-type: none"> <li>CR2012 (PRG)</li> <li>CR2012_DIAI (FB)</li> </ul> </li> <li>PLC_CYCLE (PRG)</li> <li>PLC_PRG (PRG)</li> </ul>	<ul style="list-style-type: none"> <li>Global Variables <ul style="list-style-type: none"> <li>CanOpen implicit Variables (CONSTANT)</li> <li>DEMO_CR2012</li> <li>Globale_Variablen</li> <li>Networkmanagement implicit Variables CAN (CONSTANT)</li> <li>PDM_COMMUNICATION</li> <li>Variablen_Konfiguration (VAR_CONFIG)</li> </ul> </li> </ul>

- Insert the program [CR2012] in the main program [PLC\_PRG] e.g.:



- ▶ The comments of the POUs and global variables usually contain information on how the individual elements have to be configured, included or excluded. This information has to be followed.
- ▶ Adapt input and output variables as well as parameters and possible visualisations to your own conditions.
- ▶ [Project] > [Save] and  
[Project] > [Rebuild all].
- ▶ After possibly required corrections and addition of missing libraries (→ Error messages after rebuild) save the project again.
- ▶ Follow this principle to step by step (!) add further functions from other projects and check the results.
- ▶ [Project] > [Save] and  
[Project] > [Rebuild all].

© ifm electronic gmbh

### 4.3.3 ifm demo programs

#### Contents

Demo program for controller .....	40
Demo programs for PDM and BasicDisplay .....	42

3982

In directory DEMO\_PLC\_CDV... (for Controller) or DEMO\_PDM\_CDV... (für PDMs) under C:\...\CoDeSys V...\Projects\ we explain certain functions in tested demo programs. If required, these functions can be implemented in own projects. Structures and variables of the *ifm* demos match those in the *ifm* templates.

Each demo program shows just **one** topic. For the Controller as well some visualisations are shown which demonstrate the tested function on the PC screen.

Comments in the POU's and in the variable lists help you adapt the demo to your project.

If not stated otherwise the demo programs apply to all controllers or to all PDMs.

The demo programs described here apply for:

- CoDeSys from version 2.3.9.6
- on the *ecomatmobile* DVD "Software, tools and documentation" from version 010500

#### Demo program for controller

3995

Demo program	Function
CR2500Demo_CanTool_xx.pro	separate for PDM360, PDM360compact, PDM360smart and Controller: Contains FBs to set and analyse the CAN interface.
CR2500Demo_ClockFu_xx.pro CR2500Demo_ClockKo_xx.pro CR2500Demo_ClockSt_xx.pro	Clock generator for Controller as a function of a value on an analogue input: Fu = in function block diagram K0 = in ladder diagram St = in structured text
CR2500Demo_CR1500_xx.pro	Connection of a keypad module CR1500 as slave of a Controller (CANopen master).
CR2500Demo_CR2012_xx.pro	I/O cabinet module CR2012 as slave of a Controller (CANopen master), Connection of a joystick with direction switch and reference medium voltage.
CR2500Demo_CR2016_xx.pro	I/O cabinet module CR2016 as slave of a Controller (CANopen master), 4 x frequency input, 4 x digital input high side, 4 x digital input low side, 4 x analogue input ratiometric, 4 x PWM1000 output and 12 x digital output.
CR2500Demo_CR2031_xx.pro	I/O compact module CR2031 as slave of a Controller (CANopen master), Current measurement on the PWM outputs
CR2500Demo_CR2032_xx.pro	I/O compact module CR2032 as slave of a Controller (CANopen master), 4 x digital input, 4 x digital input analogue evaluation, 4 x digital output, 4 x PWM output.



Demo program	Function
CR2500Demo_CR2033_xx.pro	I/O compact module CR2033 as slave of a Controller (CANopen master), 4 x digital input, 4 x digital input analogue evaluation, 4 x digital output,
CR2500Demo_CR2101_xx.pro	Inclination sensor CR2101 as slave of a Controller (CANopen master).
CR2500Demo_CR2102_xx.pro	Inclination sensor CR2102 as slave of a Controller (CANopen master).
CR2500Demo_CR2511_xx.pro	I/O smart module CR2511 as slave of a Controller (CANopen master), 8 x PWM output current-controlled.
CR2500Demo_CR2512_xx.pro	I/O smart module CR2512 as slave of a Controller (CANopen master), 8 x PWM output. Display of the current current for each channel pair.
CR2500Demo_CR2513_xx.pro	I/O smart module CR2513 as slave of a Controller (CANopen master), 4 x digital input, 4 x digital output, 4 x analogue input 0...10 V.
CR2500Demo_Interrupt_xx.pro	Example with <b>SET_INTERRUPT_XMS</b> (→ page 274).
CR2500Demo_Operating_hours_xx.pro	Example of an operating hours counter with interface to a PDM.
CR2500Demo_PWM_xx.pro	Converts a potentiometer value on an input into a normed value on an output with the following POU's: - <b>INPUT_VOLTAGE</b> , - <b>NORM</b> (→ page 192), - <b>PWM100</b> (→ page 222).
CR2500Demo_RS232_xx.pro	Example for the reception of data on the serial interface by means of the Windows hyper terminal.
StartersetDemo.pro StartersetDemo2.pro StartersetDemo2_fertig.pro	Various e-learning exercises with the starter set EC2074.

\_xx = indication of the demo version

## Demo programs for PDM and BasicDisplay

3996

Demo program	Function
CR1051Demo_CanTool_xx.pro CR1053Demo_CanTool_xx.pro CR1071Demo_CanTool_xx.pro	separate for PDM360, PDM360compact, PDM360smart and Controller: Contains FBs to set and analyse the CAN interface.
CR1051Demo_Input_Character_xx.pro	Allows to enter any character in a character string: - capital letters, - small letters, - special characters, - figures.  Selection of the characters via rotary button. Example also suited for e.g. entering a password.  Figure P01000: Selection and takeover of characters
CR1051Demo_Input_Lib_xx.pro	Demo of <b>INPUT_INT</b> from the library <code>ifm_pdm_input_Vxxyyzz</code> (possible alternative to 3S standard). Select and set values via rotary button.  Figure P10000: 6 values INT Figure P10010: 2 values INT Figure P10020: 1 value REAL
CR1051Demo_Linear_logging_on_flash_intern_xx.pro	Writes a CVS data block with the contents of a CAN message in the internal flash memory ( <code>/home/project/daten.csv</code> ), when [F3] is pressed or a CAN message is received on ID 100. When the defined memory range is full the recording of the data is finished.  POUs used: - <b>WRITE_CSV_8BYTE</b> , - <b>SYNC</b> .  Figure P35010: Display of data information Figure P35020: Display of current data record Figure P35030: Display of list of 10 data records
CR1051Demo_O2M_1Cam_xx.pro	Connection of 1 camera O2M100 to the monitor with <b>CAM_O2M</b> . Switching between partial screen and full screen.  Figure 39000: Selection menu Figure 39010: Camera image + text box Figure 39020: Camera image as full screen Figure 39030: Visualisation only
CR1051Demo_O2M_2Cam_xx.pro	Connection of 2 cameras O2M100 to the monitor with <b>CAM_O2M</b> . Switching between the cameras and between partial screen and full screen.  Figure 39000: Selection menu Figure 39010: Camera image + text box Figure 39020: Camera image as full screen Figure 39030: Visualisation only
CR1051Demo_Powerdown_Retain_bin_xx.pro	Example with <b>PDM_POWER_DOWN</b> from the library <code>ifm_CR1051_Vxxyyzz.Lib</code> , to save retain variable in the file <code>Retain.bin</code> . Simulation of ShutDown with [F3].
CR1051Demo_Powerdown_Retain_bin2_xx.pro	Example with <b>PDM_POWER_DOWN</b> from the library <code>ifm_CR1051_Vxxyyzz.Lib</code> , to save retain variable in the file <code>Retain.bin</code> . Simulation of ShutDown with [F3].
CR1051Demo_Powerdown_Retain_cust_xx.pro	Example with <b>PDM_POWER_DOWN</b> and the <b>PDM_READ_RETAIN</b> from the library <code>ifm_CR1051_Vxxyyzz.Lib</code> , to save retain variable in the file <code>/home/project/myretain.bin</code> . Simulation of ShutDown with [F3].
CR1051Demo_Read_Textline_xx.pro	The example program reads 7 text lines at a time from the PDM file system using <b>READ_TEXTLINE</b> .  Figure P01000: Display of read text

Demo program	Function
CR1051Demo_Real_in_xx.pro	Simple example for entering a REAL value in the PDM. Figure P01000: Enter and display REAL value
CR1051Demo_Ringlogging_on_flash_intern_xx.pro	Writes a CVS data block in the internal flash memory when [F3] is pressed or a CAN message is received on ID 100. The file names can be freely defined. When the defined memory range is full the recording of the data starts again.  POUs used: - <b>WRITE_CSV_8BYTE</b> , - <b>SYNC</b> .  Figure P35010: Display of data information Figure P35020: Display of current data record Figure P35030: Display of list of 8 data records
CR1051Demo_Ringlogging_on_flash_pcmcia_xx.pro	Writes a CVS data block on the PCMCIA card when [F3] is pressed or a CAN message is received on ID 100. The file names can be freely defined. When the defined memory range is full the recording of the data starts again.  POUs used: - <b>WRITE_CSV_8BYTE</b> , - <b>OPEN_PCMCIA</b> , - <b>SYNC</b> .  Figure P35010: Display of data information Figure P35020: Display of current data record Figure P35030: Display of list of 8 data records
CR1051Demo_RW-Parameter_xx.pro	In a list parameters can be selected and changed.  Example with the following POUs: - <b>READ_PARAMETER_WORD</b> , - <b>WRITE_PARAMETER_WORD</b> .  Figure P35010: List of 20 parameters

\_xx = indication of the demo version

## 4.4 Hints to wiring diagrams

1426

The wiring diagrams (→ installation instructions of the controllers, chapter "Wiring") show the standard device configurations. The wiring diagrams help allocate the input and output channels to the IEC addresses and the device terminals.

### Examples:

#### 12 GND<sub>A</sub>

12	Terminal number
GND <sub>A</sub>	Terminal designation

#### 30 %IX0.7 BL

30	Terminal number
%IX0.7	IEC address for a binary input
BL	Hardware version of the input, here: <b>Binary Low</b> side

#### 47 %QX0.3 BH/PH

47	Terminal number
%QX0.3	IEC address for a binary output
BH/PH	Hardware version of the output, here: <b>Binary High</b> side or <b>PWM</b> High side

The different abbreviations have the following meaning:

A	Analogue input
BH	Binary input/output, high side
BL	Binary input/output, low side
CYL	Input period measurement
ENC	Input encoder signals
FRQ	Frequency input
H-bridge	Output with H-bridge function
PWM	<b>Pulse-width</b> modulated signal
PWM <sub>I</sub>	PWM output with current measurement
IH	Pulse/counter input, high side
IL	Pulse/counter input, low side
R	Read back channel for one output

Allocation of the input/output channels:

Depending on the device configuration there is one input and/or one output on a device terminal (→ catalogue, installation instructions or data sheet of the corresponding device).

**!** Contacts of Reed relays may be clogged (reversibly) if connected to the device inputs without series resistor.

- ▶ **Remedy:** Install a series resistor for the Reed relay:  
Series resistor = max. input voltage / permissible current in the Reed relay  
**Example:** 32 V / 500 mA = 64 Ohm
- ▶ The series resistor must not exceed 5 % of the input resistance RE of the device input (→ data sheet). Otherwise, the signal will not be detected as TRUE.  
**Example:**  
RE = 3 000 Ohm  
⇒ max. series resistor = 150 Ohm

© ifm electronic gmbh

## 4.5 First steps

### Contents

Add missing libraries .....	46
Create visualisation .....	48
Create PLC program .....	50

3044


- Setup the target (→ [Setup the target](#) (→ page [27](#))).
- Activate PLC configuration (→ [Set up programming system](#) (→ page [26](#))).

### 4.5.1 Add missing libraries

9882

The device data is known to the CoDeSys project, the PLC configuration is activated. Some libraries are already loaded automatically. Depending on the application you have to add some libraries to the project. This is done as follows.

- Click on the tab [Resources] in CoDeSys:



- Double-click on [Library Manager] in the left column.
- Activate the library overview of this device with [Ins] or the menu [Insert] > [Additional Library ...].
- > The window [Open] appears showing the library overview.

The libraries shown here have the following functions:

Library	Description
ifm_CRnnnn_CANopenMaster_Vxxyzz	CANopen master for interface CAN1
ifm_CRnnnn_CANopenSlave_Vxxyzz	CANopen slave for interface CAN1
ifm_CRnnnn_CAN2openMaster_Vxxyzz	CANopen master for interface CAN2
ifm_CRnnnn_CAN2openSlave_Vxxyzz	CANopen slave for interface CAN1
ifm_CRnnnn_Vxxyzz.LIB	Device library

**NOTE**

The software versions suitable for the selected target must always be used:

- operating system (`ifm_CRnnnn_Vxxyyzz.H86` / `ifm_CRnnnn_Vxxyyzz.RESX`),
- PLC configuration (`ifm_CRnnnn_Vxx.CFG`),
- device library (`ifm_CRnnnn_Vxxyyzz.LIB`) and
- the further files (→ chapter **Overview of the files and libraries used** (→ page [333](#)))

CRnnnn	device article number
Vxx: 00...99	target version number
yy: 00...99	release number
zz: 00...99	patch number

The basic file name (e.g. "CR0032") and the software version number "xx" (e.g. "02") must always have the same value! Otherwise the device goes to the STOP mode.

The values for "yy" (release number) and "zz" (patch number) do **not** have to match.

**!** The following files must also be loaded:

- the internal libraries (created in IEC 1131) required for the project,
- the configuration files (`*.CFG`) and
- the target files (`*.TRG`).

**!** It may happen that the target system cannot or only partly be programmed with your currently installed version of CoDeSys. In such a case, please contact the technical support department of **ifm electronic gmbh**.

► Add the following libraries one after the other if they are not yet integrated in the project:

- Standard library `Standard.Lib` from `C:\...\CoDeSys\Library\`
- Device library `ifm_CRnnnn_Vxxyyzz.LIB` from  
`C:\...\CoDeSys\Targets\ifm\Library\ifm_CRnnnn\`

► Save the project with [Ins]+[s].


> The project is now prepared for the PLC program of the application.

## 4.5.2 Create visualisation


3100

For this project we first create the visualisation and only then the PLC program.

- ▶ Click on the tab [Visualizations] in CoDeSys:
- ▶ Beside the folder symbol right-click on [Visualizations] followed by a click on [Add Object ...]:



- > The window [New Visualization] appears.
- ▶ After [Name of the new Visualization] enter the name of the first image in capital letters (!) (max. 8 characters, no space!):



- ▶ Confirm with [OK].
- > CoDeSys opens the drawing field for this visualisation:



**IMPORTANT:** The drawing field corresponds to the size of the LCD display.


For handling the visualisation editor

- CoDeSys online help or
- CoDeSys programming manual → *ecomatmobile* DVD "Software, tools and documentation"


To complete the test program we now create a simple visualisation.




- ▶ Select the symbol "rectangle".
- ▶ Indicate to a point on the drawing area which is the start point of a rectangle. Press the left mouse button and keep it pressed to drag out a rectangle in any direction. Release the mouse button at the end point of the rectangle:



- ▶ Right-click on the rectangle to open the context menu and select [Configure ...]:



- > The window [Regular Element Configuration (#0)] appears:




- ▶ In the field [Category] select the entry [Text].
- ▶ Enter a display text in the field [Text] > [Content] (→ upper screenshot).
- ▶ Confirm the entry with [OK].
- ▶ Save the project with [Ins]+[s] from time to time!

## 4.5.3 Create PLC program

9885

For this project we first create the visualisation and only then the PLC program.


- For the actual programming you go to programming (PLC\_PRG) via the tab [POUs]:



Only some networks are necessary for an executable program. To be able to use important device functions you only need the following POU's:

- PDMsmart\_MAIN from the library `ifm_CR1071_init_Vxxxyzz.LIB` and
- PDMsmart\_MAIN\_MAPPER from the library `ifm_CRnnnn_Vxxxyzz.LIB`.

- Adopt the program from the following example:



- > You can already use the following functions:
  - read the key status or
  - set the LEDs.

The variable `init_1` is already set to TRUE when it is defined:

```
init_1: BOOL := TRUE
```

- At the end of the first cycle you must reset the variable `init_1`:
  - network 3 in the above example.

**i** You can find all important system variables for the PDM360smart, e.g. key F1 here:

→ under the tab [Resources] at the top of the list:

→ library `ifm_CRnnnn_Vxxxyzz.LIB`

→ global variables <R> and

→ PDMsmart\_MAIN <R>

## 4.6 Device update to new software version

### Contents

What is required? .....	51
Adopt application program? .....	51
Device update with the downloader .....	52
Load the application program into the controller .....	52

3084

When the operating system software or the CoDeSys runtime system is considerably improved, *ifm* releases a new version. The versions are numbered consecutively (V01, V02, V03, ...).

Please see the respective documentation for the new functions of the new software version. Note whether special requirements for the hardware version are specified in the documentation.

If you have a device with an older version and if the conditions for the hardware and your project are ok, you can update your device to the new software version.

### 4.6.1 What is required?

9888

What is required?	Where from?
current CoDeSys version	e.g. <i>ecomatmobile</i> DVD "Software, tools and documentation"
program <i>ifm</i> downloader	e.g. <i>ecomatmobile</i> DVD "Software, tools and documentation"
current files of the software update	<ul style="list-style-type: none"> <li><i>ecomatmobile</i> DVD "Software, tools and documentation"</li> <li>ifm download area → <a href="http://www.ifm.com">www.ifm.com</a> &gt; select your country &gt; [Service] &gt; [Download] &gt; [Control systems]</li> </ul>

### 4.6.2 Adopt application program?

9891

Is the application program stored in the device to be available after the device update? Then the following points have to be done before the device update:

- ▶ Export the application program in CoDeSys with [Project] > [Export...].
- ▶ Install the respective target system corresponding to the device update with [Start Programs] > [ifm electronic] > [CoDeSys V2.3] > [InstallTarget].
- ▶ Create a new project with the current version of the target system in CoDeSys.
- ▶ Import the exported application program in CoDeSys with [Project] > [Import...].
- ▶ If required, update the libraries in the project.
- ▶ Prepare the project for translation in CoDeSys with [Project] > [Clean all].
- ▶ Store the project.
- ▶ Prepare the project for transmission to the device in CoDeSys with [Project] > [Rebuild all].
- ▶ Update the device (→ following chapter).

### 4.6.3 Device update with the downloader

9889

The operating system is transferred to the controller using the independent program **ifm** downloader.



- ▶ Select the interface (RS232 or CAN) in the menu with [Interface].
- ▶ Select the operating system file (e.g. ifm\_CR1071\_V030002.H86) in the menu with [Download].
- > The download starts automatically after the selection of the operating system file.
- > The application program is deleted.
- > The device update of the operating system has been completed successfully.

### 4.6.4 Load the application program into the controller

9892

When the device update has been completed successfully, the application program can be loaded into the device.

- ▶ Open the updated project (according to the device update) in CoDeSys.
- ▶ Connect the programming system with the device in CoDeSys with [Online] > [Login].
- ▶ Load the updated project into the controller with [Online] > [Write file to PLC].
- > THAT'S IT!

## 5 Limitations and programming notes

### Contents

Limits of the device.....	53
Programming notes for CoDeSys projects.....	59

3055

Here we show you the limits of the device and help you with programming notes.

### 5.1 Limits of the device

7358

**Note** Note the limits of the device! → data sheet

#### 5.1.1 CPU frequency

8005

► It must also be taken into account which CPU is used in the device:

Controller family / article no.	CPU frequency [MHz]
BasicController: CR040n	50
CabinetController: CR0301, CR0302	20
CabinetController: CR0303	40
ClassicController: CR0020, CR0505	40
ClassicController: CR0032, CR0033	150
ExtendedController: CR0200	40
ExtendedController: CR0232, CR0233	150
SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506	40
SmartController: CR25nn	20

Monitor family / article no.	CPU frequency [MHz]
BasicDisplay: CR0451	50
PDM360: CR1050, CR1051	50
PDM360compact: CR1052, CR1053, CR1055, CR1056	50
PDM360NG: CR108n	400
PDM360smart: CR1070, CR1071	20

The higher the CPU frequency, the higher the performance when complex units are used at the same time.

## 5.1.2 Watchdog behaviour

1490

For (nearly) all programmable *ecomatmobile* devices the program runtime is monitored by a watchdog of CoDeSys.

If the maximum watchdog time is exceeded:

- the device carries out a reset and starts again

BUT:

BasicController: CR040n:

- all processes are stopped (reset)
- all outputs are switched off
- the status LED flashes red at 10 Hz
- reset necessary (after resolving the fault) via maintenance tool

BasicDisplay: CR0451:

- all processes are stopped (reset)
- all outputs are switched off
- the screen goes black
- the status LED flashes red at 10 Hz
- reset necessary (after resolving the fault) via maintenance tool

SafetyController: CR7nnn

- all processes are stopped (reset)
- all outputs are switched off
- the screen goes black
- the status LED flashes red at 5 Hz
- restart necessary (after resolving the fault) via voltage off/on

PDM360NG: CR108n

- all processes are stopped (reset)
- all outputs are switched off
- the screen goes black
- the status LED flashes red at 5 Hz
- reset necessary (after resolving the fault) via voltage off/on plus 'Set the device parameters' → [Set device parameters \(setup\)](#) (→ page [13](#))

Depending on the hardware the individual controllers have a different time behaviour:

Device	Watchdog [ms]
BasicController: CR040n	100
BasicDisplay: CR0451 (application program)	100
BasicDisplay: CR0451 (visualisation)	1 200
CabinetController: CR030n	100...200
ClassicController: CR0020, CR0032, CR0033, CR0505	100
ExtendedController: CR0200, CR0232, CR0233	100
PCB controller: CS0015	100...200
SafetyController: CR7nnn	100
SmartController: CR25nn	100...200
PDM360: CR1050, CR1051	no watchdog
PDM360compact: CR1052, CR1053, CR1055, CR1056	no watchdog
PDM360NG: CR108n	monitored by Linux *)
PDM360smart: CR1070, CR1071	100...200

\*) The Linux kernel and critical processes are separately monitored (different times).

## 5.1.3 Limitations for PDM360smart

9895

**!** For the limit values please make sure to adhere to the data sheet!

Particularly note the following limitations:

Designation	PDM360smart CR1070, CR1071
Length of strings	< 80 characters
Length of path names	< 80 characters
Number of graphical objects per visualisation page	50...100
Number of bitmaps <sup>1)</sup> per project	< 100
Number of character sets per project	< 5
Number of POUs <sup>2)</sup> per project	< 24 576

<sup>1)</sup> Specifications for the start screen → chapter **Visualisation limits** (→ page [56](#)).

<sup>2)</sup> POU (Program Organisation Unit) = function, function block or program block

## 5.1.4 Available memory

9896

Applies only to the following devices:

- PDM360smart: CR1070, CR1071

Physical memory	Physically existing FLASH memory (non-volatile, slow memory)	1 Mbytes
	Physically existing SRAM <sup>1)</sup> (volatile, fast memory)	256 Kbytes
	Physically existing EEPROM (non-volatile, slow memory)	---
	Physically existing FRAM <sup>2)</sup> (non-volatile, fast memory)	2 Kbytes
Use of the FLASH memory	Memory reserved for the code of the IEC application	448 Kbytes
	Memory for data other than the IEC application that can be written by the user such as files, bitmaps, fonts	176 Kbytes
	Memory for data other than the IEC application that can be processed by the user by means of FBs such as FLASHREAD, FLASHWRITE	16 Kbytes
RAM	Memory for the data in the RAM reserved for the IEC application	48 Kbytes
Remanent memory	Memory for the data declared as VAR_RETAIN in the IEC application	128 bytes
	Memory for the flags agreed as RETAIN in the IEC application	---
	Remanent memory freely available to the user. Access is made via FRAMREAD, FRAMWRITE.	1536 bytes
	FRAM <sup>2)</sup> freely available to the user. Access is made via the address operator.	---

<sup>1)</sup> SRAM indicates here all kinds of volatile and fast memories.

<sup>2)</sup> FRAM indicates here all kinds of non-volatile and fast memories.

## 5.1.5 Visualisation limits

9908

Embedded displays used, for example, in the PDM360, cannot provide the full colour scope of bitmap graphics because the available power reserves are restricted. Nevertheless, the following preparations enable bitmap images in the PDM:

- Correct selection of the motifs,
- correct scaling of the bitmaps before using them on the PDM.

Power reserves of the device → chapter **Limits of the device** (→ page [53](#))

### Image specifications for the start screen:

Parameter	Limitation
File type	Bitmap (* .bmp) RLE compressed
Filename	Only small letters, naming convention = 8.3
Image size	128 x 64 pixel
Colours	1 bit = only black and white, no grey shades
Required memory space	approx. 1 kbyte, depending on the image content by RLE compression

The graphics used in the project may be larger than the specified image size. In this case, however, only a (selectable) section of the image will be visible.

### Colours:

<div>Colors</div> <ul style="list-style-type: none"> <li><input type="radio"/> True Color (32 bit)</li> <li><input type="radio"/> True Color (24 bit)</li> <li><input type="radio"/> High Color (16 Bit)</li> <li><input type="radio"/> High Color (15 Bit)</li> <li><input type="radio"/> 256 Colors</li> <li><input type="radio"/> 16 Colors</li> <li><input type="radio"/> GrayScale</li> <li><input checked="" type="radio"/> Monochrome</li> <li><input type="radio"/> Adaptive w/ Palette</li> </ul>	<ul style="list-style-type: none"> <li>• only supports the 2 colours black and white</li> <li>• monochrome bitmap bilevel</li> <li>• For the monochrome bitmap only the colours white (R=0, G=0, B=0) and black (R = 224, G = 224, B = 224) or the monochrome colour format bilevel should be used.</li> </ul>
--	--

### Resample / scale image

9910

If an image is loaded in the device which does not correspond to the size or colour requirements, it is not displayed.

- ▶ First carry out all transformations of the bitmap or the image in an image processing program on your computer. On the device itself no adaptations will be made (size, scaling, colour).
- ▶ Only save the suitably transformed images in the visualisation of the device.
- ▶ Load only RLE coded bitmaps into the device.

→ chapter **Image size vector graphics / pixel graphics** (→ page [332](#))



## CoDeSys visualisation elements

9902

Applies only to the following devices:

- PDM360smart: CR1070, CR1071

**i** Not all CoDeSys functions can be executed successfully on the PDM:

Visualisation element	Functional safety for the PDM	
Line	o	Line thickness < 1 mm
Line type for frame	—	Not supported
Rectangle	+	No problems known
Rounded rectangle	—	Not supported
Circle, ellipse	+	No problems known
Polygons	o	Possible but too many elements on one page slow down the system
Pie chart	—	Not supported
BMP graphics files	+	< 100 a project File name: < 27 characters For a size of 128 x 64 pixels: < 60 bitmaps a project
Visualisation	o	Possible but too many elements on one page slow down the system
Buttons	+	No problems known
WMF graphics files	—	Not supported
Tables	—	No sensible use possible
Trend curves	—	Not supported
Alarm table	—	No sensible use possible
Scales	—	Not supported → note below
Bar graph	+	No problems known
Histogram	+	No problems known
Dynamic text (XML)	—	Not supported
Placeholder %t (system time)	—	Not supported
Online Change	—	Not supported

To avoid too long image loading times please note:

- Do not group graphical elements in the graphics!
- If possible, do not superimpose graphics.
- Some visualisations with the CoDeSys options are not very satisfactory, e.g. round scales.  
Solution:  
Integrate the requested elements as (an externally generated) BMP graphic. It is then sufficient to turn an arrow in the visualisation depending on the values. This arrow could change its colour if limit values are exceeded.

## Texts

9903

Applies only to the following devices:

- PDM360smart: CR1070, CR1071

- To avoid too long image loading times:  
Reduce the number of different character sets (fonts) per project.

### Supported fonts/font sizes:

Font	Font size [point]	Note
Arial	6, 8, 10, 13, 20, 26	normal
Arial	32	only numbers
Arial Black	8, 10, 13, 20, 26	bold

- NOT supported attributes:
  - underlined
  - italic
  - crossed out
- If the set font is not supported, the characters are represented in "Arial" with font size 6 point.
- If the set font is not supported, the characters are first represented in the next smaller font size.
- The smallest font size which is clearly visible on the PDM is 8 point.

## 5.2 Programming notes for CoDeSys projects

### Contents

FB, FUN, PRG in CoDeSys .....	59
Note the cycle time!.....	60
Libraries .....	61
Operating sequence .....	62
Creating application program .....	63
Using ifm downloader.....	64

7426

Here you receive tips how to program the device.

- See the notes in the CoDeSys programming manual  
→ *ecomatmobile* DVD "Software, tools and documentation".

### 5.2.1 FB, FUN, PRG in CoDeSys

8473

In CoDeSys we differentiate between the following types of units (POUs):

#### FB = function block

- A FB may have several inputs and several outputs.
- A FB may be called several times within a project.
- For every call you must declare an instance.
- Allowed: in a FB call of FB or FUN.

#### FUN = function

- A function may have several inputs but only one output.
- The output is of the same data type as the function itself.

#### PRG = program

- A PRG may have several inputs and several outputs.
- A PRG may be called only once within a project.
- Allowed: in a PRG call of PRG, FB or FUN.

#### **NOTE**

Function blocks must NOT be called within a function.  
Otherwise: During the executing the application program will crash.  
POU-calls must not be recursive (POU must not call itself), also not indirectly.

**Background:**

By calling a function all variables...

- will become initialised and
- after return will lose their validity.

Function blocks have two calls:

- one initialising call and
- the call to do something.

Therefore, that means for a FB call inside a function, that there is every time an additional initialising call.

## 5.2.2 Note the cycle time!

8006

For the programmable devices from the controller family *ecomatmobile* numerous functions are available which enable use of the devices in a wide range of applications.

As these units use more or fewer system resources depending on their complexity it is not always possible to use all units at the same time and several times.

### NOTICE

Risk that the controller acts too slowly! Cycle time must not become too long!

- When designing the application program the above-mentioned recommendations must be complied with and tested. If necessary, the cycle time must be optimised by restructuring the software and the system set-up.

## 5.2.3 Libraries

9938

The CoDeSys projects should contain at least the following libraries:

- Standard library `Standard.Lib` in `C:\...\CoDeSys\Library\`
- Device library `ifm_CRnnnn_Vxxyzz.LIB`  
in `C:\...\CoDeSys\Targets\ifm\Library\ifm_CRnnnn`

When the PDM is used as a CANopen master at least the following libraries are necessary:

- `3S_CanDrvOptTableEx.lib` in `C:\...\CoDeSys\Library\`
- `3S_CanOpenNetVarOptTableEx.lib` in `C:\...\CoDeSys\Library\`
- `3S_CanOpenManagerOptTableEx.lib` in `C:\...\CoDeSys\Library\`
- `3S_CanOpenMasterOptTableEx.lib` in `C:\...\CoDeSys\Library\`

When the PDM is used as a CANopen slave at least the following libraries are necessary:

- `3S_CanDrvOptTableEx.lib` in `C:\...\CoDeSys\Library\`
- `3S_CanOpenNetVarOptTableEx.lib` in `C:\...\CoDeSys\Library\`
- `3S_CanOpenManagerOptTableEx.lib` in `C:\...\CoDeSys\Library\`
- `3S_CanOpenDeviceOptTableEx.lib` in `C:\...\CoDeSys\Library\`

For handling files and writing data:

**!** Danger for the system if handling is wrong! Experience required!

- Library `SysLibFile.Lib`  
in `C:\...\CoDeSys\Library\` **OR:**
- Library `ifm_CRnnnn_Vxxyzz.LIB`  
in `C:\...\CoDeSys\Targets\ifm\Library\ifm_CRnnnn`

## 5.2.4 Operating sequence

7427

In principle, there are two options to create a PDM project:

<b>A) First the visualisation, then the PLC program.</b>	
<b>Advantages:</b> <ul style="list-style-type: none"> <li>• In the program it is possible to cross-reference to the finished images.</li> <li>• When the PLC program is tested the images already exist</li> </ul>	<b>Disadvantage:</b> <ul style="list-style-type: none"> <li>• The PLC parameters and variables required in the images have not yet been defined.</li> </ul>
<b>B) First the PLC program, then the visualisation.</b>	
<b>Advantage:</b> <ul style="list-style-type: none"> <li>• All parameters and variables are defined in the PLC program before they are referred to in the visualisations.</li> </ul>	<b>Disadvantages:</b> <ul style="list-style-type: none"> <li>• The parameters from the images (image number, key, LED, etc.) must be found elsewhere.</li> <li>• The PLC program can only be tested after creation of the visualisation.</li> </ul>

In both cases we urgently recommend to design a precise structure of the visualisation and its contents **before** starting.

## 5.2.5 Creating application program


8007

The application program is generated by the CoDeSys programming system and loaded in the controller several times during the program development for testing:

In CoDeSys: [Online] > [Write file in the controller].

For each such download via CoDeSys the source code is translated again. The result is that each time a new checksum is formed in the controller memory. This process is also permissible for safety controllers until the release of the software.

At least for safety-related applications the software and its checksum have to be identical for the series production of the machine.



Graphics: Creation and distribution of the (certified) software

## 5.2.6 Using ifm downloader

8008

The **ifm** downloader serves for easy transfer of the program code from the programming station to the controller. As a matter of principle each application software can be copied to the controllers using the **ifm** downloader. Advantage: A programming system with CoDeSys licence is not required.

Safety-related application software **MUST** be copied to the controllers using the **ifm** downloader so as not to falsify the checksum by which the software has been identified.

**!** The **ifm** downloader cannot be used for the following devices:

- BasicController: CR040n
- BasicDisplay: CR0451
- PDM360: CR1050, CR1051,
- PDM360compact: CR1052, CR1053, CR1055, CR1056,
- PDM360NG: CR108n



## 6 Using CAN

### Contents

General about CAN .....	65
Physical connection of CAN .....	69
Exchange of CAN data .....	73
Description of the CAN standard program units .....	77
CAN units acc. to SAE J1939 .....	98
ifm CANopen libraries .....	115
CAN errors and error handling .....	180

1163

### 6.1 General about CAN

1164

The CAN bus (**C**ontroller **A**rea **N**etwork) belongs to the fieldbuses.

It is an asynchronous serial bus system which was developed for the networking of control devices in automobiles by Bosch in 1983 and presented together with Intel in 1985 to reduce cable harnesses (up to 2 km per vehicle) thus saving weight.

#### 6.1.1 Topology

1244

The CAN network is set up in a line structure. A limited number of spurs is allowed. Moreover, a ring type bus (infotainment area) and a star type bus (central locking) are possible. Compared to the line type bus both variants have one disadvantage:

- In the ring type bus all control devices are connected in series so that the complete bus fails if one control device fails.
- The star type bus is mostly controlled by a central processor as all information must flow through this processor. Consequently no information can be transferred if the central processor fails. If an individual control device fails, the bus continues to function.

The linear bus has the advantage that all control devices are in parallel of a central cable. Only if this fails, the bus no longer functions.

#### **NOTE**

The line must be terminated at its two ends using a terminating resistor of 120  $\Omega$  to prevent corruption of the signal quality.

The devices of **ifm electronic** equipped with a CAN interface have no terminating resistors.

The disadvantage of spurs and star-type bus is that the wave resistance is difficult to determine. In the worst case the bus no longer functions.

For a high-speed bus (> 125 kbits/s) 2 terminating resistors of 120  $\Omega$  (between CAN\_HIGH and CAN\_LOW) must additionally be used at the cable ends.

## 6.1.2 CAN interfaces

269

The controllers have several CAN interfaces depending on the hardware structure. In principle, all interfaces can be used with the following functions independently of each other:

- CAN at level 2 (layer 2)
- CANopen (→ chapter *ifm CANopen libraries* (→ page [115](#))) protocol to CiA 301/401 for master/slave operation (via CoDeSys)
- *CANopen network variables* (→ page [148](#)) (via CoDeSys)
- Protocol SAE J1939 (for engine management, → chapter *CAN units acc. to SAE J1939* (→ page [98](#)))
- Bus load detection
- Error frame counter
- Download interface (not all devices)
- 100 % bus load without package loss

Which CAN interface of the device has which potential, → data sheet of the device.

The actual data sheet you will find on the *ifm* homepage:

→ [www.ifm.com](http://www.ifm.com) > select your country > [data sheet search] > (article no.)

 more interesting CAN protocols:

- "Truck & Trailer Interface" to ISO 11992 → chapter *Use of the CAN interface to ISO 11992*  
Available for the following devices: SmartController: CR2501
- ISOBUS to ISO 11783 for agricultural machines
- NMEA 2000 for maritime applications
- CANopen truck gateway to CiA 413 (conversion between ISO 11992 and SAE J1939)

## 6.1.3 Available CAN interfaces and CAN protocols

6467

In the **ifm** devices the following CAN interfaces and CAN protocols are available:

Device	Interface default download identifier	CAN 1 ID 127	CAN 2 ID 126	CAN 3 ID 125	CAN 4 ID 124	Standard Baudrate [kbit/s]
BasicController: CR040n		CAN layer 2 CANopen SAE J1939	CAN layer 2 CANopen SAE J1939	---	---	250
BasicDisplay: CR0451		CAN layer 2 CANopen SAE J1939	---	---	---	250
CabinetController: CR0301, CR0302		CAN layer 2 CANopen SAE J1939	---	---	---	125
CabinetController: CR0303		CAN layer 2 CANopen SAE J1939	CAN layer 2 SAE J1939	---	---	125
ClassicController: CR0020, CR0505		CAN layer 2 CANopen SAE J1939	CAN layer 2 SAE J1939	---	---	125
ClassicController: CR0032, CR0033		CAN layer 2 CANopen SAE J1939	CAN layer 2 CANopen SAE J1939	CAN layer 2 CANopen SAE J1939	CAN layer 2 CANopen SAE J1939	125
ExtendedController: CR0200		<b>CPU 1 CAN 1</b> ID 127  CAN layer 2 CANopen SAE J1939	<b>CPU 1 CAN 2</b> ID 126  CAN layer 2 SAE J1939	<b>CPU 2 CAN 1</b> ID 127  CAN layer 2 CANopen SAE J1939	<b>CPU 2 CAN 2</b> ID 126  CAN layer 2 SAE J1939	125
ExtendedController: CR0232, CR0233		CAN layer 2 CANopen SAE J1939	CAN layer 2 CANopen SAE J1939	CAN layer 2 CANopen SAE J1939	CAN layer 2 CANopen SAE J1939	125
PCB controller: CS0015		CAN layer 2 CANopen SAE J1939	---	---	---	rotary switch
SafetyController: CR7021, CR7506		CAN layer 2 CANopen CANopen Safety SAE J1939	CAN layer 2 CANopen Safety SAE J1939	---	---	125
ExtendedSafetyController: CR7201		<b>CPU 1 CAN 1</b> ID 127  CAN layer 2 CANopen CANopen Safety SAE J1939	<b>CPU 1 CAN 2</b> ID 126  CAN layer 2 CANopen Safety SAE J1939	<b>CPU 2 CAN 1</b> ID 127  CAN layer 2 CANopen SAE J1939	<b>CPU 2 CAN 2</b> ID 126  CAN layer 2 SAE J1939	125
SmartController: CR2500		CAN layer 2 CANopen SAE J1939	CAN layer 2 SAE J1939	---	---	125
PDM360: CR1050, CR1051		CAN layer 2 CANopen	CAN layer 2 CANopen SAE J1939	---	---	125
PDM360compact: CR1052, CR1053, CR1055, CR1056		CAN layer 2 CANopen	---	---	---	125

Interface default download identifier	CAN 1 ID 127	CAN 2 ID 126	CAN 3 ID 125	CAN 4 ID 124	Standard Baudrate [kbit/s]
Device					
PDM360smart: CR1070, CR1071	CAN layer 2 CANopen SAE J1939	---	---	---	125
PDM360NG: CR108n	CAN layer 2 CANopen SAE J1939	CAN layer 2 CANopen SAE J1939	CAN layer 2 CANopen SAE J1939	CAN layer 2 CANopen SAE J1939	125

## 6.1.4 System configuration

2270

The controllers are delivered with the following download identifier (= ID):

- ID 127 for CAN interface 1
- ID 126 for CAN interface 2 (if available)
- ID 125 for CAN interface 3 (if available)
- ID 124 for CAN interface 4 (if available)

The download system uses this identifier for the first communication with a non configured module via CAN.

The download IDs can be set as follows:

- via the PLC browser of the programming system,
- via the the downloader or the maintenance tool or
- via the application program.

Via the mode "Autoconfig" of the boot loader only CAN interface 1 can be set.

As the download mechanism works on the basis of the CANopen SDO service (even if the controller is not operated in the CANopen mode) all controllers in the network must have a unique identifier. The actual COB IDs are derived from the module numbers according to the "predefined connection set". Only one non configured module is allowed to be connected to the network at a time. After assignment of the new participant number 1...126, a download or debugging can be carried out and then another device can be connected to the system.

**!** The download ID is set irrespective of the CANopen identifier. Ensure that these IDs do not overlap with the download IDs and the CANopen node numbers of the other controllers or network participants.

Comparison of download-ID vs. COB-ID:

Controller program download		CANopen	
Download-ID	COB-ID SDO	Node ID	COB-ID SDO
1...127	TX: 580 <sub>16</sub> + download ID	1...127	TX: 580 <sub>16</sub> + node ID
	RX: 600 <sub>16</sub> + download ID		RX: 600 <sub>16</sub> + node ID

TX = slave sends to master  
RX = slave receives from master

### **!** NOTE

The CAN download ID of the device must match the CAN download ID set in CoDeSys!  
In the CAN network the CAN download IDs must be unique!

## 6.2 Physical connection of CAN

### Contents

Network structure .....	69
CAN bus level.....	70
CAN bus level according to ISO 11992-1 .....	70
Bus cable length.....	71
Wire cross-sections.....	72

1177

The mechanisms of the data transmission and error handling described in the chapters **Exchange of CAN data** (→ page 73) and **CAN errors and error handling** (→ page 180) are directly implemented in the CAN controller. ISO 11898 describes the physical connection of the individual CAN participants in layer 1.

### 6.2.1 Network structure

1178

The ISO 11898 standard assumes a line structure of the CAN network.




Figure: CAN network line structure

#### NOTE

The line must be terminated at its two ends using a terminating resistor of 120 Ω to prevent corruption of the signal quality.

The devices of **ifm electronic** equipped with a CAN interface have no terminating resistors.

#### Spurs

Ideally no spur should lead to the bus participants (node 1 ... node n) because reflections occur depending on the total cable length and the time-related processes on the bus. To avoid system errors, spurs to a bus participant (e.g. I/O module) should not exceed a certain length. 2 m spurs (referred to 125 kbits/s) are considered to be uncritical. The sum of all spurs in the whole system should not exceed 30 m. In special cases the cable lengths of the line and spurs must be calculated exactly.

## 6.2.2 CAN bus level

1179

The CAN bus is in the inactive (recessive) state if the output transistor pairs are switched off in all bus participants. If at least one transistor pair is switched on, a bit is transferred to the bus. This activates the bus (dominant). A current flows through the terminating resistors and generates a difference voltage between the two bus cables. The recessive and dominant states are converted into voltages in the bus nodes and detected by the receiver circuits.




Figure: CAN bus level

This differential transmission with common return considerably improves the transmission security. Noise voltages which interfere with the system externally or shifts of the ground potential influence both signal cables with the same interference. These influences are therefore not considered when the difference is formed in the receiver.

## 6.2.3 CAN bus level according to ISO 11992-1

1182

Available for the following devices: only SmartController: CR2501 on the 2nd CAN interface.

The physical layer of the ISO 11992-1 is different from ISO 11898 in its higher voltage level. The networks are implemented as point-to-point connection. The terminating networks have already been integrated.




Figure: voltage level to ISO 11992-1 (here: 12 V system)

## 6.2.4 Bus cable length

1180

The length of the bus cable depends on:

- type of the bus cable (cable, connector),
- cable resistance,
- required transmission rate (baud rate),
- length of the spurs.

To simplify matters, the following dependence between bus length and baud rate can be assumed:




Figure: bus cable length

Baud rate [kBit/s]	Bus length [m]	Bit length nominal [μs]
1 000	30	1
800	50	1.25
500	100	2
250	250	4
125	500	8
62.5	1 000	20
20	2 500	50
10	5 000	100

Table: Dependencies bus length / baud rate / bit time

## 6.2.5 Wire cross-sections

1181

For the layout of the CAN network the wire cross-section of the bus cable used must also be taken into account. The following table describes the dependence of the wire cross-section referred to the cable length and the number of the connected nodes.

Cable length [m]	Wire cross-section [mm <sup>2</sup> ] at 32 nodes	Wire cross-section [mm <sup>2</sup> ] at 64 nodes	Wire cross-section [mm <sup>2</sup> ] at 100 nodes
< 100	0.25	0.25	0.25
< 250	0.34	0.50	0.50
< 500	0.75	0.75	1.00

Depending on the EMC requirements the bus cables can be laid out as follows:

- in parallel,
- as twisted pair
- and/or shielded.



## 6.3 Exchange of CAN data

### Contents

Hints .....	74
Data reception .....	76
Data transmission.....	76

1168

CAN data is exchanged via the CAN protocol of the link layer (level 2) of the seven-layer ISO/OSI reference model specified in the international standard ISO 11898.

Every bus participant can transmit messages (multimaster capability). The exchange of data functions similarly to radio. Data is transferred on the bus without transmitter or address. The data is only marked by the identifier. It is the task of every participant to receive the transmitted data and to check by means of the identifier whether the data is relevant for this participant. This procedure is carried out automatically by the CAN controller together with the operating system.

For the normal exchange of CAN data the programmer only has to make the data objects with their identifiers known to the system when designing the software. This is done via the following FBs:

- **CANx\_RECEIVE** (→ page [84](#)) (receive CAN data) and
- **CANx\_TRANSMIT** (→ page [89](#)) (transmit CAN data).

Using these FBs the following units are combined into a data object:

- RAM address of the useful data,
- data type,
- selected identifier (ID).

These data objects participate in the exchange of data via the CAN bus. The transmit and receive objects can be defined from all valid IEC data types (e.g. BOOL, WORD, INT, ARRAY).

The CAN message consists of a CAN identifier (**CAN-ID** (→ page [74](#))) and maximum 8 data bytes. The ID does not represent the transmit or receive module but identifies the message. To transmit data it is necessary that a transmit object is declared in the transmit module and a receive object in at least one other module. Both declarations must be assigned to the same identifier.

## 6.3.1 Hints

8394

### CAN-ID

1166

Depending of the CAN-ID the following CAN identifiers are free available for the data transfer:

CAN-ID base	CAN-ID extended
11 bits	29 bits
2 047 CAN identifiers	536 870 912 CAN identifiers
Standard applications	Engine management (SAE J1939), Truck & Trailer interface (ISO 11992)

#### NOTE

In some devices the 29 bits CAN-ID is not available for all CAN interfaces, → data sheet.  
The same CAN controller can NOT simultaneously receive 11-bit and 29-bit CAN identifiers.  
We recommend: Only use 11-bit CAN identifiers OR 29-bit CAN identifiers in a CAN network.

#### Example 11 bits CAN-ID (base):

S O F	CAN-ID base Bit 28 ... Bit 18											R T R	I D E
0	0	0	0	0	0	1	1	1	1	1	1	0	0
	0			7			F						

#### Example 29 bits CAN-ID (extended):

S O F	CAN-ID base Bit 28 ... Bit 18											S R R	I D E	CAN-ID extended Bit 17 ... Bit 0																R T R
	0	0	0	0	0	1	1	1	1	1	1			1	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	0	1			F			C					0			0			0			0								

#### Legend:

SOF = **S**tart of frame

Edge of recessive to dominant

RTR = **R**emote transmission request

dominant: This message sends data

recessive: This message requests data

IDE = **I**dentifier extension flag

dominant: After this control bits follows

recessive: After this the second part of the 29 bits identifier follows

SRR = **S**ubstitute remote request

recessive: Extended CAN-ID: Replaces the RTR bit at this position

## Summary CAN / CANopen

3956

- The COB ID of the network variables must differ from the CANopen slave ID in the controller configuration and from the IDs of the FBs CANx\_TRANSMIT and CANx\_RECEIVE!
- If more than 8 bytes of network variables are put into one COB ID, CANopen automatically expands the data packet to several successive COB IDs. This can lead to conflicts with manually defined COB IDs!
- Network variables cannot transport any string variables.
- Network variables can be transported...
  - if a variable becomes TRUE (Event),
  - in case of data changes in the network variable or
  - cyclically when the timer has elapsed.
- The interval time is the period between transmissions if cyclical transmission has been selected. The minimum distance is the waiting time between two transmissions, if the variable changes too often.
- To reduce the bus load, split the messages via network variables or CANx\_TRANSMIT to several plc cycles using several events.
- Each call of CANx\_TRANSMIT or CANx\_RECEIVE generates a message packet of 8 bytes.
- In the controller configuration the values for [Com Cycle Period] and [Sync. Window Length] should be identical. These values must be higher than the plc cycle time.
- If [Com Cycle Period] is selected for a slave, the slave searches for a Sync object of the master during exactly this period. This is why the value for [Com Cycle Period] must be higher than the [Master Synch Time].
- We recommend to select "optional startup" for slaves and "automatic startup" for the network. This reduces unnecessary bus load and allows a briefly lost slave to integrate into the network again.
- Since we have no inhibit timer, we recommend to set analogue inputs to "synchronous transmission" to avoid bus overload.
- Binary inputs, especially the irregularly switching ones, should best be set to "asynchronous transmission" using an event timer.
- To be considered during the monitoring of the slave status:
  - after the start of the slaves it takes a while until the slaves are operational.
  - When the system is switched off, slaves can indicate an incorrect status change due to early voltage loss.

## 6.3.2 Data reception

1169

In principle the received data objects are automatically stored in a buffer (i.e. without influence of the user).

Each identifier has such a buffer (queue). Depending on the application software this buffer is emptied according to the FiFo principle (First In, First Out) via **CANx\_RECEIVE** (→ page [84](#)).

## 6.3.3 Data transmission

1170

By calling **CANx\_TRANSMIT** (→ page [89](#)) the application program transfers exactly one CAN message to the CAN controller. As feedback you are informed whether the message was successfully transferred to the CAN controller. Which then automatically carries out the actual transfer of the data on the CAN bus.

The transmit order is rejected if the controller is not ready because it is in the process of transferring a data object. The transmit order must then be repeated by the application program. This information is indicated by a bit.

If several CAN messages are ready for transmission, the message with the lowest ID is transmitted first. Therefore, the programmer must assign the **CAN-ID** (→ page [74](#)) very carefully.

## 6.4 Description of the CAN standard program units

### Contents

CAN1_BAUDRATE .....	79
CAN1_DOWNLOADID .....	81
CANx_ERRORHANDLER .....	82
CANx_RECEIVE .....	84
CANx_RECEIVE_RANGE .....	86
CANx_TRANSMIT .....	89
CAN1_EXT .....	90
CAN1_EXT_ERRORHANDLER .....	91
CAN1_EXT_RECEIVE .....	92
CANx_EXT_RECEIVE_ALL .....	94
CAN1_EXT_TRANSMIT .....	96

1186

The CAN FBs are described for use in the application program.


### NOTE

To use the full capacity of CAN it is absolutely necessary for the programmer to define an exact **bus concept** before starting to work:

- How many data objects are needed with what identifiers?
- How is the *ecomatmobile* device to react to possible CAN errors?
- How often must data be transmitted? **CANx\_TRANSMIT** (→ page 89) and **CANx\_RECEIVE** (→ page 84) must be called accordingly.
- Check whether the transmit orders were successfully assigned to CANx\_TRANSMIT (output RESULT) or ensure that the received data is read from the data buffer of the queue using CANx\_RECEIVE and processed in the rest of the program immediately.

To be able to set up a communication connection, the same transmission rate (baud rate) must first be set for all participants of the CAN network. For the controller this is done using **CAN1\_BAUDRATE** (→ page 79) (for the 1st CAN interface) or via **CAN2** (for the 2nd CAN interface).

Irrespective of whether the devices support one or several CAN interfaces the FBs related to the interface are specified by a number in the CAN FB (e.g. CAN1\_TRANSMIT or CAN2\_RECEIVE). To simplify matters the designation (e.g. CANx\_TRANSMIT) is used for all variants in the documentation.

 When installing the *ecomatmobile* DVD "Software, tools and documentation", projects with templates have been stored in the program directory of your PC:

...\ifm electronic\CoDeSys V...\Projects\Template\_CDVxyyzz

- ▶ Open the requested template in CoDeSys via:  
[File] > [New from template...]
- > CoDeSys creates a new project which shows the basic program structure. It is strongly recommended to follow the shown procedure.  
→ chapter **Set up programming system via templates** (→ page [30](#))

In this example data objects are exchanged with other CAN participants via the identifiers 1 and 2. To do so, a receive identifier must exist for the transmit identifier (or vice versa) in the other participant.

## 6.4.1 CAN1\_BAUDRATE

651

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

654

CAN1\_BAUDRATE sets the transmission rate for the bus participant.

- ▶ To do so, the corresponding value in kbits/s is entered at the input BAUDRATE.
- > After executing the FB the new value is stored in the device and will even be available after a power failure.

### NOTICE

Please note for CR250n, CR0301, CR0302 and CS0015:

The EEPROM memory module may be destroyed by the permanent use of this unit!

- ▶ Only carry out the unit **once** during initialisation in the first program cycle!
- ▶ Afterwards block the unit again with **ENABLE = FALSE!**

**!** The new baud rate will become effective on RESET (voltage OFF/ON or soft reset).

**ExtendedController:** In the slave module, the new baud rate will become effective after voltage OFF/ON.

## Parameters of the inputs

655

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
BAUDRATE	WORD	Baud rate [kbits/s] permissible values: 50, 100, 125, 250, 500, 1000 preset value = 125 kbits/s



## 6.4.2 CAN1\_DOWNLOADID

645

= CAN1 Download-ID

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

648

CAN1\_DOWNLOADID sets the download identifier for the first CAN interface.

Using the FB the communication identifier for the program download and for debugging can be set. The new value is entered when the input ENABLE is set to TRUE. The new download ID will become effective after voltage OFF/ON or after a soft reset.

### NOTICE

Please note for CR250n, CR0301, CR0302 and CS0015:

The EEPROM memory module may be destroyed by the permanent use of this unit!

- ▶ Only carry out the unit **once** during initialisation in the first program cycle!
- ▶ Afterwards block the unit again with ENABLE = FALSE!

### Parameters of the inputs

649

Parameter	Data type	Description
ENABLE	BOOL	TRUE (or only 1 cycle): ID is set  FALSE: unit is not executed
ID	BYTE	download identifier permissible values: 1...127

## 6.4.3 CANx\_ERRORHANDLER

633

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

### CAN1\_ERRORHANDLER

9344

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR2500
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

636

Error routine for monitoring the CAN interfaces

CANx\_ERRORHANDLER monitors the CAN interfaces and evaluates the CAN errors. If a certain number of transmission errors occurs, the CAN participant becomes error passive. If the error frequency decreases, the participant becomes error active again (= normal condition).

If a participant already is error passive and still transmission errors occur, it is disconnected from the bus (= bus off) and the error bit CANx\_BUSOFF is set. Returning to the bus is only possible if the "bus off" condition has been removed (signal BUSOFF\_RECOVER).

The input CAN\_RESTART is used for rectifying other CAN errors. The CAN interface is reinitialised.

Afterwards, the error bit must be reset in the application program.

The procedures for the restart of the interfaces are different:

- For CAN interface 1 or devices with only one CAN interface:  
set the input CAN\_RESTART = TRUE (only 1 cycle)
- For CAN interface 2:  
set the input START = TRUE (only 1 cycle) in **CAN2**

### NOTE

In principle, CAN2 must be executed to initialise the second CAN interface, before FBs can be used for it.

If the automatic bus recover function is to be used (default setting) CANx\_ERRORHANDLER must **not** be integrated and instanced in the program!

## Parameters of the inputs

637

Parameter	Data type	Description
BUSOFF_RECOVER	BOOL	TRUE (only 1 cycle): remedy 'bus off' status  FALSE: this function is not executed
CAN_RESTART	BOOL	TRUE (only 1 cycle): completely reinitialise CAN interface 1  FALSE: this function is not executed

© ifm electronic gmbh

## 6.4.4 CANx\_RECEIVE

627

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



### CAN1\_RECEIVE

9354

Contained in the library: `ifm_CRnnnn_Vxyyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn

**POU not for safety signals!**

(For safety signals → **CAN\_SAFETY\_RECEIVE**)

- SmartController: CR2500
- PDM360smart: CR1070, CR1071

### Description

630

CANx\_RECEIVE configures a data receive object and reads the receive buffer of the data object.

The FB must be called once for each data object during initialisation, in order to inform the CAN controller about the identifiers of the data objects.

In the further program cycle CANx\_RECEIVE is called for reading the corresponding receive buffer, also repeatedly in case of long program cycles. The programmer must ensure by evaluating the byte AVAILABLE that newly received data objects are retrieved from the buffer and further processed.

Each call of the FB decrements the byte AVAILABLE by 1. If the value of AVAILABLE is 0, there is no data in the buffer.

By evaluating the output OVERFLOW, an overflow of the data buffer can be detected. If OVERFLOW = TRUE at least 1 data object has been lost.

**!** If CAN2\_RECEIVE is to be used, the second CAN interface must be initialised first using **CAN2**.

## Parameters of the inputs

631

Parameter	Data type	Description
CONFIG	BOOL	TRUE (only 1 cycle): Configure data object  FALSE: unit is not executed
CLEAR	BOOL	TRUE: deletes the data buffer (queue)  FALSE: this function is not executed
ID	WORD	number of the data object identifier permissible values = 0...2 047

## Parameters of the outputs

632

Parameter	Data type	Description
DATA	ARRAY[0...7] OF BYTES	the array contains a maximum of 8 data bytes
DLC	BYTE	number of bytes transmitted in the array DATA possible values = 0...8
RTR	BOOL	not supported
AVAILABLE	BYTE	number of received messages
OVERFLOW	BOOL	TRUE: overflow of the data buffer → loss of data!  FALSE: buffer not yet full

## 6.4.5 CANx\_RECEIVE\_RANGE

4179

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



### CAN1\_RECEIVE\_RANGE

9359

Contained in the library: `ifm_CRnnnn_Vxyyyzz.LIB` (xx > 05)

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506

**POU not for safety signals!**

(For safety signals → **CAN\_SAFETY\_RECEIVE**)

- SmartController: CR2500
- PDM360smart: CR1070, CR1071

### Description

2295

CANx\_RECEIVE\_RANGE configures a sequence of data receive objects and reads the receive buffer of the data objects.

For the first CAN interface max. 2048 IDs per bit are possible.

For the second CAN interface max. 256 IDs per 11 OR 29 bits are possible.

The second CAN interface requires a long initialisation time. To ensure that the watchdog does not react, the process should be distributed to several cycles in the case of bigger ranges. → **Example: Initialisation of CANx\_RECEIVE\_RANGE in 4 cycles** (→ page 88).

The FB must be called once for each sequence of data objects during initialisation to inform the CAN controller about the identifiers of the data objects.

The FB must NOT be mixed with **CANx\_RECEIVE** (→ page 84) or CANx\_RECEIVE\_RANGE for the same IDs at the same CAN interfaces.

In the further program cycle CANx\_RECEIVE\_RANGE is called for reading the corresponding receive buffer, also repeatedly in case of long program cycles. The programmer has to ensure by evaluating the byte AVAILABLE that newly received data objects are retrieved from buffer SOFORT and are further processed as the data are only available for one cycle.

Each call of the FB decrements the byte AVAILABLE by 1. If the value of AVAILABLE is 0, there is no data in the buffer.

By evaluating the output OVERFLOW, an overflow of the data buffer can be detected. If OVERFLOW = TRUE, at least 1 data object has been lost.

Receive buffer: max. 16 software buffers per identifier.

## Parameters of the inputs

2290

Parameter	Data type	Description
CONFIG	BOOL	TRUE (only for 1 cycle): configure data object FALSE: this function is not executed
CLEAR	BOOL	TRUE: deletes the data buffer (queue) FALSE: this function is not executed
FIRST_ID	CAN1: WORD CAN2: DWORD	number of the first data object identifier of the sequence permissible values normal frame = 0...2 047 ( $2^{11}$ ) permissible values extended frame = 0...536 870 912 ( $2^{29}$ )
LAST_ID	CAN1: WORD CAN2: DWORD	number of the last data object identifier of the sequence permissible values normal frame = 0...2 047 ( $2^{11}$ ) permissible values extended frame = 0...536 870 912 ( $2^{29}$ ) LAST_ID has to be bigger than FIRST_ID.

## Parameters of the outputs

4381

Parameter	Data type	Description
ID	CAN1: WORD CAN2: DWORD	ID of the transmitted data object
DATA	ARRAY[0...7] OF BYTE	the array contains max. 8 data bytes
DLC	BYTE	number of bytes transmitted in the array DATA possible values = 0...8
AVAILABLE	BYTE	number of messages in the buffer
OVERFLOW	BOOL	TRUE: overflow of the data buffer → loss of data! FALSE: buffer not yet full

**Example: Initialisation of CANx\_RECEIVE\_RANGE in 4 cycles**

2294

```

PLC_PRG (PRG-ST) (-1/191/-1/89)
0001 PROGRAM PLC_PRG
0002 VAR
0003   init : BOOL := FALSE;
0004   initstep : WORD := 1;
0005   can20 : CAN2;
0006   cr2 : CAN2_RECEIVE_RANGE;
0007   cnt : WORD;
0008 END_VAR
0009
0001 (* CAN2 init *)
0002 can20(ENABLE:= TRUE, START:= init, EXTENDED_MODE:= FALSE, BAUDRATE:= 125);
0003
0004 (* CAN2_RECEIVE_RANGE in mehreren Steps initialisieren *)
0005 CASE initstep OF
0006   1:
0007     cr2(CONFIG:= TRUE, CLEAR:= FALSE, FIRST_ID:= 16#100, LAST_ID:= 16#10F, ID=> , DATA=> , DLC=> , AVAILABLE=> , OVERFLOW=> );
0008     initstep := initstep + 1;
0009   2:
0010     cr2(CONFIG:= TRUE, CLEAR:= FALSE, FIRST_ID:= 16#110, LAST_ID:= 16#11F, ID=> , DATA=> , DLC=> , AVAILABLE=> , OVERFLOW=> );
0011     initstep := initstep + 1;
0012   3:
0013     cr2(CONFIG:= TRUE, CLEAR:= FALSE, FIRST_ID:= 16#120, LAST_ID:= 16#12F, ID=> , DATA=> , DLC=> , AVAILABLE=> , OVERFLOW=> );
0014     initstep := initstep + 1;
0015   4:
0016     cr2(CONFIG:= TRUE, CLEAR:= FALSE, FIRST_ID:= 16#130, LAST_ID:= 16#13F, ID=> , DATA=> , DLC=> , AVAILABLE=> , OVERFLOW=> );
0017     initstep := initstep + 1;
0018 ELSE
0019   cr2(CONFIG:= FALSE, CLEAR:= FALSE, FIRST_ID:= 16#100, LAST_ID:= 16#100, ID=> , DATA=> , DLC=> , AVAILABLE=> , OVERFLOW=> );
0020 END_CASE
0021
0022 init := FALSE;
0023
0024 (* Test *)
0025 IF cr2.available > 0 THEN
0026   cnt := cnt + 1;
0027 END_IF

```




## 6.4.6 CANx\_TRANSMIT

609

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



### CAN1\_TRANSMIT

9362

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn

**POU not for safety signals!**

(For safety signals → **CAN\_SAFETY\_TRANSMIT**)

- SmartController: CR2500
- PDM360smart: CR1070, CR1071

### Description

612

CANx\_TRANSMIT transmits a CAN data object (message) to the CAN controller for transmission.

The FB is called for each data object in the program cycle, also repeatedly in case of long program cycles. The programmer must ensure by evaluating the FB output RESULT that his transmit order was accepted. Simplified it can be said that at 125 kbits/s one transmit order can be executed per ms.

The execution of the FB can be temporarily blocked (ENABLE = FALSE) via the input ENABLE. So, for example a bus overload can be prevented.

Several data objects can be transmitted virtually at the same time if a flag is assigned to each data object and controls the execution of the FB via the ENABLE input.

**I** If CAN2\_TRANSMIT is to be used, the second CAN interface must be initialised first using **CAN2**.

## Parameters of the inputs

613

Parameter	Data type	Description
ID	WORD	number of the data object identifier permissible values = 0...2 047
DLC	BYTE	number of bytes to be transmitted from the array DATA permissible values = 0...8
DATA	ARRAY[0...7] OF BYTES	the array contains a maximum of 8 data bytes
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active

## Parameters of the outputs

614

Parameter	Data type	Description
RESULT	BOOL	TRUE (only 1 cycle): the unit has accepted the transmit order

## 6.4.7 CAN1\_EXT

4192


Unit type = function block (FB)

Contained in the library: `ifm_CAN1_EXT_Vxxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

4333

CAN1\_EXT initialises the first CAN interface for the extended identifier (29 bits).

The FB has to be retrieved if the first CAN interface e.g. with the function libraries for **CAN units acc. to SAE J1939** (→ page 98) is to be used.

A change of the baud rate will become effective after voltage OFF/ON. The baud rates of CAN 1 and CAN 2 can be set differently.

The input START is only set for one cycle during reboot or restart of the interface.

 The FB must be executed **before** CAN1\_EXT\_... .

### Parameters of the inputs

4334

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
START	BOOL	TRUE (in the 1st cycle): interface is initialised FALSE: initialisation cycle completed
EXTENDED_MODE	BOOL	TRUE: identifier of the 1st CAN interface operates with 29 bits FALSE: identifier of the 1st CAN interface operates with 11 bits
BAUDRATE	WORD	baud rate [kbits/s] permissible values = 50, 100, 125, 250, 500, 1000 preset value = 125 kbits/s

## 6.4.8 CAN1\_EXT\_ERRORHANDLER

4195

Unit type = function block (FB)

Contained in the library: `ifm_CAN1_EXT_Vxyxyz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

4335

CAN1\_EXT\_ERRORHANDLER monitors the first CAN interface and evaluates the CAN errors. If a certain number of transmission errors occurs, the CAN participant becomes error passive. If the error frequency decreases, the participant becomes error active again (= normal condition).

If a participant already is error passive and still transmission errors occur, it is disconnected from the bus (= bus off) and the error bit CANx\_BUSOFF is set. Returning to the bus is only possible if the "bus off" condition has been removed (signal BUSOFF\_RECOVER).

Afterwards, the error bit CANx\_BUSOFF must be reset in the application program.

**I** If the automatic bus recover function is to be used (default setting) CAN1\_EXT\_ERRORHANDLER must **not** be integrated and instanced in the program!

### Parameters of the inputs

2177

Parameter	Data type	Description
BUSOFF_RECOVER	BOOL	TRUE (only for 1 cycle): <ul style="list-style-type: none"> <li>&gt; reboot of the CAN interface x</li> <li>&gt; remedy "bus off" status</li> </ul> FALSE: this function is not executed

## 6.4.9 CAN1\_EXT\_RECEIVE

4302

Unit type = function block (FB)

Contained in the library: `ifm_CAN1_EXT_Vxyxyz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

4336

CAN1\_EXT\_RECEIVE configures a data receive object and reads the receive buffer of the data object.

The FB must be called once for each data object during initialisation to inform the CAN controller about the identifiers of the data objects.

In the further program cycle CAN1\_EXT\_RECEIVE is called for reading the corresponding receive buffer, this is done several times in case of long program cycles. The programmer must ensure by evaluating the byte AVAILABLE that newly received data objects are retrieved from the buffer and further processed.

Each call of the FB decrements the byte AVAILABLE by 1. If the value of AVAILABLE is 0, there is no data in the buffer.

By evaluating the output OVERFLOW, an overflow of the data buffer can be detected. If OVERFLOW = TRUE at least 1 data object has been lost.

**I** If this unit is to be used, the 1st CAN interface must first be initialised for the extended ID with **CAN1\_EXT** (→ page [90](#)).

## Parameters of the inputs

2172

Parameter	Data type	Description
CONFIG	BOOL	TRUE (only for 1 cycle): configure data object  FALSE: this function is not executed
CLEAR	BOOL	TRUE: deletes the data buffer (queue)  FALSE: this function is not executed
ID	WORD	number of the data object identifier permissible values normal frame = 0...2 047 (2 <sup>11</sup> ) permissible values extended frame = 0...536 870 912 (2 <sup>29</sup> )

## Parameters of the outputs

632

Parameter	Data type	Description
DATA	ARRAY[0...7] OF BYTES	the array contains a maximum of 8 data bytes
DLC	BYTE	number of bytes transmitted in the array DATA possible values = 0...8
RTR	BOOL	not supported
AVAILABLE	BYTE	number of received messages
OVERFLOW	BOOL	TRUE: overflow of the data buffer → loss of data!  FALSE: buffer not yet full

## 6.4.10 CANx\_EXT\_RECEIVE\_ALL

4183

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



### CAN1\_EXT\_RECEIVE\_ALL

9351

Contained in the library: `ifm_CAN1_EXT_Vxyxyz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506

**POU not for safety signals!**

(For safety signals → **CAN\_SAFETY\_RECEIVE**)

- SmartController: CR2500
- PDM360smart: CR1070, CR1071

### Description

4326

CANx\_EXT\_RECEIVE\_ALL configures all data receive objects and reads the receive buffer of the data objects.

The FB must be called once during initialisation to inform the CAN controller about the identifiers of the data objects.

In the further program cycle CANx\_EXT\_RECEIVE\_ALL is called for reading the corresponding receive buffer, also repeatedly in case of long program cycles. The programmer must ensure by evaluating the byte AVAILABLE that newly received data objects are retrieved from the buffer and further processed.

Each call of the FB decrements the byte AVAILABLE by 1. If the value of AVAILABLE is 0, there is no data in the buffer.

By evaluating the output OVERFLOW, an overflow of the data buffer can be detected. If OVERFLOW = TRUE at least 1 data object has been lost.

Receive buffer: max. 16 software buffers per identifier.

## Parameters of the inputs

4329

Parameter	Data type	Description
CONFIG	BOOL	TRUE (only for 1 cycle): configure data object  FALSE: unit is not executed
CLEAR	BOOL	TRUE: deletes the data buffer (queue)  FALSE: this function is not executed

## Parameters of the outputs

2292

Parameter	Data type	Description
ID	DWORD	ID of the transmitted data object
DATA	ARRAY[0...7] OF BYTE	the array contains max. 8 data bytes
DLC	BYTE	number of bytes transmitted in the array DATA possible values = 0...8
AVAILABLE	BYTE	number of messages in the buffer
OVERFLOW	BOOL	TRUE: overflow of the data buffer → loss of data!  FALSE: buffer not yet full



## 6.4.11 CAN1\_EXT\_TRANSMIT

4307

Unit type = function block (FB)

Contained in the library: `ifm_CAN1_EXT_Vxyxyz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

4337

CAN1\_EXT\_TRANSMIT transfers a CAN data object (message) to the CAN controller for transmission.

The FB is called for each data object in the program cycle; this is done several times in case of long program cycles. The programmer must ensure by evaluating the output RESULT that his transmit order was accepted. To put it simply, at 125 kbits/s one transmit order can be executed per 1 ms.

The execution of the FB can be temporarily blocked via the input ENABLE = FALSE. This can, for example, prevent a bus overload.

Several data objects can be transmitted virtually at the same time if a flag is assigned to each data object and controls the execution of the FB via the ENABLE input.

**!** If this unit is to be used, the 1st CAN interface must first be initialised for the extended ID with **CAN1\_EXT** (→ page [90](#)).

## Parameters of the inputs

4380

Parameter	Data type	Description
ID	DWORD	number of the data object identifier permissible values: 11-bit ID = 0...2 047, 29-bit ID = 0...536 870 911
DLC	BYTE	number of bytes to be transmitted from the array DATA permissible values = 0...8
DATA	ARRAY[0...7] OF BYTE	the array contains max. 8 data bytes
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active

## Parameters of the outputs

614

Parameter	Data type	Description
RESULT	BOOL	TRUE (only 1 cycle): the unit has accepted the transmit order

## 6.5 CAN units acc. to SAE J1939

### Contents

CAN for the drive engineering .....	99
Units for SAE J1939 .....	102

7482

The network protocol SAE J1939 describes the communication on a CAN bus in utility vehicles for submitting diagnosis data (e.g. engine speed, temperature) and control information.

### 6.5.1 CAN for the drive engineering

#### Contents

Identifier acc. to SAE J1939 .....	100
Example: detailed message documentation .....	101
Example: short message documentation .....	102

7678

With the standard SAE J1939 the CiA bietet offers to the user a CAN bus protocol for the drive engineering. For this protocol the CAN controller of the 2nd interface is switched to the "extended mode". This means that the CAN messages are transferred with a 29-bit identifier. Due to the longer identifier numerous messages can be directly assigned to the identifier.

For writing the protocol this advantage was used and certain messages were combined in ID groups. The ID assignment is specified in the standards SAE J1939 and ISO 11992. The protocol of ISO 11992 is based on the protocol of SAE J1939.

Standard	Application area
SAE J1939	Drive management
ISO 11992	"Truck & Trailer Interface"

The 29-bit identifier consists of two parts:

- an 11-bit ID and
- an 18-bit ID.

As for the software protocol the two standards do not differ because ISO 11992 is based on SAE J1939. Concerning the hardware interface, however, there is one difference: higher voltage level for ISO 11992.

**I** To use the functions to SAE J1939 the protocol description of the aggregate manufacturer (e.g. for engines, gears) is definitely needed. For the messages implemented in the aggregate control device this description must be used because not every manufacturer implements all messages or implementation is not useful for all aggregates.

The following information and tools should be available to develop programs for functions to SAE J1939:

- List of the data to be used by the aggregates
- Overview list of the aggregate manufacturer with all relevant data
- CAN monitor with 29-bit support
- If required, the standard SAE J1939

## Identifier acc. to SAE J1939

7675

For the data exchange with SAE J1939 the 29 bit identifiers are determinant. This identifier is pictured schematically as follows:

A	S O F	Identifier 11 bits											S R R	I D E	Identifier 18 bits																		R T R	
		Priority				R	D P	PDU format (PF) 6+2 bits				S R R			I D E	still PF		PDU specific (PS) destination address group extern or proprietary								Source address								
B	S O F	1	3	2	1			1	1	8	7		6	5		4	3	1	1	2	1	8	7	6	5	4	3	2	1	8	7	6	5	4
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33
C	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	
D	-	28	27	26	25	24	23	22	21	20	19	18	-	-	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	-	

Legend:

A = CAN extended message format

B = J1939 message format

C = J1939 message bit position

D = CAN 29 bit ID position

SOF = **S**tart **o**f **f**rame

SRR = **S**ubstitute **r**emote **r**equ**e**st

IDE = **I**dentifier **e**xtension **f**lag

RTR = **R**emote **t**ransmission **r**equ**e**st

PDU = **P**rotocol **D**ata **U**nit

PGN = **P**arameter **G**roup **N**umber = PDU format (PF) + PDU source (PS)

(→ **CAN-ID** (→ page [74](#)))

To do so, the 3 essentially communication methods with SAE J1939 are to be respected:

- destination specific communication with PDU1 (PDU format 0...239)
- broadcast communication with PDU2 (PDU format 240...255)
- proprietary communication with PDU1 or PDU2

## Example: detailed message documentation

7679

ETC1: Electronic Transmission Controller #1 (3.3.5)      0CF00203<sub>16</sub>

Transmission repetition rate	RPT	10 ms
Data length	LEN	8 Bytes
PDU format	PF	240
PDU specific	PS	2
Default priority	PRI0	3
Data Page	PG	0
Source Address	SA	3
Parameter group number	PGN	00F002 <sub>16</sub>
Identifier	ID	0CF00203 <sub>16</sub>
Data Field	SRC	The meaning of the data bytes 1...8 is not further described. It can be seen from the manufacturer's documentation.

As in the example of the manufacturer all relevant data has already been prepared, it can be directly transferred to the FBs.

Meaning:

Designation in the manufacturer's documentation	Unit input library function	Example value
Transmission repetition rate	RPT	T#10ms
Data length	LEN	8
PDU format	PF	240
PDU specific	PS	2
Default priority	PRI0	3
Data page	PG	0
Source address / destination address	SA / DA	3
Data field	SRC / DST	array address

Depending on the required function the corresponding values are set. For the fields SA / DA or SRC / DST the meaning (but not the value) changes according to the receive or transmit function.

The individual data bytes must be read from the array and processed according to their meaning.

## Example: short message documentation

7680

But even if the aggregate manufacturer only provides a short documentation, the function parameters can be derived from the identifier. In addition to the ID, the "transmission repetition rate" and the meaning of the data fields are also always needed.

If the protocol messages are not manufacturer-specific, the standard SAE J1939 or ISO 11992 can also serve as information source.

Structure of the identifier 0CF00203<sub>16</sub>:

PRIO, reserved, PG		PF + PS				SA / DA	
0	C	F	0	0	2	0	3

As these values are hexadecimal numbers of which individual bits are sometimes needed, the numbers must be further broken down:

SA / DA		Source / Destination Address (hexadecimal)		Source / Destination Address (decimal)	
0	3	00	03	0	3

PF		PDU format (PF) (hexadecimal)		PDU format (PF) (decimal)	
F	0	0F	00	16	0

PS		PDU specific (PS) (hexadecimal)		PDU specific (PS) (decimal)	
0	2	00	02	0	2

PRIO, reserved, PG		PRIO, reserved, PG (binary)	
0	C	0000	1100

Out of the 8 bits (0C<sub>16</sub>) only the 5 least significant bits are needed:

Not necessary			Priority			res.	PG
x	x	x	0 <sub>2</sub>	1 <sub>2</sub>	1 <sub>2</sub>	0 <sub>2</sub>	0 <sub>2</sub>
x			03 <sub>10</sub>			0 <sub>10</sub>	0 <sub>10</sub>

### Further typical combinations for "PRIO, reserve., PG"

18<sub>16</sub>:

Not necessary			priority			res.	PG
x	x	x	1 <sub>2</sub>	1 <sub>2</sub>	0 <sub>2</sub>	0 <sub>2</sub>	0 <sub>2</sub>
x			6 <sub>10</sub>			0 <sub>10</sub>	0 <sub>10</sub>

1C<sub>16</sub>:

Not necessary			priority			res.	PG
x	x	x	1 <sub>2</sub>	1 <sub>2</sub>	1 <sub>2</sub>	0 <sub>2</sub>	0 <sub>2</sub>
x			7 <sub>10</sub>			0 <sub>10</sub>	0 <sub>10</sub>

## 6.5.2 Units for SAE J1939

### Contents

J1939_x .....	103
J1939_x_RECEIVE .....	105
J1939_x_TRANSMIT .....	107
J1939_x_RESPONSE .....	109
J1939_x_SPECIFIC_REQUEST .....	111
J1939_x_GLOBAL_REQUEST .....	113

8566

Here you find funktion blocks of the CAN function for SAE J1939.

**!** If this unit is to be used, the 1st CAN interface must first be initialised for the extended ID with **CAN1\_EXT** (→ page [90](#)).


## J1939\_x

2274

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## J1939\_1

9375

Contained in the library: ifm\_J1939\_1\_Vxyxyz.LIB

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR2500
- PDM360smart: CR1070, CR1071

## Description

4325

J1939\_x serves as protocol handler for the communication profile SAE J1939.

### **NOTE**

J1939 communication via the 1st CAN interface:

- First initialise the interface via **CAN1\_EXT** (→ page [90](#))!

J1939 communication via the 2nd CAN interface:

- First initialise the interface via **CAN2**!

To handle the communication, the protocol handler must be called in each program cycle. To do so, the input ENABLE is set to TRUE.

The protocol handler is started if the input START is set to TRUE for one cycle.

Using MY\_ADDRESS, a device address is assigned to the controller. It must differ from the addresses of the other J1939 bus participants. It can then be read by other bus participants.



## Parameters of the inputs

469

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
START	BOOL	TRUE (only for 1 cycle): protocol handler started FALSE: during further processing of the program
MY_ADRESS	BYTE	node ID of the device

© ifm electronic gmbh


## J1939\_x\_RECEIVE

2278

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## J1939\_1\_RECEIVE

9393

Contained in the library: ifm\_J1939\_1\_Vxyxyz.LIB

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR2500
- PDM360smart: CR1070, CR1071

## Description

2288

J1939\_x\_RECEIVE serves for receiving one individual message or a block of messages.

To do so, the FB must be initialised for one cycle via the input CONFIG. During initialisation, the parameters PG, PF, PS, RPT, LIFE and the memory address of the data array DST are assigned.

- ▶ The address must be determined by means of the operator ADR and assigned to the FB!
- ▶ The receipt of data must be evaluated via the RESULT byte. If RESULT = 1 the data can be read from the memory address assigned via DST and can be further processed.
- > When a new message is received, the data in the memory address DST is overwritten.
- > The number of received message bytes is indicated via the output LEN.
- > If RESULT = 3, no valid messages have been received in the indicated time window (LIFE \* RPT).

**I** This block must also be used if the messages are requested using J1939\_...\_REQUEST.

## Parameters of the inputs

457

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
CONFIG	BOOL	TRUE (only for 1 cycle): for the configuration of the data object FALSE: during further processing of the program
PG	BYTE	page address (normally = 0)
PF	BYTE	PDU format byte
PS	BYTE	PDU specific byte
DST	DWORD	target address of the array in which the received data is stored ► The address must be determined by means of the operator ADR and assigned to the FB!
RPT	TIME	monitoring time Within this time window the messages must be received repeatedly. Otherwise, an error will be signalled. If no monitoring is requested, RPT must be set to T#0s.
LIFE	BYTE	number of permissible faulty monitoring calls

## Parameters of the outputs

458

Parameter	Data type	Description
RESULT	BYTE	0 = not active 1 = data has been received 3 = signalling of errors: nothing has been received during the time window (LIFE*RPT)
DEVICE	BYTE	device address of the sender
LEN	WORD	number of bytes received


## J1939\_x\_TRANSMIT

2279

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## J1939\_1\_TRANSMIT

4322

Contained in the library: `ifm_J1939_1_Vxyxyz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR2500
- PDM360smart: CR1070, CR1071


## Description

2298

J1939\_x\_TRANSMIT is responsible for transmitting individual messages or blocks of messages. To do so, the parameters PG, PF, PS, RPT and the address of the data array SRC are assigned to the FB.

- ▶ The address must be determined by means of the operator ADR and assigned to the FB!
- ▶ In addition, the number of data bytes to be transmitted and the priority (typically 3, 6 or 7) must be assigned.

Given that the transmission of data is processed via several control cycles, the process must be evaluated via the RESULT byte. All data has been transmitted if RESULT = 1.

 If more than 8 bytes are to be sent, a "multi package transfer" is carried out.

## Parameters of the inputs

439

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
PRIO	BYTE	message priority (0...7)
PG	BYTE	page address (normally = 0)
PF	BYTE	PDU format byte
PS	BYTE	PDU specific byte
SRC	DWORD	memory address of the data array whose content is to be transmitted ► The address must be determined by means of the operator ADR and assigned to the FB!
LEN	WORD	number of bytes to be transmitted
RPT	TIME	repeat time during which the data messages are transmitted cyclically

## Parameters of the outputs

440

Parameter	Data type	Description
RESULT	BYTE	0 = not active 1 = data transmission completed 2 = unit active (data transmission) 3 = error, data cannot be sent


## J1939\_x\_RESPONSE

2280

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## J1939\_1\_RESPONSE

9399

Contained in the library: `ifm_J1939_1_Vxxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR2500
- PDM360smart: CR1070, CR1071

## Description

2299

J1939\_x\_RESPONSE handles the automatic response to a request message.

This FB is responsible for the automatic sending of messages to "Global Requests" and "Specific Requests". To do so, the FB must be initialised for one cycle via the input CONFIG.

The parameters PG, PF, PS, RPT and the address of the data array SRC are assigned to the FB.

- The address must be determined by means of the operator ADR and assigned to the FB!
- In addition, the number of data bytes to be transmitted is assigned.

## Parameters of the inputs

451

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
CONFIG	BOOL	TRUE (only for 1 cycle): for the configuration of the data object FALSE: during further processing of the program
PG	BYTE	page address (normally = 0)
PF	BYTE	PDU format byte
PS	BYTE	PDU specific byte
SRC	DWORD	memory address of the data array whose content is to be transmitted ► The address must be determined by means of the operator ADR and assigned to the FB!
LEN	WORD	number of bytes to be transmitted

## Parameters of the outputs

440

Parameter	Data type	Description
RESULT	BYTE	0 = not active 1 = data transmission completed 2 = unit active (data transmission) 3 = error, data cannot be sent


## J1939\_x\_SPECIFIC\_REQUEST

2281

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## J1939\_1\_SPECIFIC\_REQUEST

8884

Contained in the library: `ifm_J1939_1_Vxyyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR2500
- PDM360smart: CR1070, CR1071

## Description

2300

J1939\_x\_SPECIFIC\_REQUEST is responsible for the automatic requesting of individual messages from a specific J1939 network participant. To do so, the logical device address DA, the parameters PG, PF, PS and the address of the array DST in which the received data is stored are assigned to the FB.

- ▶ The address must be determined by means of the operator ADR and assigned to the FB!
- ▶ In addition, the priority (typically 3, 6 or 7) must be assigned.
- ▶ Given that the request of data can be handled via several control cycles, this process must be evaluated via the RESULT byte. All data has been received if RESULT = 1.
- > The output LEN indicates how many data bytes have been received.



## Parameters of the inputs

445

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
PRI0	BYTE	priority (0...7)
DA	BYTE	logical address (target address) of the called device
PG	BYTE	page address (normally = 0)
PF	BYTE	PDU format byte
PS	BYTE	PDU specific byte
DST	DWORD	target address of the array in which the received data is stored ► The address must be determined by means of the operator ADR and assigned to the FB!

## Parameters of the outputs

446

Parameter	Data type	Description
RESULT	BYTE	0 = not active 1 = data transmission completed 2 = unit active (data transmission) 3 = error, data cannot be sent
LEN	WORD	number of data bytes received

## J1939\_x\_GLOBAL\_REQUEST

2282

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## J1939\_1\_GLOBAL\_REQUEST

4315

Contained in the library: `ifm_J1939_1_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR2500
- PDM360smart: CR1070, CR1071

## Description

2301

J1939\_x\_GLOBAL\_REQUEST is responsible for the automatic requesting of individual messages from all (global) active J1939 network participants. To do so, the logical device address DA, the parameters PG, PF, PS and the address of the array DST in which the received data is stored are assigned to the FB.

- ▶ The address must be determined by means of the operator ADR and assigned to the FB!
- ▶ In addition, the priority (typically 3, 6 or 7) must be assigned.
- ▶ Given that the request of data can be handled via several control cycles, this process must be evaluated via the RESULT byte. All data has been received if RESULT = 1.
- > The output LEN indicates how many data bytes have been received.

## Parameters of the inputs

463

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
PRI0	BYTE	priority (0...7)
PG	BYTE	page address (normally = 0)
PF	BYTE	PDU format byte
PS	BYTE	PDU specific byte
DST	DWORD	target address of the array in which the received data is stored ► The address must be determined by means of the operator ADR and assigned to the FB!

## Parameters of the outputs

464

Parameter	Data type	Description
RESULT	BYTE	0 = not active 1 = data transmission completed 2 = unit active (data transmission) 3 = error, data cannot be sent
SA	BYTE	logical device address (sender address) of the called device
LEN	WORD	number of data bytes received

## 6.6 ifm CANopen libraries

### Contents

Technical about CANopen .....	117
Libraries for CANopen.....	154

1856

### **NOTE**

The following devices support CANopen only for the 1st CAN interface:

- Controller CR0020, CR200, CR0301, CR0302, CR0303, CR0505, CR250n, CR7021, CR7201, CR7506
- PDM360smart: CR1070, CR1071

If the CANopen master has already been added, the device can no longer be used as a CANopen slave via CoDeSys.

Implementation of a separate protocol on interface 2 or using the protocol to SAE J1939 or ISO 11992 is possible at any time.

The following devices can be used on all CAN interfaces with all protocols:

- BasicController: CR040n
- BasicDisplay: CR0451
- Controller CRnn32, CRnn33
- PDM360: CR1050, CR1051
- PDM360compact: CR1052, CR1053, CR1055, CR1056
- PDM360NG: CR108n

## 6.6.1 Technical about CANopen

### Contents

CANopen network configuration, status and error handling .....	117
CANopen support by CoDeSys.....	118
CANopen master.....	119
CANopen slave .....	140
CANopen network variables.....	148

7773

**CANopen tables** (→ page [303](#)) you will find in the annex.

### CANopen network configuration, status and error handling

7471

For all programmable devices the CANopen interface of CoDeSys is used. Whereas the network configuration and parameter setting of the connected devices are directly carried out via the programming software, the error messages can only be reached via nested variable structures in the CANopen stack. The documentation below shows you the structure and use of the network configuration and describes the units of the **ifm** CANopen device libraries.

The chapters **CANopen support by CoDeSys** (→ page [118](#)), **CANopen master** (→ page [119](#)), **CANopen slave** (→ page [140](#)) and **CANopen network variables** (→ page [148](#)) describe the internal units of the CoDeSys CANopen stacks and their use. They also give information of how to use the network configurator.

The chapters concerning the libraries `ifm_CRnnnn_CANopenMaster_Vxxyyzz.lib` and `ifm_CRnnnn_CANopenSlave_Vxxyyzz.lib` describe all units for error handling and polling the device status when used as master or slave.

#### NOTE

Irrespective of the device used the structure of the function interfaces of all libraries is the same. The slight differences (e.g. CANOPEN\_LED\_STATUS) are directly described in the corresponding FBs.

It is absolutely necessary to use only the corresponding device-specific library. The context can be seen from the integrated article number of the device.

Example CR0020: → `ifm_CR0020_CANopenMaster_Vxxyyzz.lib`

→ chapter **Setup the target** (→ page [27](#))

When other libraries are used the device can no longer function correctly.

## CANopen support by CoDeSys

1857

### General information about CANopen with CoDeSys

2075

CoDeSys is one of the leading systems for programming control systems to the international standard IEC 61131. To make CoDeSys more interesting for users many important functions were integrated in the programming system, among them a configurator for CANopen. This CANopen configurator enables configuration of CANopen networks (with some restrictions) under CoDeSys.

CANopen is implemented as a CoDeSys library in IEC 61131-3. The library is based on simple basic CAN functions called CAN driver.

Implementation of the CANopen functions as CoDeSys library enables simple scaling of the target system. The CANopen function only uses target system resources if the function is really used. To use target system resources carefully CoDeSys automatically generates a data basis for the CANopen master function which exactly corresponds to the configuration.

From the CoDeSys programming system version 2.3.6.0 onwards an *ecomatmobile* controller can be used as CANopen master and as CANopen slave.

#### NOTE

For all *ecomatmobile* controllers and the PDM360smart you must use CANopen libraries with the following addition:

- For CR0032 target version up to V01, all other devices up to V04.00.05: "**OptTable**"
- For CR0032 target version from V02 onwards, all other devices from V05 onwards: "**OptTableEx**"

If a new project is created, these libraries are in general automatically loaded. If you add the libraries via the library manager, you must ensure a correct selection.

The CANopen libraries without this addition are used for all other programmable devices (e.g. PDM360compact).

### CANopen terms and implementation

1858

According to the CANopen specification there are no masters and slaves in a CAN network. Instead of this there is an NMT master (NMT = network management), a configuration master, etc. according to CANopen. It is always assumed that all participants of a CAN network have equal rights.

Implementation assumes that a CAN network serves as periphery of a CoDeSys programmable controller. As a result of this an *ecomatmobile* controller or a PDM360 display is called CANopen master in the CAN configurator of CoDeSys. This master is an NMT master and configuration master. Normally the master ensures that the network is put into operation. The master takes the initiative to start the individual nodes (= network nodes) known via the configuration. These nodes are called slaves.

To bring the master closer to the status of a CANopen slave an object directory was introduced for the master. The master can also act as an SDO server (SDO = Service Data Object) and not only as SDO client in the configuration phase of the slaves.

## IDs (addresses) in CANopen

3952

In CANopen there are different types of addresses (IDs):

- **COB ID**  
The **C**ommunication **O**bject **I**dentifier addresses the message (= the communication object) in the list of devices. A communication object consists of one or more CAN messages with a specific functionality, e.g.
  - PDO (**P**rocess **D**ata **O**bject = message object with process data),
  - SDO (**S**ervice **D**ata **O**bject = message object with service data),
  - emergency (message object with emergency data),
  - time (message object with time data) or
  - error control (message object with error messages).
- **CAN ID**  
The **CAN** Identifier defines CAN messages in the complete network. The CAN ID is the main part of the arbitration field of a CAN data frame. The CAN ID value determines implicitly the priority for the bus arbitration.
- **Download ID**  
The download ID indicates the node ID for service communication via SDO for the program download and for debugging.
- **Node ID**  
The **N**ode **I**dentifier is a unique descriptor for CANopen devices in the CAN network. The Node ID is also part of some pre-defined connectionsets (→ **Function code / Predefined Connectionset** (→ page [306](#))).

Comparison of download-ID vs. COB-ID:

Controller program download		CANopen	
Download ID	COB ID SDO	Node ID	COB ID SDO
1...127	TX: 580 <sub>16</sub> + download ID	1...127	TX: 580 <sub>16</sub> + node ID
	RX: 600 <sub>16</sub> + download ID		RX: 600 <sub>16</sub> + node ID

TX = slave sends to master  
RX = slave receives from master

## CANopen master

### Contents

Differentiation from other CANopen libraries .....	120
Create a CANopen project .....	122
Add and configure CANopen slaves .....	125
Master at runtime .....	129
Start the network .....	132
Network states.....	132

1859

## Differentiation from other CANopen libraries

1990

The CANopen library implemented by 3S (Smart Software Solutions) differentiates from the systems on the market in various points. It was not developed to make other libraries of renowned manufacturers unnecessary but was deliberately optimised for use with the CoDeSys programming and runtime system.

The libraries are based on the specifications of CiA DS301, V402.

For users the advantages of the CoDeSys CANopen library are as follows:

- Implementation is independent of the target system and can therefore be directly used on every controller programmable with CoDeSys.
- The complete system contains the CANopen configurator and integration in the development system.
- The CANopen functionality is reloadable. This means that the CANopen FBs can be loaded and updated without changing the operating system.
- The resources of the target system are used carefully. Memory is allocated depending on the used configuration, not for a maximum configuration.
- Automatic updating of the inputs and outputs without additional measures.

The following functions defined in CANopen are at present supported by the **ifm** CANopen library:

- **Transmitting PDOs:** master transmits to slaves (slave = node, device)  
Transmitting event-controlled (i.e. in case of a change), time-controlled (RepeatTimer) or as synchronous PDOs, i.e. always when a SYNC was transmitted by the master. An external SYNC source can also be used to initiate transmission of synchronous PDOs.
- **Receiving PDOs:** master receives from slave  
Depending on the slave: event-controlled, request-controlled, acyclic and cyclic.
- **PDO mapping**  
Assignment between a local object directory and PDOs from/to the CANopen slave (if supported by the slave).
- **Transmitting and receiving SDOs** (unsegmented, i.e. 4 bytes per entry in the object directory)  
Automatic configuration of all slaves via SDOs at the system start.  
Application-controlled transmission and reception of SDOs to/from configured slaves.
- **Synchronisation**  
Automatic transmission of SYNC messages by the CANopen master.



- **Nodeguarding**  
Automatic transmission of guarding messages and lifetime monitoring for every slave configured accordingly.  
We recommend: It is better to work with the heartbeat function for current devices since then the bus load is lower.
- **Heartbeat**  
Automatic transmission and monitoring of heartbeat messages.
- **Emergency**  
Reception of emergency messages from the configured slaves and message storage.
- **Set Node-ID and baud rate** in the slaves  
By calling a simple function, node ID and baud rate of a slave can be set at runtime of the application.

The following functions defined in CANopen are at present **not** supported by the CANopen 3S (Smart Software Solutions) library:

- Dynamic identifier assignment,
- Dynamic SDO connections,
- SDO transfer block by block, segmented SDO transfer (the functionality can be implemented via **CANx\_SDO\_READ** (→ page [176](#)) and **CANx\_SDO\_WRITE** (→ page [178](#)) in the corresponding **ifm** device library).
- All options of the CANopen protocol which are not mentioned above.

## Create a CANopen project

1860

Below the creation of a new project with a CANopen master is completely described step by step. It is assumed that you have already installed CoDeSys on your processor and the Target and EDS files have also been correctly installed or copied.

- ▶ A more detailed description for setting and using the dialogue [controller and CANopen configuration] is given in the CoDeSys manual under [Resources] > [PLC Configuration] or in the Online help.
- > After creation of a new project (→ chapter **Setup the target** (→ page 27)) the CANopen master must first be added to the controller configuration via [Insert] > [Append subelement]. For controllers with 2 or more CAN interfaces interface 1 is automatically configured for the master.
- > The following libraries and software modules are automatically integrated:
  - The `Standard.LIB` which provides the standard functions for the controller defined in IEC 61131.
  - The `3S_CanOpenManager.LIB` which provides the CANopen basic functionalities (possibly `3S_CanOpenManagerOptTable.LIB` for the C167 controller)
  - One or several of the libraries `3S_CANOpenNetVar.LIB`, `3S_CANOpenDevice.LIB` and `3S_CANOpenMaster.LIB` (possibly `3S_...OptTable.LIB` for the C167 controller) depending on the requested functionality
  - The system libraries `SysLibSem.LIB` and `SysLibCallback.LIB`
  - To use the prepared network diagnostic, status and EMCY functions, the library `ifm_CRnnnn_CANOpenMaster_Vxxyyzz.LIB` must be manually added to the library manager. Without this library the network information must be directly read from the nested structures of the CoDeSys CANopen libraries.
- > The following libraries and software modules must still be integrated:
  - The device library for the corresponding hardware, e.g. `ifm_CR0020_Vxxyyzz.LIB`. This library provides all device-specific functions.
  - EDS files for all slaves to be operated on the network. The EDS files are provided for all CANopen slaves by **ifm electronic**. → chapter **Set up programming system via templates** (→ page 30)  
**For the EDS files of other manufacturers' nodes contact the corresponding manufacturer.**


## CANopen master: Tab [CAN parameters]

1967

The most important parameters for the master can be set in this dialogue window. If necessary, the contents of the master EDS file can be viewed via the button [EDS...].

This button is only indicated if the EDS file (e.g. CR0020MasterODEntry.EDS) is in the directory ...\\CoDeSys V2.3\\Library\\PLCConf.

During the compilation of the application program the object directory of the master is automatically generated from this EDS file.



Example: PLC configuration for CR0505 CANopen master

## CAN parameters: Baud rate

10028


Select the baud rate for the master.

The baud rate must correspond to the transmission speed of the other network participants.

## CAN parameters: Communication Cycle Period/Sync. Window Length

10029

After expiry of the [Communication Cycle Period] a SYNC message is transmitted by the master.



The [Sync. Window Length] indicates the time during which synchronous PDOs are transmitted by the other network participants and must be received by the master.

As in most applications no special requirements are made for the SYNC object, the same time can be set for [Communication Cycle Period] and [Sync. Window Length].

Please ensure the time is entered in [ $\mu$ s] (the value 50 000 corresponds to 50 ms).

## CAN parameters: Sync. COB ID

10030

In this field the identifier for the SYNC message can be set. It is always transmitted after the communication cycle period has elapsed. The default value is 128 and should normally not be changed. To activate transmission of the SYNC message, the checkbox [activate] must be set.

### **NOTE**

The SYNC message is always generated at the start of a program cycle. The inputs are then read, the program is processed, the outputs are written to and then all synchronous PDOs are transmitted.

Please note that the SYNC time becomes longer if the set SYNC time is shorter than the program cycle time.

**Example:** communication cycle period = 10 ms and program cycle time = 30 ms.  
The SYNC message is only transmitted after 30 ms.

## CAN parameters: Node ID

10031

Enter the node number (not the download ID!) of the master in this field.

The node number may only occur once in the network, otherwise the communication is disturbed.

**CAN parameters: Automatic startup**

10032


After successful configuration the network and the connected nodes are set to the state [operational] and then started.

If the checkbox is not activated, the network must be started manually.

**CAN parameters: Heartbeat**

10033

If the other participants in the network support heartbeat, the option [support DSP301, V4.01...] can be selected. If necessary, the master can generate its own heartbeat signal after the set time has elapsed.



## Add and configure CANopen slaves

### Contents

CANopen slave: Tab [CAN parameters] .....	127
Tab [Receive PDO-Mapping] and [Send PDO-Mapping] .....	128
Tab [Service Data Objects] .....	129

1861


Next you can add the CANopen slaves. To do so, you must call again the dialogue in the controller configuration [Insert] > [Append subelement]. A list of the CANopen device descriptions (EDS files) stored in the directory PLC\_CONF is available. By selecting the corresponding device it is directly added to the tree of the controller configuration.

### NOTE

If a slave is added via the configuration dialogue in CoDeSys, source code is dynamically integrated in the application program for every node. At the same time every additionally inserted slave extends the cycle time of the application program. This means: In a network with many slaves the master can process no further time-critical tasks (e.g. FB OCC\_TASK).

A network with 27 slaves has a basic cycle time of 30 ms.

Please note that the maximum time for a PLC cycle of approx. 50 ms should not be exceeded (watchdog time: 100 ms).



Example: PLC configuration for CR0020 CANopen master with connected I/O CompactModule

## **CANopen slave: Tab [CAN parameters]**

1968

### **CAN parameters: Node ID**

10036

The node ID is used to clearly identify the CAN module and corresponds to the number on the module set between 1 and 127.

The ID is entered decimally and is automatically increased by 1 if a new module is added.

### **CAN parameters: Write DCF**

10037

If [Write DCF] is activated, a DCF file is created after adding an EDS file to the set directory for compilation files. The name of the DCF file consists of the name of the EDS file and appended node ID.

### **CAN parameters: Create all SDOs**

10038

If this option is activated, SDOs are generated for all communication objects.

Default values are not written again!

### **CAN parameters: Node reset**

10039

The slave is reset ("load") as soon as the configuration is loaded to the controller.

### **CAN parameters: Optional device**

10040

If the option [optional device] is activated, the master tries only once to read from this node. In case of a missing response, the node is ignored and the master goes to the normal operating state.

If the slave is connected to the network and detected at a later point in time, it is automatically started. To do so, you must have selected the option [Automatic startup] in the CAN parameters of the master.

### **CAN parameters: No initialization**

10041

If this option is activated, the master immediately takes the node into operation without transmitting configuration SDOs. (Nevertheless, the SDO data is generated and stored in the controller.)

## CAN parameters: Nodeguarding / heartbeat settings

10042

Depending on the device you can choose:

- [nodeguarding] and [life time factor] must be set OR
- [heartbeat] must be set.

We recommend: It is better to work with the heartbeat function for current devices since then the bus load is lower.

## CAN parameters: Emergency telegram

10043

This option is normally selected. The EMCY messages are transferred with the specified identifier.

## CAN parameters: Communication cycle

10044

In special applications a monitoring time for the SYNC messages generated by the master can be set here.

Please note that this time must be longer than the SYNC time of the master. The optimum value must be determined experimentally, if necessary.

In most cases nodeguarding and heartbeat are sufficient for node monitoring.

## Tab [Receive PDO-Mapping] and [Send PDO-Mapping]

1969

With the tabs [Receive PDO-Mapping] and [Send PDO-Mapping] in the configuration dialogue of a CAN module the module mapping (assignment between local object directory and PDOs from/to the CANopen slave) described in the EDS file can be changed (if supported by the CAN module).

All [mappable] objects of the EDS file are available on the left and can be added to or removed from the PDOs (Process Data Objects) on the right.

The [StandardDataTypes] can be added to generate spaces in the PDO.

## PDO-Mapping: Insert

10046

With the button [Insert] you can generate more PDOs and insert the corresponding objects. The inputs and outputs are assigned to the IEC addresses via the inserted PDOs.

In the controller configuration the settings made can be seen after closing the dialogue. The individual objects can be given symbolic names.



## PDO-Mapping: Properties

10047

The PDO properties defined in the standard can be edited in a dialogue via properties.

COB-ID	Every PDO message requires a clear COB ID (communication object identifier). If an option is not supported by the module or the value must not be changed, the field is grey and cannot be edited.
Inhibit Time	The inhibit time (100 µs) is the minimum time between two messages of this PDO so that the messages which are transferred when the value is changed are not transmitted too often. The unit is 100 µs.
Transmission Type	<p>For transmission type you receive a selection of possible transmission modes for this module:</p> <p><b>acyclic – synchronous</b> After a change the PDO is transferred with the next SYNC.</p> <p><b>cyclic – synchronous</b> The PDO is transferred synchronously. [Number of SYNCs] indicates the number of the synchronisation messages between two transmissions of this PDO.</p> <p><b>asynchronous – device profile specific</b> The PDO is transmitted on event, i.e. when the value is changed. The device profile defines which data can be transferred in this way.</p> <p><b>asynchronous – manufacturer specific</b> The PDO is transmitted on event, i.e. when the value is changed. The device manufacturer defines which data is transferred in this way.</p> <p><b>(a)synchronous – RTR only</b> These services are not implemented.</p> <p><b>Number of SYNCs</b> Depending on the transmission type this field can be edited to enter the number of synchronisation messages (definition in the CAN parameter dialogue of [Com. Cycle Period], [Sync Window Length], [Sync. COB ID]) after which the PDO is to be transmitted again.</p> <p><b>Event-Time</b> Depending on the transmission type the period in milliseconds [ms] required between two transmissions of the PDO is indicated in this field.</p>

## Tab [Service Data Objects]

1970

### Index, name, value, type and default

Here all objects of the EDS or DCF file are listed which are in the range from index 2000<sub>16</sub> to 9FFF<sub>16</sub> and defined as writable. Index, name, value, type and default are indicated for every object. The value can be changed. Select the value and press the [space bar]. After the change you can confirm the value with the button [Enter] or reject it with [ESC].

For the initialisation of the CAN bus the set values are transferred as SDOs (Service Data Object) to the CAN module thus having direct influence on the object directory of the CANopen slave. Normally they are written again at every start of the application program – irrespective of whether they are permanently stored in the CANopen slave.

## Master at runtime

### Contents

Reset of all configured slaves on the bus at the system start.....	130
Polling of the slave device type.....	130
Configuration of all correctly detected devices .....	130
Automatic configuration of slaves .....	131
Start of all correctly configured slaves .....	131
Cyclical transmission of the SYNC message.....	131
Nodeguarding with lifetime monitoring .....	131
Heartbeat from the master to the slaves.....	131
Reception of emergency messages.....	131

8569

Here you find information about the functionality of the CANopen master libraries at runtime.

The CANopen master library provides the CoDeSys application with implicit services which are sufficient for most applications. These services are integrated for users in a transparent manner and are available in the application without additional calls. The following description assumes that the library `ifm_CRnnnn_CANopenMaster_Vxxyyzz.LIB` was manually added to the library manager to use the network diagnostic, status and EMCY functions.

Services of the CANopen master library:

### Reset of all configured slaves on the bus at the system start

8570

To reset the slaves, the NMT command "Reset Remote Node" is used as standard explicitly for every slave separately. (NMT stands for **N**etwork **M**anagement according to CANopen. The individual commands are described in the CAN document DSP301.) In order to avoid overload of slaves having less powerful CAN controllers it is useful to reset the slaves using the command "All Remote Nodes". The service is performed for **all** configured slaves using `CANx_MASTER_STATUS` (→ page 160) with `GLOBAL_START=TRUE`. If the slaves are to be reset **individually**, this input must be set to `FALSE`.

### Polling of the slave device type

8021

Polling of the slave device type using SDO (polling for object 100016) and comparison with the configured slave ID:

Indication of an error status for the slaves from which a wrong device type was received. The request is repeated after 0.5 s if ...

- no device type was received
- AND the slave was **not** identified as optional in the configuration
- AND the timeout has **not** elapsed.

### Configuration of all correctly detected devices

8022

Every SDO is monitored for a response and repeated if the slave does not respond within the monitoring time.

## Automatic configuration of slaves

8023

Automatic configuration of slaves using SDOs while the bus is in operation:  
Prerequisite: The slave logged in the master via a bootup message.

## Start of all correctly configured slaves

8574

Start of all correctly configured slaves after the end of the configuration of the corresponding slave:

To start the slaves the NMT command "Start remote node" is normally used. As for the "reset" this command can be replaced by "Start All Remote Nodes".

The service can be called via CANx\_Master\_STATUS with GLOBAL\_START=TRUE.

## Cyclical transmission of the SYNC message

8025

This value can only be set during the configuration.

## Nodeguarding with lifetime monitoring

8576

Setting of nodeguarding with lifetime monitoring for every slave possible:

The error status can be monitored for max. 8 slaves via CANx\_MASTER\_STATUS with ERROR\_CONTROL=TRUE.

We recommend: It is better to work with the heartbeat function for current devices since then the bus load is lower.

## Heartbeat from the master to the slaves

8577

The error status can be monitored for max. 8 slaves via CANx\_MASTER\_STATUS with ERROR\_CONTROL=TRUE.

## Reception of emergency messages

8578

Reception of emergency messages for every slave, the emergency messages received last are stored separately for every slave:

The error messages can be read via CANx\_MASTER\_STATUS with EMERGENCY\_OBJECT\_SLAVES=TRUE.

In addition this FB provides the EMCY message generated last on the output GET\_EMERGENCY.

## Start the network

1863

Here you find information about how to start the CANopen network.

After downloading the project to the controller or a reset of the application the master starts up the CAN network again. This always happens in the same order of actions:

- All slaves are reset unless they are marked as "No initialization" in the configurator. They are reset individually using the NMT command "Reset Node" ( $81_{16}$ ) with the node ID of the slave. If the flag GLOBAL\_START was set via CANx\_MASTER\_STATUS (→ page 160), the command is used once with the node ID 0 to start up the network.
- All slaves are configured. To do so, the object  $1000_{16}$  of the slave is polled.
  - If the slave responds within the monitoring time of 0.5 s, the next configuration SDO is transmitted.
  - If a slave is marked as "optional" and does not respond to the polling for object  $1000_{16}$  within the monitoring time, it is marked as not available and no further SDOs are transmitted to it.
  - If a slave responds to the polling for object  $1000_{16}$  with a type other than the configured one (in the lower 16 bits), it is configured but marked as a wrong type.
- All SDOs are repeated as long as a response of the slave was seen within the monitoring time. Here the application can monitor start-up of the individual slaves and possibly react by setting the flag SET\_TIMEOUT\_STATE in the NODE\_STATE\_SLAVE array of CANx\_MASTER\_STATUS.
- If the master configured a heartbeat time unequal to 0, the heartbeat is generated immediately after the start of the master controller.
- After all slaves have received their configuration SDOs, guarding starts for slaves with configured nodeguarding.
- If the master was configured to [Automatic startup], all slaves are now started individually by the master. To do so, the NMT command "Start Remote Node" ( $1_{16}$ ) is used. If the flag GLOBAL\_START was set via CANx\_Master\_STATUS, the command is used with the node ID 0 and so all slaves are started with "Start all Nodes".
- All configured TX-PDOs are transmitted at least once (for the slaves RX-PDOs).
- If [Automatic startup] is deactivated, the slaves must be started separately via the flag START\_NODE in the NODE\_STATE\_SLAVE array or via the input GLOBAL\_START of CANx\_MASTER\_STATUS.

## Network states

### Contents

Boot up of the CANopen master .....	133
Boot up of the CANopen slaves .....	135
Start-up of the network without [Automatic startup] .....	136
The object directory of the CANopen master .....	139

1864

Here you read how to interpret the states of the CANopen network and how to react.

For the **Start the network** (→ page [132](#)) of the CANopen network and during operation the individual functions of the library pass different states.

### NOTE

In the monitor mode (online mode) of CoDeSys the states of the CAN network can be seen in the global variable list "CANopen implicit variables". This requires exact knowledge of CANopen and the structure of the CoDeSys CANopen libraries.

To facilitate access **CANx\_MASTER\_STATUS** (→ page [160](#)) from the library `ifm_CRnnnn_CANopenMaster_Vxyyyzz.LIB` is available.

### Boot up of the CANopen master

1971

During boot-up of the CAN network the master passes different states which can be read via the output `NODE_STATE` of **CANx\_MASTER\_STATUS** (→ page [160](#)).

(Network state of the master → next chapter)

Whenever a slave does not respond to an SDO request (upload or download), the request is repeated. The master leaves state 3, as described above, but not before all SDOs have been transmitted successfully. So it can be detected whether a slave is missing or whether the master has not correctly received all SDOs. It is of no importance for the master whether a slave responds with an acknowledgement or an abort. It is only important for the master whether he received a response at all.

An exception is a slave marked as "optional". Optional slaves are asked for their 1000<sub>n</sub> object only once. If they do not respond within 0.5 s, the slave is first ignored by the master and the master goes to state 5 without further reaction of this slave.

## NMT state for CANopen master

9964

State hex   dec		Description
00	0	not defined
01	1	Master waits for a boot-up message of the node. OR: Master waits for the expiry of the given guard time.
02	2	- Master waits for 300 ms. - Master requests the object 1000 <sub>16</sub> . - Then the state is set to 3.
03	3	The master configures its slaves. To do so, all SDOs generated by the configurator are transmitted to the slaves one after the other: - The Master sends to the slave a SDO read request (index 1000 <sub>16</sub> ). - The generated SDOs are compressed into a SDO array. - The slave knows it's first SDO and the number of it's SDOs.
05	5	After transmission of all SDOs to the slaves the master goes to state 5 and remains in this state. State 5 is the normal operating state for the master.

To read the node state out of the FB:

Used function block	Node state is found here
CANx_MASTER_STATUS CANx_SLAVE_STATUS	output NODE_STATE
CANOPEN_GETSTATE	output NODESTATE

## Boot up of the CANopen slaves

1972

You can read the states of a slave via the array `NODE_STATE_SLAVE` of `CANx_MASTER_STATUS` (→ page 160). During boot up of the CAN network the slave passes the states -1, 1 and 2 automatically.

(Network state of the slave → next chapter)

## NMT state for CANopen slave

9965

State hex   dec		Description
FF	-1	The slave is reset by the NMT message "Reset Node" and automatically goes to state 1.
00	0	not defined
01	1	state = waiting for BOOTUP After max. 2 s or immediately on reception of its boot up message the slave goes to state 2.
02	2	state = BOOTUP After a delay of 0.5 s the slave automatically goes to state 3.
03	3	state = PREPARED The slave is configured in state 3. The slave remains in state 3 as long as it has received all SDOs generated by the configurator. It is not important whether during the slave configuration the response to SDO transfers is abort (error) or whether the response to all SDO transfers is no error. Only the response as such received by the slave is important – not its contents.  If in the configurator the option "Reset node" has been activated, a new reset of the node is carried out after transmitting the object $1011_{16}$ sub-index 1 which then contains the value "load". The slave is then polled again with the upload of the object $1000_{16}$ .  Slaves with a problem during the configuration phase remain in state 3 or directly go to an error state (state > 5) after the configuration phase.
04	4	state = PRE-OPERATIONAL A node always goes to state 4 except for the following cases: <ul style="list-style-type: none"> <li>it is an "optional" slave and it was detected as non available on the bus (polling for object <math>1000_{16}</math>) OR:</li> <li>the slave is present but reacted to the polling for object <math>1000_{16}</math> with a type in the lower 16 bits other than expected by the configurator.</li> </ul>
05	5	state = OPERATIONAL State 5 is the normal operating state of the slave: [Normal Operation].  If the master was configured to [Automatic startup], the slave starts in state 4 (i.e. a "start node" NMT message is generated) and the slave goes automatically to state 5.  If the flag <code>GLOBAL_START</code> was set, the master waits until all slaves are in state 4. All slaves are then started with the NMT command [Start All Nodes].
61	97	A node goes to state 97 if it is optional (optional device in the CAN configuration) and has not reacted to the SDO polling for object $1000_{16}$ .  If the slave is connected to the network and detected at a later point in time, it is automatically started. To do so, you must have selected the option [Automatic startup] in the CAN parameters of the master.
62	98	A node goes to state 98 if the device type (object $1000_{16}$ ) does not correspond to the configured type.
63	99	In case of a nodeguarding timeout the slave is set to state 99.  As soon as the slave reacts again to nodeguard requests and the option [Automatic startup] is activated, it is automatically started by the master. Depending on the status contained in the response to the nodeguard requests, the node is newly configured or only started.  To start the slave manually it is sufficient to use the method [NodeStart].

Nodeguard messages are transmitted to the slave ...

- if the slave is in state 4 or higher AND
- if nodeguarding was configured.

To read the node state out of the FB:

Used function block	Node state is found here
CANx_MASTER_STATUS CANx_SLAVE_STATUS	output NODE_STATE
CANOPEN_GETSTATE	output NODESTATE

## CANopen status of the node

1973

Node status according to CANopen (with these values the status is also coded by the node in the corresponding messages).

Status hex   dec	CANopen status	Description
00   0	BOOTUP	Node received the boot-up message.
04   4	PREPARED	Node is configured via SDOs.
05   5	OPERATIONAL	Node participates in the normal exchange of data.
7F   127	PRE-OPERATIONAL	Node sends no data, but can be configred by the master.

If nodeguarding active: the most significant status bit toggles between the messages.

Read the node status from the function block:

Function block used	Node status is found here
CANx_MASTER_STATUS CANx_SLAVE_STATUS	Structure element LAST_STATE from the array NODE_STATE_SLAVE
CANOPEN_GETSTATE	Output LASTNODESTATE



## Start-up of the network without [Automatic startup]

8583

Sometimes it is necessary that the application determines the instant to start the CANopen slaves. To do so, the option [Automatic startup] of the CANopen master must be deactivated in the configuration. It is then up to the application to start the slaves.

## Starting the network with GLOBAL\_START

1974

In a CAN network with many participants (in most cases more than 8) it often happens that NMT messages in quick succession are not detected by all (mostly slow) IO nodes (e.g. CompactModules CR2013). The reason for this is that these nodes must listen to all messages with the ID 0. NMT messages transmitted at too short intervals overload the receive buffer of such nodes.

A help for this is to reduce the number of NMT messages in quick succession.

- ▶ To do so, set the input GLOBAL\_START of **CANx\_MASTER\_STATUS** (→ page [160](#)) to TRUE (with [Automatic startup]).
- > The CANopen master library uses the command "Start All Nodes" instead of starting all nodes individually using the command "Start Node".
- > GLOBAL\_START is executed only once when the network is initialised.
- > If this input is set, the controller also starts nodes with status 98 (see above). However, the PDOs for these nodes remain deactivated.

## Starting the network with START\_ALL\_NODES

1975

If the network is not automatically started with GLOBAL\_START of **CANx\_MASTER\_STATUS** (→ page [160](#)), it can be started at any time, i.e. every node one after the other. If this is not requested, the option is as follows:

- ▶ Set the input START\_ALL\_NODES of **CANx\_Master\_STATUS** to TRUE. START\_ALL\_NODES is typically set by the application program at runtime.
- > If this input is set, nodes with status 98 (see above) are started. However, the PDOs for these nodes remain deactivated.

## Initialisation of the network with RESET\_ALL\_NODES

1976

The same reasons which apply to the command START\_ALL\_NODES also apply to the NMT command RESET\_ALL\_NODES (instead of RESET\_NODES for every individual node).

- ▶ To do so, the input RESET\_ALL\_NODES of **CANx\_MASTER\_STATUS** (→ page [160](#)) must be set to TRUE.
- > This resets all nodes once at the same time.

## Access to the status of the CANopen master

1977

You should poll the status of the master so that the application code is not processed before the IO network is ready. The following code fragment example shows one option:

### Variable declaration

```
VAR
    FB_MasterStatus := CR0020_MASTER_STATUS;
    :
END_VAR
```

### program code

```
If    FB_MasterStatus.NODE_STATE = 5 THEN
    <application code>
END_IF
```

By setting the flag TIME\_OUT\_STATE in the array NODE\_STATE\_SLAVE of **CANx\_MASTER\_STATUS** (→ page [160](#)) the application can react and, for example, jump the non configurable node.

## The object directory of the CANopen master


1978

In some cases it is helpful if the CANopen master has its own object directory. This enables, for example, the exchange of data of the application with other CAN nodes.

The object directory of the master is generated using an EDS file named `CRnnnnMasterODEntry.EDS` during compilation and is given default values. This EDS file is stored in the directory `CoDeSys Vn\Library\PLCconf`. The content of the EDS file can be viewed via the button [EDS...] in the configuration window [CAN parameters].

Even if the object directory is not available, the master can be used without restrictions.

The object directory is accessed by the application via an array with the following structure:



Structure element	Description
.dwIdxSubIdxF	Structure of the component 16#iiii:ssff: iiii – index (2 bytes, bits 16...31), Idx ss – sub-index (1 byte, bits 8...15), SubIdx ff – flags (1 byte, bits 0...7), F  Meaning of the flag bits: bit 0: write bit 1: content is a pointer to an address bit 2: mappable bit 3: swap bit 4: signed value bit 5: floating point bit 6: contains more sub-indices
.dwContent	contains the contents of the entry
.wLen	length of the data
.byAttrib	initially intended as access authorisation can be freely used by the application of the master
.byAccess	in the past access authorisation can be freely used by the application of the master

On the platform CoDeSys has no editor for this object directory.

The EDS file only determines the objects used to create the object directory. The entries are always generated with length 4 and the flags (least significant byte of the component of an object directory entry `.dwIdxSubIdxF`) are always given the value 1. This means both bytes have the value  $41_{16}$ .

If an object directory is available in the master, the master can act as SDO server in the network. Whenever a client accesses an entry of the object directory by writing, this is indicated to the application via the flag `OD_CHANGED` in `CANx_MASTER_STATUS` (→ page 160). After evaluation this flag must be reset.

The application can use the object directory by directly writing to or reading the entries or by pointing the entries to IEC variables. This means: when reading/writing to another node these IEC variables are directly accessed.

If index and sub-index of the object directory are known, an entry can be addressed as follows:

```
I := GetODMEntryValue(16#iiiiiss00, pCanOpenMaster[0].wODMFirstIdx,  
pCanOpenMaster[0].wODMFirstIdx + pCanOpenMaster[0].wODMCount;
```

For "iii" the index must be used and for "ss" the sub-index (as hex values).

The number of the array entry is available in `I`. You can now directly access the components of the entry.

It is sufficient to enter address, length and flags so that this entry can be directly transferred to an IEC variable:

```
ODMEntries[I].dwContent := ADR(<variable name>);  
ODMEntries[I].wLen := sizeof(<variable name>);  
ODMEntries[I].dwIdxSubIdxF := ODMEntries[I].dwIdxSubIdxF OR  
OD_ENTRYFLG_WRITE OR OD_ENTRYFLG_ISPOINTER;
```

It is sufficient to change the content of `".dwContent"` to change only the content of the entry.

## CANopen slave

### Contents

Functionality of the CANopen slave library .....	141
CANopen slave configuration.....	141
Access to the CANopen slave at runtime .....	148

1865

A CoDeSys programmable controller can also be a CANopen slave in a CAN network.

### Functionality of the CANopen slave library

1979

The CANopen slave library in combination with the CANopen configurator provides the user with the following options:

- In CoDeSys: configuration of the properties for nodeguarding/heartbeat, emergency, node ID and baud rate at which the device is to operate.
- Together with the parameter manager in CoDeSys, a default PDO mapping can be created which can be changed by the master at runtime. The PDO mapping is changed by the master during the configuration phase. By means of mapping IEC variables of the application can be mapped to PDOs. This means IEC variables are assigned to the PDOs to be able to easily evaluate them in the application program.
- The CANopen slave library provides an object directory. The size of this object directory is defined while compiling CoDeSys. This directory contains all objects which describe the CANopen slave and in addition the objects defined by the parameter manager. In the parameter manager only the list types parameters and variables can be used for the CANopen slave.
- The library manages the access to the object directory, i.e. it acts as SDO server on the bus.
- The library monitors nodeguarding or the heartbeat consumer time (always only of one producer) and sets corresponding error flags for the application.
- An EDS file can be generated which describes the configured properties of the CANopen slave so that the device can be integrated and configured as a slave under a CANopen master.

The CANopen slave library explicitly does not provide the following functionalities described in CANopen (all options of the CANopen protocol which are not indicated here or in the above section are not implemented either):

- Dynamic SDO and PDO identifiers
- SDO block transfer
- Automatic generation of emergency messages. Emergency messages must always be generated by the application using `CANx_SLAVE_EMCY_HANDLER` (→ page 167) and `CANx_SLAVE_SEND_EMERGENCY` (→ page 169). To do so, the library `ifm_CRnnnn_CANopenSlave_Vxxyyzz.LIB` provides these FBs.
- Dynamic changes of the PDO properties are currently only accepted on arrival of a StartNode NMT message, not with the mechanisms defined in CANopen.


CANopen slave configuration

Contents	
Tab [Base settings].....	142
Tab [CAN settings] .....	144
Tab [Default PDO mapping] .....	145
Changing the standard mapping by the master configuration .....	147
	1980

To use the controller as CANopen slave the CANopen slave must first be added via [Insert] > [Append subelement]. For controllers with 2 or more CAN interfaces the CAN interface 1 is automatically configured as a slave. All required libraries are automatically added to the library manager.

Tab [Base settings]

1981



Base settings: Bus identifier

10049

Parameter is currently not used.

Base settings: Name of updatetask

10050

Name of the task where the CANopen slave is called.

Base settings: Generate EDS file

10051

If an EDS file is to be generated from the settings to be able to add the CANopen slave to any master configuration, the option [Generate EDS file] must be activated and the name of a file must be indicated. As an option a template file can be indicated whose entries are added to the EDS file of the CANopen slave. In case of overlapping the template definitions are not overwritten.

## Example of an object directory

1991

The following entries could for example be in the object directory:

```
[FileInfo]
FileName=D:\CoDeSys\lib2\plcconf\MyTest.eds
FileVersion=1
FileRevision=1
Description=EDS for CoDeSys-Project:
D:\CoDeSys\CANopenTestprojekte\TestHeartbeatODsettings_Device.pro
CreationTime=13:59
CreationDate=09-07-2005
CreatedBy=CoDeSys
ModificationTime=13:59
ModificationDate=09-07-2005
ModifiedBy=CoDeSys

[DeviceInfo]
VendorName=3S Smart Software Solutions GmbH
ProductName=TestHeartbeatODsettings_Device
ProductNumber=0x33535F44
ProductVersion=1
ProductRevision=1
OrderCode=xxxx.yyyy.zzzz
LMT_ManufacturerName=3S GmbH
LMT_ProductName=3S_Dev
BaudRate_10=1
BaudRate_20=1
BaudRate_50=1
BaudRate_100=1
BaudRate_125=1
BaudRate_250=1
BaudRate_500=1
BaudRate_800=1
BaudRate_1000=1
SimpleBootUpMaster=1
SimpleBootUpSlave=0
ExtendedBootUpMaster=1
ExtendedBootUpSlave=0

...

[1018sub0]
ParameterName=Number of entries
ObjectType=0x7
DataType=0x5
AccessType=ro
DefaultValue=2
PDOMapping=0

[1018sub1]
ParameterName=VendorID
ObjectType=0x7
DataType=0x7
AccessType=ro
DefaultValue=0x0
PDOMapping=0

[1018sub2]
ParameterName=Product Code
ObjectType=0x7
DataType=0x7
AccessType=ro
DefaultValue=0x0
PDOMapping=0
```

For the meaning of the individual objects please see the CANopen specification DS301.

In addition to the prescribed entries, the EDS file contains the definitions for SYNC, guarding, emergency and heartbeat. If these objects are not used, the values are set to 0 (preset). But as the objects are present in the object directory of the slave at runtime, they are written to in the EDS file.

The same goes for the entries for the communication and mapping parameters. All 8 possible sub-indices of the mapping objects  $16xx_{16}$  or  $1Axx_{16}$  are present, but possibly not considered in the sub-index 0.

**i** Bit mapping is not supported by the library!

## Tab [CAN settings]

1982

The screenshot shows the 'CAN settings' tab in a configuration window. It includes fields for 'Node id' (50), 'Device Type' (0x191), and 'Baud rate' (125000). There is an unchecked checkbox for 'Automatic startup'. The 'Node guard' section has 'Nodeguarding' checked, with 'Guard COB-ID' set to '0x700+NodeId', 'Guard time (ms)' at 200, and 'Life time factor' at 2. The 'Heartbeat settings' section has both 'Activate heartbeat generation' and 'Activate heartbeat consumer' checked, with 'Heartbeat producer time' at 300 ms, 'Heartbeat Consumer Time' at 500 ms, and 'Consumer ID' at 100. The 'Emergency telegram' section has 'Emergency' checked, with 'COB-ID' set to '0x80+NodeId'.

Here you can set the **node ID** and the **baud rate**.

### Device type

(this is the default value of the object  $1000_{16}$  entered in the EDS) has  $191_{16}$  as default value (standard IO device) and can be freely changed.

The index of the CAN controller results from the position of the CANopen slave in the controller configuration.



The **nodeguarding** parameters, the **heartbeat** parameters and the emergency COB ID can also be defined in this tab. The CANopen slave can only be configured for the monitoring of a heartbeat. We recommend: It is better to work with the heartbeat function for current devices since then the bus load is lower.


## **NOTE**

When applying guarding or heartbeat AND when creating an EDS file for integration with a CANopen master:

- ▶ enter guard time = 0  
enter life time factor = 0  
enter heartbeat time = 0
- > The values set for the CANopen master are transmitted to the CANopen slave during configuration. Thus, the CANopen master has safely activated the guarding or heartbeat for this node.

## **Tab [Default PDO mapping]**

1983




In this tab the assignment between local object directory (OD editor) and PDOs transmitted/received by the CANopen slave can be defined. Such an assignment is called "mapping".

In the object directory entries used (variable OD) the connection to variables of the application is made between object index/sub-index. You only have to ensure that the sub-index 0 of an index containing more than one sub-index contains the information concerning the number of the sub-indices.

## Example: list of variables

10052

On the first receive PDO (COB ID = 512 + node ID) of the CANopen slave the data für variable PLC\_PRG.a shall be received.



### Info

[Variables] and [parameters] can be selected as list type.

For the exchange of data (e.g. via PDOs or other entries in the object directory) a variable list is created.

The parameter list should be used if you do not want to link object directory entries to application variables. For the parameter list only the index 1006<sub>16</sub> / SubIdx 0 is currently predefined. In this entry the value for the "Com. Cycle Period" can be entered by the master. This signals the absence of the SYNC message.

So you have to create a variable list in the object directory (parameter manager) and link an index/sub-index to the variable PLC\_PRG.a.

- ▶ To do so, add a line to the variable list (a click on the right mouse button opens the context menu) and enter a variable name (any name) as well as the index and sub-index.
- ▶ The only allowed access right for a receive PDO is [write only].
- ▶ Enter "PLC\_PRG.a" in the column [variable] or press [F2] and select the variable.


### NOTE

Data to be read by the CANopen master (e.g. inputs, system variables) must have the access right [read only].

Data to be written by the CANopen master (e.g. outputs in the slave) must have the access right [write only].

SDO parameters to be written and at the same time to be read from and written to the slave application by the CANopen master must have the access right [read-write].

To be able to open the parameter manager the parameter manager must be activated in the target settings under [Network functionality]. The areas for index/sub-index already contain sensible values and should not be changed.



In the default PDO mapping of the CANopen slave the index/sub-index entry is then assigned to a receive PDO as mapping entry. The PDO properties can be defined via the dialogue known from chapter [Add and configure CANopen slaves](#) (→ page [125](#)).

Only objects from the parameter manager with the attributes [read only] or [write only] are marked in the possibly generated EDS file as mappable (= can be assigned) and occur in the list of the mappable objects. All other objects are not marked as mappable in the EDS file.

## NOTE

If more than 8 data bytes are mapped to a PDO, the next free identifiers are then automatically used until all data bytes can be transferred.

To obtain a clear structure of the identifiers used you should add the correct number of the receive and transmit PDOs and assign them the variable bytes from the list.

## Changing the standard mapping by the master configuration

1984

You can change the default PDO mapping (in the CANopen slave configuration) within certain limits by the master.

The rule applies that the CANopen slave cannot recreate entries in the object directory which are not yet available in the standard mapping (default PDO mapping in the CANopen slave configuration). For a PDO, for example, which contains a mapped object in the default PDO mapping no second object can be mapped in the master configuration.

So the mapping changed by the master configuration can at most contain the PDOs available in the standard mapping. Within these PDOs there are 8 mapping entries (sub-indices).

Possible errors which may occur are not displayed, i.e. the supernumerary PDO definitions / supernumerary mapping entries are processed as if not present.

In the master the PDOs must always be created starting from 1400<sub>16</sub> (receive PDO communication parameter) or 1800<sub>16</sub> (transmit PDO communication parameter) and follow each other without interruption.

## Access to the CANopen slave at runtime

1985

### Setting of the node numbers and the baud rate of a CANopen slave

1986

For the CANopen slave the node number and the baud rate can be set at runtime of the application program.

- ▶ For setting the **node number** `CANx_SLAVE_NODEID` (→ page 166) of the library `ifm_CRnnnn_CANopenSlave_Vxxyzz.lib` is used.
- ▶ For setting the **baud rate** `CAN1_BAUDRATE` (→ page 79) or `CAN1_EXT` (→ page 90) or `CANx` of the corresponding device library is used for the controllers and the PDM360smart. For PDM360 or PDM360compact `CANx_SLAVE_BAUDRATE` is available via the library `ifm_CRnnnn_CANopenSlave_Vxxyzz.lib`.

### Access to the OD entries by the application program

1987

As standard, there are entries in the object directory which are mapped to variables (parameter manager).

However, there are also automatically generated entries of the CANopen slave which cannot be mapped to the contents of a variable via the parameter manager. Via `CANx_SLAVE_STATUS` (→ page 172) these entries are available in the library `ifm_CRnnnn_CANopenSlave_Vxxyzz.LIB`.

### Change the PDO properties at runtime

1988

If the properties of a PDO are to be changed at runtime, this is done by another node via SDO write access as described by CANopen.

As an alternative, it is possible to directly write a new property, e.g. the "event time" of a send PDO and then transmit a command "StartNode-NMT" to the node although it has already been started. As a result of this the device reinterprets the values in the object directory.

### Transmit emergency messages via the application program

1989

To transmit an emergency message via the application program `CANx_SLAVE_EMCY_HANDLER` (→ page 167) and `CANx_SLAVE_SEND_EMERGENCY` (→ page 169) can be used. The library `ifm_CRnnnn_CANopenSlave_Vxxyzz.LIB` provides these functions.

## CANopen network variables

### Contents

General information.....	149
Configuration of CANopen network variables .....	149
Particularities for network variables .....	154

1868

### General information

2076

#### Network variables

Network variables are one option to exchange data between two or several controllers. For users the mechanism should be easy to use. At present network variables are implemented on the basis of CAN and UDP. The variable values are automatically exchanged on the basis of broadcast messages. In UDP they are implemented as broadcast messages, in CAN as PDOs. These services are not confirmed by the protocol, i.e. it is not checked whether the receiver receives the message. Exchange of network variables corresponds to a "1 to n connection" (1 transmitter to n receivers).

#### Object directory

The object directory is another option to exchange variables. This is a 1 to 1 connection using a confirmed protocol. The user can check whether the message arrived at the receiver. The exchange is not carried out automatically but via the call of FBs from the application program.

→ chapter **The object directory of the CANopen master** (→ page [139](#))

## Configuration of CANopen network variables

### Contents

Settings in the target settings.....	150
Settings in the global variable lists .....	151

1869


To use the network variables with CoDeSys you need the following libraries:

- 3s\_CanDrv.lib
- 3S\_CANopenManager.lib
- 3S\_CANopenNetVar.lib
- SysLibCallback.lib.

CoDeSys automatically generates the required initialisation code and the call of the network blocks at the start and end of the cycle.

### Settings in the target settings

1994




Example: target settings for ClassicController CR0020

- Select the dialogue box [Target settings].
- Select the tab [Network functionality].
- Activate the check box [Support network variables].
- Enter the name of the requested network, here CAN, in [Names of supported network interfaces].
- To use network variables you must also add a CANopen master or CANopen slave (device) to the controller configuration.
- Please note the particularities when using network variables for the corresponding device types.  
→ Chapter **Particularities for network variables** (→ page [154](#))

## Settings in the global variable lists


1995

- Create a new global variable list. In this list the variables to be exchanged with other controllers are defined.
- Open the dialogue with the menu point [Object Properties].
- > The window [Properties] appears:



If you want to define the network properties:

- Click the button [Add network].  
If you have configured several network connections, you can also configure here several connections per variable list.
- > The window [Properties] extends as follows:



Meaning of the options:

### Global variable list: Network type

10055

As network type you can enter one of the network names indicated in the target settings. If you click on the button [Settings] next to it, you can select the CAN interface:

1. CAN interface: value = 0
2. CAN interface: value = 1
- etc.

### Global variable list: Pack variables

10056

If this option is activated with [v], the variables are combined, if possible, in one transmission unit. For CAN the size of a transmission unit is 8 bytes.

If it is not possible to include all variables of the list in one transmission unit, several transmission units are formed for this list.

If the option is not activated, every variable has its own transmission unit.

If [Transmit on change] is configured, it is checked separately for every transmission unit whether it has been changed and must be transmitted.

### Global variable list: List identifier (COB-ID)

10057

The basic identifier is used as a unique identification to exchange variable lists of different projects. Variable lists with identical basic identifier are exchanged. Ensure that the definitions of the variable lists with the same basic identifier match in the different projects.

## **NOTE**

In CAN networks the basic identifier is directly used as COB-ID of the CAN messages. It is not checked whether the identifier is also used in the remaining CAN configuration.

To ensure a correct exchange of data between two controllers the global variable lists in the two projects must match. To ensure this you can use the feature [Link to file]. A project can export the variable list file before compilation, the other projects should import this file before compilation.

In addition to simple data types a variable list can also contain structures and arrays. The elements of these combined data types are transmitted separately.

Strings must not be transmitted via network variables as otherwise a runtime error will occur and the watchdog will be activated.

If a variable list is larger than a PDO of the corresponding network, the data is split up to several PDOs. Therefore it cannot be ensured that all data of the variable list is received in **one** cycle. Parts of the variable list can be received in different cycles. This is also possible for variables with structure and array types.



#### Global variable list: Transmit checksum

10058

This option is not supported.

#### Global variable list: Acknowledgement

10059

This option is not supported.

#### Global variable list: Read

10060

The variable values of one (or several) controllers are read.

#### Global variable list: Write

10061

The variables of this list are transmitted to other controllers.

### **NOTE**

You should only select one of these options for every variable list, i.e. either only read or only write.

If you want to read or write several variables of a project, please use several variable lists (one for reading, one for writing).

To get the same data structure for the communication between two participants you should copy the variable list from one controller to the other.

In a network the same variable list should only be exchanged between two participants.

#### Global variable list: Cyclic transmission

10062

Only valid if [write] is activated. The values are transmitted in the specified [interval] irrespective of whether they have changed.

#### Global variable list: Transmit on change

10063

The variable values are only transmitted if one of the values has been changed. With [Minimum gap] (value > 0) a minimum time between the message packages can be defined.




#### Global variable list: Transmit on event

10064

If this option is selected, the CAN message is only transmitted if the indicated binary [variable] is set to TRUE. This variable cannot be selected from the list of the defined variables via the input help.

## Particularities for network variables

1992

Device	Description
<p>ClassicController: CR0020, CR0505</p> <p>ExtendedController: CR0200</p> <p>SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506</p>	<p>Network variables are only supported on interface 1 (enter the value 0).</p> <p><b>CANopen master</b> Transmit and receive lists are processed directly. You only have to make the settings described above.</p> <p><b>CANopen slave</b> Transmit lists are processed directly. For receive lists you must also map the identifier area in the object directory to receive PDOs. It is sufficient to create only two receive PDOs and to assign the first object the first identifier and the second object the last identifier. If the network variables are only transferred to one identifier, you only have to create one receive PDO with this identifier.</p> <p> Please note that the identifier of the network variables and of the receive PDOs must be entered as <b>decimal</b> value.</p>
<p>ClassicController: CR0032, CR0033</p> <p>ExtendedController: CR0232, CR0233</p>	<p>Network variables are supported on all CAN interfaces. (All other informations as above)</p>
BasicController: CR040n	<p>Network variables are supported on all CAN interfaces. (All other informations as above)</p>
BasicDisplay: CR0451	<p>Only one CAN interface is available (enter value = 0). (All other informations as above)</p>
PDM360smart: CR1070, CR1071	<p>Only one CAN interface is available (enter value = 0).</p> <p><b>CANopen master</b> Transmit and receive lists are processed directly. You only have to make the settings described above.</p> <p><b>CANopen slave</b> Transmit lists are processed directly. For receive lists you must additionally map the identifier area in the object directory to receive PDOs. It is sufficient to create only two receive PDOs and to assign the first object the first identifier and the second object the last identifier. If the network variables are only transferred to one identifier, you only have to create one receive PDO with this identifier.</p> <p> Please note that the identifier of the network variables and of the receive PDOs must be entered as <b>decimal</b> value.</p>
<p>PDM360: CR1050, CR1051</p> <p>PDM360compact: CR1052, CR1053, CR1055, CR1056</p>	<p>Network variables are supported on the CAN interfaces 1 (value = 0) and 2 (value = 1).</p> <p><b>CANopen master</b> Transmit and receive lists are processed directly. You only have to make the settings described above.</p> <p><b>CANopen slave</b> Transmit and receive lists are processed directly. You only have to make the settings described above.</p> <p> If [support network variables] is selected in the PDM360 or PDM360compact, you must at least create one variable in the global variables list and call it once in the application program. Otherwise the following error message is generated when compiling the program:</p> <p>Error 4601: Network variables 'CAN': No cyclic or freewheeling task for network variable exchange found.</p>
PDM360NG: CR108n	<p>Network variables are supported on all CAN interfaces. (All other informations as above)</p>

## 6.6.2 Libraries for CANopen

### Contents

ifm library for the CANopen master.....	155
ifm library for the CANopen slave .....	165
Further ifm libraries for CANopen .....	175

8587

### ifm library for the CANopen master

#### Contents

CANx_MASTER_EMCY_HANDLER .....	155
CANx_MASTER_SEND_EMERGENCY .....	157
CANx_MASTER_STATUS .....	160

1870

The library `ifm_CRnnnn_CANopenMaster_Vxyxyz.LIB` provides a number of FBs for the CANopen master which will be explained below.

## CANx\_MASTER\_EMCY\_HANDLER

2006

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## CAN1\_MASTER\_EMCY\_HANDLER

9411

Contained in the library: ifm\_CRnnnn\_CANopenMaster\_Vxxyyzz.LIB

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360: CR1050, CR1051
- PDM360compact: CR1052, CR1053, CR1055, CR1056
- PDM360smart: CR1070, CR1071

## Description

2009

CANx\_MASTER\_EMCY\_HANDLER monitors the device-specific error status of the master. The FB must be called in the following cases:

- the error status is to be transmitted to the network and
- the error messages of the application are to be stored in the object directory.

**!** If application-specific error messages are to be stored in the object directory, CANx\_MASTER\_EMCY\_HANDLER must be called **after** (repeatedly) calling **CANx\_MASTER\_SEND\_EMERGENCY** (→ page [157](#)).

## Parameters of the inputs

2010

Parameter	Data type	Description
CLEAR_ERROR_FIELD	BOOL	TRUE: deletes the contents of the array ERROR_FIELD FALSE: this function is not executed

## Parameters of the outputs

2011

Parameter	Data type	Description
ERROR_REGISTER	BYTE	shows the content of the object directory index 1001 <sub>16</sub> (Error Register)
ERROR_FIELD	ARRAY [0...5] OF WORD	the array [0...5] shows the contents of the object directory index 1003 <sub>16</sub> (Error Field) - ERROR_FIELD[0]: number of stored errors - ERROR_FIELD[1...5]: stored errors, the most recent error is in index [1]


## CANx\_MASTER\_SEND\_EMERGENCY

2012

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## CAN1\_MASTER\_SEND\_EMERGENCY

9430

Contained in the library: ifm\_CRnnnn\_CANopenMaster\_Vxxyyzz.LIB

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360: CR1050, CR1051
- PDM360compact: CR1052, CR1053, CR1055, CR1056
- PDM360smart: CR1070, CR1071

## Description

2015

CANx\_MASTER\_SEND\_EMERGENCY transmits application-specific error states. The FB is called if the error status is to be transmitted to other devices in the network.

**I** If application-specific error messages are to be stored in the object directory, **CANx\_MASTER\_EMcy\_HANDLER** (→ page [155](#)) must be called **after** (repeatedly) calling CANx\_MASTER\_SEND\_EMERGENCY.


## Parameters of the inputs

2016

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
ERROR	BOOL	FALSE → TRUE (edge): transmits the given error code  TRUE → FALSE (edge) AND the fault is no longer indicated: the message that there is no error is sent after a delay of approx. 1 s  else: this function is not executed
ERROR_CODE	WORD	The error code provides detailed information about the detected fault. The values should be entered according to the CANopen specification. → chapter <b>Overview CANopen error codes</b> (→ page <a href="#">186</a> )
ERROR_REGISTER	BYTE	This object reflects the general error state of the CANopen network participant. The values should be entered according to the CANopen specification.
MANUFACTURER_ERROR_FIELD	ARRAY [0...4] OF BYTE	Here, up to 5 bytes of application-specific error information can be entered. The format can be freely selected.

## Example: CANx\_MASTER\_SEND\_EMERGENCY

2018



In this example 3 error messages will be generated subsequently:

1. ApplError1, Code = FF00<sub>16</sub> in the error register 81<sub>16</sub>
2. ApplError2, Code = FF01<sub>16</sub> in the error register 81<sub>16</sub>
3. ApplError3, Code = FF02<sub>16</sub> in the error register 81<sub>16</sub>

CAN1\_MASTER\_EMCY\_HANDLER sends the error messages to the error register "Object 1001" in the error array "Object 1003".




## CANx\_MASTER\_STATUS

9933

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## CAN1\_MASTER\_STATUS

9435

Contained in the library:	Available for the following devices:
ifm_CRnnnn_CANopenMaster_Vxxyzz.LIB	- PDM360: CR1050, CR1051
ifm_CRnnnn_CANopenMaster_Vxxyzz.LIB	- PDM360compact: CR1052, CR1053, CR1055, CR1056 - PDM360smart: CR1070, CR1071

## Description

2024





Status indication of the device used with CANopen.

CANx\_MASTER\_STATUS shows the status of the device used as CANopen master. Furthermore, the status of the network and of the connected slaves can be monitored.

The FB simplifies the use of the CoDeSys CANopen master libraries. We urgently recommend to carry out the evaluation of the network status and of the error messages via this FB.


## Parameters of the inputs

2695

Parameter	Data type	Description
GLOBAL_START	BOOL	<p>TRUE: all connected network participants (slaves) are started simultaneously during network initialisation</p> <p>FALSE: the connected network participants are started one after the other</p> <p> → chapter <b>Starting the network with GLOBAL_START</b> (→ page <a href="#">137</a>)</p>
CLEAR_RX_OVERFLOW_FLAG	BOOL	<p>FALSE → TRUE (edge): delete error flag "receive buffer overflow"</p> <p>FALSE: this function is not executed</p>
CLEAR_RX_BUFFER	BOOL	<p>FALSE → TRUE (edge): delete data in the receive buffer</p> <p>FALSE: this function is not executed</p>
CLEAR_TX_OVERFLOW_FLAG	BOOL	<p>FALSE → TRUE (edge): delete error flag "transmit buffer overflow"</p> <p>FALSE: this function is not executed</p>
CLEAR_TX_BUFFER	BOOL	<p>FALSE → TRUE (edge): delete data in the transmit buffer</p> <p>FALSE: this function is not executed</p>
CLEAR_OD_CHANGED_FLAG	BOOL	<p>FALSE → TRUE (edge): delete flag "data in the object directory changed"</p> <p>FALSE: this function is not executed</p>
CLEAR_ERROR_CONTROL	BOOL	<p>FALSE → TRUE (edge): delete the guard error list (ERROR_CONTROL)</p> <p>FALSE: this function is not executed</p>
RESET_ALL_NODES	BOOL	<p>FALSE → TRUE (edge): reset all nodes</p> <p>FALSE: this function is not executed</p>
START_ALL_NODES	BOOL	<p>TRUE: all connected network participants (slaves) are started simultaneously at runtime of the application program</p> <p>FALSE: the connected network participants must be started one after the other</p> <p> → chapter <b>Starting the network with START_ALL_NODES</b> (→ page <a href="#">137</a>)</p>
NODE_STATE_SLAVES	DWORD	<p>shows the status of all network nodes</p> <p>example code → chapter <b>Example: CANx_MASTER_STATUS</b> (→ page <a href="#">163</a>)</p> <p> → chapter <b>Master at runtime</b> (→ page <a href="#">129</a>)</p>
EMERGENCY_OBJECT_SLAVES	DWORD	<p>shows the most recent occurred error messages of all network nodes</p> <p> → chapter <b>Access to the structures at runtime of the application</b> (→ page <a href="#">165</a>)</p>

## Parameters of the outputs

9935

Parameter	Data type	Description
NODE_ID	BYTE	node ID of the master
BAUD RATE	WORD	baud rate of the master
NODE_STATE	INT	current status of the master
SYNC	BOOL	SYNC signal of the master This is set in the <b>CANopen master: Tab [CAN parameters]</b> (→ page 123) of the master depending on the set time.
RX_OVERFLOW	BOOL	error flag "receive buffer overflow"
TX_OVERFLOW	BOOL	error flag "transmit buffer overflow"
OD_CHANGED	BOOL	flag "object directory master was changed"
ERROR_CONTROL	ARRAY [0...7] OF BYTE	The array contains a list (max. 8) of the missing network nodes (guard or heartbeat error).  → chapter <b>Access to the structures at runtime of the application</b> (→ page 165)
GET_EMERGENCY	STRUCT EMERGENCY_MESSAGE	at the output the data for the structure EMERGENCY_MESSAGE are available  the most recent error message of a network node is always displayed  To obtain a list of all occurred errors, the array "EMERGENCY_OBJECT_SLAVES" must be evaluated.

## Parameters of internal structures

2698

Below are the structures of the arrays used in this FB.

Name	Data type	Description
CANx_EMERGENCY_MESSAGE	STRUCT	NODE_ID BYTE ERROR_CODE: WORD ERROR_REGISTER: BYTE MANUFACTURER_ERROR_FIELD: ARRAY[0...4] OF BYTE  The structure is defined by the global variables of the library <code>ifm_CRnnnn_CANopenMaster_Vxxyzz.LIB</code> .
CANx_NODE_STATE	STRUCT	NODE_ID BYTE NODE_STATE: BYTE LAST_STATE: BYTE RESET_NODE: BOOL START_NODE: BOOL PREOP_NODE: BOOL SET_TIMEOUT_STATE: BOOL SET_NODE_STATE: BOOL  The structure is defined by the global variables of the library <code>ifm_CRnnnn_CANopenMaster_Vxxyzz.LIB</code> .

Detailed description of the functionalities of the CANopen master and the mechanisms → chapter **CANopen master** (→ page 119).

Using the controller CR0020 as an example the following code fragments show the use of **CANx\_MASTER\_STATUS** (→ page 160).

## Example: CANx\_MASTER\_STATUS

2031

### Slave information

2699

To be able to access the information of the individual CANopen nodes, an array for the corresponding structure must be generated. The structures are contained in the library. You can see them under [Data types] in the library manager.

The number of the array elements is determined by the global variable MAX\_NODEINDEX which is automatically generated by the CANopen stack. It contains the number of the slaves minus 1 indicated in the network configurator.

**i** The numbers of the array elements do **not** correspond to the node ID. The identifier can be read from the corresponding structure under NODE\_ID.

```
PROGRAM MasterStatus
VAR
    Status: CR0032_MASTER_STATUS;
    StartAllNodes: BOOL = TRUE;
    ClearRxOverflowFlag: BOOL;
    ClearRxBuffer: BOOL;
    ClearTxOverflowFlag: BOOL;
    ClearTxBuffer: BOOL;
    ClearOdChanged: BOOL;
    ClearErrorControl: BOOL;
    ResetAllNodes: BOOL;
    ResetSingleNodeArray: ARRAY[0..MAX_NODEINDEX] OF RESET_NODE;
    NodeStateSlavesArray: ARRAY[0..MAX_NODEINDEX] OF NODE_STATE;
    EmergencyObjectSlavesArray: ARRAY[0..MAX_NODEINDEX] OF EMERGENCY_MESSAGE;
    node_id: BYTE;
    baudrate: WORD;
    node_state: INT;
    Sync: BOOL;
    RxOverflow: BOOL;
    TxOverflow: BOOL;
    OdChanged: BOOL;
    GuardHeartbeatErrorArray: ARRAY[0..7] OF BYTE;
    GetEmergency: EMERGENCY_MESSAGE;
END_VAR
```

### Structure node status

2034

```
TYPE CAN1_NODE_STATE :
STRUCT
    NODE_ID: BYTE;
    NODE_STATE: BYTE;
    LAST_STATE: BYTE;
    RESET_NODE: BOOL;
    START_NODE: BOOL;
    PREOP_NODE: BOOL;
    SET_TIMEOUT_STATE: BOOL;
    SET_NODE_STATE: BOOL;
END_STRUCT
END_TYPE
```

## Structure Emergency\_Message

2035

```


TYPE CAN1_EMERGENCY_MESSAGE :
STRUCT
  NODE_ID: BYTE;
  ERROR_CODE: WORD;
  ERROR_REGISTER: BYTE;
  MANUFACTURER_ERROR_FIELD: ARRAY[0..4] OF BYTE;
END_STRUCT
END_TYPE

```

## Access to the structures at runtime of the application

2036

At runtime you can access the corresponding array element via the global variables of the library and therefore read the status or EMCY messages or reset the node.



If `ResetSingleNodeArray[0].RESET_NODE` is set to `TRUE` for a short time in the example given above, the first node is reset in the configuration tree.

 concerning the possible error codes → chapter [CAN errors and error handling](#) (→ page [180](#)).

## ifm library for the CANopen slave

### Contents

CANx_SLAVE_NODEID .....	166
CANx_SLAVE_EMCY_HANDLER.....	167
CANx_SLAVE_SEND_EMERGENCY .....	169
CANx_SLAVE_STATUS .....	172

1874

The library `ifm_CRnnnn_CANopenSlave_Vxxyzz.LIB` provides a number of FBs for the CANopen slave which will be explained below.

## CANx\_SLAVE\_NODEID

2044

= CANx Slave Node-ID

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## CAN1\_SLAVE\_NODEID

9499

Contained in the library: ifm\_CRnnnn\_CANopenSlave\_Vxxyyzz.LIB

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360: CR1050, CR1051
- PDM360compact: CR1052, CR1053, CR1055, CR1056
- PDM360smart: CR1070, CR1071

## Description

2049

CANx\_SLAVE\_NODEID enables the setting of the node ID of a CANopen slave at runtime of the application program.

Normally, the FB is called once during initialisation of the controller, in the first cycle. Afterwards, the input ENABLE is set to FALSE again.

## Parameters of the inputs

2047

Parameter	Data type	Description
ENABLE	BOOL	FALSE → TRUE (edge): set node ID  FALSE: unit is not executed
NODEID	BYTE	value of the new node number

## CANx\_SLAVE\_EMCY\_HANDLER

2050

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## CAN1\_SLAVE\_EMCY\_HANDLER

9493

Contained in the library: ifm\_CRnnnn\_CANopenSlave\_Vxxyyzz.LIB

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360: CR1050, CR1051
- PDM360compact: CR1052, CR1053, CR1055, CR1056
- PDM360smart: CR1070, CR1071

## Description

2053

CANx\_SLAVE\_EMCY\_HANDLER monitors the device-specific error status (device operated as slave).

The FB must be called in the following cases:

- the error status is to be transmitted to the CAN network and
- the error messages of the application are to be stored in the object directory.

**!** If application-specific error messages are to be stored in the object directory, CANx\_SLAVE\_EMCY\_HANDLER must be called **after** (repeatedly) calling **CANx\_SLAVE\_SEND\_EMERGENCY** (→ page [169](#)).



## Parameters of the inputs

2054

Parameter	Data type	Description
CLEAR_ERROR_FIELD	BOOL	FALSE → TRUE (edge): delete ERROR FIELD  FALSE: unit is not executed

## Parameters of the outputs

2055

Parameter	Data type	Description
ERROR_REGISTER	BYTE	shows the contents of the object directory index 1001 <sub>16</sub> (Error Register).
ERROR_FIELD	ARRAY [0...5] OF WORD	the array [0...5] shows the contents of the object directory index 1003 <sub>16</sub> (Error Field):  - ERROR_FIELD[0]: Number of stored errors  - ERROR_FIELD[1...5]: stored errors, the most recent error is in index [1]


## CANx\_SLAVE\_SEND\_EMERGENCY

2056

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## CAN1\_SLAVE\_SEND\_EMERGENCY

9505

Contained in the library: ifm\_CRnnnn\_CANopenSlave\_Vxxyyzz.LIB

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360: CR1050, CR1051
- PDM360compact: CR1052, CR1053, CR1055, CR1056
- PDM360smart: CR1070, CR1071

## Description

2059

Using CANx\_SLAVE\_SEND\_EMERGENCY application-specific error states are transmitted. These are error messages which are to be sent in addition to the device-internal error messages (e.g. short circuit on the output).

The FB is called if the error status is to be transmitted to other devices in the network.

**I** If application-specific error messages are to be stored in the object directory, **CANx\_SLAVE\_EMCY\_HANDLER** (→ page [167](#)) must be called **after** (repeatedly) calling CANx\_SLAVE\_SEND\_EMERGENCY.


## Parameters of the inputs

2060

Parameter	Data type	Description
ENABLE	BOOL	<p>TRUE: unit is executed</p> <p>FALSE: unit is not executed &gt; POU inputs and outputs are not active</p>
ERROR	BOOL	<p>FALSE → TRUE (edge): transmits the given error code</p> <p>TRUE → FALSE (edge) AND the fault is no longer indicated: the message that there is no error is sent after a delay of approx. 1 s</p> <p>else: this function is not executed</p>
ERROR_CODE	WORD	<p>The error code provides detailed information about the detected fault. The values should be entered according to the CANopen specification. → chapter <b>Overview CANopen error codes</b> (→ page <a href="#">186</a>)</p>
ERROR_REGISTER	BYTE	<p>This object reflects the general error state of the CANopen network participant. The values should be entered according to the CANopen specification.</p>
MANUFACTURER_ERROR_FIELD	ARRAY [0...4] OF BYTE	<p>Here, up to 5 bytes of application-specific error information can be entered. The format can be freely selected.</p>

## Example: CANx\_SLAVE\_SEND\_EMERGENCY

2062



In this example 3 error messages will be generated subsequently:

1. ApplError1, Code = FF00<sub>16</sub> in the error register 81<sub>16</sub>
2. ApplError2, Code = FF01<sub>16</sub> in the error register 81<sub>16</sub>
3. ApplError3, Code = FF02<sub>16</sub> in the error register 81<sub>16</sub>

CAN1\_SLAVE\_EMCY\_HANDLER sends the error messages to the error register "Object 1001<sub>16</sub>" in the error array "Object 1003<sub>16</sub>".


## CANx\_SLAVE\_STATUS

2706

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## CAN1\_SLAVE\_STATUS


9510

Contained in the library:	Available for the following devices:
ifm_CRnnnnn_CANOpenSlave_Vxxyyzz.LIB	- ClassicController: CR0032, CR0033 - ExtendedController: CR0232, CR0233
ifm_CRnnnnn_CANOpenSlave_Vxxyyzz.LIB	- PDM360: CR1050, CR1051
ifm_CRnnnnn_CANOpenSlave_Vxxyyzz.LIB	- PDM360compact: CR1052, CR1053, CR1055, CR1056 - PDM360smart: CR1070, CR1071

## Description

2707

CANx\_SLAVE\_STATUS shows the status of the device used as CANopen slave. The FB simplifies the use of the CoDeSys CANopen slave libraries. We urgently recommend to carry out the evaluation of the network status via this FB.

 For a detailed description of the FBs of the CANopen slave and the mechanisms:  
→ chapter **CANopen slave** (→ page [140](#)).

At runtime you can then access the individual outputs of the block to obtain a status overview.

## Example:

**PROGRAM** SlaveStatus

**VAR**

```
Status: CR0032_SLAVE_STATUS;
ClearRxOverflowFlag: BOOL;
ClearRxBuffer: BOOL;
ClearTxOverflowFlag: BOOL;
ClearTxBuffer: BOOL;
ClearResetFlag: BOOL;
ClearOdChangedFlag: BOOL;
node_id: BYTE;
baudrate: WORD;
node_state: BYTE;
Sync: BOOL;
SyncError: BOOL;
GuardHeartbeatError: BOOL;
RxOverflow: BOOL;
TxOverflow: BOOL;
ResetNode: BOOL;
ResetCom: BOOL;
OdChanged: BOOL;
OdChangedIndex: INT;
```

**END\_VAR**

## Parameters of the inputs

2708

Parameter	Data type	Description
CLEAR_RX_OVERFLOW_FLAG	BOOL	FALSE → TRUE (edge): delete error flag "receive buffer overflow"  FALSE: this function is not executed
CLEAR_RX_BUFFER	BOOL	FALSE → TRUE (edge): delete data in the receive buffer  FALSE: this function is not executed
CLEAR_TX_OVERFLOW_FLAG	BOOL	FALSE → TRUE (edge): delete error flag "transmit buffer overflow"  FALSE: this function is not executed
CLEAR_TX_BUFFER	BOOL	FALSE → TRUE (edge): delete data in the transmit buffer  FALSE: this function is not executed
CLEAR_RESET_FLAG	BOOL	FALSE → TRUE (edge): delete the flags "nodes reset" and "communications interface reset"  FALSE: this function is not executed
CLEAR_OD_CHANGED_FLAG	BOOL	FALSE → TRUE (edge): delete the flags "data in the object directory changed" and "index position"  FALSE: this function is not executed

## Parameters of the outputs

2068

Parameter	Data type	Description
NODE_ID	BYTE	ode ID of the slave
BAUDRATE	WORD	baud rate of the slave
NODE_STATE	BYTE	current status of the slave
SYNC	BOOL	received SYNC signal of the master
SYNC_ERROR	BOOL	no SYNC signal of the master received OR: the set SYNC time (ComCyclePeriod in the master) was exceeded
GUARD_HEARTBEAT_ERROR	BOOL	no guard or heartbeat signal of the master received OR: the set times were exceeded
RX_OVERFLOW	BOOL	error flag "receive buffer overflow"
TX_OVERFLOW	BOOL	error flag "transmit buffer overflow"
RESET_NODE	BOOL	the CAN stack of the slave was reset by the master  This flag can be evaluated by the application and, if necessary, be used for further reactions.
RESET_COM	BOOL	the communication interface of the CAN stack was reset by the master  This flag can be evaluated by the application and, if necessary, be used for further reactions.
OD_CHANGED	BOOL	flag "object directory master was changed"
OD_CHANGED_INDEX	INT	the output shows the changed index of the object directory

## Further ifm libraries for CANopen

### Contents

CANx_SDO_READ .....	176
CANx_SDO_WRITE.....	178

2071

Here we present further **ifm** FBs which are sensible additions for CANopen.



## CANx\_SDO\_READ

621

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## CAN1\_SDO\_READ

9442

Contained in the library: `ifm_CRnnnn_Vxyyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR2500
- PDM360smart: CR1070, CR1071

## Description


624

CANx\_SDO\_READ reads the **Tab [Service Data Objects]** (→ page [129](#)) with the indicated indexes from the node.

By means of these, the entries in the object directory can be read. So it is possible to selectively read the node parameters.

<ul style="list-style-type: none"> <li>- all <i>ecomatmobile</i> controllers</li> <li>- PCB controller: CS0015</li> <li>- PDM360smart: CR1070, CR1071</li> </ul>	<ul style="list-style-type: none"> <li>- PDM360: CR1050, CR1051</li> <li>- PDM360compact: CR1052, CR1053, CR1055, CR1056</li> </ul>
From the device library <code>ifm_CRnnnn_Vxyyyzz.LIB</code>	From the device library <code>ifm_CANx_SDO_Vxyyyzz.LIB</code>
Prerequisite: Node must be in the mode "PRE-OPERATIONAL" or "OPERATIONAL".	Prerequisite: The node must be in the mode "CANopen master" or "CANopen slave".

## Example:



## Parameters of the inputs

625

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
NODE	BYTE	number of the node
IDX	WORD	index in object directory
SUBIDX	BYTE	sub-index referred to the index in the object directory
DATA	DWORD	address of the receive data array permissible length = 0...255 transmission with ADR operator

## Parameters of the outputs

626

Parameter	Data type	Description
RESULT	BYTE	0 = unit inactive 1 = execution of the unit completed 2 = unit active 3 = error: unit has not been executed
LEN	WORD	length of the entry in "number of bytes"  The value for LEN must correspond to the length of the receive array. Otherwise, problems with SDO communication will occur.

## CANx\_SDO\_WRITE

615

Unit type = function block (FB)

x = number 1...n of the CAN interface (depending on the device, → data sheet)

Symbol in CoDeSys:



## CAN1\_SDO\_WRITE

9451

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR2500
- PDM360smart: CR1070, CR1071

## Description

618


CANx\_SDO\_WRITE writes the **Tab [Service Data Objects]** (→ page [129](#)) with the specified indexes to the node.

Using this FB, the entries can be written to the object directory. So it is possible to selectively set the node parameters.

<ul style="list-style-type: none"> <li>- all <i>ecomatmobile</i> controllers</li> <li>- PCB controller: CS0015</li> <li>- PDM360smart: CR1070, CR1071</li> </ul>	<ul style="list-style-type: none"> <li>- PDM360: CR1050, CR1051</li> <li>- PDM360compact: CR1052, CR1053, CR1055, CR1056</li> </ul>
From the device library <code>ifm_CRnnnn_Vxxyyzz.LIB</code>	From the device library <code>ifm_CANx_SDO_Vxxyyzz.LIB</code>
Prerequisite: the node must be in the state "PRE-OPERATIONAL" or "OPERATIONAL" and in the mode "CANopen master".	Prerequisite: The node must be in the mode "CANopen master" or "CANopen slave".

**!** The value for LEN must correspond to the length of the transmit array. Otherwise, problems with SDO communication will occur.

### Example:



### Parameters of the inputs

619

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
NODE	BYTE	number of the node
IDX	WORD	index in object directory
SUBIDX	BYTE	sub-index referred to the index in the object directory.
LEN	WORD	length of the entry in "number of bytes"  The value for LEN must correspond to the length of the transmit array. Otherwise, problems with SDO communication will occur.
DATA	DWORD	address of the transmit data array permissible length = 0...255 transmission with ADR operator

### Parameters of the outputs

620

Parameter	Data type	Description
RESULT	BYTE	0 = unit inactive 1 = execution of the unit stopped 2 = unit active 3 = error: unit has not been executed

## 6.7 CAN errors and error handling

### Contents

CAN errors .....	181
Structure of an EMCY message.....	183
Overview CANopen error codes .....	186

1171

The error mechanisms described are automatically processed by the CAN controller integrated in the controller. This cannot be influenced by the user. (Depending on the application) the user should react to signalled errors in the application software.

Goal of the CAN error mechanisms:

- Ensuring uniform data objects in the complete CAN network
- Permanent functionality of the network even in case of a faulty CAN participant
- Differentiation between temporary and permanent disturbance of a CAN participant
- Localisation and self-deactivation of a faulty participant in 2 steps:
  - error passive
  - disconnection from the bus (bus off)
This gives a temporarily disturbed participant a "rest".

To give the interested user an overview of the behaviour of the CAN controller in case of an error, error handling is easily described below. After error detection the information is automatically prepared and made available to the programmer as CAN error bits in the application software.

### 6.7.1 CAN errors

#### Contents

Error message.....	181
Error counter .....	182
Participant, error active .....	182
Participant, error passive .....	182
Participant, bus off.....	183

8589

### Error message

1172

If a bus participant detects an error condition, it immediately transmits an error flag. The transmission is then aborted or the correct messages already received by other participants are rejected. This ensures that correct and uniform data is available to all participants. Since the error flag is directly transmitted the sender can immediately start to repeat the disturbed message as opposed to other fieldbus systems (they wait until a defined acknowledgement time has elapsed). This is one of the most important features of CAN.

One of the basic problems of serial data transmission is that a permanently disturbed or faulty bus participant can block the complete system. Error handling for CAN would increase such a risk. To exclude this, a mechanism is required which detects the fault of a participant and disconnects this participant from the bus, if necessary.

## Error counter

1173

A transmit and receive error counter are integrated in the CAN controller. They are counted up (incremented) for every faulty transmit or receive operation. If a transmission was correct, these counters are counted down (decremented).

However, the error counters are more incremented in case of an error than decremented in case of success. Over a defined period this can lead to a considerable increase of the counts even if the number of the undisturbed messages is greater than the number of the disturbed messages. Longer undisturbed periods slowly reduce the counts. So the counts indicate the relative frequency of disturbed messages.

If the participant itself is the first to detect errors (= self-inflicted errors), the error is more severely "punished" for this participant than for other bus participants. To do so, the counter is incremented by a higher amount.

If the count of a participant exceeds a defined value, it can be assumed that this participant is faulty. To prevent this participant from disturbing bus communication by active error messages (error active), it is switched to "error passive".




Figure: mechanism of the error counter

## Participant, error active

1174

An error active participant participates in the bus communication without restriction and is allowed to signal detected errors by transmitting the active error flag. As already described the transmitted message is destroyed.

## Participant, error passive

1175

An error passive participant can also communicate without restriction. However, it is only allowed to identify a detected error by a passive error flag, which does not interfere with the bus communication. An error passive participant becomes error active again if it is below a defined count value.

To inform the user about incrementing of the error counter, the system variable CANx\_WARNING is set if the value of the error counter is > 96. In this state the participant is still error active.

## Participant, bus off

1176

If the error count value continues to be incremented, the participant is disconnected from the bus (bus off) after exceeding a maximum count value.

To indicate this state the flag CANx\_BUSOFF is set in the application program.

**I** The error CANx\_BUSOFF is automatically handled and reset by the operating system. If the error is to be handled or evaluated more precisely via the application program, **CANx\_ERRORHANDLER** (→ page [82](#)) must be used. The error CANx\_BUSOFF must then be reset explicitly by the application program.

## 6.7.2 Structure of an EMCY message

### Contents

A distinction is made between the following errors: .....	184
Structure of an error message .....	184
Identifier .....	185
EMCY error code.....	185
Object 0x1003 (error field) .....	185
Signalling of device errors .....	185

8591

Under CANopen error states are indicated via a simple standardised mechanism. For a CANopen device every occurrence of an error is indicated via a special message which details the error.

If an error or its cause disappears after a certain time, this event is also indicated via the EMCY message. The errors occurred last are stored in the object directory (object 1003<sub>16</sub>) and can be read via an SDO access (→ **CANx\_SDO\_READ** (→ page 176)). In addition, the current error situation is reflected in the error register (object 1001<sub>16</sub>).

### A distinction is made between the following errors:

8046

#### Communication error

- The CAN controller signals CAN errors.  
(The frequent occurrence is an indication of physical problems. These errors can considerably affect the transmission behaviour and thus the data rate of a network.)
- Life guarding or heartbeat error

#### Application error

- Short circuit or wire break
- Temperature too high

### Structure of an error message

8047

The structure of an error message (EMCY message) is as follows:

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
EMCY error code as entered in the object 1003 <sub>16</sub>		object 1001 <sub>16</sub>	manufacturer-specific information				



## Identifier

8048

The identifier for the error message consists of the sum of the following elements:

EMCY default identifier 128 ( $80_{16}$ )  
+  
node ID

## EMCY error code

8049

It gives detailed information which error occurred. A list of possible error codes has already been defined in the communication profile. Error codes which only apply to a certain device class are defined in the corresponding device profile of this device class.

## Object 0x1003 (error field)

8050

The object  $1003_{16}$  represents the error memory of a device. The sub-indices contain the errors occurred last which triggered an error message.

If a new error occurs, its EMCY error code is always stored in the sub-index  $1_{16}$ . All other older errors are moved back one position in the error memory, i.e. the sub-index is incremented by 1. If all supported sub-indices are used, the oldest error is deleted. The sub-index  $0_{16}$  is increased to the number of the stored errors. After all errors have been rectified the value "0" is written to the error field of the sub-index  $1_{16}$ .

To delete the error memory the value "0" can be written to the sub-index  $0_{16}$ . Other values must not be entered.

## Signalling of device errors

1880

As described, EMCY messages are transmitted if errors occur in a device. In contrast to programmable devices error messages are automatically transmitted by decentralised input/output modules (e.g. CompactModules CR2033).

Corresponding error codes → corresponding device manual.

Programmable devices only generate an EMCY message automatically (e.g. short circuit on an output) if **CANx\_MASTER\_EMCY\_HANDLER** (→ page [155](#)) or **CANx\_SLAVE\_EMCY\_HANDLER** (→ page [167](#)) is integrated in the application program.

Overview of the automatically transmitted EMCY error codes for all **ifm** devices programmable with CoDeSys → chapter **Overview CANopen error codes** (→ page [186](#)).

If in addition application-specific errors are to be transmitted by the application program, **CANx\_MASTER\_SEND\_EMERGENCY** (→ page [157](#)) or **CANx\_SLAVE\_SEND\_EMERGENCY** (→ page [169](#)) are used.

## 6.7.3 Overview CANopen error codes

8545

Error Code (hex)	Meaning
00xx	Reset or no error
10xx	Generic error
20xx	Current
21xx	Current, device input side
22xx	Current inside the device
23xx	Current, device output side
30xx	Voltage
31xx	Mains voltage
32xx	Voltage inside the device
33xx	Output voltage
40xx	Temperature
41xx	Ambient temperature
42xx	Device temperature
50xx	Device hardware
60xx	Device software
61xx	Internal software
62xx	User software
63xx	Data set
70xx	Additional modules
80xx	Monitoring
81xx	Communication
8110	CAN overrun-objects lost
8120	CAN in error passiv mode
8130	Life guard error or heartbeat error
8140	Recovered from bus off
8150	Transmit COB-ID collision
82xx	Protocol error
8210	PDO not proceeded due to length error
8220	PDO length exceeded
90xx	External error
F0xx	Additional functions
FFxx	Device specific

## Object 0x1001 (error register)

8547

This object reflects the general error state of a CANopen device. The device is to be considered as error free if the object 1001<sub>16</sub> signals no error any more.

Bit	Meaning
0	generic error
1	current
2	voltage
3	temperature
4	communication error
5	device profile specific
6	reserved – always 0
7	manufacturer specific

For an error message more than one bit in the error register can be set at the same time.

**Example:** CR2033, message "wire break" at channel 2 (→ installation manual of the device):

COB-ID	DLC	Byte 0	Byte 1	Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4
80 <sub>16</sub> + node ID		00	FF	81	10	00	00	00	00

**Error-Code** = FF00<sub>16</sub>

**Error register** = 81<sub>16</sub> = 1000 0001<sub>2</sub>, thus it consists of the following errors:

- generic error
- manufacturer specific

**Concerned channel** = 0010<sub>16</sub> = 0000 0000 0001 0000<sub>2</sub> = wire break channel 2

## Manufacturer specific information

8548

A device manufacturer can indicate additional error information. The format can be freely selected.

**Example:**

In a device two errors occur and are signalled via the bus:

- Short circuit of the outputs:  
Error code 2300<sub>16</sub>,  
the value 03<sub>16</sub> (0000 0011<sub>2</sub>) is entered in the object 1001<sub>16</sub>  
(generic error and current error)
- CAN overrun:  
Error code 8110<sub>16</sub>,  
the value 13<sub>16</sub> (0001 0011<sub>2</sub>) is entered in the object 1001<sub>16</sub>  
(generic error, current error and communication error)

>> CAN overrun processed:

Error code 0000<sub>16</sub>,  
the value 03<sub>16</sub> (0000 0011<sub>2</sub>) is entered in the object 1001<sub>16</sub>  
(generic error, current error, communication error reset)

It can be seen only from this information that the communication error is no longer present.

## Overview CANopen EMCY codes (CR107n)

2673

All indications (hex) for the 1st CAN interface

EMCY code object 1003 <sub>16</sub>		Object 1001 <sub>16</sub>	Manufacturer-specific information					
Byte 0	1	2	3	4	5	6	7	Description
00h	21h	03h	I0	I1	I2	I3	I4	Diagnosis inputs (only CR1071)
00h	31h	05h						Terminal voltage VBB0/VBBs
00h	42h	09h						Excess temperature
00h	61h	11h						Memory error
00h	80h	11h						CAN1 monitoring SYNC error (only slave)
00h	81h	11h						CAN1 warning threshold (> 96)
10h	81h	11h						CAN1 receive buffer overrun
11h	81h	11h						CAN1 transmit buffer overrun
30h	81h	11h						CAN1 guard/heartbeat error (only slave)

## 7 Input/output functions

### Contents

Processing input values .....	189
Adapting analogue values .....	191
Counter functions for frequency and period measurement.....	198
PWM functions .....	213
Controller functions .....	226

1590

In this chapter you will find FBs which allow you to read and process the signals of the inputs and outputs.

### 7.1 Processing input values

#### Contents

ANALOG_RAW .....	189
TOGGLE .....	190

1602

In this chapter we show you FBs which allow you to read and process the analogue or digital signals at the device input.

#### **NOTE**

The raw values shown in the PLC configuration of CoDeSys directly come from the ADC. They are not yet corrected!

Therefore different raw values can appear in the PLC configuration for identical devices. Error correction and normalisation are only carried out by ifm function blocks (e.g. INPUT, INPUT\_ANALOG). The function blocks provide the corrected value.

## 7.1.1 ANALOG\_RAW

9916

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- PDM360smart: CR1071

**Symbol in CoDeSys:**



### Description

9918

ANALOG\_RAW provides the raw analogue signal of the inputs, without any filtering.

### Parameters of the outputs

9919

Parameter	Data type	Description
P0	ARRAY [0...3] of WORD	Raw input values of the analogue inputs: P0.0 for %IX0.00 P0.1 for %IX0.01 P0.2 for %IX0.02 P0.3 for %IX0.03

## 7.1.2 TOGGLE

3194

Unit type = function block (FB)

Contained in the library:	Available for the following devices:
ifm_PDM_UTIL_Vxxyyzz.LIB	- PDM360: CR1050, CR1051 - PDM360compact: CR1052, CR1053, CR1055, CR1056
ifm_PDMng_UTIL_Vxxyyzz.LIB	- PDM360NG: CR108n
ifm_PDMsmart_UTIL_Vxxyyzz.LIB	- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

3304

TOGGLE enables the setting and resetting of a Boolean variable via only one input bit.

The first rising edge on the input IN sets the output OUT to 'TRUE'.

The next rising edge resets the output back to 'FALSE'.

etc.

### Parameters of the inputs

3305

Parameter	Data type	Description
IN	BOOL	edge FALSE → TRUE: setting / resetting of the output

### Parameters of the outputs

3306

Parameter	Data type	Description
OUT	BOOL	1st edge on IN ⇒ TRUE 2nd edge on IN ⇒ FALSE 3rd edge on IN ⇒ TRUE ...

## 7.2 Adapting analogue values

### Contents

NORM .....	192
NORM_DINT .....	194
NORM_REAL .....	196

1603

If the values of analogue inputs or the results of analogue functions must be adapted, the following FBs will help you.



## 7.2.1 NORM

401


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

404

NORM normalises a value within defined limits to a value with new limits.

The FB normalises a value of type WORD within the limits of XH and XL to an output value within the limits of YH and YL. This FB is for example used for generating PWM values from analogue input values.

#### **NOTE**

The value for X must be in the defined input range between XL and XH (there is no internal plausibility check of the value).

Due to rounding errors the normalised value can deviate by 1.

If the limits (XH/XL or YH/YL) are defined in an inverted manner, normalisation is also done in an inverted manner.

## Parameters of the inputs

405

Parameter	Data type	Description
X	WORD	current input value
XH	WORD	upper limit of input value range
XL	WORD	lower limit of input value range
YH	WORD	upper limit of output value range
YL	WORD	lower limit of output value range

## Parameters of the outputs

406

Parameter	Data type	Description
Y	WORD	normalised value

### Example 1

407

lower limit value input	0	XL
upper limit value input	100	XH
lower limit value output	0	YL
upper limit value output	2000	YH

then the FB converts the input signal for example as follows:

<b>from X =</b>	50	0	100	75
<b>to Y =</b>	1000	0	2000	1500

### Example 2

408

lower limit value input	2000	XL
upper limit value input	0	XH
lower limit value output	0	YL
upper limit value output	100	YH

then the FB converts the input signal for example as follows:

<b>from X =</b>	1000	0	2000	1500
<b>to Y =</b>	50	100	0	25


## 7.2.2 NORM\_DINT

3200

Unit type = function block (FB)

Contained in the library:	Available for the following devices:
ifm_PDM_UTIL_Vxxyyzz.LIB	- PDM360: CR1050, CR1051 - PDM360compact: CR1052, CR1053, CR1055, CR1056
ifm_PDMng_UTIL_Vxxyyzz.LIB	- PDM360NG: CR108n
ifm_PDMsmart_UTIL_Vxxyyzz.LIB	- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

3307

NORM\_DINT normalises a value within defined limits to a value with new limits.

The FB normalises a value of type DINT, which is within the limits of XH and XL, to an output value within the limits of YH and YL. This FB is for example used to generate PWM values from analogue input values.

#### **NOTE**

The value for X must be in the defined input range between XL and XH (there is no internal plausibility check of the value). Outside this value range the output X\_OUT\_OF\_RANGE is set.

Due to rounding errors the normalised value can deviate by 1.

If the limits (XH/XL or YH/YL) are indicated in an inverted manner, normalisation is also done in an inverted manner.

## Parameters of the inputs

3308

Parameter	Data type	Description
X	DINT	current input value
XH	DINT	upper limit of input value range
XL	DINT	lower limit of input value range
YH	DINT	upper limit of output value range
YL	DINT	lower limit of output value range

## Parameters of the outputs

3309

Parameter	Data type	Description
Y	DINT	normalised value
X_OUT_OF_RANGE	BOOL	input value X is outside the defined value range XL/XH


## 7.2.3 NORM\_REAL

3202

Unit type = function block (FB)

Contained in the library:	Available for the following devices:
ifm_PDM_UTIL_Vxxyyzz.LIB	- PDM360: CR1050, CR1051 - PDM360compact: CR1052, CR1053, CR1055, CR1056
ifm_PDMng_UTIL_Vxxyyzz.LIB	- PDM360NG: CR108n
ifm_PDMsmart_UTIL_Vxxyyzz.LIB	- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

3310

NORM\_REAL normalises a value within defined limits to a value with new limits.

The FB normalises a value of type REAL, which is within the limits of XH and XL, to an output value within the limits of YH and YL. This FB is for example used to generate PWM values from analogue input values.

#### **NOTE**

The value for X must be in the defined input range between XL and XH (there is no internal plausibility check of the value). Outside this value range the output X\_OUT\_OF\_RANGE is set.

Due to rounding errors the normalised value can deviate by 1.

If the limits (XH/XL or YH/YL) are indicated in an inverted manner, normalisation is also done in an inverted manner.

## Parameters of the inputs

3311

Parameter	Data type	Description
X	REAL	current input value
XH	REAL	upper limit of input value range
XL	REAL	lower limit of input value range
YH	REAL	upper limit of output value range
YL	REAL	lower limit of output value range

## Parameters of the outputs

3312

Parameter	Data type	Description
Y	REAL	normalised value
X_OUT_OF_RANGE	BOOL	input value X is outside the defined value range XL/XH

## 7.3 Counter functions for frequency and period measurement

### Contents

Applications .....	199
Use as digital inputs .....	199

1591

Depending on the controller up to 16 fast inputs are supported which can process input frequencies of up to 30 kHz. Further to the pure frequency measurement at the inputs FRQ, the inputs ENC can be also used to evaluate incremental encoders (counter function) with a maximum frequency of 10 kHz. The inputs CYL are used for period measurement of slow signals.

Input	Frequency [kHz]	Description
FRQ 0 / ENC 0	30 / 10	frequency measurement / encoder 1, channel A
FRQ 1 / ENC 0	30 / 10	frequency measurement / encoder 1, channel B
FRQ 2 / ENC 1	30 / 10	frequency measurement / encoder 2, channel A
FRQ 3 / ENC 1	30 / 10	frequency measurement / encoder 2, channel B
CYL 0 / ENC 2	10	period measurement / encoder 3, channel A
CYL 1 / ENC 2	10	period measurement / encoder 3, channel B
CYL 2 / ENC 3	10	period measurement / encoder 4, channel A
CYL 3 / ENC 3	10	period measurement / encoder 4, channel B

The following functions are available for easy evaluation:

### 7.3.1 Applications

1592

It must be taken into account that the different measuring methods can cause errors in the frequency detection.

**FREQUENCY** (→ page [200](#)) is suitable for frequencies between 100 Hz and 30 kHz; the error decreases at high frequencies.

**PERIOD** (→ page [203](#)) carries out a period measurement. It is thus suitable for frequencies lower than 1000 Hz. In principle it can also measure higher frequencies, but this has a significant impact on the cycle time. This must be taken into account when setting up the application software.

## 7.3.2 Use as digital inputs

### Contents

FREQUENCY .....	200
PERIOD .....	203
PERIOD_RATIO .....	204
PHASE .....	206
INC_ENCODER .....	208
FAST_COUNT .....	211

1593

If the fast inputs (FRQx / CYLx) are used as "normal" digital inputs, the increased sensitivity to interfering pulses must be taken into account (e.g. contact bouncing for mechanical contacts). The standard digital input has an input frequency of 50 Hz. If necessary, the input signal must be debounced by means of the software.



## FREQUENCY

537

Unit type = function block (FB)


Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- (For safety signals use **SAFE\_FREQUENCY\_OK** together with **PERIOD** (→ page 203)!)
- SmartController: CR25nn
- PDM360smart: CR1071

 For the extended side of the ExtendedControllers the FB name ends with "\_E".

Symbol in CoDeSys:




### Description

540

FREQUENCY measures the signal frequency at the indicated channel. Maximum input frequency → data sheet.


This FB measures the frequency of the signal at the selected CHANNEL. To do so, the positive edge is evaluated. Depending on the TIMEBASE, frequency measurements can be carried out in a wide value range. High frequencies require a short time base, low frequencies a correspondingly longer time base. The frequency is provided directly in [Hz].

 For FREQUENCY only the inputs FRQ0...FRQ3 can be used.

## Parameters of the inputs

541

Parameter	Data type	Description
INIT	BOOL	TRUE (for only 1 cycle): unit is initialised  FALSE: during further processing of the program
CHANNEL	BYTE	number of the fast input channel (0...x, value depends on the device, → data sheet)
TIMEBASE	TIME	time base

-  The FB may provide wrong values before initialisation.
- Only evaluate the output if the FB has been initialised.

## Parameters of the outputs

542

Parameter	Data type	Description
F	REAL	frequency in [Hz]

## PERIOD

370


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn  
(For safety signals use **SAFE\_FREQUENCY\_OK** together with **FREQUENCY** (→ page 200) in addition!)
- SmartController: CR25nn
- PDM360smart: CR1071

### Symbol in CoDeSys:



### Description

373

PERIOD measures the frequency and the cycle period (cycle time) in [μs] at the indicated channel. Maximum input frequency → data sheet.

This FB measures the frequency and the cycle time of the signal at the selected CHANNEL. To calculate, all positive edges are evaluated and the average value is determined by means of the number of indicated PERIODS.

In case of low frequencies there will be inaccuracies when using FREQUENCY. To avoid this, PERIOD can be used. The cycle time is directly indicated in [μs].

The maximum measuring range is approx. 71 min.

### NOTE

For PERIOD only the inputs CYL0...CYL3 can be used.

For PDM360smart: CR1071: all inputs.

Frequencies < 0.5 Hz are no longer clearly indicated!

## Parameters of the inputs

374

Parameter	Data type	Description
INIT	BOOL	TRUE (for only 1 cycle): unit is initialised  FALSE: during further processing of the program
CHANNEL	BYTE	number of the fast input channel (0...x, value depends on the device, → data sheet)
PERIODS	BYTE	number of periods to be compared

**!** The FB may provide wrong values before initialisation.

► Do not evaluate the output before the FB has been initialised.

We urgently recommend to program an own instance of this FB for each channel to be evaluated. Otherwise, wrong values may be provided.

## Parameters of the outputs

375

Parameter	Data type	Description
C	DWORD	cycle time of the detected periods in [ $\mu$ s]
F	REAL	frequency of the detected periods in [Hz]
ET	TIME	time elapsed since the beginning of the period measurement (can be used for very slow signals)

## PERIOD\_RATIO

364

Unit type = function block (FB)


Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1071

 For the extended side of the ExtendedControllers the FB name ends with "\_E".

Symbol in CoDeSys:



### Description

367

PERIOD\_RATIO measures the frequency and the cycle period (cycle time) in [μs] during the indicated periods at the indicated channel. In addition, the mark-to-space ratio is indicated in per mill. Maximum input frequency → data sheet.

This FB measures the frequency and the cycle time of the signal at the selected CHANNEL. To calculate, all positive edges are evaluated and the average value is determined by means of the number of indicated PERIODS. In addition, the mark-to-space ratio is indicated in [%].

**For example:** In case of a signal ratio of 25 ms high level and 75 ms low level the value RATIO1000 is provided as 250 ‰.

In case of low frequencies there will be inaccuracies when using FREQUENCY. To avoid this, PERIOD\_RATIO can be used. The cycle time is directly indicated in [μs].

The maximum measuring range is approx. 71 min.

### NOTE

For PERIOD\_RATIO only the inputs CYL0...CYL3 can be used.  
For PDM360smart: CR1071: all inputs.

The output RATIO1000 provides the value 0 for a mark-to-space ratio of 100 % (input signal permanently at supply voltage).

Frequencies < 0.05 Hz are no longer clearly indicated!

## Parameters of the inputs

368

Parameter	Data type	Description
INIT	BOOL	TRUE (for only 1 cycle): unit is initialised  FALSE: during further processing of the program
CHANNEL	BYTE	number of the fast input channel (0...x, value depends on the device, → data sheet)
PERIODS	BYTE	number of periods to be compared

**I** The FB may provide wrong values before initialisation.

► Do not evaluate the output before the FB has been initialised.

We urgently recommend to program an own instance of this FB for each channel to be evaluated. Otherwise, wrong values may be provided.

## Parameters of the outputs

369

Parameter	Data type	Description
C	DWORD	cycle time of the detected periods in [ $\mu$ s]
F	REAL	frequency of the detected periods in [Hz]
ET	TIME	time elapsed since the beginning of the last change in state of the input signal (can be used for very slow signals)
RATIO1000	WORD	mark-to-space ratio in [%]

## PHASE

358

Unit type = function block (FB)


Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1071

 For the extended side of the ExtendedControllers the FB name ends with "\_E".

Symbol in CoDeSys:



### Description

361

PHASE reads a pair of channels with fast inputs and compares the phase position of the signals. Maximum input frequency → data sheet.

This FB compares a pair of channels with fast inputs so that the phase position of two signals towards each other can be evaluated. An evaluation of the cycle period is possible even in the range of seconds.

 For frequencies lower than 15 Hz a cycle period or phase shift of 0 is indicated.

## Parameters of the inputs

362

Parameter	Data type	Description
INIT	BOOL	TRUE (for only 1 cycle): unit is initialised  FALSE: during further processing of the program
CHANNEL	BYTE	number of the input channel pair (0/2):  0 = channel pair 0 = inputs 0 + 1 2 = channel pair 1 = inputs 2 + 3

**i** The FB may provide wrong values before initialisation.

► Do not evaluate the output before the FB has been initialised.

We urgently recommend to program an own instance of this FB for each channel to be evaluated. Otherwise, wrong values may be provided.

## Parameters of the outputs

363

Parameter	Data type	Description
C	DWORD	cycle period in [ $\mu$ s]
P	INT	angle of the phase shift (0...360 °)
ET	TIME	time elapsed since the beginning of the period measurement (can be used for very slow signals)



## INC\_ENCODER

4187

Unit type = function block (FB)


Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR25nn
- PDM360smart: CR1071

 For the extended side of the ExtendedControllers the FB name ends with "\_E".

Symbol in CoDeSys:



### Description

4330  
2602

INC\_ENCODER handles up/down counter functions for the evaluation of encoders.

Two frequency inputs form the input pair which is evaluated by means of the FB. The following table shows the permissible limit frequencies and the max. number of incremental encoders that can be connected:

Device	Limit frequency	max. number of encoders
BasicController: CR040n	1 kHz	2
CabinetController: CR030n	10 kHz	2
ClassicController: CR0020, CR0505	10 kHz	4
ClassicController: CR0032, CR0033	30 kHz	4
ExtendedController: CR0200	10 kHz	8
ExtendedController: CR0232, CR0233	30 kHz	8
PCB controller: CS0015	0.5 kHz	2
SafetyController: CR7020, CR7021, CR7505, CR7506	10 kHz	4
SafetyController: CR7032	30 kHz	4
ExtendedSafetyController: CR7200, CR7201	10 kHz	8
ExtendedSafetyController: CR7132	30 kHz	8
SmartController: CR25nn	10 kHz	2
PDM360smart: CR1071	1 kHz	2

**NOTE**

Depending on the further load on the unit the limit frequency might fall when "many" encoders are evaluated.

If the load is too high the cycle time can get unacceptably long (→ [Limitations and programming notes](#) (→ page [53](#))).

Via PRESET\_VALUE the counter can be set to a preset value. The value is adopted if PRESET is set to TRUE. Afterwards, PRESET must be set to FALSE again for the counter to become active again.

The current counter value is available at the output COUNTER. The outputs UP and DOWN indicate the current counting direction of the counter. The outputs are TRUE if the counter has counted in the corresponding direction in the preceding program cycle. If the counter stops, the direction output in the following program cycle is also reset.


On input RESOLUTION the resolution of the encoder can be evaluated in multiples:

1 = normal resolution (identical with the resolution of the encoder),

2 = double evaluation of the resolution,


4 = 4-fold evaluation of the resolution.

All other values on this input mean normal resolution.




RESOLUTION = 1

In the case of normal resolution only the falling edge of the B-signal is evaluated.



RESOLUTION = 2

In the case of double resolution the falling and the rising edges of the B-signal are evaluated.



RESOLUTION = 4

In the case of 4-fold resolution the falling and the rising edges of the A-signal and the B-signal are evaluated.

## Parameters of the inputs

4332  
529

Parameter	Data type	Description
INIT	BOOL	TRUE (for only 1 cycle): unit is initialised  FALSE: during further processing of the program
CHANNEL	BYTE	number of the input channel pair (0...3) (0...x, value depends on the device, → data sheet)  0 = channel pair 0 = inputs 0 + 1 1 = channel pair 1 = inputs 2 + 3 2 = channel pair 2 = inputs 4 + 5 3 = channel pair 3 = inputs 6 + 7
PRESET_VALUE	DINT	preset value of the counter
PRESET	BOOL	TRUE (only 1 cycle): preset value is adopted  FALSE: counter active
RESOLUTION	BYTE	factor of the encoder resolution (1, 2, 4):  1 = normal resolution 2 = double resolution 4 = 4-fold resolution  all other values count as "1"

## Parameters of the outputs

530

Parameter	Data type	Description
COUNTER	DINT	current counter value
UP	BOOL	TRUE: counter counts upwards  FALSE: counter stands still
DOWN	BOOL	TRUE: counter counts downwards  FALSE: counter stands still

## FAST\_COUNT

567

Unit type = function block (FB)


Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1071

 For the extended side of the ExtendedControllers the FB name ends with "\_E".

Symbol in CoDeSys:



### Description

570

FAST\_COUNT operates as counter block for fast input pulses.

This FB detects fast pulses at the FRQ input channels 0...3. With the FRQ input channel 0 FAST\_COUNT operates like the block CTU. Maximum input frequency → data sheet.

 Due to the technical design, for the *ecomatmobile* controllers channel 0 can only be used as up counter. The channels 1...3 can be used as up and down counters.

## Parameters of the inputs

571

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed starting from the start value FALSE: unit is not executed
INIT	BOOL	TRUE (for only 1 cycle): unit is initialised FALSE: during further processing of the program
CHANNEL	BYTE	number of the fast input channel (0...x, value depends on the device, → data sheet)
MODE_UP_DOWN	BOOL	TRUE: counter counts downwards. FALSE: counter counts upwards
LOAD	BOOL	TRUE: start value PV being loaded FALSE: start value "0" being loaded
PV	DWORD CR1071: WORD	start value (preset value)

**!** After setting the parameter ENABLE the counter counts as from the indicated start value. The counter does NOT continue from the value which was valid at the last deactivation of ENABLE.

## Parameters of the outputs

572

Parameter	Data type	Description
CV	DWORD CR1071: WORD	output value of the counter

## 7.4 PWM functions

### Contents

Availability of PWM.....	214
PWM signal processing.....	214

2303

In this chapter you will find out more about the pulse width modulation in the **ifm** device.

### 7.4.1 Availability of PWM

8472

PWM is available in the following devices:

	Number of available PWM outputs	of which current-controlled (PWMi)	PWM frequency [Hz]
BasicController: CR0401	8	0	20...250
BasicController: CR0403	12	2	20...250
CabinetController: CR0301	4	0	25...250
CabinetController: CR0302, CR0303	8	0	25...250
ClassicController: CR0020	12	8	25...250
ClassicController: CR0505	8	8	25...250
ClassicController: CR0032, CR0033	16	16	25...250
ExtendedController: CR0200	24	16	25...250
ExtendedController: CR0232, CR0233	32	32	25...250
PCB controller: CS0015	8	0	25...250
SafetyController: CR7020, CR7021	12	8	25...250
SafetyController: CR7505, CR0506	8	8	25...250
ExtendedSafetyController: CR7200, CR7201	24	16	25...250
SmartController: CR25nn	4	4	25...250
PDM360smart: CR1071	4	0	25...250

## 7.4.2 PWM signal processing

### Contents

PWM – introduction .....	215
PWM functions and their parameters .....	215

1526

### PWM – introduction

6889

The abbreviation PWM stands for **pulse width modulation**. It is mainly used to trigger proportional valves (PWM valves) for mobile and robust controller applications. Also, with an additional component (accessory) for a PWM output the pulse-width modulated output signal can be converted into an analogue output voltage.




Figure: PWM principle

The PWM output signal is a pulsed signal between GND and supply voltage. Within a defined period (PWM frequency) the mark-to-space ratio is then varied. Depending on the mark-to-space ratio, the connected load determines the corresponding RMS current.

The PWM function of the *ecomatmobile* controller is a hardware function provided by the processor. To use the integrated PWM outputs of the controller, they must be initialised in the application program and parameterised corresponding to the requested output signal.

## PWM functions and their parameters

### Contents

PWM / PWM1000.....	216
PWM frequency.....	216
PWM channels 0...3 .....	217
Calculation of the RELOAD value.....	217
Calculation examples RELOAD value.....	218
PWM channels 4...7 / 8...11 (if exist) .....	219
PWM dither.....	220
Ramp function .....	220
PWM .....	220
PWM100 .....	222
PWM1000.....	224

1527

### PWM / PWM1000

1528

Depending on the application and the requested resolution, PWM or PWM1000 can be selected for the application programming. High accuracy and thus resolution is required when using the control functions. This is why the more technical PWM FB is used in this case.

If the implementation is to be kept simple and if there are no high requirements on the accuracy, **PWM1000** (→ page [224](#)) can be used. For this FB the PWM frequency can be directly entered in [Hz] and the mark-to-space ratio in steps of 1 ‰.

### PWM frequency

1529

Depending on the valve type, a corresponding PWM frequency is required. For the PWM function the PWM frequency is transmitted via the reload value (**PWM** (→ page [220](#))) or directly as a numerical value in [Hz] (**PWM1000** (→ page [224](#))). Depending on the controller, the PWM outputs differ in their operating principle but the effect is the same.

The PWM frequency is implemented by means of an internally running counter, derived from the CPU pulse. This counter is started with the initialisation of the PWM. Depending on the PWM output group (0...3 and / or 4...7 or 4...11), it counts from  $FFFF_{16}$  backwards or from  $0000_{16}$  forwards. If a transmitted comparison value (VALUE) is reached, the output is set. In case of an overflow of the counter (change of the counter reading from  $0000_{16}$  to  $FFFF_{16}$  or from  $FFFF_{16}$  to  $0000_{16}$ ), the output is reset and the operation restarts.

If this internal counter shall not operate between  $0000_{16}$  and  $FFFF_{16}$ , another preset value (RELOAD) can be transmitted for the internal counter. In doing so, the PWM frequency increases. The comparison value must be within the now specified range.



## PWM channels 0...3

1530

These 4 PWM channels allow the most flexibility for the parameter setting. The PWM channels 0...3 are available in all *ecomatmobile* controller versions; depending on the type they feature a current control or not.

For each channel an own PWM frequency (RELOAD value) can be set. There is a free choice between **PWM** (→ page 220) and **PWM1000** (→ page 224).

### Calculation of the RELOAD value

1531




Figure: RELOAD value for the PWM channels 0...3

The RELOAD value of the internal PWM counter is calculated on the basis of the parameter DIV64 and the CPU frequency as follows:

	<ul style="list-style-type: none"> <li>- CabinetController: CR0303</li> <li>- ClassicController: CR0020, CR0505</li> <li>- ExtendedController: CR0200</li> <li>- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506</li> </ul>	<ul style="list-style-type: none"> <li>- CabinetController: CR0301, CR0302</li> <li>- SmartController: CR25nn</li> <li>- PCB controller: CS0015</li> <li>- PDM360smart: CR1071</li> </ul>
DIV64 = 0	$\text{RELOAD} = 20 \text{ MHz} / f_{\text{PWM}}$	$\text{RELOAD} = 10 \text{ MHz} / f_{\text{PWM}}$
DIV64 = 1	$\text{RELOAD} = 312.5 \text{ kHz} / f_{\text{PWM}}$	$\text{RELOAD} = 156.25 \text{ kHz} / f_{\text{PWM}}$

Depending on whether a high or a low PWM frequency is required, the input DIV64 must be set to FALSE (0) or TRUE (1). In case of frequencies below 305 Hz respectively 152 Hz (according to the controller), DIV64 must be set to "1" to ensure that the RELOAD value is not greater than  $\text{FFFF}_{16}$ .

## Calculation examples RELOAD value

1532

<ul style="list-style-type: none"> <li>- CabinetController: CR0303</li> <li>- ClassicController: CR0020, CR0505</li> <li>- ExtendedController: CR0200</li> <li>- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506</li> </ul>	<ul style="list-style-type: none"> <li>- CabinetController: CR0301, CR0302</li> <li>- SmartController: CR25nn</li> <li>- PCB controller: CS0015</li> <li>- PDM360smart: CR1071</li> </ul>
<p>The PWM frequency shall be 400 Hz.</p> <p>20 MHz</p> <p>_____ = 50 000<sub>10</sub> = C350<sub>16</sub> = RELOAD</p> <p>400 Hz</p> <p>Thus the permissible range of the PWM value is the range from 0000<sub>16</sub> to C350<sub>16</sub>.</p> <p>The comparison value at which the output switches must then be between 0000<sub>16</sub> and C350<sub>16</sub>.</p>	<p>The PWM frequency shall be 200 Hz.</p> <p>10 MHz</p> <p>_____ = 50 000<sub>10</sub> = C350<sub>16</sub> = RELOAD</p> <p>200 Hz</p> <p>Thus the permissible range of the PWM value is the range from 0000<sub>16</sub> to C350<sub>16</sub>.</p> <p>The comparison value at which the output switches must then be between 0000<sub>16</sub> and C350<sub>16</sub>.</p>

This results in the following mark-to-space ratios:

Mark-to-space ratio	Switch-on time	Value for mark-to-space ratio
Minimum	0 %	C350 <sub>16</sub>
Maximum	100 %	0000 <sub>16</sub>

Between minimum and maximum triggering 50 000 intermediate values (PWM values) are possible.

## PWM channels 4...7 / 8...11 (if exist)

1533

Applies only to the following devices:

- CabinetController: CR0303
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506

These 4/8 PWM channels can only be set to one common PWM frequency. For programming, PWM and PWM1000 must not be mixed.




Figure: RELOAD value for PWM channels 4...7 / 8...11

The RELOAD value of the internal PWM counter is calculated (for all *ecomatmobile* controllers) on the basis of the parameters DIV64 and the CPU frequency as follows:

DIV64 = 0	$\text{RELOAD} = 10\,000_{16} - (2.5\text{ MHz} / f_{\text{PWM}})$
DIV64 = 1	$\text{RELOAD} = 10\,000_{16} - (312.5\text{ kHz} / f_{\text{PWM}})$

Depending on whether a high or a low PWM frequency is required, the input DIV64 must be set to FALSE (0) or TRUE (1). In case of PWM frequencies below 39 Hz, DIV64 must be set to "1" to ensure that the RELOAD value is not smaller than  $0000_{16}$ .

### Example:

The PWM frequency shall be 200 Hz.

2.5 MHz

$$\underline{\hspace{2cm}} = 12\,500_{10} = 30D4_{16}$$

200 Hz

$$\text{RELOAD value} = 10\,000_{16} - 30D4_{16} = \text{CF}2\text{C}_{16}$$

Thus the permissible range of the PWM value is the range from  $\text{CF}2\text{C}_{16}$  to  $\text{FFFF}_{16}$ .

The comparison value at which the output switches must then be between  $\text{CF}2\text{C}_{16}$  and  $\text{FFFF}_{16}$ .

### **NOTE**

The PWM frequency is the same for all PWM outputs (4...7 or 4...11).

PWM and PWM1000 must not be mixed.

This results in the following mark-to-space ratios:

Mark-to-space ratio	Switch-on time	Value for mark-to-space ratio
Minimum	0 %	FFFF <sub>16</sub>
Maximum	100 %	CF2C <sub>16</sub>

Between minimum and maximum triggering 12 500 intermediate values (PWM values) are possible.

**I** For ClassicController and ExtendedController applies:

If the PWM outputs 4...7 are used (regardless of whether current-controlled or via one of the PWM FBs) the same frequency and the corresponding reload value have to be set for the outputs 8...11. This means that the same FBs have to be used for these outputs.

## PWM dither

1534

For certain hydraulic valve types a so-called dither frequency must additionally be superimposed on the PWM frequency. If valves were triggered over a longer period by a constant PWM value, they could block due to the high system temperatures.

To prevent this, the PWM value is increased or reduced on the basis of the dither frequency by a defined value (DITHER\_VALUE). As a consequence a vibration with the dither frequency and the amplitude DITHER\_VALUE is superimposed on the constant PWM value. The dither frequency is indicated as the ratio (divider, DITHER\_DIVIDER \* 2) of the PWM frequency.

## Ramp function

1535

In order to prevent abrupt changes from one PWM value to the next, e.g. from 15 % ON to 70 % ON (→ figure in **PWM – introduction** (→ page [215](#))), it is possible to delay the increase by using PT1. The ramp function used for PWM is based on the CoDeSys library UTIL.LIB. This allows a smooth start e.g. for hydraulic systems.

**I** When installing the *ecomatmobile* DVD "Software, tools and documentation", projects with examples have been stored in the program directory of your PC:

...\ifm electronic\CoDeSys V...\Projects\DEMO\_PLC\_CDV... (for controllers) or  
 ...\ifm electronic\CoDeSys V...\Projects\DEMO\_PDM\_CDV... (for PDMs).

There you also find projects with examples regarding this subject. It is strongly recommended to follow the shown procedure.

→ chapter **ifm demo programs** (→ page [40](#))

**I** The PWM function of the controller is a hardware function provided by the processor. The PWM function remains set until a hardware reset (power off and on) has been carried out on the controller.

## PWM

320

Unit type = function block (FB)


Contained in the library: `ifm_CRnnnn_Vxyyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR25nn
- PDM360smart: CR1071

 For the extended side of the ExtendedControllers the FB name ends with "\_E".

Symbol in CoDeSys:



### Description

323

PWM is used for initialisation and parameter setting of the PWM outputs.

PWM has a more technical background. Due to their structure, PWM values can be very finely graded. So, this FB is suitable for use in controllers.

PWM is called once for each channel during initialisation of the application program. When doing so, input INIT must be set to TRUE. During initialisation, the parameter RELOAD is also assigned.

### NOTE

The value RELOAD must be identical for the channels 4...7.

But for the ClassicController or ExtendedController: for the channels 4...11

But for the PDM360smart: CR1071: for the channels 0...3

For these channels, PWM and **PWM1000** (→ page [224](#)) must not be mixed.

The PWM frequency (and so the RELOAD value) is internally limited to 5 kHz.

Depending on whether a high or a low PWM frequency is required, the input DIV64 must be set to FALSE (0) or TRUE (1).

During cyclical processing of the program INIT is set to FALSE. The FB is called and the new PWM value is assigned. The value is adopted if the input CHANGE = TRUE.

A current measurement for the initialised PWM channel can be implemented:

- via **OUTPUT\_CURRENT** \*)
  - \*) Applies only to the following devices:
    - ClassicController: CR0020, CR0032, CR0033, CR0505
    - ExtendedController: CR0200, CR0232, CR0233
    - SafetyController: CR7nnn
    - SmartController: CR25nn
- or for example using the **ifm** unit EC2049 (series element for current measurement).

PWM\_Dither is called once for each channel during initialisation of the application program. When doing so, input INIT must be set to TRUE. During initialisation, the DIVIDER for the determination of the dither frequency and the VALUE are assigned.

**i** The parameters DITHER\_FREQUENCY and DITHER\_VALUE can be individually set for each channel.


### Parameters of the inputs

324

Parameter	Data type	Description
INIT	BOOL	TRUE (for only 1 cycle): unit is initialised  FALSE: during further processing of the program
RELOAD	WORD	Value for the determination of the PWM frequency (→ chapter <a href="#">Calculation of the RELOAD value</a> (→ page <a href="#">217</a> ))
DIV64	BOOL	CPU cycle / 64
CHANNEL	BYTE	current PWM channel / output
VALUE	WORD	current PWM value
CHANGE	BOOL	TRUE: new PWM value is adopted  FALSE: the changed PWM value has no influence on the output
DITHER_VALUE	WORD	amplitude of the dither value (→ chapter <a href="#">PWM dither</a> (→ page <a href="#">220</a> ))
DITHER_DIVIDER	WORD	dither frequency = PWM frequency / DIVIDER * 2

## PWM100

332

 New *ecomatmobile* controllers only support **PWM1000** (→ page [224](#)).


Contained in the library: `ifm_CRnnnn_Vxyyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7200, CR7505
- SmartController: CR25nn
- PDM360smart: CR1071

 For the extended side of the ExtendedControllers the FB name ends with "\_E".

### Symbol in CoDeSys:



### Description

335

PWM100 handles the initialisation and parameter setting of the PWM outputs.

The FB enables a simple application of the PWM FB in the *ecomatmobile* controller. The PWM frequency can be directly indicated in [Hz] and the mark-to-space ratio in steps of 1 %. This FB is **not** suited for use in controllers, due to the relatively coarse grading.

The FB is called once for each channel in the initialisation of the application program. For this, the input INIT must be set to TRUE. During initialisation, the parameter FREQUENCY is also assigned.

### NOTE

The value FREQUENCY must be identical for the channels 4...7.  
 But for the ClassicController or ExtendedController: for the channels 4...11  
 But for the PDM360smart: CR1071: for the channels 0...3  
 For these channels, **PWM** (→ page [220](#)) and PWM100 must not be mixed.  
 The PWM frequency is limited to 5 kHz internally.

During cyclical processing of the program INIT is set to FALSE. The FB is called and the new PWM value is assigned. The value is adopted if the input CHANGE = TRUE.

A current measurement for the initialised PWM channel can be implemented:

- via **OUTPUT\_CURRENT** \*)  
 \*) Applies only to the following devices:
  - ClassicController: CR0020, CR0032, CR0033, CR0505
  - ExtendedController: CR0200, CR0232, CR0233
  - SafetyController: CR7nnn
  - SmartController: CR25nn
- or for example using the **ifm** unit EC2049 (series element for current measurement).

DITHER is called once for each channel during initialisation of the application program. When doing so, input INIT must be set to TRUE. During initialisation, the value FREQUENCY for determining the dither frequency and the dither value (VALUE) are transmitted.

**i** The parameters DITHER\_FREQUENCY and DITHER\_VALUE can be individually set for each channel.

### Parameters of the inputs

336

Parameter	Data type	Description
INIT	BOOL	TRUE (for only 1 cycle): unit is initialised  FALSE: during further processing of the program
FREQUENCY	WORD	PWM frequency in [Hz]
CHANNEL	BYTE	current PWM channel / output
VALUE	BYTE	current PWM value
CHANGE	BOOL	TRUE: new PWM value is adopted  FALSE: the changed PWM value has no influence on the output
DITHER_VALUE	BYTE	amplitude of the dither value in [%]
DITHER_FREQUENCY	WORD	dither frequency in [Hz]



## PWM1000

326

Unit type = function block (FB)


Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1071

 For the extended side of the ExtendedControllers the FB name ends with "\_E".

Symbol in CoDeSys:



### Description

329

PWM1000 handles the initialisation and parameter setting of the PWM outputs.

The FB enables a simple use of the PWM FB in the *ecomatmobile* device. The PWM frequency can be directly indicated in [Hz] and the mark-to-space ratio in steps of 1 %.

The FB is called once for each channel during initialisation of the application program. When doing so, input INIT must be set to TRUE. During initialisation, the parameter FREQUENCY is also assigned.

### NOTE

The value FREQUENCY must be identical for the channels 4...7.

But for the ClassicController or ExtendedController: for the channels 4...11

But for the PDM360smart: CR1071: for the channels 0...3

For these channels, **PWM** (→ page [220](#)) and PWM1000 must not be mixed.

The PWM frequency is limited to 5 kHz internally.

During cyclical processing of the program INIT is set to FALSE. The FB is called and the new PWM value is assigned. The value is adopted if the input CHANGE = TRUE.

A current measurement for the initialised PWM channel can be implemented:

- via **OUTPUT\_CURRENT** \*)  
 \*) Applies only to the following devices:
  - ClassicController: CR0020, CR0032, CR0033, CR0505
  - ExtendedController: CR0200, CR0232, CR0233
  - SafetyController: CR7nnn
  - SmartController: CR25nn
- or for example using the **ifm** module EC2049 (series element for current measurement).

DITHER is called once for each channel during initialisation of the application program. When doing so, input INIT must be set to TRUE. During initialisation, the value FREQUENCY for determining the dither frequency and the dither value (VALUE) are transmitted.

**i** The parameters DITHER\_FREQUENCY and DITHER\_VALUE can be individually set for each channel.

### Parameters of the inputs

330

Parameter	Data type	Description
INIT	BOOL	TRUE (for only 1 cycle): unit is initialised  FALSE: during further processing of the program
FREQUENCY	WORD	PWM frequency in [Hz]
CHANNEL	BYTE	current PWM channel / output
VALUE	WORD	current PWM value
CHANGE	BOOL	TRUE: new PWM value is adopted  FALSE: the changed PWM value has no influence on the output
DITHER_VALUE	WORD	amplitude of the dither value in [%]
DITHER_FREQUENCY	WORD	dither frequency in [Hz]

## 7.5 Controller functions

### Contents

General .....	227
Setting rule for a controller .....	229
Functions for controllers .....	229

1622

### 7.5.1 General

1623

Controlling is a process during which the unit to be controlled (control variable  $x$ ) is continuously detected and compared with the reference variable  $w$ . Depending on the result of this comparison, the control variable is influenced for adaptation to the reference variable.




Figure: Principle of controlling

The selection of a suitable control device and its optimum setting require exact indication of the steady-state behaviour and the dynamic behaviour of the controlled system. In most cases these characteristic values can only be determined by experiments and can hardly be influenced.

Three types of controlled systems can be distinguished:

### Self-regulating process

1624

For a self-regulating process the control variable  $x$  goes towards a new final value after a certain manipulated variable (steady state). The decisive factor for these controlled systems is the amplification (steady-state transfer factor  $K_S$ ). The smaller the amplification, the better the system can be controlled. These controlled systems are referred to as P systems ( $P$  = proportional).




Figure: P controller = self-regulating process

## Controlled system without inherent regulation

1625

Controlled systems with an amplifying factor towards infinity are referred to as controlled systems without inherent regulation. This is usually due to an integrating performance. The consequence is that the control variable increases constantly after the manipulated variable has been changed or by the influence of an interfering factor. Due to this behaviour it never reaches a final value. These controlled systems are referred to as I systems ( $I = \text{integral}$ ).




Figure: I controller = controlled system without inherent regulation

## Controlled system with delay

1626

Most controlled systems correspond to series systems of P systems (systems with compensation) and one or several T1 systems (systems with inertia). A controlled system of the 1st order is for example made up of the series connection of a throttle point and a subsequent memory.




Figure: PT system = controlled system with delay

For controlled systems with dead time the control variable does not react to a change of the control variable before the dead time  $T_t$  has elapsed. The dead time  $T_t$  or the sum of  $T_t + T_u$  relates to the controllability of the system. The controllability of a system is the better, the greater the ratio  $T_g/T_u$ .

The controllers which are integrated in the library are a summary of the preceding basic functions. It depends on the respective controlled system which functions are used and how they are combined.

## 7.5.2 Setting rule for a controller

1627

For controlled systems, whose time constants are unknown the setting procedure to Ziegler and Nickols in a closed control loop is of advantage.

### Setting control

1628

At the beginning the controlling system is operated as a purely P-controlling system. In this respect the derivative time  $T_V$  is set to 0 and the reset time  $T_N$  to a very high value (ideally to  $\infty$ ) for a slow system. For a fast controlled system a small  $T_N$  should be selected.

Afterwards the gain  $K_P$  is increased until the control deviation and the adjustment deviation perform steady oscillation at a constant amplitude at  $K_P = K_{P_{critical}}$ . Then the stability limit has been reached.

Then the time period  $T_{critical}$  of the steady oscillation has to be determined.

Add a differential component only if necessary.

$T_V$  should be approx. 2...10 times smaller than  $T_N$

$K_P$  should be equal to  $K_D$ .

Idealised setting of the controlled system:

Control unit	$K_P = K_D$	$T_N$	$T_V$
P	$2.0 * K_{P_{critical}}$	—	—
PI	$2.2 * K_{P_{critical}}$	$0.83 * T_{critical}$	—
PID	$1.7 * K_{P_{critical}}$	$0.50 * T_{critical}$	$0.125 * T_{critical}$

**I** For this setting process it has to be noted that the controlled system is not harmed by the oscillation generated. For sensitive controlled systems  $K_P$  must only be increased to a value at which no oscillation occurs.

### Damping of overshoot

1629

To dampen overshoot **PT1** (→ page [231](#)) (low pass) can be used. In this respect the preset value XS is damped by the PT1 link before it is supplied to the controller function.

The setting variable T1 should be approx. 4...5 times greater than  $T_N$  (of the PID or GLR controller).

### 7.5.3 Functions for controllers

#### Contents

DELAY .....	230
PT1 .....	231
PID1 .....	232
PID2 .....	234
GLR .....	237

1634

The section below describes in detail the units that are provided for set-up by software controllers in the *ecomatmobile* device. The units can also be used as basis for the development of your own control functions.

## DELAY

585


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

588

DELAY delays the output of the input value by the time T (dead-time element).




Figure: Time characteristics of DELAY

**I** To ensure that the FB works correctly, it must be called in each cycle.

### Parameters of the inputs

589

Parameter	Data type	Description
X	WORD	input value
T	TIME	time delay (dead time)

### Parameters of the outputs

590

Parameter	Data type	Description
Y	WORD	input value, delayed by the time T

## PT1

338


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1071

Symbol in CoDeSys:



## Description

341

PT1 handles a controlled system with a first-order time delay.

This FB is a proportional controlled system with a time delay. It is for example used for generating ramps when using the PWM FBs.

The output variable Y of the low-pass filter has the following time characteristics (unit step):




Figure: Time characteristics of PT1

## Parameters of the inputs

342

Parameter	Data type	Description
X	INT	input value
T1	TIME	delay time (time constant)

## Parameters of the outputs

343

Parameter	Data type	Description
Y	INT	output variable



## PID1

351


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1071

Symbol in CoDeSys:



### Description

354

PID1 handles a PID controller.

The change of the manipulated variable of a PID controller has a **proportional**, **integral** and **differential** component. The manipulated variable changes first by an amount which depends on the rate of change of the input value (D component). After the end of the derivative action time the manipulated variable returns to the value corresponding to the proportional range and changes in accordance with the reset time.

### NOTE

The manipulated variable Y is already standardised to the PWM FB (RELOAD value = 65,535). Note the reverse logic:

65,535 = minimum value

0 = maximum value.

Note that the input values KI and KD depend on the cycle time. To obtain stable, repeatable control characteristics, the FB should be called in a time-controlled manner.

If  $X > X_S$ , the manipulated variable is increased.

If  $X < X_S$ , the manipulated variable is reduced.

The manipulated variable  $Y$  has the following time characteristics:




Figure: Typical step response of a PID controller

## Parameters of the inputs

355

Parameter	Data type	Description
X	WORD	actual value
XS	WORD	desired value
XMAX	WORD	maximum value of the target value
KP	BYTE	constant of the proportional component
KI	BYTE	integral value
KD	BYTE	proportional component of the differential component

## Parameters of the outputs

356

Parameter	Data type	Description
Y	WORD	manipulated variable

## Recommended settings

357

KP = 50

KI = 30

KD = 5

With the values indicated above the controller operates very quickly and in a stable way. The controller does not fluctuate with this setting.

- To optimise the controller, the values can be gradually changed afterwards.

## PID2

9167


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1071

Symbol in CoDeSys:



### Description

347

PID2 handles a PID controller with self optimisation.

The change of the manipulated variable of a PID controller has a proportional, integral and differential component. The manipulated variable changes first by an amount which depends on the rate of change of the input value (D component). After the end of the derivative action time TV the manipulated variable returns to the value corresponding to the proportional component and changes in accordance with the reset time TN.

The values entered at the inputs KP and KD are internally divided by 10. So, a finer grading can be obtained (e.g.: KP = 17, which corresponds to 1.7).

#### **NOTE**

The manipulated variable Y is already standardised to the PWM FB (RELOAD value = 65,535). Note the reverse logic:

65,535 = minimum value

0 = maximum value.

Note that the input value KD depends on the cycle time. To obtain stable, repeatable control characteristics, the FB should be called in a time-controlled manner.

If  $X > X_S$ , the manipulated variable is increased.

If  $X < X_S$ , the manipulated variable is reduced.

A reference variable is internally added to the manipulated variable.

$Y = Y + 65,536 - (X_S / X_{MAX} * 65,536)$ .

The manipulated variable Y has the following time characteristics.




Figure: Typical step response of a PID controller

## Parameters of the inputs

348

Parameter	Data type	Description
X	WORD	actual value
XS	WORD	desired value
XMAX	WORD	maximum value of the desired value
KP	BYTE	constant of the proportional component (/10)
TN	TIME	reset time (integral component)
KD	BYTE	proportional component of the differential component (/10)
TV	TIME	derivative action time (differential component)
SO	BOOL	self optimisation
RESET	BOOL	Reset

## Parameters of the outputs

349

Parameter	Data type	Description
Y	WORD	manipulated variable

## Recommended setting

9127  
350

- ▶ Select TN according to the time characteristics of the system:  
fast system = small TN  
slow system = large TN
- ▶ Slowly increment KP gradually, up to a value at which still definitely no fluctuation will occur.
- ▶ Readjust TN if necessary.
- ▶ Add differential component only if necessary:  
Select a TV value approx. 2...10 times smaller than TN.  
Select a KD value more or less similar to KP.

Note that the maximum control deviation is + 127. For good control characteristics this range should not be exceeded, but it should be exploited to the best possible extent.

Function input SO (self-optimisation) clearly improves the control performance. A precondition for achieving the desired characteristics:

- The controller is operated with I component (TN > 50 ms)
- Parameters KP and especially TN are already well adjusted to the actual controlled system.
- The control range (X – XS) of  $\pm 127$  is utilised (if necessary, increase the control range by multiplying X, XS and XMAX).
- ▶ When you have finished setting the parameters, you can set SO = TRUE.
- > This will significantly improve the control performance, especially reducing overshoot.

## GLR

531


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506
- SmartController: CR25nn
- PDM360smart: CR1071

Symbol in CoDeSys:



### Description

534

GLR handles a synchro controller.

The synchro controller is a controller with PID characteristics.

The values entered at the inputs KP and KD are internally divided by 10. So, a finer grading can be obtained (e.g.: KP = 17, which corresponds to 1.7).

The manipulated variable referred to the greater actual value is increased accordingly.

The manipulated variable referred to the smaller actual value corresponds to the reference variable.

Reference variable =  $65\,536 - (XS / XMAX * 65\,536)$ .

### **NOTE**

The manipulated variables Y1 and Y2 are already standardised to the PWM FB (RELOAD value = 65 535). Note the reverse logic:

65 535 = minimum value

0 = maximum value.

Note that the input value KD depends on the cycle time. To obtain stable, repeatable control characteristics, the FB should be called in a time-controlled manner.

## Parameters of the inputs

535

Parameter	Data type	Description
X1	WORD	actual value channel 1
X2	WORD	actual value channel 2
XS	WORD	desired value = reference variable
XMAX	WORD	maximum value of the desired value
KP	BYTE	constant of the proportional component (/10)
TN	TIME	reset time (integral component)
KD	BYTE	proportional component of the differential component (/10)
TV	TIME	derivative action time (differential component)
RESET	BOOL	Reset

## Parameters of the outputs

536

Parameter	Data type	Description
Y1	WORD	manipulated variable channel 1
Y2	WORD	manipulated variable channel 2

## 8 Communication via interfaces

### Contents

Use of the serial interface .....	240
-----------------------------------	-----

8602

Here we show you functions to use for communication via interfaces.

### 8.1 Use of the serial interface

#### Contents

SERIAL_SETUP .....	240
SERIAL_TX .....	242
SERIAL_RX .....	243
SERIAL_PENDING .....	245

1600

#### **NOTE**

In principle, the serial interface is not available for the user because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit SERIAL\_MODE to TRUE. Then however, program download and debugging are only possible via the CAN interface.

For CRnn32: Debugging of the application software is then only possible via all 4 CAN interfaces or via USB.

The serial interface can be used in the application program by means of the following FBs.



## 8.1.1 SERIAL\_SETUP

302


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

305

SERIAL\_SETUP initialises the serial RS232 interface.

SERIAL\_SETUP sets the serial interface to the indicated parameters. Using the input ENABLE, the FB is activated for one cycle.

The SERIAL FBs form the basis for the creation of an application-specific protocol for the serial interface.

#### **NOTE**

In principle, the serial interface is not available for the user, because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit SERIAL\_MODE to TRUE. Then however, program download and debugging are only possible via the CAN interface.

For CRnn32: Debugging of the application software is then only possible via all 4 CAN interfaces or via USB.

#### **NOTICE**

The driver module of the serial interface can be damaged!

Disconnecting the serial interface while live can cause undefined states which damage the driver module.

- Do not disconnect the serial interface while live.

## Parameters of the inputs

306

Parameter	Data type	Description
ENABLE	BOOL	TRUE (only 1 cycle): interface is initialised  FALSE: during further processing of the program
BAUDRATE	WORD	baud rate (permissible values = 9 600, 19 200, 28 800, (57 600)) preset value → data sheet
DATABITS	BYTE	data bits (permissible values: 7 or 8) preset value = 8
PARITY	BYTE	parity (permissible values: 0=none, 1=even, 2=uneven) preset value = 0
STOPBITS	BYTE	stop bits (permissible values: 1 or 2) preset value = 1

## 8.1.2 SERIAL\_TX

296


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

299

SERIAL\_TX transmits one data byte via the serial RS232 interface.

Using the input ENABLE the transmission can be enabled or blocked.

The SERIAL FBs form the basis for the creation of an application-specific protocol for the serial interface.

#### **NOTE**

In principle, the serial interface is not available for the user, because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit SERIAL\_MODE to TRUE. Then however, program download and debugging are only possible via the CAN interface.

For CRnn32: Debugging of the application software is then only possible via all 4 CAN interfaces or via USB.

### Parameters of the inputs

300

Parameter	Data type	Description
ENABLE	BOOL	TRUE: transmission enabled FALSE: transmission blocked
DATA	BYTE	byte to be transmitted

## 8.1.3 SERIAL\_RX

308

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

311

SERIAL\_RX reads a received data byte from the serial receive buffer at each call.

Then, the value of AVAILABLE is decremented by 1.

If more than 1000 data bytes are received, the buffer overflows and data is lost. This is indicated by the bit OVERFLOW.

The SERIAL FBs form the basis for the creation of an application-specific protocol for the serial interface.

#### **NOTE**

In principle, the serial interface is not available for the user, because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit SERIAL\_MODE to TRUE. Then however, program download and debugging are only possible via the CAN interface.

For CRnn32: Debugging of the application software is then only possible via all 4 CAN interfaces or via USB.

## Parameters of the inputs

312

Parameter	Data type	Description
CLEAR	BOOL	TRUE: receive buffer is deleted FALSE: this function is not executed

## Parameters of the outputs

313

Parameter	Data type	Description
RX	BYTE	byte data received from the receive buffer
AVAILABLE	WORD	number of data bytes received 0 = no valid data available
OVERFLOW	BOOL	TRUE: overflow of the data buffer, loss of data!

### Example:

3 bytes are received:

1st call of SERIAL\_RX

1 valid value at output RX

→ AVAILABLE = 3

2nd call of SERIAL\_RX

1 valid value at output RX

→ AVAILABLE = 2

3rd call of SERIAL\_RX

1 valid value at output RX

→ AVAILABLE = 1

4th call of SERIAL\_RX

invalid value at the output RX

→ AVAILABLE = 0

If AVAILABLE = 0, the FB can be skipped during processing of the program.

## 8.1.4 SERIAL\_PENDING

314

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

317

SERIAL\_PENDING determines the number of data bytes stored in the serial receive buffer.

In contrast to **SERIAL\_RX** (→ page [243](#)) the contents of the buffer remain unchanged after calling this FB.

The SERIAL FBs form the basis for the creation of an application-specific protocol for the serial interface.

### NOTE

In principle, the serial interface is not available for the user, because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit SERIAL\_MODE to TRUE. Then however, program download and debugging are only possible via the CAN interface.

For CRnn32: Debugging of the application software is then only possible via all 4 CAN interfaces or via USB.

### Parameters of the outputs

319

Parameter	Data type	Description
NUMBER	WORD	number of data bytes received

## 9 Managing the data

### Contents

Software reset .....	247
Reading / writing the system time .....	248
Reading of the device temperature .....	251
Saving, reading and converting data in the memory .....	253
Data access and data check .....	265

8606

Here we show you functions how to read or manage data in the device.

### 9.1 Software reset

#### Contents

SOFTRESET .....	247
-----------------	-----

1594

Using this FB the control can be restarted via an order in the application program.

## 9.1.1 SOFTRESET

260

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

263

SOFTRESET leads to a complete reboot of the controller.

The FB can for example be used in conjunction with CANopen if a node reset is to be carried out. The behaviour of the controller after a SOFTRESET corresponds to that after switching the supply voltage off and on.

**I** In case of active communication, the long reset period must be taken into account because otherwise guarding errors will be signalled.

### Parameters of the inputs

264

Parameter	Data type	Description
ENABLE	BOOL	<p>TRUE: unit is executed</p> <p>FALSE: unit is not executed &gt; POU inputs and outputs are not active</p>



## 9.2 Reading / writing the system time

### Contents

TIMER_READ .....	249
TIMER_READ_US .....	250

1601

The following FBs offered by **ifm electronic** allow you to read the continually running system time of the controller and to evaluate it in the application program, or to change the system time as needed.

© ifm electronic gmbh

## 9.2.1 TIMER\_READ

236

Unit type = function block (FB)

Contained in the library: ifm\_CRnnnn\_Vxyyyzz.LIB

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

239

TIMER\_READ reads the current system time.

When the supply voltage is applied, the controller generates a clock pulse which is counted upwards in a register. This register can be read using the FB call and can for example be used for time measurement.

**I** The system timer goes up to FFFF FFFF<sub>16</sub> at the maximum (corresponds to about 49.7 days) and then starts again from 0.

### Parameters of the outputs

241

Parameter	Data type	Description
T	TIME	current system time (resolution [ms])

## 9.2.2 TIMER\_READ\_US

657

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

660

TIMER\_READ\_US reads the current system time in [μs].

When the supply voltage is applied, the device generates a clock pulse which is counted upwards in a register. This register can be read by means of the FB call and can for example be used for time measurement.

#### Info

The system timer runs up to the counter value 4 294 967 295 μs at the maximum and then starts again from 0.

4 294 967 295 μs = 4 295 s = 71.6 min = 1.2 h

### Parameters of the outputs

662

Parameter	Data type	Description
TIME_US	DWORD	current system time (resolution [μs])

## 9.3 Reading of the device temperature

### Contents

TEMPERATURE .....	253
-------------------	-----

2364

## 9.3.1 TEMPERATURE

2216

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- ClassicController: CR0032, CR0033
- ExtendedController: CR0232, CR0233
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

2365

TEMPERATURE reads the current temperature in the device.

The FB can be called cyclically and indicates the current device temperature on its output.

### Parameters of the inputs

2366

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active

### Parameters of the outputs

2367

Parameter	Data type	Description
TEMPERATURE	INT	current internal temperature of the device [°C]

## 9.4 Saving, reading and converting data in the memory

### Contents

Manual data storage .....	254
---------------------------	-----

1595

PDM: file functions → chapter **File functions**

### 9.4.1 Manual data storage

#### Contents

GET_TEXT_FROM_FLASH .....	254
MEMCPY .....	256
FLASHWRITE .....	257
FLASHREAD .....	259
FRAMWRITE .....	261
FRAMREAD .....	263


1597

Besides the possibility to store the data automatically, user data can be stored manually, via FB calls, in integrated memories from where they can also be read.

Depending on the device the following memories are available:

Memory / device	Properties
<b>EEPROM memory</b> Available for the following devices: - CabinetController: CR0301, CR0302 - PCB controller: CS0015 - SmartController: CR25nn	Slow writing and reading. Limited writing and reading frequency. Any memory area can be selected. Storing data with E2WRITE. Reading data with E2READ.
<b>FRAM memory <sup>1)</sup></b> Available for the following devices: - CabinetController: CR0303 - ClassicController: CR0020, CR0032, CR0033, CR0505 - ExtendedController: CR0200, CR0232, CR0233 - SafetyController: CR7nnn - PDM360smart: CR1070, CR1071	Fast writing and reading. Unlimited writing and reading frequency. Any memory area can be selected. Storing data with FRAMWRITE. Reading data with FRAMREAD.
<b>Flash memory</b> For all devices	Fast writing and reading. Limited writing and reading frequency. Really useful only for storing large data quantities. Before anew writing, the memory contents must be deleted. Storing data with FLASHWRITE. Reading data with FLASHREAD.

<sup>1)</sup> FRAM indicates here all kinds of non-volatile and fast memories.

 By means of the storage partitioning (→ data sheet or operating instructions) the programmer can find out which memory area is available.

## GET\_TEXT\_FROM\_FLASH

3196


Unit type = function block (FB)

Contained in the library: `ifm_PDMsmart_UTIL_Vxxxyyzz.Lib`

Available for the following devices:

- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

3301

GET\_TEXT\_FROM\_FLASH controls **FLASHREAD** (→ page [259](#)) or **FRAMREAD** (→ page [263](#)) to directly read text of type STRING.

As opposed to PDM360 and PDM360compact, PDM360smart has no file system. Therefore flash memories or FRAM memories <sup>1)</sup> are recommended to store text messages. To read these memory areas FLASHREAD or FRAMREAD is needed.

To ensure reading of one or several texts, the start address of the text must be calculated in the memory. This calculation and setting/resetting of the ENABLE input are made in GET\_TEXT\_FROM\_FLASH.

The texts in the memory must be organised according to the rules below:

#### Text length

The text length should be the same for all texts and is limited to max. 20 characters because of the display size of the PDM360.

#### Text creation

The texts should be created using a spreadsheet program (e.g. Excel) and then saved in CSV format. This CSV file can be directly loaded to the requested memory area using the **ifm** downloader.

→ on the **ecomatmobile** DVD "Software, tools and documentation":

- DE: description "Batchverarbeitung\_ifm.pdf" (→ \doku\_d)
- UK: description "Batchmode\_ifm.pdf" (→ \doku\_gb)

A STRING is automatically terminated with a NULL byte by the programming system. Therefore a text of 20 characters uses 21 bytes in the memory. The FB takes this into account for the calculation. With a text length of 20 characters  $16394/21 = 780$  texts can be saved in the flash memory.

<sup>1)</sup> FRAM indicates here all kinds of non-volatile and fast memories.

## Parameters of the inputs

3302

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
TEXT_UP	BOOL	edge FALSE → TRUE: read next text
TEXT_DOWN	BOOL	edge FALSE → TRUE: read previous text
TEXT_MIN	WORD	lower limit for MESSAGE_NO
TEXT_MAX	WORD	upper limit for MESSAGE_NO
TEXT_LENGTH	BYTE	text length
MESSAGE_NO	WORD	text number
NULL_TERMINATE	BOOL	TRUE: string has null termination FALSE: string has no null termination

## Parameters of the outputs

3303

Parameter	Data type	Description
READ	BOOL	command read ► Set this signal on input ENABLE of FLASHREAD or FRAMREAD!
START_ADR	WORD	calculated start address ► Set this signal to the input SCR of FLASHREAD or FRAMREAD!
ACTIV	BOOL	is TRUE if input ENABLE = 1
ACT_MESSAGE_NO	WORD	current text number



## MEMCPY

409


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxyyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

412

MEMCPY enables writing and reading different types of data directly in the memory.

The FB writes the contents of the address of SRC to the address DST. In doing so, as many bytes as indicated under LEN are transmitted. So it is also possible to transmit exactly one byte of a word file.

- The address must be determined by means of the operator ADR and assigned to the FB!

### Parameters of the inputs

413

Parameter	Data type	Description
DST	DWORD	address of the target variables ► The address must be determined by means of the operator ADR and assigned to the FB!
SRC	DWORD	address of the source variables ► The address must be determined by means of the operator ADR and assigned to the FB!
LEN	WORD	number of data bytes

## FLASHWRITE

555

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

558

#### **WARNING**

Danger due to uncontrollable process operations!

The status of the inputs/outputs is "frozen" during execution of FLASHWRITE.


- Do not execute this FB when the machine is running!

FLASHWRITE enables writing of different data types directly into the flash memory.

The FB writes the contents of the address SRC into the flash memory. In doing so, as many bytes as indicated under LEN are transmitted.

- The address must be determined by means of the operator ADR and assigned to the FB!

An erasing operation must be carried out before the memory is written again. This is done by writing any content to the address "0".

 Using this FB, large data volumes are to be stored during set-up, to which there is only read access in the process.

## Parameters of the inputs

559

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
DST	WORD CR0301, CR0302, CS0015: INT	relative start address in the memory (→ table below)
LEN	WORD CR0301, CR0302, CS0015: INT	number of data bytes (→ table below)
SRC	DWORD CR0301, CR0302, CS0015: DINT	address of the source variables ► The address must be determined by means of the operator ADR and assigned to the FB!

Device	permissible values for DST dec   hex		permissible values for LEN dec   hex	
CabinetController: CR030n	0...16 383	0...3FFF	0...16 383	0...3FFF
ClassicController: CR0020, CR0505	0...65 535	0...FFFF	0...65 535	0...FFFF
ExtendedController: CR0200	0...65 535	0...FFFF	0...65 535	0...FFFF
PCB controller: CS0015	0...16 383	0...3FFF	0...16 383	0...3FFF
SafetyController: CR7021, CR7201, CR7506	0...65 535	0...FFFF	0...65 535	0...FFFF
SmartController: CR25nn	0...65 535	0...FFFF	0...65 535	0...FFFF
PDM360smart: CR1070, CR1071	0...16 383	0...3FFF	0...16 384	0...4000

## FLASHREAD

561

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

564

FLASHREAD enables reading of different types of data directly from the flash memory.

The FB reads the contents as from the address of SRC from the flash memory. In doing so, as many bytes as indicated under LEN are transmitted.

- The address must be determined by means of the operator ADR and assigned to the FB!

### Parameters of the inputs

565

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
SRC	WORD CR0301, CR0302, CS0015: INT	relative start address in the memory (→ table below)
LEN	WORD CR0301, CR0302, CS0015: INT	number of data bytes (→ table below)
DST	DWORD CR0301, CR0302, CS0015: DINT	address of the target variables ► The address must be determined by means of the operator ADR and assigned to the FB!

Device	permissible values for SRC dec   hex		permissible values for LEN dec   hex	
CabinetController: CR030n	0...16 383	0...3FFF	0...16 383	0...3FFF
ClassicController: CR0020, CR0505	0...65 535	0...FFFF	0...65 535	0...FFFF
ExtendedController: CR0200	0...65 535	0...FFFF	0...65 535	0...FFFF
PCB controller: CS0015	0...16 383	0...3FFF	0...16 383	0...3FFF
SafetyController: CR7021, CR7201, CR7506	0...65 535	0...FFFF	0...65 535	0...FFFF
SmartController: CR25nn	0...16 383	0...3FFF	0...16 383	0...3FFF
PDM360smart: CR1070, CR1071	0...16 383	0...3FFF	0...16 384	0...4000

## FRAMWRITE

543

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR0303
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- SafetyController: CR7nnn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

546

FRAMWRITE enables the quick writing of different data types directly into the FRAM memory <sup>1)</sup>.

The FB writes the contents of the address SRC to the non-volatile FRAM memory. In doing so, as many bytes as indicated under LEN are transmitted.

- The address must be determined by means of the operator ADR and assigned to the FB!

The FRAM memory can be written in several partial segments which are independent of each other. Monitoring of the memory segments must be carried out in the application program.

<sup>1)</sup> FRAM indicates here all kinds of non-volatile and fast memories.

### Parameters of the inputs

547

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
DST	WORD CR0303: INT	relative start address in the memory (→ table below)
LEN	WORD CR0303: INT	number of data bytes (→ table below)
SRC	DWORD CR0303: DINT	address of the source variables ► The address must be determined by means of the operator ADR and assigned to the FB!

Device	permissible values for DST dec   hex		permissible values for LEN dec   hex	
CabinetController: CR0303	512...2 047	200...7FF	0...128	0...80
ClassicController: CR0020, CR0505	0...1 023	0...3FF		
ExtendedController: CR0200	0...1 023	0...3FF		
SafetyController: CR7021, CR7201, CR7506	0...1 023	0...3FF		
PDM360smart: CR1070, CR1071	512...2 047	200...7FF	0...128	0...80

© ifm electronic gmbh

## FRAMREAD

549

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR0303
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- SafetyController: CR7nnn
- PDM360smart: CR1070, CR1071

### Symbol in CoDeSys:



### Description

552

FRAMREAD enables quick reading of different data types directly from the FRAM memory <sup>1)</sup>.

The FB reads the contents as from the address of SRC from the FRAM memory. In doing so, as many bytes as indicated under LEN are transmitted.

- The address must be determined by means of the operator ADR and assigned to the FB!

The FRAM memory can be read in several independent partial segments. Monitoring of the memory segments must be carried out in the application program.

<sup>1)</sup> FRAM indicates here all kinds of non-volatile and fast memories.

### Parameters of the inputs

553

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
SRC	WORD CR0303: INT	relative start address in the memory (→ table below)
LEN	WORD CR0303: INT	number of data bytes (→ table below)
DST	DWORD CR0303: DINT	address of the target variables ► The address must be determined by means of the operator ADR and assigned to the FB!



Device	permissible values for SRC dec   hex		permissible values for LEN dec   hex	
CabinetController: CR0303	0...2 047	0...7FF	0...128	0...80
ClassicController: CR0020, CR0505	0...1 023	0...3FF		
ExtendedController: CR0200	0...1 023	0...3FF		
SafetyController: CR7021, CR7201, CR7506	0...1 023	0...3FF		
PDM360smart: CR1070, CR1071	0...2 047	0...7FF	0...128	0...80

© ifm electronic gmbh

## 9.5 Data access and data check

### Contents

SET_IDENTITY .....	266
GET_IDENTITY .....	268
SET_PASSWORD .....	270
CHECK_DATA .....	271

1598

The FBs described in this chapter control the data access and enable a data check.

## 9.5.1 SET\_IDENTITY

284

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:




### Description

287

SET\_IDENTITY sets an application-specific program identification.

Using this FB, a program identification can be created by the application program. This identification (i.e. the software version) can be read via the software tool DOWNLOADER.EXE in order to identify the loaded program.

The following figure shows the correlations of the different identifications as indicated by the different software tools. (Example: ClassicController CR0020):



\*) ⓘ 'Nozzle in front' is substitutionally here for a customised text.

## Parameters of the inputs

288

Parameter	Data type	Description
ID	STRING(80)	any string with a maximum length of 80 characters

## 9.5.2 GET\_IDENTITY

2212

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

2344

GET\_IDENTITY reads the application-specific program identification stored in the controller.

With this FB the stored program identification can be read by the application program. The following information is available:

- Hardware name and version  
e.g.: "CR0032 00.00.01"
- Name of the runtime system  
e.g.: "CR0032"
- Version and build of the runtime system  
e.g.: "V00.00.01 071128"
- Name of the application  
e.g.: "Crane1704"

The name of the application can be changed with **SET\_IDENTITY** (→ page [266](#)).

## Parameters of the inputs

2609

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active

## Parameters of the outputs

2610

Parameter	Data type	Description
DEVICENAME	STRING(31)	hardware name and version as string of max. 31 characters e.g.: "CR0032 00.00.01"
FIRMWARE	STRING(31)	name of the runtime system as string of max. 31 characters e.g.: "CR0032"
RELEASE	STRING(31)	version and build of the runtime system as string of max. 31 characters e.g.: "V00.00.01 071128"
APPLICATION	STRING(79)	name of the application as string of max. 79 characters e.g.: "Crane1704"

## 9.5.3 SET\_PASSWORD

266

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

269

SET\_PASSWORD sets a user password for the program and memory upload with the DOWNLOADER.

If the password is activated, reading of the application program or the data memory with the software tool DOWNLOADER is only possible if the correct password has been entered.


If an empty string (default condition) is assigned to the input PASSWORD, an upload of the application software or of the data memory is possible at any time.

### NOTICE

Please note for CR250n, CR0301, CR0302 and CS0015:

The EEPROM memory module may be destroyed by the permanent use of this unit!

- ▶ Only carry out the unit **once** during initialisation in the first program cycle!
- ▶ Afterwards block the unit again with ENABLE = FALSE!

 The password is reset when loading a new application program.

### Parameters of the inputs

270

Parameter	Data type	Description
ENABLE	BOOL	TRUE (only 1 cycle): ID set  FALSE: unit is not executed
PASSWORD	STRING(16)	password (maximum string length 16)

## 9.5.4 CHECK\_DATA

603


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SafetyController: CR7nnn
- SmartController: CR25nn
- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

606

CHECK\_DATA stores the data in the application data memory via a CRC code.

The FB serves for monitoring a range of the data memory (possible WORD addresses as from %MW0) for unintended changes to data in safety-critical applications. To do so, the FB determines a CRC checksum of the indicated data range.

- The address must be determined by means of the operator ADR and assigned to the FB!
- In addition, the number of data bytes LENGTH (length as from the STARTDR) must be indicated.

If the input UPDATE = FALSE and data in the memory are changed inadvertently, RESULT = FALSE. The result can then be used for further actions (e.g. deactivation of the outputs).

Data changes in the memory (e.g. by the application program or *ecomatmobile* device) are only permitted if the output UPDATE is set to TRUE. The value of the checksum is then recalculated. The output RESULT is permanently TRUE again.

**!** This FB is a safety function. However, the controller does not automatically become a safety controller by using this FB. Only a tested and approved controller with a special operating system can be used as safety controller.



## Parameters of the inputs

607

Parameter	Data type	Description
STARTADR	DINT	start address of the monitored data memory (WORD address as from %MW0)
LENGTH	WORD	length of the monitored data memory in [byte]
UPDATE	BOOL	TRUE: changes to data permissible FALSE: changes to data not permitted

## Parameters of the outputs


608

Parameter	Data type	Description
RESULT	BOOL	TRUE: CRC checksum ok FALSE: CRC checksum faulty (data modified)
CHECKSUM	WORD	result of the CRC checksum evaluation

## Example: CHECK\_DATA

4168

In the following example the program determines the checksum and stores it in the RAM via pointer pt:



**!** The method shown here is not suited for the flash memory.

# 10 Optimising the PLC cycle

## Contents

Processing interrupts.....	274
Controlling the cycle time .....	280

8609

Here we show you functions to optimise the PLC cycle.

## 10.1 Processing interrupts

### Contents

SET_INTERRUPT_XMS .....	274
SET_INTERRUPT_I .....	277

1599

The PLC cyclically processes the stored application program in its full length. The cycle time can vary due to program branchings which depend e.g. on external events (= conditional jumps). This can have negative effects on certain functions.

By means of systematic interrupts of the cyclic program it is possible to call time-critical processes independently of the cycle in fixed time periods or in case of certain events.

Since interrupt functions are principally not permitted for SafetyControllers, they are thus not available.

## 10.1.1 SET\_INTERRUPT\_XMS

272


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0032, CR0033, CR0505
- ExtendedController: CR0200, CR0232, CR0233
- PCB controller: CS0015
- SmartController: CR25nn
- PDM360smart: CR1071

Symbol in CoDeSys:



### Description

275

SET\_INTERRUPT\_XMS handles the execution of a program part at an interval of x ms.

In the conventional PLC the cycle time is decisive for real-time monitoring. So, the PLC is at a disadvantage as compared to customer-specific controllers. Even a "real-time operating system" does not change this fact when the whole application program runs in one single block which cannot be changed.

A possible solution would be to keep the cycle time as short as possible. This often leads to splitting the application up to several control cycles. This, however, makes programming complex and difficult.

Another possibility is to call a certain program part at fixed intervals (every x ms) independently of the control cycle.

The time-critical part of the application is integrated by the user in a block of the type PROGRAM (PRG). This block is declared as the interrupt routine by calling SET\_INTERRUPT\_XMS once (during initialisation). As a consequence, this program block is always processed after the REPEATTIME has elapsed (every x ms). If inputs and outputs are used in this program part, they are also read and written in the defined cycle. Reading and writing can be stopped via the FB inputs READ\_INPUTS, WRITE\_OUTPUTS and ANALOG\_INPUTS.

So, in the program block all time-critical events can be processed by linking inputs or global variables and writing outputs. So, timers can be monitored more precisely than in a "normal cycle".

**NOTE**

To avoid that the program block called by interrupt is additionally called cyclically, it should be skipped in the cycle (with the exception of the initialisation call).

Several timer interrupt blocks can be active. The time requirement of the interrupt functions must be calculated so that all called functions can be executed. This in particular applies to calculations, floating point arithmetic or controller functions.

**Please note:** In case of a high CAN bus activity the set REPEATTIME may fluctuate.

**NOTE**

The uniqueness of the inputs and outputs in the cycle is affected by the interrupt routine. Therefore only part of the inputs and outputs is serviced. If initialised in the interrupt program, the following inputs and outputs will be read or written.

**Inputs, digital:**

%IX0.0...%IX0.7 (CRnn32)  
%IX0.12...%IX0.15, %IX1.4...%IX1.8 (all other ClassicController, ExtendedController, SafetyController)  
%IX0.0, %IX0.8 (SmartController)  
IN08...IN11 (CabinetController)  
IN0...IN3 (PCB controller)

**Inputs, analogue:**

%IX0.0...%IX0.7 (CRnn32)  
All channels (selection bit-coded) (all other controller)

**Outputs, digital:**

%QX0.0...%QX0.7 (ClassicController, ExtendedController, SafetyController)  
%QX0.0, %QX0.8 (SmartController)  
OUT00...OUT03 (CabinetController)  
OUT0...OUT7 (PCB controller)

Global variants, too, are no longer unique if they are accessed simultaneously in the cycle and by the interrupt routine. This problem applies in particular to larger data types (e.g. DINT).

All other inputs and outputs are processed once in the cycle, as usual.

## Parameters of the inputs

276

Parameter	Data type	Description
ENABLE	BOOL	TRUE (only 1 cycle): changes to data allowed  FALSE: changes to data not allowed (during processing of the program)
REPEATTIME	TIME	Time window during which the interrupt is triggered.
READ_INPUTS	BOOL	TRUE: inputs integrated into the routine are read (if necessary, set inputs to IN_FAST).  FALSE: this function is not executed
WRITE_OUTPUTS	BOOL	TRUE: outputs integrated into the routine are written to.  FALSE: this function is not executed
ANALOG_INPUTS	BYTE	(only for devices with analogue channels)  TRUE: analogue inputs integrated into the routine are read and the raw value of the voltage is transferred to the system flags ANALOG_IRQxx  FALSE: this function is not executed

## 10.1.2 SET\_INTERRUPT\_I

278


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- CabinetController: CR030n
- ClassicController: CR0020, CR0505
- ExtendedController: CR0200
- PCB controller: CS0015
- SmartController: CR25nn
- PDM360smart: CR1071

Symbol in CoDeSys:



### Description

281

**SET\_INTERRUPT\_I** handles the execution of a program part by an interrupt request via an input channel.

In the conventional PLC the cycle time is decisive for real-time monitoring. So the PLC is at a disadvantage as compared to customer-specific controllers. Even a "real-time operating system" does not change this fact when the whole application program runs in one single block which cannot be changed.

A possible solution would be to keep the cycle time as short as possible. This often leads to splitting the application up to several control cycles. This, however, makes programming complex and difficult.

Another possibility is to call a certain program part only upon request by an input pulse independently of the control cycle.

The time-critical part of the application is integrated by the user in a block of the type PROGRAM (PRG). This block is declared as the interrupt routine by calling **SET\_INTERRUPT\_I** once (during initialisation). As a consequence, this program block will always be executed if an edge is detected on the input **CHANNEL**. If inputs and outputs are used in this program part, these are also read and written in the interrupt routine, triggered by the input edge. Reading and writing can be stopped via the FB inputs **READ\_INPUTS**, **WRITE\_OUTPUTS** and **ANALOG\_INPUTS**.

So in the program block all time-critical events can be processed by linking inputs or global variables and writing outputs. So FBs can only be executed if actually called by an input signal.

**NOTE**

The program block should be skipped in the cycle (except for the initialisation call) so that it is not cyclically called, too.

The input (CHANNEL) monitored for triggering the interrupt cannot be initialised and further processed in the interrupt routine.

The inputs must be in the operating mode IN\_FAST, otherwise the interrupts cannot be read.

**NOTE**

The uniqueness of the inputs and outputs in the cycle is affected by the interrupt routine. Therefore only part of the inputs and outputs is serviced. If initialised in the interrupt program, the following inputs and outputs will be read or written.

**Inputs, digital:**

%IX0.0...%IX0.7 (CRnn32)

%IX0.12...%IX0.15, %IX1.4...%IX1.8 (all other ClassicController, ExtendedController, SafetyController)

%IX0.0, %IX0.8 (SmartController)

IN08...IN11 (CabinetController)

IN0...IN3 (PCB controller)

**Inputs, analogue:**

%IX0.0...%IX0.7 (CRnn32)

All channels (selection bit-coded) (all other controller)

**Outputs, digital:**

%QX0.0...%QX0.7 (ClassicController, ExtendedController, SafetyController)

%QX0.0, %QX0.8 (SmartController)

OUT00...OUT03 (CabinetController)

OUT0...OUT7 (PCB controller)

Global variants, too, are no longer unique if they are accessed simultaneously in the cycle and by the interrupt routine. This problem applies in particular to larger data types (e.g. DINT).

All other inputs and outputs are processed once in the cycle, as usual.

## Parameters of the inputs

282

Parameter	Data type	Description
ENABLE	BOOL	TRUE (only for 1 cycle): changes to data permissible  FALSE: changes to data not permitted (during processing of the program)
CHANNEL	BYTE	interrupt input  Classic/ExtendedController: 0 = %IX1.4 1 = %IX1.5 2 = %IX1.6 3 = %IX1.7  SmartController: 0 = %IX0.0 1 = %IX0.8  CabinetController: 0 = IN08 (etc.) 3 = IN11  CS0015: 0 = IN0 (etc.) 3 = IN3
MODE	BYTE	type of edge at the input CHANNEL which triggers the interrupt  1 = rising edge 2 = falling edge 3 = rising and falling edge
READ_INPUTS	BOOL	TRUE: inputs integrated into the routine are read (if necessary, set inputs to IN_FAST)  FALSE: this function is not executed
WRITE_OUTPUTS	BOOL	TRUE: outputs integrated into the routine are written  FALSE: this function is not executed
ANALOG_INPUTS	BYTE	(only for devices with analogue channels)  selection of the inputs bit-coded:  0 <sub>10</sub> = no input selected 1 <sub>10</sub> = 1st analogue input selected (0000 0001 <sub>2</sub> ) 2 <sub>10</sub> = 2nd analogue input selected (0000 0010 <sub>2</sub> ) ... 128 <sub>10</sub> = 8th analogue input selected (1000 0000 <sub>2</sub> )  A combination of the inputs is possible via an OR operation of the values. Example: Select 1st and 3rd analogue input: (0000 0001 <sub>2</sub> ) OR (0000 0100 <sub>2</sub> ) = (0000 0101 <sub>2</sub> ) = 5 <sub>10</sub>



## 10.2 Controlling the cycle time

### Contents

PLCPRGTC .....	281
----------------	-----

3142

© ifm electronic gmbh

## 10.2.1 PLCPRGTC

9954

Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:




### Description


9955

PLCPRGTC allows to change the call cycle time for PLC\_PRG for time-critical applications.

If the module is not integrated, the update of the visualisation is automatically interrupted every 10 ms and PLC\_PRG and the resulting program parts are executed. The remaining time is used for updating the visualisation. Example:



If PLC\_PRG is to be processed more often (e.g. to process fast signals), the function block PLCPRGTC allows to reduce the cycle time for calling the PLC\_PRG. Example:



### NOTE

For a shorter task time for PLC\_PRG less time remains for updating the visualisation.

In the worst case, this can lead to a considerably delayed loading of the screen and to a loss of display values.

## Parameters of the inputs

9957

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
TASKCYCLE	TIME	Cycle time for task request of the visualisation

© ifm electronic gmbh

# 11 LED, buzzer, visualisation

<b>Contents</b>	
Manage visualisation.....	284
	8615

Here we show the following functions:

- LED control
- Buzzer control
- Management of the visualisation

## 11.1 Manage visualisation

<b>Contents</b>	
PDMsmart_MAIN .....	284
PDMsmart_MAIN_MAPPER .....	287
PDM_PAGECONTROL.....	288
Library Instrumente .....	290
	8617

Here we show you function to manage visualisations.

## 11.1.1 PDMsmart\_MAIN

9928

Unit type = program (PRG)

Contained in the library: `ifm_PDMsmart_INIT_Vxxxyyzz.LIB`

Available for the following devices:

- PDM360smart: CR1070, CR1071

### Symbol in CoDeSys:



### Description

9930

PDMsmart\_MAIN contains the following important FBs for the initialisation of the PDM360:

- PDM\_OPEN\_IO
- PDM\_KEY
- PDM\_LED
- PDM\_ENC\_DATA

You should integrate PDMsmart\_MAIN into each PDM project. Otherwise the FBs described above must be processed step by step.

### **NOTE**

If PDMsmart\_MAIN is used, the single FBs indicated above must not be used.

If the single FBs indicated above are used, PDMsmart\_MAIN must not be used.

► You should integrate PDMsmart\_MAIN into one of the first networks of the application program.

**!** Setting the input INIT to TRUE is only allowed in the first program cycle.

If you want to check whether the initialisation of PDMsmart\_MAIN was successful:

► Read the status of the variable PDM\_FILE\_OPEN\_ERROR.

> If PDM\_FILE\_OPEN\_ERROR = TRUE → initialisation failed  
(e.g. input INIT was not reset).

## Parameters of the inputs

3529

Parameter	Data type	Description
INIT	BOOL	TRUE (for only 1 cycle): unit is initialised  FALSE: during further processing of the program

## Global variable of this program

9931

All variables of this program are stored in the global variables of the library.

Name	Data type	Description
SOFTKEY_F1	BOOL	TRUE = function key F1 pressed
... SOFTKEY_F6		... TRUE = function key F6 pressed
SOFTKEY_ESC	BOOL	TRUE = function key ESC pressed
SOFTKEY_OK	BOOL	TRUE = function key OK pressed
SOFTKEY_LEFT	BOOL	TRUE = function key LEFT pressed
SOFTKEY_RIGHT	BOOL	TRUE = function key RIGHT pressed
SOFTKEY_DOWN	BOOL	TRUE = function key DOWN pressed
SOFTKEY_UP	BOOL	TRUE = function key UP pressed

Further variables are defined as system flag in the system control:

→ **Address assignment inputs / outputs** (→ page [301](#))

## 11.1.2 PDMsmart\_MAIN\_MAPPER

9923


Unit type = function block (FB)

Contained in the library: `ifm_CRnnnn_Vxxyyzz.LIB`

Available for the following devices:

- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

9925

The program `PDMsmart_MAIN_MAPPER` is the interface between CoDeSys keyboard commands for handling the visualisation and the runtime system of the PDM. The entries via the PC keyboard are emulated by setting/resetting the individual inputs.

## Parameters of the inputs

9926

Parameter	Data type	Description
DIRECTION	BOOL	<p>corresponds to the PC key [[Shift] useful with the input TAB:</p> <p>TRUE:     The cursor moves to the previous element</p> <p>FALSE:    The cursor moves to the next element</p>
TAB	BOOL	<p>TRUE (first pulse): selection of the first element of the element list for which editing is configured</p> <p>TRUE (next pulse) and DIRECTION=FALSE: continue to the next element which is enabled for editing</p> <p>TRUE (next pulse) and DIRECTION=TRUE: return to the previous element which is enabled for editing</p> <p>FALSE:    this function is not executed</p>
SPACE	BOOL	<p>TRUE (first pulse): activate the selected visualisation element. Depending on the selected input mode navigation is possible in the input field</p> <p>TRUE (second pulse): finish input; write the (new) value to the PDM</p> <p>FALSE:    this function is not executed</p>
ESC	BOOL	<p>TRUE (pulse): abort the edit mode; do not change the value</p> <p>FALSE:    this function is not executed</p>
KEY_LEFT	BOOL	<p>TRUE (pulse) and input mode=position: shift the cursor in the input field one position to the left</p> <p>FALSE:    this function is not executed</p>
KEY_RIGHT	BOOL	<p>TRUE (pulse) and input mode=position: Cursor im Eingabefeld um eine Position nach rechts verschieben</p> <p>FALSE:    this function is not executed</p>
KEY_DOWN	BOOL	<p>TRUE (pulse) and input mode=step increment: decrease the value in the input field by the indicated step increment</p> <p>FALSE:    this function is not executed</p>
KEY_UP	BOOL	<p>TRUE (pulse) and input mode=step increment: increase the value in the input field by the indicated step increment</p> <p>FALSE:    this function is not executed</p>
TAB_DELAY_TIME	TIME	<p>time delay for the input TAB typical values: 250...400 ms</p> <p>set the value a little higher than the interval time VISU_TASK</p>




## 11.1.3 PDM\_PAGECONTROL

3186

Unit type = program (PRG)

Contained in the library:	Available for the following devices:
ifm_PDM_UTIL_Vxxyzz.LIB	- PDM360: CR1050, CR1051 - PDM360compact: CR1052, CR1053, CR1055, CR1056
ifm_PDMng_UTIL_Vxxyzz.LIB	- PDM360NG: CR108n
ifm_PDMsmart_UTIL_Vxxyzz.LIB	- PDM360smart: CR1070, CR1071

Symbol in CoDeSys:



### Description

3294

PDM\_PAGECONTROL controls the opening of certain visualisation pages. In CoDeSys the visualisation pages are opened and feedback is given via the system variable CurrentVisu (type STRING[40]).

With this program it is possible to open a selected visualisation page or to scroll through the visualisations step by step.

Optimum use of the program is ensured when all visualisation names correspond to the same pattern, i.e. a combination of a basename followed by a 5-digit number (library version V04.00.07 or higher; before: 3-digit \*).

Example BASENAME = PAGE:

Visualisation name = PAGE00001, PAGE00002, PAGE00003, etc.

For the basename 1...35 capital letters (no special characters) are allowed. The visualisations should be numbered consecutively. The program creates the final visualisation name from the parameter BASENAME and the number or reads the number from the current visualisation name and provides it in the output parameter ACT\_PAGE.

Instead of naming the visualisations with basename and consecutive number every visualisation can also be named individually, e.g. SERVICE1, MOTORDATA2, CONFIGURATION3. In this case, however, programming is more complex because basename and visualisation number must be assigned individually. Scrolling step by step is then very restricted.

**I** Use the letter P as BASENAME, your program is then compatible with the *ifm* templates.

\*) **I** Also note the new 5-digit numbering when naming your existing visualisation pages!

## Parameters of the inputs

3293

Parameter	Data type	Description
INIT	BOOL	TRUE (only for 1 cycle): Display is initialised with the initialisation indicated in INIT_PAGE.  FALSE: during further processing of the program
INIT_PAGE	WORD	visualisation number which is to be called with INIT
PAGE_UP	BOOL	edge FALSE → TRUE: increments the visualisation number
PAGE_DOWN	BOOL	edge FALSE → TRUE: decrements the visualisation number
PAGE_EXTERN	WORD	The indicated visualisation page is directly opened (independent of PAGE_UP / PAGE_DOWN).  if PAGE_EXTERN = ACT_PAGE, then PAGE_EXTERN is reset "0"!
PAGE_MAX	WORD	maximum number of selectable visualisation pages
BASENAME	STRING [35]	Common part of the name of the visualisation page Visualisation pages are numbered by their names: eg. P00001. The following applies: - "P" = BASENAME (only capital letters!) - "00001" = visualisation number (5 digits!)

## Parameters of the outputs

3295

Parameter	Data type	Description
ACT_PAGE	WORD	current visualisation number

## 11.1.4 Library Instrumente

### Contents

CONTROL_ANALOGCLOCK .....	292
SCALE_LED_GRAF.....	293
SCALE_METER .....	295

3354

### Integration of finished visualisation elements


**I** This library continues to be available to remain compatible with older applications. Instead, we recommend the use of background bitmaps - because of the much better representation.

Also see: Representable → [CoDeSys visualisation elements](#)

The library `Instrumente_x.LIB` provides a number of ready-to-use visualisation elements. You can directly integrate them in your visualisation pages via [Insert] > [Visualization]. The visualisation elements are designed so that the active elements can be animated via placeholders. To do so, the placeholders are directly linked to a variable from the application program. More information is given in the CoDeSys online help under "Placeholders in Visualization".

The library contains the following FBs:

- **CONTROL\_ANALOGCLOCK** (→ page [292](#))  
indicates the current time on the dial of an analogue clock:




Analog\_Clock

- **SCALE\_LED\_GRAF** (→ page [293](#))  
indicates input values as a 10-digit value-dependent LED row:



Visu = Bargraf\_LED10\_H







Visu = Bargraf\_LED10\_H2





Visu = Bargraf\_LED10\_V

- **SCALE\_METER** (→ page [295](#))  
shows input values as a circular scale of a meter:

			
METER_NO = 1	METER_NO = 2	METER_NO = 3	METER_NO = 4
Visu = Meter1	Visu = Meter2	Visu = Meter3	Visu = Meter4

- In addition, the library provides neutral scales as visualisation 2:

	
Visu = ClockFace1	Visu = ClockFace2

## CONTROL\_ANALOGCLOCK

3366

Unit type = program (PRG)

Contained in the library: `Instrumente_x.LIB`

Available for the following devices:

- PDM360: CR1050, CR1051
- PDM360compact: CR1052, CR1053, CR1055, CR1056
- PDM360NG: CR108n
- PDM360smart: CR1070, CR1071


Symbol in CoDeSys:



### Description

3378

CONTROL\_ANALOGCLOCK indicates the current time on the dial of an analogue clock:



### Parameters of the inputs

3379

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
PDM_RTC	DT	system time and date from SysRtcGetTime

## SCALE\_LED\_GRAF

3369


Unit type = function block (FB)

Contained in the library: `Instrumente_x.LIB`

Available for the following devices:

- PDM360: CR1050, CR1051
- PDM360compact: CR1052, CR1053, CR1055, CR1056
- PDM360NG: CR108n
- PDM360smart: CR1070, CR1071


Symbol in CoDeSys:



### Description

3381

SCALE\_LED\_GRAF shows input values as a 10-digit, value-dependent row of LEDs, e.g. one of the 3 visualisations from this library:



The FB represents an input value in relation to a defined value range.

## Parameters of the inputs

3382

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
X	INT	input value
XH	INT	upper limit of the value range
XL	INT	lower limit of the value range
MODE	BYTE	operating mode of the rows of LEDs, value range = 0...10
CHANGEPOINT	BYTE	colour change point for MODE = 9 or 10, value range = 0...10

## Operating mode of the row of LEDs

3383

All variables of this program are stored in the global variables of the library.

Mode	Row of LEDs	Description
1		Red individual segment in a row of LEDs lighting green
2		Green individual segment in a row of LEDs lighting red
3		Red individual segment
4		Green individual segment
5		Red row of segments in a row of LEDs lighting green
6		Green row of segments in a row of LEDs lighting red
7		Red row of segments
8		Green row of segments
9		Red row of segments with colour change point (here CHANGEPOINT = 5)
10		Green row of segments with colour change point (here CHANGEPOINT = 7)

## SCALE\_METER

3372


Unit type = function block (FB)

Contained in the library: `Instrumente_x.LIB`

Available for the following devices:

- PDM360: CR1050, CR1051
- PDM360compact: CR1052, CR1053, CR1055, CR1056
- PDM360NG: CR108n
- PDM360smart: CR1070, CR1071


Symbol in CoDeSys:



### Description

3384

SCALE\_METER shows input values as a circular scale of a meter:



The FB represents an input value in relation to a defined value range.

In the visualisation Meter1, "%s" is used as a placeholder for the parameterised values and unit. In the other visualisations there are no or no definable scale values.



## Parameters of the inputs

3385

Parameter	Data type	Description
ENABLE	BOOL	TRUE: unit is executed FALSE: unit is not executed > POU inputs and outputs are not active
METER_NO	BYTE	1 = meter1 = 270° scale with definable values and unit 2 = meter2 = 270° scale 3 = meter3 = tank display 4 = meter4 = temperature display
X	INT	input value
XH	INT	upper limit of the value range
XL	INT	lower limit of the value range
UNIT	STRING [6]	for METER_NO = 1: unit of measurement in the scale (text)
STARTCOLUM	INT	start value of the scale, e.g.: 10 = scale starts at 10
STEP	INT	step increment of the scale, e.g.: 10 = scale values for 10, 20, 30, ...

## 12 Annex

### Contents

Error and diagnosis .....	298
Address assignment and I/O operating modes .....	299
System flags .....	302
CANopen tables .....	303
Visualisations in the device .....	315
Overview of the files and libraries used .....	333

1664

Additionally to the indications in the data sheets you find summary tables in the annex.

### 12.1 Error and diagnosis

9901

#### 12.1.1 Rectify faults and errors

3109

Here we show you how to react to certain errors and faults to be able to use the device again.

Effect	Cause	Remedy
After a restart of the setup menu from (= soft reset) booting stops with a blank screen.	Rare software error	Hard reset via power OFF / ON
Very long times to change from one image to the other	a) Too many graphical elements in the image b) Too many different character sets (fonts) c) Too many units which are a load for the system d) Units called too often e) Too many REAL variables in the image	Adhere to the recommended limitations! → <b>Limitations and programming notes</b> (→ page 53)
System crash (no reaction)	a) Wrong placeholders for variables in the CoDeSys program	a) Check placeholders: e.g. %s (wrong: %S)
Screen remains dark	Global variable BACKLIGHT set too low	a) Start and exit again the SETUP program → BACKLIGHT = 90 b) Assign a higher value to the BACKLIGHT variable in the application program

## 12.1.2 System messages and operating states

9900

Depending on the operating state different system messages are displayed on the device. All messages are listed in the following list.

System message	Operating status
Bootloader...	Setting at the factory The runtime system (operating system) and an application program have to be loaded.
No Application	No application program has been loaded yet. The runtime system (operating system) is stored in the device.
Application stopped	The execution of the application program was stopped by the programming software. Only the programming system can start it again!
Application running	An application program containing no visualisation has been loaded and started.
Undervoltage Application stopped	Undervoltage was detected. The application program was stopped.
Fatal Error	An intolerable error was found (e.g. storage or CRC error). This state can only be left by a reset (switch on/off).

## 12.2 Address assignment and I/O operating modes

### Contents

Addresses / variables of the I/Os .....	299
Possible operating modes of inputs / outputs .....	301
Address assignment inputs / outputs .....	301

1656

→ also data sheet

## 12.2.1 Addresses / variables of the I/Os

### Contents

Addresses / variables of the inputs .....	300
Addresses / variables of the outputs .....	301

2376

## Addresses / variables of the inputs

9943

IEC address	I/O variable	Note
%QB18 **)	I00_MODE	Configuration byte for %IX0.0
%QB19 **)	I01_MODE	Configuration byte for %IX0.1
%QB20 **)	I02_MODE	Configuration byte for %IX0.2
%QB21 **)	I03_MODE	Configuration byte for %IX0.3
%IX1.0	F1	Function key [F1]
%IX1.1	F2	Function key [F2]
%IX1.2	F3	Function key [F3]
%IX1.3	F4	Function key [F4]
%IX1.4	F5	Function key [F5]
%IX1.5	F6	Function key [F6]
%IX1.6	KEY_ESC	Function key [ESC]
%IX1.7	KEY_UP	Function key [▲]
%IX1.8	KEY_OK	Function key [OK]
%IX1.9	KEY_LEFT	Function key [◀]
%IX1.10	KEY_DOWN	Function key [▼]
%IX1.11	KEY_RIGHT	Function key [▶]
%IW2	SUPPLY_VOLTAGE	WORD supply voltage in [mV]

\*\*) Applies only to the following devices: PDM360smart: CR1071

## Addresses / variables of the outputs

9944

IEC address	I/O variable	Note
%QB2	LED_F1	LED in function key [F1] 0...100 %
%QB3	LED_F2	LED in function key [F2] 0...100 %
%QB4	LED_F3	LED in function key [F3] 0...100 %
%QB5	LED_F4	LED in function key [F4] 0...100 %
%QB6	LED_F5	LED in function key [F5] 0...100 %
%QB7	LED_F6	LED in function key [F6] 0...100 %
%QB8	LED_ESC	LED in function key [ESC] 0...100 %
%QB9	LED_UP	LED in function key [▲] 0...100 %
%QB10	LED_OK	LED in function key [OK] 0...100 %
%QB11	LED_LEFT	LED in function key [◀] 0...100 %
%QB12	LED_DOWN	LED in function key [▼] 0...100 %
%QB13	LED_RIGHT	LED in function key [▶] 0...100 %
%QB14	LED_NIGHT	LED brightness active in night mode
%QB15	LED_MAX_VALUE	LED brightness for normal operation (0...100 %).
%QB16	LED_NIGHT_VALUE	LED brightness for night operation (0...100 %).
%QB17	BACKLIGHT	Background illumination of the display 0...100 %

## 12.2.2 Possible operating modes of inputs / outputs

9950

Applies only to the following devices: PDM360smart: CR1071

Inputs	Operating mode	Config. value	Outputs	Operating mode	Config. value
I00...I03	IN_NOMODE	0	Q00...Q03	OUT_NOMODE	0
	IN_DIGITAL_H (plus)	1		OUT_DIGITAL_H	1 (default)
	IN_VOLTAGE30	16 (default)			
	IN_FAST	128 (default)			

Possible configuration combinations (where permissible) are created by adding the values.

## 12.2.3 Address assignment inputs / outputs

### Contents

Address assignment of the inputs.....	302
Address assignment of the outputs.....	302

2371

### Address assignment of the inputs

9947

Applies only to the following devices: PDM360smart: CR1071

Abbreviations→ chapter [Hints to wiring diagrams](#) (→ page [44](#))

Operating modes of the inputs and outputs → chapter [Possible operating modes of inputs / outputs](#) (→ page [301](#))

IEC address	Name I/O variable	Configuration with variable	Default value	Possible operating modes
%IX0.0	I00	I00_MODE	192	BL / FRQ
%IX0.1	I01	I01_MODE	192	BL / FRQ
%IX0.2	I02	I02_MODE	192	BL / FRQ
%IX0.3	I03	I03_MODE	192	BL / FRQ

### Address assignment of the outputs

9948

Applies only to the following devices: PDM360smart: CR1071

Abbreviations→ chapter [Hints to wiring diagrams](#) (→ page [44](#))

Operating modes of the inputs and outputs → chapter [Possible operating modes of inputs / outputs](#) (→ page [301](#))

IEC address	Name I/O variable	Configuration with variable	Default value	Possible operating modes
%QX0.0	Q00	Q00_MODE	1	Off / H digital / PWM
%QX0.1	Q01	Q01_MODE	1	Off / H digital / PWM
%QX0.2	Q02	Q02_MODE	1	Off / H digital / PWM
%QX0.3	Q03	Q03_MODE	1	Off / H digital / PWM

## 12.3 System flags

9946

System flags	Type	Description
CANx_BUSOFF	BOOL	CAN interface x: interface is not on the bus
CANx_LASTERROR <sup>1)</sup>	BYTE	CAN interface x: error number of the last CAN transmission: 0= no error ≠0 → CAN specification → LEC
CANx_WARNING	BOOL	CAN interface x: warning threshold reached (> 96)
ERROR	BOOL	set the group error message, switch off the relay <sup>*</sup> )
ERROR_IO	BOOL	group error message input/output error
ERROR_MEMORY	BOOL	memory error
ERROR_POWER	BOOL	voltage error: SUPPLY_VOLTAGE < 10000 mV or > 32000 mV
ERROR_TEMPERATUR	BOOL	temperature error (< - 25 °C or > 85 °C)

CANx stands for the number of the CAN interface (CAN 1...x, depending on the device).

<sup>1)</sup> Access to these flags requires detailed knowledge of the CAN controller and is normally not required.

<sup>\*</sup>) Relay exists only in the following devices:

CR0020, CR0032, CR0033, CR0200, CR0232, CR0233, CR0505, CR7020, CR7021, CR7200, CR7201, CR7505, CR7506

## 12.4 CANopen tables

### Contents

IDs (addresses) in CANopen .....	304
Structure of CANopen messages.....	304
Bootup message.....	309
Network management (NMT).....	309
CANopen error code .....	313

9941

The following tables will inform you about important values and settings of the CANopen interfaces.

### 12.4.1 IDs (addresses) in CANopen

3952

In CANopen there are different types of addresses (IDs):

- **COB ID**  
The **Communication Object Identifier** addresses the message (= the communication object) in the list of devices. A communication object consists of one or more CAN messages with a specific functionality, e.g.
  - PDO (**P**rocess **D**ata **O**bject = message object with process data),
  - SDO (**S**ervice **D**ata **O**bject = message object with service data),
  - emergency (message object with emergency data),
  - time (message object with time data) or
  - error control (message object with error messages).
- **CAN ID**  
The **CAN Identifier** defines CAN messages in the complete network. The CAN ID is the main part of the arbitration field of a CAN data frame. The CAN ID value determines implicitly the priority for the bus arbitration.
- **Download ID**  
The download ID indicates the node ID for service communication via SDO for the program download and for debugging.
- **Node ID**  
The **Node Identifier** is a unique descriptor for CANopen devices in the CAN network. The Node ID is also part of some pre-defined connectionsets (→ **Function code / Predefined Connectionset** (→ page 306)).

Comparison of download-ID vs. COB-ID:

Controller program download		CANopen	
Download ID	COB ID SDO	Node ID	COB ID SDO
1...127	TX: 580 <sub>16</sub> + download ID	1...127	TX: 580 <sub>16</sub> + node ID
	RX: 600 <sub>16</sub> + download ID		RX: 600 <sub>16</sub> + node ID

TX = slave sends to master  
RX = slave receives from master



## 12.4.2 Structure of CANopen messages

### Contents

Structure of the COB ID .....	305
Function code / Predefined Connectionset .....	306
SDO command bytes .....	307
SDO abort code .....	308

9971

A CANopen message consists of the COB ID and up to 8-byte data:

COB ID			DLC	Byte 1		Byte 2		Byte 3		Byte 4		Byte 5		Byte 6		Byte 7		Byte 8	
X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X

Details are given in the following chapters.

**!** Please note the reversed byte order!

### Examples:

Value [hex]	Data type	Byte 1		Byte 2		Byte 3		Byte 4		Byte 5		Byte 6		Byte 7		Byte 8	
12	BYTE	1	2	–	–	–	–	–	–	–	–	–	–	–	–	–	–
1234	WORD	3	4	1	2	–	–	–	–	–	–	–	–	–	–	–	–
12345678	DWORD	7	8	5	6	3	4	1	2	–	–	–	–	–	–	–	–

### Structure of the COB ID

9972

The first part of a message is the COB ID. Structure of the 11-bit COB ID:

Nibble 0				Nibble 1				Nibble 2			
11	10	9	8	7	6	5	4	3	2	1	0
--	3	2	1	0	6	5	4	3	2	1	0
--	function code				node ID						

The COB ID consists of the **Function code / Predefined Connectionset** (→ page 306) and the node ID.

### Example:

Communication object = TPDO1 (TX)

Node number of the device =  $20_{16} = 32_{10}$

### Calculation:

Function code for the communication object TPDO1 =  $3_{16}$

Significance of the function code in the 11-bit COB ID =  $3_{16} \times 80_{16} = 180_{16}$

Add the node number ( $20_{16}$ ) ⇒ the COB ID is:  $1A0_{16}$

1				A				0			
3	2	1	0	3	2	1	0	3	2	1	0
0	0	0	1	1	0	1	0	0	0	0	0
--	$3_{16} = 3_{10}$				$20_{16} = 32_{10}$						

## Function code / Predefined Connectionset

9966

In the "CANopen Predefined Connectionset" some function codes are predefined.

When using the predefined connectionset you can operate a CANopen network of up to 127 participants without the risk of a double assignment of COB IDs.

Broadcast or multicast messages:

Communication object	Function code [hex]	COB ID [hex]	Related parameter objects [hex]
NMT	0	000	
SYNC	1	080	1005, 1006, 1007, 1028
TIME	2	100	1012, 1013

Point-to-point messages:

Communication object	Function code [hex]	COB ID [hex]	Related parameter objects [hex]
EMERGENCY	1	080 + node ID	1014, 1015
TPDO1 (TX)	3	180 + node ID	1800
RPDO1 (RX)	4	20016 + node ID	1400
TPDO2 (TX)	5	280 + node ID	1801
RPDO2 (RX)	6	30016 + node ID	1401
TPDO3 (TX)	7	380 + node ID	1802
RPDO3 (RX)	8	400 + node ID	1402
TPDO4 (TX)	9	480 + node ID	1803
RPDO4 (RX)	A	500 + node ID	1403
Default SSDO (TX)	B	58016 + node ID	1200
Default CSDO (RX)	C	60016 + node ID	1280
NMT Error Control	E	70016 + node ID	1016, 1017

TX = slave sends to master

RX = slave receives from master

SSDO = server SDO

CSDO = client SDO

## SDO command bytes

9968

Structure of an SDO message:

COB ID	DLC	Command	Index		Sub-index	Data *)			
XXX	8	byte	byte 0	byte 1	byte	byte 0	byte 1	byte 2	byte 3

\*) depending on the data to be transmitted

**!** Please note the reversed byte order!

An SDO COB ID consists of:

CANopen	
Node ID	COB ID SDO
1...127	TX: 580 <sub>16</sub> + node ID
	RX: 600 <sub>16</sub> + node ID

TX = slave sends to master

RX = slave receives from master

DLC (data length code) indicates the number of the data bytes (for SDO: DLC = 8).

SDO command bytes:

Command hex   dec	Message	Data length	Description
21   33	request	more than 4 bytes	send data to slave
22   34	request	1...4 bytes	send data to slave
23   35	request	4 bytes	send data to slave
27   39	request	3 bytes	send data to slave
2B   43	request	2 bytes	send data to slave
2F   47	request	1 byte	send data to slave
40   64	request	---	request data from slave
42   66	response	1...4 bytes	send data from slave to master
43   67	response	4 bytes	send data from slave to master
47   71	response	3 bytes	send data from slave to master
4B   75	response	2 bytes	send data from slave to master
4F   79	response	1 byte	send data from slave to master
60   96	response	---	data transfer ok: send confirmation of receipt from slave to master
80   128	response	4 bytes	data transfer failed send abort message from slave to master → chapter <b>SDO abort code</b> (→ page <a href="#">308</a> )

## SDO abort code

9970

**i** The SDO abort code is NOT part of the emergency message!

Abord code [hex]	Description
0503 0000	toggle bit not alternated
0504 0000	SDO protocol timed out
0504 0001	client/server command specifier not valid or unknown
0504 0002	invalid block size (block mode only)
0504 0003	invalid sequence number (block mode only)
0504 0004	CRC error (block mode only)
0504 0005	out of memory
0601 0000	unsupported access to an object
0601 0001	attempt to read a write only object
0601 0002	attempt to write a read only object
0602 0000	object does not exist in the object dictionary
0604 0041	object cannot be mapped to the PDO
0604 0042	the number and length of the objects to be mapped would exceed PDO length
0604 0043	general parameter incompatibility reason
0604 0047	general internal incompatibility in the device
0606 0000	access failed due to an hardware error
0607 0010	data type does not match, length of service parameter does not match
0607 0012	data type does not match, length of service parameter too high
0607 0013	data type does not match, length of service parameter too low
0609 0011	sub-index does not exist
0609 0030	value range of parameter exceeded (only for write access)
0609 0031	value of parameter written too high
0609 0032	value of parameter written too low
0609 0036	maximum value is less than minimum value
0800 0000	general error
0800 0020	data cannot be transferred or stored to the application
0800 0021	data cannot be transferred or stored to the application because of local control
0800 0022	data cannot be transferred or stored to the application because of the present device state
0800 0023	object dictionary dynamic generation fails or no object dictionary is present (e.g. object dictionary is generated from file and generation fails because of an file error)

## 12.4.3 Bootup message

9961

After booting the CAN participate sends the boot-up message once:

	Byte 1	Byte 0
hex	$700_{16} + \text{node ID}$	NMT state
dec	$1\,792_{10} + \text{node ID}$	NMT state

The participant is now capable of communicating in the CAN network.

Structure:

The node ID of the participant is  $7D_{16} = 125_{10}$ .

The byte 1 of the boot-up message is:  $77D_{16} = 1\,917_{10}$

**!** There are units that cannot send  $[700_{16} + \text{node ID}]$ .

Instead these units send the following bootup message and without state:

hex	$80_{16} + \text{node ID}$
dec	$128_{10} + \text{node ID}$

## 12.4.4 Network management (NMT)

9974

### Network management commands

9962

With the following network management commands the user can influence the operating mode of individual or all CAN participants. Structure:

Byte 1	Byte 2	Byte 2
COB ID	command	node ID


Node ID = 00  $\Rightarrow$  command valid for all nodes in the network at the same time

COB ID	NMT command		Description	
00	$01_{16} = 01_{10}$	node ID	start_remode_node	start CAN participate
00	$02_{16} = 02_{10}$	node ID	stop_remode_node	stop CAN participate
00	$80_{16} = 128_{10}$	node ID	enter_pre-operational	switch to pre-operational
00	$81_{16} = 129_{10}$	node ID	reset node	reset CAN participate
00	$82_{16} = 130_{10}$	node ID	reset communication	reset CAN communication

## NMT state

9963

The status byte informs about the state of the CAN participant.



Graphics: state transitions under CANopen

## NMT state for CANopen master

9964

State hex   dec	Description
00   0	not defined
01   1	Master waits for a boot-up message of the node. OR: Master waits for the expiry of the given guard time.
02   2	- Master waits for 300 ms. - Master requests the object 1000 <sub>16</sub> . - Then the state is set to 3.
03   3	The master configures its slaves. To do so, all SDOs generated by the configurator are transmitted to the slaves one after the other: - The Master sends to the slave a SDO read request (index 1000 <sub>16</sub> ). - The generated SDOs are compressed into a SDO array. - The slave knows it's first SDO and the number of it's SDOs.
05   5	After transmission of all SDOs to the slaves the master goes to state 5 and remains in this state. State 5 is the normal operating state for the master.

To read the node state out of the FB:

Used function block	Node state is found here
CANx_MASTER_STATUS CANx_SLAVE_STATUS	output NODE_STATE
CANOPEN_GETSTATE	output NODESTATE

**NMT state for CANopen slave**

9965

State hex   dec		Description
FF	-1	The slave is reset by the NMT message "Reset Node" and automatically goes to state 1.
00	0	not defined
01	1	state = waiting for BOOTUP After max. 2 s or immediately on reception of its boot up message the slave goes to state 2.
02	2	state = BOOTUP After a delay of 0.5 s the slave automatically goes to state 3.
03	3	state = PREPARED The slave is configured in state 3. The slave remains in state 3 as long as it has received all SDOs generated by the configurator. It is not important whether during the slave configuration the response to SDO transfers is abort (error) or whether the response to all SDO transfers is no error. Only the response as such received by the slave is important – not its contents.  If in the configurator the option "Reset node" has been activated, a new reset of the node is carried out after transmitting the object 1011 <sub>16</sub> sub-index 1 which then contains the value "load". The slave is then polled again with the upload of the object 1000 <sub>16</sub> .  Slaves with a problem during the configuration phase remain in state 3 or directly go to an error state (state > 5) after the configuration phase.
04	4	state = PRE-OPERATIONAL A node always goes to state 4 except for the following cases: <ul style="list-style-type: none"> <li>it is an "optional" slave and it was detected as non available on the bus (polling for object 1000<sub>16</sub>) OR:</li> <li>the slave is present but reacted to the polling for object 1000<sub>16</sub> with a type in the lower 16 bits other than expected by the configurator.</li> </ul>
05	5	state = OPERATIONAL State 5 is the normal operating state of the slave: [Normal Operation].  If the master was configured to [Automatic startup], the slave starts in state 4 (i.e. a "start node" NMT message is generated) and the slave goes automatically to state 5.  If the flag GLOBAL_START was set, the master waits until all slaves are in state 4. All slaves are then started with the NMT command [Start All Nodes].
61	97	A node goes to state 97 if it is optional (optional device in the CAN configuration) and has not reacted to the SDO polling for object 1000 <sub>16</sub> .  If the slave is connected to the network and detected at a later point in time, it is automatically started. To do so, you must have selected the option [Automatic startup] in the CAN parameters of the master.
62	98	A node goes to state 98 if the device type (object 1000 <sub>16</sub> ) does not correspond to the configured type.
63	99	In case of a nodeguarding timeout the slave is set to state 99.  As soon as the slave reacts again to nodeguard requests and the option [Automatic startup] is activated, it is automatically started by the master. Depending on the status contained in the response to the nodeguard requests, the node is newly configured or only started.  To start the slave manually it is sufficient to use the method [NodeStart].

Nodeguard messages are transmitted to the slave ...

- if the slave is in state 4 or higher AND
- if nodeguarding was configured.

To read the node state out of the FB:

Used function block	Node state is found here
CANx_MASTER_STATUS CANx_SLAVE_STATUS	output NODE_STATE
CANOPEN_GETSTATE	output NODESTATE

## CANopen status of the node

1973

Node status according to CANopen (with these values the status is also coded by the node in the corresponding messages).

Status hex   dec		CANopen status	Description
00	0	BOOTUP	Node received the boot-up message.
04	4	PREPARED	Node is configured via SDOs.
05	5	OPERATIONAL	Node participates in the normal exchange of data.
7F	127	PRE-OPERATIONAL	Node sends no data, but can be configred by the master.

If nodeguarding active: the most significant status bit toggles between the messages.

Read the node status from the function block:

Function block used	Node status is found here
CANx_MASTER_STATUS CANx_SLAVE_STATUS	Structure element LAST_STATE from the array NODE_STATE_SLAVE
CANOPEN_GETSTATE	Output LASTNODESTATE



12.4.5 CANopen error code

Contents

Emergency messages..... 313  
Overview CANopen error codes ..... 314  
Object 0x1001 (error register) ..... 315


9967

Emergency messages

9973

Device errors in the slave or problems in the CAN bus trigger emergency messages:

COB ID	DLC	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
80 <sub>16</sub> + node ID		error code		object 1001 <sub>16</sub>	device-specific				

 Please note the reversed byte order!

## Overview CANopen error codes

8545

Error Code (hex)	Meaning
00xx	Reset or no error
10xx	Generic error
20xx	Current
21xx	Current, device input side
22xx	Current inside the device
23xx	Current, device output side
30xx	Voltage
31xx	Mains voltage
32xx	Voltage inside the device
33xx	Output voltage
40xx	Temperature
41xx	Ambient temperature
42xx	Device temperature
50xx	Device hardware
60xx	Device software
61xx	Internal software
62xx	User software
63xx	Data set
70xx	Additional modules
80xx	Monitoring
81xx	Communication
8110	CAN overrun-objects lost
8120	CAN in error passiv mode
8130	Life guard error or heartbeat error
8140	Recovered from bus off
8150	Transmit COB-ID collision
82xx	Protocol error
8210	PDO not proceeded due to length error
8220	PDO length exceeded
90xx	External error
F0xx	Additional functions
FFxx	Device specific

## Object 0x1001 (error register)

8547

This object reflects the general error state of a CANopen device. The device is to be considered as error free if the object 1001<sub>16</sub> signals no error any more.

Bit	Meaning
0	generic error
1	current
2	voltage
3	temperature
4	communication error
5	device profile specific
6	reserved – always 0
7	manufacturer specific

For an error message more than one bit in the error register can be set at the same time.

**Example:** CR2033, message "wire break" at channel 2 (→ installation manual of the device):

COB-ID	DLC	Byte 0	Byte 1	Byte	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4
80 <sub>16</sub> + node ID		00	FF	81	10	00	00	00	00

Error-Code = FF00<sub>16</sub>

Error register = 81<sub>16</sub> = 1000 0001<sub>2</sub>, thus it consists of the following errors:

- generic error
- manufacturer specific

Concerned channel = 0010<sub>16</sub> = 0000 0000 0001 0000<sub>2</sub> = wire break channel 2

## 12.5 Visualisations in the device

### Contents

General .....	316
Recommendations for user interfaces .....	316
Basic information about bitmap graphics .....	330

3111

In this chapter you find important information about bitmap graphics in CoDeSys visualisations.

### 12.5.1 General

10464

In addition to the graphical elements created with the CoDeSys visualisation editor, you can also integrate graphics created with other programs. Such graphics files can, for example, be pictograms, logos or smaller images. But before you integrate such an "external graphics" some basics have to be taken into account which will be explained in the following chapters.

 More information is given here:

- Creation and parameter setting of visualisations:
  - CoDeSys programming manual (→ *ecomatmobile* DVD "Software, tools and documentation")
  - ifm manual "PDM – Handbuch zur Einführung"
- See the **Limitations and programming notes** (→ page [53](#))!

## 12.5.2 Recommendations for user interfaces

### Contents

Recommendations for a user-friendly product design .....	317
Do you know the future users? .....	318
Check suitability for use .....	319
Language as an obstacle .....	319
Cultural details are often not transferable .....	320
Directives and standards.....	322

7435

User-friendliness is a decisive criterion for the acceptance and use of technical products!

In this chapter we will give some recommendations how the user interface (also called **Human-Machine-Interface HMI**) of a machine can be designed as user-friendly as possible.

### Recommendations for a user-friendly product design

7436

All important interfaces between humans and machines are determined by the user platform and design. Important criteria for the design of interfaces between humans and machines are...

- Clear condition:
  - For each function a clear description.
  - Design according to expectations, learned contents remain the same
- Readability:
  - Take the environment (illumination, read distance) into account.
- Intuitive handling:
  - Operating element / function must be obvious.
  - User interface must be self-explanatory.
- Sensuality
  - Operating elements must be user-friendly.
  - Clear differentiation from other displays and operating elements.
- Feedback
  - Quick reaction to user activities.
  - Cause for a message must be clearly obvious.
- Environment of the product because of distraction or irritation by...
  - noise
  - darkness
  - light reflection
  - vibrations
  - extreme temperatures

From the manufacturer's view the following features are also important:

- Display as a brand-specific feature.
- Display must meet standards.

## Do you know the future users?

7444

The future users of the product should be known:

- Age
- Gender
- Senses:
  - Eyesight
  - Hearing ability
  - Preferred hand (right or left hander)
  - Tactile ability
- Training and education:
  - General education level
  - Specific training seminars and experience
- Motivation and cognitive abilities:
  - Perception (sense organs): Not all available information is used but massively filtered, integrated and changed in many ways before it comes into awareness.
  - Thinking: The working memory where intellectual manipulation of information takes place has a very small capacity.
  - Learning: The information stored in the long-term memory is often changed in advance (e.g. due to expectations) and subsequently (e.g. by subsequent information).
  - Remembering: The information which is "actually" present in the long-term memory is often not retrievable.
  - Motivation and concentration: fatigue, weariness, distractibility etc. can affect the cognitive capability.
- Familiarity with the problem or application area:
  - Be able to recognise dangers
  - Know what is to happen after an action
- Intensity of the application (how often and how intensely is the product used)
- Culture, e.g.:
  - Language
  - Meaning of colours and symbols
  - Reading direction

## Check suitability for use

7422

In many cases a test set-up with potential users can provide important results where and how the product is/has to be improved to be successful in the market.

For this "usability test" the following steps must be carried out:

- Determine the user group (target group):
  - Who is to handle the product?
- Prepare an interview guideline:
  - What method do I use to interview what user (operator, fitter, maintenance personnel)?
  - What do I want to achieve with the interviews? (Improvement potentials)
- Conduct and evaluate interviews.
- Create context scenarios:
  - Create an evaluable test environment.
  - Identify critical user scenarios.
- Carry out usability test:
  - How do the test persons cope with the product in the test set-up?
  - Where is what corrective action needed for the product?
- After the product has been optimised repeat the tests, if necessary.

## Language as an obstacle

7454

In order to produce equipment which satisfies end users worldwide, language must be taken into account. The operator is not able to effectively carry out his tasks if he cannot understand the instructions on the screen. Manufacturers are still trying to solve this problem considering the many different languages in the world. A few languages are listed below:

### Chinese characters

A Chinese character, also known as a Han character, is a logogram, i.e. it can be represented as a word. The number of characters in the Kangxi dictionary is over 47000 but in China knowledge of three to four thousand characters is sufficient. In modern times the Chinese characters have been greatly simplified and are used in mainland China while traditional Chinese characters are still used in Honk Kong and Taiwan. The Chinese characters have been romanised. They are called Pinyin and are also widely used in China.

### Japanese characters

The modern Japanese writing system uses three main scripts:

- Kanji are ideographs from Chinese characters
- Hiragana is used for native Japanese words and
- Katakana is used for loanwords
- Romanised Japanese characters, called Romanji, are also used in Japanese texts.

### Korean characters

The modern Korean writing system is called Hangul and officially used in North and South Korea. In addition, Hanja is used which refers to the characters borrowed from Chinese.

## Arabic alphabet

This script is used for writing several languages in Asia (e.g. Middle East, Pakistan,) and Africa (e.g. Arabic and Urdu). It is written from right to left in a cursive style and includes 28 letters.

## Unicode

Unicode is a standard for the consistent representation and use of characters found in the writing systems of the world. It was not easy to adapt languages to computers, partly due to the large number of characters of some languages. It is possible to encode one English character with just one byte because written English only needs a small number of characters. This does not apply to languages like Japanese, Chinese or Korean which have more than 256 characters and therefore require double byte or multi-byte encoding. Several encoding methods are used and Unicode seems to be the most universal method. It obviously encodes into all languages in the world.

For example the Han unification, contracted to Unihan, is an approach by Unicode and the Universal Character Set (according to ISO 10646) to map several character sets of the Chinese, Japanese and Korean languages in a single set of unified characters.

Arabic characters can be encoded by Unicode from Version 5.0 or higher (several character sets and ISO 8859-6).

ISO 10646 specifies the Universal Multiple Octet Coded Character Set. It is used for the representation, interchange, processing, storage and input of the written form of the languages in the world as well as for additional symbols.

The Unicode standard versions 4...6 all comply with ISO 10646.

## Pictogram

This is a graphical symbol, also called a pictograph, representing a concept, object, event or an activity by illustration. Pictograms have been used for many thousand years. They are still important in the event of language barriers and illiteracy in the modern world and are used as pictorial signs, representational signs, instructions or statistical diagrams. Due to their graphical nature they are used in different areas of life. To indicate, for example, to toilets and airports a standard set of pictograms is defined in the standard ISO 7001 "Graphical Symbols - Public Information Symbols".

A pictogram has been developed into a functional visual language for people with cognitive problems. Each image represents a word or concept. It comprises two elements, drawn images and text. The symbols are mostly white on a black square.

## Cultural details are often not transferable

7461

Country, culture or language-specific details should be avoided in the source text because their use is often not necessary and adaptation to the target culture is time-consuming. In most cases the author does not know that his texts or graphics are characterised in terms of culture or language or lead to localisation problems due to other design-related decisions. Problems can, for example, occur in the following areas:

- Colours
- Symbols
- Illustrations
- Reading direction










## Colours

7464

The selection of the "right" colour is an important element for the text and product design. Many colours are culture-specific and can lead to misunderstandings if used incorrectly and even to an image loss of the product as a result of handling faults.

Examples:

	Colour	Meaning in Europe + USA	Meaning in other cultures
	Red	Drama, turmoil, blood (fight, revenge and death), love, danger, nobility	China: fortune, cheerful Russia: beautiful Egypt: death India: life, creative Japan: anger, danger
	Yellow	Caution, warning, sunlight, eternity, envy, hate	China: birth, health, force Egypt: cheerful, property India: success Japan: nobility
	Green	Nature, ecology, hope, immortal, fortune	China: eternity, family, harmony, health, peace, posterity Egypt: fertile, strength India: property, fertile Japan: future, youth, energy
	Blue	Water, sky, loyalty, freedom, reliable, joy, friendship, male	Asia: richness, strength Egypt: virtue, faith, truth
	White	Light, pure, wise, life, perfect, ideal, good, matter of fact, clear, innocent, honest	Asia: death, grief, purity Egypt: joy
	Black	Death, grief, darkness, evil. Also: fraternity, power and unity	(Grief not in Buddhism) Egypt: resurrection
	Grey	Wisdom and age	Asia: helpful

## Symbols

7465

As symbols are often produced in analogy to culture-specific concepts or use allusions to familiar areas of the source culture, they pose a problem for localisation.

Example:



The symbol for a house that is to stand for start or beginning is not clearly understandable because the English term "home" cannot be transferred without problem.

## Illustrations

7466

An image is not always a sensible substitute for a text.

The representation of more complex processes can become impossible. How is, for example, the request "press the button until you feel a slight resistance" to be illustrated?

Even if an illustration is a good representation of a fact, its use has to be well considered at international level. Replacing text by images is only sensible and reduces cost if the illustrations are independent of culture, i.e. can be used in ALL intended target countries without adaptations. Many things which are self-evident for us are not self-evident in other cultures.

The illustration of people can lead to problems: What sex must or may a person have? What skin colour? What age? Eventually, the addressees in all target countries are to feel equally addressed. Clothing which does not stand out in Western Europe can lead to irritations in Arabic or African countries. Gestures and individual body parts, especially hands and eyes, should not be represented because they often trigger an offensive or insulting association.

## Reading direction

7468

In most cultures reading is done from left to right and from top to bottom.

Some Asian cultures, however, read from bottom to top and from back to front.

Many Arabic cultures read from right to left.

These particularities have to be taken into account for graphical instructions!

## Directives and standards

### Contents

ISO 7001 _ Graphical symbols - Public information symbols .....	323
ISO 9126 _ Software engineering - Product quality .....	324
ISO 9241 _ Ergonomics of human-system interaction.....	326
ISO 10646 _ Information technology — Universal multiple-octet coded character set (UCS) .	328
ISO 13406 _ Ergonomic requirements for work with visual displays based on flat panels.....	329
ISO 13407 _ Human-centred design processes for interactive systems .....	329
ISO 20282 _ Ease of operation of everyday products .....	330

7445

The following list is only a selection and is not complete.

### ISO 7001 \_ Graphical symbols - Public information symbols

7456

A graphical symbol, also called a pictograph, represents a concept, object, event or an activity by illustration. Pictograms have been used for many thousand years. They are still important in the event of language barriers and illiteracy in the modern world and are used as pictorial signs, representational signs, instructions or statistical diagrams. Due to their graphical nature they are used in different areas of life.

Examples:



## ISO 9126 \_ Software engineering - Product quality

7446

The standard describes the following criteria:

**Functionality:** To what extent does the software have the required functions?

- Suitability: suitability of functions for specified tasks, e.g. task-oriented composition of functions from sub-functions.
- Correctness: providing the correct or agreed results or effects, e.g. necessary accuracy of calculated values.
- Interoperability: ability to interact with specified systems.
- Security: ability to prevent unauthorised access (inadvertent or intentional) to programs and data.
- Compliance: software features that cause the software to comply with application-specific standards or agreements or legal provisions and similar regulations.

**Reliability:** Can the software maintain a defined performance level under defined conditions for a defined period?

- Maturity: low failure frequency by error states.
- Error tolerance: ability to maintain a specified performance level in case of software errors or non-compliance with its specified interface.
- Robustness: ability to ensure a stable system in case of inputs which have not been intended. The software withstands "lusers".
- Restorability: ability to restore the performance level in case of a failure and to retrieve the directly involved data. The time and the needed level of input have to be taken into account.
- Conformity: degree to which the software complies with standards or agreements on reliability.

**Usability:** What level of input does the use of the software require from users and how is it assessed by them?

- Understandability: level of input required from the user to understand the concept and its application.
- Learnability: level of input required from the user to learn the application (e.g. handling, input, output).
- Usability: level of input required from the user to handle the application.
- Attractiveness: attractiveness of the application for the user.
- Conformity: degree to which the software complies with standards or agreements on usability.

**Efficiency:** How is the relationship between performance level of the software and equipment used?

- Time behaviour: response and processing times as well as data processing speed when executing the function.
- Consumption behaviour: Number and actuation time of the required operating elements to carry out the functions. Resource consumption, such as CPU time, hard disc access, etc.
- Conformity: degree to which the software complies with standards or agreements on efficiency.

**Changeability:** What level of input is required make the defined changes in the software? Changes can include corrections, improvements or adaptations to changes of the environment, requirements or functional specifications.

- Analysability: level of input required to diagnose defects or causes of failure or to determine parts that need to be changed.
- Modifiability: level of input required to carry out improvements, eliminate faults or adapt to a changed environment.
- Stability: probability of the occurrence of unexpected effects of changes.
- Testability: level of input required to test the changed software.

**Transferability:** How easily can the software be transferred to another environment? An environment can be an organisational, hardware or software environment.

- **Adaptability:** ability of the software to adapt to different environments.
- **Installability:** level of input required to install the software in a defined environment.
- **Coexistence:** ability of the software to function in parallel with another software having similar or identical functions.
- **Exchangeability:** possibility to use this software instead of a another specified software in the environment of that software as well as the level of input required to do so.
- **Conformity:** degree to which the software complies with standards or agreements on transferability.

© ifm electronic gmbh

## ISO 9241 \_ Ergonomics of human-system interaction

7447

The standard ISO 9241 is an international standard describing the guidelines of interaction between humans and computers. The series of standards describes requirements for the work environment, hardware and software. The goal of the guideline is to avoid health damage at computer workplaces and to make it easier for the user to carry out his tasks.

The following parts (incomplete list) are part of the standard:

Part 1: General introduction

Part 2: Guidance on task requirements

Part 3: Visual display requirements

Part 4: Keyboard requirements

Part 5: Workstation layout and postural requirements

Part 6: Guidance on the work environment

Part 7: Requirements for display with reflections

Part 8: Requirements for displayed colours

Part 9: Requirements for non-keyboard input devices

(Part 10: Dialogue principles (obsolete, was replaced by part 110 in 2006))

Part 11: Guidance on usability

Part 12: Presentation of information

Part 13: User guidance

Part 14: Menu dialogues

Part 15: Command dialogues

Part 16: Direct manipulation dialogues

Part 17: Form filling dialogues

Part 110: Dialogue principles (replaces part 10)

Part 151: Guidance on World Wide Web user interfaces

Part 171: Guidance on software accessibility (published in October 2008)

Part 300: Introduction to electronic visual display requirements

Part 302: Terminology for electronic visual displays (at present in the draft stage)

Part 303: Requirements for electronic visual displays (at present in the draft stage)

Part 304: User performance test methods

Part 305: Optical laboratory test methods for electronic visual displays (at present in the draft stage)

Part 306: Field assessment methods for electronic visual displays (at present in the draft stage)

Part 307: Analysis and compliance test methods for electronic visual displays (at present in the draft stage)

Part 400: Principles and requirements for physical input devices

Part 410: Design criteria for physical input devices (at present in the draft stage)

Parts 5 and 6 deal with the work environment. Parts 3, 4, 7, 8 and 9 deal with hardware requirements, parts 11...17 and 110 deal with aspects of software ergonomics. Mainly the parts **ISO 9241-110 \_ Dialogue principles** (→ page [327](#)) and **ISO 9241-11 \_ Guidance on usability** (→ page [327](#)) contain some criteria for the ergonomic design of interactive systems.

## ISO 9241-11 \_ Guidance on usability

7448

The usability of a software depends on its context of use. In part 11 of ISO 9241 three main criteria are defined for the usability of a software:

- Effectivity to solve a task
- Efficiency to use the system
- Satisfaction of the software user

## ISO 9241-110 \_ Dialogue principles

7450

User interfaces of interactive systems such as websites or software should be easy to use. Part 110 of ISO 9241 describes the following principles for the design and evaluation of an interface between the user and system (dialogue design):

- Suitability for the task  
Suitable functionality, minimisation of unnecessary interactions
- Self-descriptiveness  
Understandability by means of support / feedback
- Suitability for learning  
User guidance, suitable metaphors, goal: minimum learning time
- Controllability  
Dialogue control by the user
- Conformity with user expectations  
Consistency, adaptation to the user model
- Suitability for individualisation  
Adaptability to the user and his context of work
- Error tolerance  
Intelligent dialogue principles so that the user avoids error is given priority. Other aspects:  
Detected user errors do not prevent the user's goal.  
Undetected errors: slight correction by the user.

## ISO 10646 \_ Information technology — Universal multiple-octet coded character set (UCS)

7455

The universal character set (UCS) is a standard set of characters which is defined in the international standard ISO 10646. For all practical purposes this is the same as Unicode.

Per character a memory space of 2 bytes is used. Unicode is a 16-bit code which represents  $2^{16} = 65536$  characters. The first goal is a clear and standardised encoding of the characters of all national languages.

Not all of these 65536 character addresses are used. A user-defined area enables approx. 2000 addresses with user-specific characters.

Another 1408576 characters can be encoded via the combination of two 16-bit codes. The hope is to be able to cover all characters that exist or have ever existed. Furthermore, technical symbols, musical signs, phonetics, etc. are mapped. However, one is still far from using all character addresses.

Examples:

	000	001	002	003	004	005	006	007
0	NUL	DLE	SP	0	@	P	~	p
1	SOH	DC1	!	1	A	Q	a	q
2	STX	DC2	"	2	B	R	b	r
3	ETX	DC3	#	3	C	S	c	s
4	EOT	DC4	\$	4	D	T	d	t
5	ENQ	NAK	%	5	E	U	e	u
6	ACK	SYN	&	6	F	V	f	v
7	BEL	ETB	'	7	G	W	g	w
8	BS	CAN	(	8	H	X	h	x
9	HT	EM	)	9	I	Y	i	y
A	LF	SUB	*	:	J	Z	j	z
B	VT	ESC	+	;	K	[	k	{
C	FF	FS	,	<	L	\	l	
D	CR	GS	-	=	M	]	m	}
E	SO	RS	.	>	N	^	n	~
F	SI	US	/	?	O	_	o	DEL

Unicode: control characters and basic characters

	219	21A	21B	21C	21D	21E	21F
0	←	→	↶	↷	↵	↶	↷
1	↑	↓	↶	↷	↵	↶	↷
2	→	←	↶	↷	↵	↶	↷
3	↓	↶	↷	↵	↶	↷	↵
4	↶	↷	↵	↶	↷	↵	↶
5	↶	↷	↵	↶	↷	↵	↶
6	↶	↷	↵	↶	↷	↵	↶
7	↶	↷	↵	↶	↷	↵	↶
8	↶	↷	↵	↶	↷	↵	↶
9	↶	↷	↵	↶	↷	↵	↶
A	↶	↷	↵	↶	↷	↵	↶
B	↶	↷	↵	↶	↷	↵	↶
C	↶	↷	↵	↶	↷	↵	↶
D	↶	↷	↵	↶	↷	↵	↶
E	↶	↷	↵	↶	↷	↵	↶
F	↶	↷	↵	↶	↷	↵	↶

Unicode: arrows



## ISO 13406 \_Ergonomic requirements for work with visual displays based on flat panels

7453

### Part 2: Ergonomic requirements for flat panel displays

According to the international standard ISO 13406-2 LCD screens are classified on the basis of the following criteria:

- Luminance, contrast and colour measured by the viewer's direction
- Reflections and contrast in case of incident illumination
- Image set-up time
- Faults (pixel faults)

## ISO 13407 \_ Human-centred design processes for interactive systems

7452

ISO 13407 is a standard which describes a prototypical human-centred software development process. A special development process can be considered to conform to the standard if its recommendations are met.

The standard represents human-centred design as an interdisciplinary activity covering knowledge of human factors and ergonomic information and techniques. The ISO process consists of four essential sub-activities:

- Understand the context of use:  
The result of this activity is a documented description of the relevant users, their tasks and their environment.
- Specify requirements:  
During this phase the targets are deducted from the existing documentation at a compromise level. The division of the system tasks is defined in...
  - tasks to be carried out by people
  - tasks to be carried out by technology
- Produce solutions:  
This can be done following a prototype development or another iterative process. These prototypes can be paper drafts (mocks) or executable program versions. If there are company-internal design rules for user interfaces, they should be used.
- Evaluate solutions:  
The solutions are checked for compliance with the defined requirements. To do so, expert assessments, usability tests, interviews or a combination of these can be used. The determined deviations are evaluated for their relevance and are a starting point of the next iteration of the development process.

This method is complementary with existing process models of the software development. According to the standard the human-centred design process should start in the earliest stage of the project and should be repeated until the system meets the requirements. The significance and required level of input for the human-centred design depend on the size and type of the product to be developed. For smaller projects this is controlled by individuals.

## ISO 20282 \_ Ease of operation of everyday products

7443

This draft consists of

- Part 1: Design requirements for context of use and user characteristics  
The following criteria are described:
  - Scope
  - User interface
  - User
  - Psychological and social characteristics
  - Physical and social environmental factors
  - Physical and sensory characteristics
- Part 2: Test method for walk-up-and-use products  
This part is a technical specification for the test methods.

## 12.5.3 Basic information about bitmap graphics

### Contents

Image size vector graphics / pixel graphics .....	332
---	-----



9858  
3112

For graphics and image files two basic types are distinguished:

	Vector graphics	Pixel graphics
Examples:	Drawings of CAD programs Character sets type TrueType, PostScript or OpenType	Digital photos Files from the scanner or capture programs
Principle:	Vector graphics are based on an image description which exactly defines the objects from which the image is made. A circle is, for example, defined via the position of the centre (coordinates), radius, line thickness and colour.	A raster graphics, also pixel graphics or bitmap, is a way of describing an image which consists of a raster-type arrangement of pixels to which one colour each is assigned. The main characteristics of a raster graphics are therefore width and height in pixels (image resolution) as well as the colour depth.
Required memory space:	Required memory space relatively small	Depending on the resolution the required memory space is high or very high: the files become larger with every additionally pixel to be stored.
Loss when scaling:	Loss-free resampling (scaling) to any image sizes possible	Resampling (scaling) to other image sizes leads to quality loss in most cases.
Hardware performance:	Since monitors are in principle based on a raster matrix, all graphics must be resampled to individual pixels (= rastered) to display them on the monitor.  Depending on the complexity of the graphics very powerful computers are needed to enable quick processing and display.	Requirements relatively low
Typical file extensions:	*.cdr (Corel Draw) *.dwg (AutoCAD) *.ai (Adobe Illustrator) *.svg (Scalable Vector Graphics)	*.bmp (Bitmap) *.gif (Compuserve GIF) *.jpg (Joint Photographic Experts Group) *.png (Portable Network Graphics)

## Image size vector graphics / pixel graphics

7380

Vector graphics	Pixel graphics
Graphical elements are described as vectors: information about start and end point, thickness and colour of a line, possibly fill pattern and colour gradient.	Pixel graphics of modern digital cameras have 5 million and more pixels (resolution = 5 megapixels). A special data compression tries to reduce the required high memory space. Unfortunately, compression leads to a poorer quality.
Reduction or enlargement is easy and leads to no quality loss (→ example below).	Enlargement leads to block graphics or blurry images (→ example below). Reducing such a megapixel image results in high loss of image information.
<p>Example:</p>  <p>Original Ø 10 mm / enlargement 5 times EPS file 35 kB</p>	<p>Example:</p>  <p>Original 30 x 30 px / enlargement 5 times BMP file 3 kB / 62 kB</p>

### Example: reducing a pixel image

9906

A digital photo with a resolution of 5 megapixels has a size of 2 560 x 1 920 pixels (= 4 915 200 pixels). This photo is to be displayed in an image size of only 128 x 64 pixels (= monitor size for this device).

Result after scaling: there are only 8 192 pixels left (= 0.167 % of the original image), the other 4 907 008 pixels are eliminated.

In other words:

- Only every 20th pixel is used horizontally.
- Only every 30th pixel is used vertically.

Therefore such a transformed photo can no longer have the quality of the original. Important information is lost.

► Remedy: Create images in the required size and resolution right from the start.

## Adapt bitmap graphics

9996

You can adapt existing bitmap graphics by means of common graphics software.  
Please ask your *ecomatmobile* specialist!

© ifm electronic gmbh

## 12.6 Overview of the files and libraries used

### Contents

Installation of the files and libraries .....	334
General overview .....	335
What are the individual files and libraries used for? .....	336

2711

(as on 2011-03-02)

Depending on the unit and the desired function, different libraries and files are used. Some are automatically loaded, others must be inserted or loaded by the programmer.

### 12.6.1 Installation of the files and libraries

2721

Factory setting: the device contains only the boot loader.

- ▶ Load the operating system (\*.H86 or \*.RESX)
- ▶ Create the project (\*.PRO) in the PC: enter the target (\*.TRG)
- ▶ Additionally depending on device and target:  
Define the PLC configuration (\*.CFG)
- > CoDeSys integrates the files belonging to the target into the project:  
\*.TRG, \*.CFG, \*.CHM, \*.INI, \*.LIB
- ▶ If required, add further libraries to the project (\*.LIB).

Certain libraries automatically integrate further libraries into the project.

Some FBs in *ifm* libraries (ifm\_\*.LIB) e.g. are based on FBs in CoDeSys libraries (3S\_\*.LIB).

## 12.6.2 General overview

2712

File name	Description and memory location <sup>3)</sup>
ifm_CRnnnn_Vxyyyz.CFG <sup>1)</sup> ifm_CRnnnn_Vxx.CFG <sup>2)</sup>	PLC configuration per device only 1 device-specific file includes: IEC and symbolic addresses of the inputs and outputs, the flag bytes as well as the memory allocation ...\CoDeSys V*\Targets\ifm\ifm_CRnnnncfg\Vxyyyz
CAA-*.CHM	Online help per device only 1 device-specific file includes: online help for this device ...\CoDeSys V*\Targets\ifm\Help\... (language)
ifm_CRnnnn_Vxyyyz.H86 ifm_CRnnnn_Vxyyyz.RESX	Operating system / runtime system (must be loaded into the controller / monitor when used for the first time) per device only 1 device-specific file ...\CoDeSys V*\Targets\ifm\Library\ifm_CRnnnn
ifm_Browser_CRnnnn.INI	CoDeSys browser commands (CoDeSys needs the file for starting the project) per device only 1 device-specific file includes: commands for the browser in CoDeSys ...\CoDeSys V*\Targets\ifm
ifm_Errors_CRnnnn.INI	CoDeSys error file (CoDeSys needs the file for starting the project) per device only 1 device-specific file includes: device-specific error messages from CoDeSys ...\CoDeSys V*\Targets\ifm
ifm_CRnnnn_Vxx.TRG	Target file per device only 1 device-specific file includes: hardware description for CoDeSys, e.g.: memory, file locations ...\CoDeSys V*\Targets\ifm
ifm_*_Vxyyyz.LIB	General libraries per device several files are possible ...\CoDeSys V*\Targets\ifm\Library
ifm_CRnnnn_Vxyyyz.LIB	Device-specific library per device only 1 device-specific file includes: POU's of this device ...\CoDeSys V*\Targets\ifm\Library\ifm_CRnnnn
ifm_CRnnnn_*_Vxyyyz.LIB	Device-specific libraries per device several files are possible → following tables ...\CoDeSys V*\Targets\ifm\Library\ifm_CRnnnn

### Legend:

\* any signs  
 CRnnnn article number of the controller / monitor  
 V\* CoDeSys version  
 Vxx version number of the ifm software  
 yy release number of the ifm software  
 zz patch number of the ifm software

<sup>1)</sup> valid for CRnn32 target version up to V01, all other devices up to V04

<sup>2)</sup> valid for CRnn32 target version from V02 onwards, CR040n target version from V01 onwards, all other devices from V05 onwards

<sup>3)</sup> memory location of the files:

System drive (C: / D:) \ program folder\ ifm electronic

## NOTE

The software versions suitable for the selected target must always be used:

- operating system (`ifm_CRnnnn_Vxxyyzz.H86` / `ifm_CRnnnn_Vxxyyzz.RESX`),
- PLC configuration (`ifm_CRnnnn_Vxx.CFG`),
- device library (`ifm_CRnnnn_Vxxyyzz.LIB`) and
- the further files (→ chapter [Overview of the files and libraries used](#) (→ page [333](#)))

CRnnnn	device article number
Vxx: 00...99	target version number
yy: 00...99	release number
zz: 00...99	patch number

The basic file name (e.g. "CR0032") and the software version number "xx" (e.g. "02") must always have the same value! Otherwise the device goes to the STOP mode.

The values for "yy" (release number) and "zz" (patch number) do **not** have to match.

**I** The following files must also be loaded:

- the internal libraries (created in IEC 1131) required for the project,
- the configuration files (`*.CFG`) and
- the target files (`*.TRG`).

**I** It may happen that the target system cannot or only partly be programmed with your currently installed version of CoDeSys. In such a case, please contact the technical support department of **ifm electronic gmbh**.



## 12.6.3 What are the individual files and libraries used for?

### Contents

Files for the operating system / runtime system .....	337
Target file .....	337
PLC configuration file .....	337
ifm device libraries.....	338
ifm CANopen libraries master / slave.....	338
CoDeSys CANopen libraries.....	339
Specific ifm libraries .....	340

2713

The following overview shows which files/libraries can and may be used with which unit. It may be possible that files/libraries which are not indicated in this list can only be used under certain conditions or the functionality has not yet been tested.

### Files for the operating system / runtime system

2714

File name	Function	Available for:
ifm_CRnnnn_Vxyyyz.H86 ifm_CRnnnn_Vxyyyz.RESX	operating system / runtime system	all <i>ecomatmobile</i> controllers BasicDisplay: CR0451 PDM: CR10nn
ifm_Browser_CRnnnn.INI	CoDeSys browser commands	all <i>ecomatmobile</i> controllers PDM: CR10nn
ifm_Errors_CRnnnn.INI	CoDeSys error file	all <i>ecomatmobile</i> controllers PDM: CR10nn

### Target file

2715

File name	Function	Available for:
ifm_CRnnnn_Vxx.TRG	Target file	all <i>ecomatmobile</i> controllers BasicDisplay: CR0451 PDM: CR10nn

### PLC configuration file

2716

File name	Function	Available for:
ifm_CRnnnn_Vxyyyz.CFG	PLC configuration	all <i>ecomatmobile</i> controllers BasicDisplay: CR0451 PDM: CR10nn

## ifm device libraries

2717

File name	Function	Available for:
ifm_CRnnnn_Vxxyzz.LIB	device-specific library	all <i>ecomatmobile</i> controllers BasicDisplay: CR0451 PDM: CR10nn
ifm_CR0200_MSTR_Vxxyzz.LIB	library without extended functions	ExtendedController: CR0200
ifm_CR0200_SMALL_Vxxyzz.LIB	library without extended functions, reduced functions	ExtendedController: CR0200

## ifm CANopen libraries master / slave

2718

These libraries are based on the CoDeSys libraries (3S CANopen POU's) and make them available to the user in a simple way.

File name	Function	Available for:
ifm_CRnnnn_CANopenMaster_Vxxyzz.LIB	CANopen master emergency and status handler	all <i>ecomatmobile</i> controllers *) PDM: CR10nn *)
ifm_CRnnnn_CANopenSlave_Vxxyzz.LIB	CANopen slave emergency and status handler	all <i>ecomatmobile</i> controllers *) PDM: CR10nn *)
ifm_CANx_SDO_Vxxyzz.LIB	CANopen SDO read and SDO write	PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056
ifm_CANopen_NT_Vxxyzz.LIB	CANopen POU's in the CAN stack	BasicController: CR040n BasicDisplay: CR0451 PDM360NG: CR108n

\*) but NOT for...

- BasicController: CR040n
- BasicDisplay: CR0451
- PDM360NG: CR108n

## CoDeSys CANopen libraries

2719

For the following devices these libraries are NOT useable:

- BasicController: CR040n
- BasicDisplay: CR0451
- PDM360NG: CR108n

File name	Function	Available for:
3S_CanDrvOptTable.LIB <sup>1)</sup> 3S_CanDrvOptTableEx.LIB <sup>2)</sup>	CANopen driver	all <i>ecomatmobile</i> controllers PDM360smart: CR1070, CR1071
3S_CanDrv.LIB <sup>3)</sup>		PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056
3S_CANOpenDeviceOptTable.LIB <sup>1)</sup> 3S_CANOpenDeviceOptTableEx.LIB <sup>2)</sup>	CANopen slave driver	all <i>ecomatmobile</i> controllers PDM360smart: CR1070, CR1071
3S_CANOpenDevice.LIB <sup>3)</sup>		PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056
3S_CANOpenManagerOptTable.LIB <sup>1)</sup> 3S_CANOpenManagerOptTableEx.LIB <sup>2)</sup>	CANopen network manager	all <i>ecomatmobile</i> controllers PDM360smart: CR1070, CR1071
3S_CANOpenManager.LIB <sup>3)</sup>		PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056
3S_CANOpenMasterOptTable.LIB <sup>1)</sup> 3S_CANOpenMasterOptTableEx.LIB <sup>2)</sup>	CANopen master	all <i>ecomatmobile</i> controllers PDM360smart: CR1070, CR1071
3S_CANOpenMaster.LIB <sup>3)</sup>		PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056
3S_CANOpenNetVarOptTable.LIB <sup>1)</sup> 3S_CANOpenNetVarOptTableEx.LIB <sup>2)</sup>	Driver for network variables	all <i>ecomatmobile</i> controllers PDM360smart: CR1070, CR1071
3S_CANOpenNetVar.LIB <sup>3)</sup>		PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056

<sup>1)</sup> valid for CRnn32 target version up to V01, all other devices up to V04

<sup>2)</sup> valid for CRnn32 target version from V02 onwards, all other devices from V05 onwards

<sup>3)</sup> For the following devices: This library is without function used as placeholder:

- BasicController: CR040n
- BasicDisplay: CR0451
- PDM360NG: CR108n

## Specific ifm libraries

2720

File name	Function	Available for:
<code>ifm_RawCAN_NT_Vxxyyzz.LIB</code>	CANopen POUs in the CAN stack based on Layer 2	BasicController: CR040n BasicDisplay: CR0451 PDM360NG: CR108n
<code>ifm_J1939_NT_Vxxyyzz.LIB</code>	J1939 communication POUs in the CAN stack	BasicController: CR040n BasicDisplay: CR0451 PDM360NG: CR108n
<code>NetVarClib.LIB</code>	additional driver for network variables	BasicController: CR040n BasicDisplay: CR0451 PDM360NG: CR108n
<code>ifm_J1939_Vxxyyzz.LIB</code>	J1939 communication POUs	up to target V04: CabinetController: CR0303 ClassicController: CR0020, CR0505 ExtendedController: CR0200 SafetyController: CR7020, CR7200, CR7505 SmartController: CR2500 PDM360smart: CR1070, CR1071
<code>ifm_J1939_x_Vxxyyzz.LIB</code>	J1939 communication POUs	from target V05: CabinetController: CR0303 ClassicController: CR0020, CR0505 ExtendedController: CR0200 SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506 SmartController: CR2500 PDM360smart: CR1070, CR1071
<code>ifm_CRnnnn_J1939_Vxxyyzz.LIB</code>	J1939 communication POUs	ClassicController: CR0032, CR0033 ExtendedController: CR0232, CR0233
<code>ifm_PDM_J1939_Vxxyyzz.LIB</code>	J1939 communication POUs	PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056
<code>ifm_CANx_LAYER2_Vxxyyzz.LIB</code>	CAN POUs on the basis of layer 2: CAN transmit, CAN receive	PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056
<code>ifm_CAN1E_Vxxyyzz.LIB</code>	changes the CAN bus from 11 bits to 29 bits	up to target V04: PDM360smart: CR1070, CR1071

File name	Function	Available for:
ifm_CAN1_EXT_Vxxyyzz.LIB	changes the CAN bus from 11 bits to 29 bits	from target V05: CabinetController: CR030n ClassicController: CR0020, CR0505 ExtendedController: CR0200 PCB controller: CS0015 SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506 SmartController: CR25nn PDM360smart: CR1070, CR1071
ifm_CAMERA_O2M_Vxxyyzz.LIB	camera POUs	PDM360: CR1051
CR2013AnalogConverter.LIB	analogue value conversion for I/O module CR2013	all <i>ecomatmobile</i> controllers PDM: CR10nn
ifm_Hydraulic_16bitOS04_Vxxyyzz.LIB	hydraulic POUs for R360 controllers	up to target V04: ClassicController: CR0020, CR0505 ExtendedController: CR0200 SafetyController: CR7020, CR7200, CR7505 SmartController: CR25nn
ifm_Hydraulic_16bitOS05_Vxxyyzz.LIB	hydraulic POUs for R360 controllers	from target V05: ClassicController: CR0020, CR0505 ExtendedController: CR0200 SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506 SmartController: CR25nn
ifm_Hydraulic_32bit_Vxxyyzz.LIB	hydraulic POUs for R360 controllers	ClassicController: CR0032, CR0033 ExtendedController: CR0232, CR0233
ifm_Hydraulic_CR0303_Vxxyyzz.LIB	hydraulic POUs for R360 controllers	CabinetController: CR0303
ifm_SafetyIO_Vxxyyzz.LIB	safety POUs	SafetyController: CR7nnn
ifm_PDM_UTIL_Vxxyyzz.LIB	auxiliary functions PDM	PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056
ifm_PDMng_UTIL_Vxxyyzz.LIB	auxiliary functions PDM	PDM360NG: CR1083
ifm_PDMsmart_UTIL_Vxxyyzz.LIB	auxiliary functions PDM	PDM360smart: CR1070, CR1071
ifm_PDM_Input_Vxxyyzz.LIB	alternative input POUs PDM	PDM: CR10nn
ifm_CR107n_Init_Vxxyyzz.LIB	initialisation POUs PDM360smart	PDM360smart: CR1070, CR1071
ifm_PDM_File_Vxxyyzz.LIB	file POUs PDM360	PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056 PDM360NG: CR1083
ifm_PDM360NG_linux_syscall_async_LIB	send Linux commands to the system	PDM360NG: CR1083
ifm_PDM360NG_USB_Vxxyyzz.LIB	manage devices at the USB interface	PDM360NG: CR1083
ifm_PDM360NG_USB_LL_Vxxyyzz.LIB	auxiliary library for ifm_PDM360NG_USB_Vxxyyzz.LIB	PDM360NG: CR1083
Instrumente_x.LIB	predefined display instruments	PDM: CR10nn

File name	Function	Available for:
Symbols_x.LIB	predefined symbols	PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056
Segment_x.LIB	predefined 7-segment displays	PDM360: CR1050, CR1051 PDM360compact: CR1052, CR1053, CR1055, CR1056

Further libraries on request.

# 13

## Glossary of Terms

### A

#### Address

This is the "name" of the bus participant. All participants need a unique address so that the signals can be exchanged without problem.

#### Application software

Software specific to the application, implemented by the machine manufacturer, generally containing logic sequences, limits and expressions that control the appropriate inputs, outputs, calculations and decisions

Necessary to meet the specific (→SRP/CS) requirements.

→ Programming language, safety-related

#### Architecture

Specific configuration of hardware and software elements in a system.

### B

#### Baud

Baud, abbrev.: Bd = unit for the data transmission speed. Do not confuse baud with "bits per second" (bps, bits/s). Baud indicates the number of changes of state (steps, cycles) per second over a transmission length. But it is not defined how many bits per step are transmitted. The name baud can be traced back to the French inventor J. M. Baudot whose code was used for telex machines.

1 MBd = 1024 x 1024 Bd = 1 048 576 Bd

#### Boot loader

On delivery **ifm** units only contain the boot loader.

The boot loader is a start program that allows to reload the operating system (= runtime system) and the application program on the device.

The boot loader contains basic routines...  
- for communication between hardware modules,  
- for reloading the operating system.

The boot loader is the first software module to be saved on the device.

#### Bus

Serial data transmission of several participants on the same cable.

### C

#### CAN

CAN = **C**ontroller **A**rea **N**etwork

CAN is a priority controlled fieldbus system for larger data volumes. It is available in different variants, e.g. "CANopen" or "CAN in Automation" (CiA).

#### CAN stack

CAN stack = stack of tasks for CAN data communication.

#### Category (CAT)

Classification of the safety-related parts of a control system in respect of their resistance to faults and their subsequent behaviour in the fault condition. This safety is achieved by the structural arrangement of the parts, fault detection and/or by their reliability.  
(→ EN 954).

#### CCF

**C**ommon **C**ause **F**ailure

Failures of different items, resulting from a common event, where these failures are not consequences of each other.

#### CiA

CiA = CAN in Automation e.V.

User and manufacturer organisation in Germany / Erlangen. Definition and control body for CAN and CAN-based network protocols.

Homepage → <http://www.can-cia.org>

## **CiA DS 304**

DS = **Draft Standard**

CAN device profile CANopen safety for safety-related communication.

## **CiA DS 401**

DS = **Draft Standard**

CAN device profile for digital and analogue I/O modules

## **CiA DS 402**

DS = **Draft Standard**

CAN device profile for drives

## **CiA DS 403**

DS = **Draft Standard**

CAN device profile for HMI

## **CiA DS 404**

DS = **Draft Standard**

CAN device profile for measurement and control technology

## **CiA DS 405**

DS = **Draft Standard**

Specification for interface to programmable controllers (IEC 61131-3)

## **CiA DS 406**

DS = **Draft Standard**

CAN device profile for encoders

## **CiA DS 407**

DS = **Draft Standard**

CAN application profile for local public transport

## **Clamp 15**

In vehicles clamp 15 is the plus cable switched by the ignition lock.

## **COB-ID**

COB = **C**ommunication **O**bject

ID = **I**dentifier

Via the COB-ID the participants distinguish the different messages to be exchanged.

## **CoDeSys**

CoDeSys® is a registered trademark of 3S – Smart Software Solutions GmbH, Germany.

"CoDeSys for Automation Alliance" associates companies of the automation industry whose hardware devices are all programmed with the widely used IEC 61131-3 development tool CoDeSys®.

Homepage → <http://www.3s-software.com>

## **CRC**

CRC = **C**yclic **R**edundancy **C**heck

CRC is a method of information technology to determine a test value for data, to detect faults during the transmission or duplication of data.

Prior to the transmission of a block of data, a CRC value is calculated. After the end of the transaction the CRC value is calculated again at the target location. Then, these two test values are compared.

## **Cycle time**

This is the time for a cycle. The PLC program performs one complete run.

Depending on event-controlled branchings in the program this can take longer or shorter.

## **D**

### **DC**

**D**irect **C**urrent

### **DC**

**D**iagnostics **C**overage

Diagnostic coverage is the measure of the effectiveness of diagnostics as the ratio between the failure rate of detected dangerous failures and the failure rate of total dangerous failures:



Formula:  $DC = \text{failure rate detected dangerous failures} / \text{total dangerous failures}$

Designation	Range
none	$DC < 60 \%$
low	$60 \% < DC < 90 \%$
medium	$90 \% < DC < 99 \%$
high	$99 \% < DC$

Table: Diagnostic coverage DC

An accuracy of 5 % is assumed for the limit values shown in the table.

Diagnostic coverage can be determined for the whole safety-related system or for only parts of the safety-related system.

## Demand rate $r_d$

The demand rate  $r_d$  is the frequency of demands to a safety-related reaction of an SRP/CS per time unit.

## Diagnosis

During the diagnosis, the "state of health" of the device is checked. It is to be found out if and what faults are given in the device.

Depending on the device, the inputs and outputs can also be monitored for their correct function.

- wire break,
- short circuit,
- value outside range.

For diagnosis, configuration and log data can be used, created during the "normal" operation of the device.

The correct start of the system components is monitored during the initialisation and start phase. Errors are recorded in the log file.

For further diagnosis, self-tests can also be carried out.

## Diagnostic coverage

### Diagnostic Coverage

Diagnostic coverage is the measure of the effectiveness of diagnostics as the ratio between the failure rate of detected dangerous failures and the failure rate of total dangerous failures:

Formula:  $DC = \text{failure rate detected dangerous failures} / \text{total dangerous failures}$

Designation	Range
none	$DC < 60 \%$
low	$60 \% < DC < 90 \%$
medium	$90 \% < DC < 99 \%$
high	$99 \% < DC$

Table: Diagnostic coverage DC

An accuracy of 5 % is assumed for the limit values shown in the table.

Diagnostic coverage can be determined for the whole safety-related system or for only parts of the safety-related system.

## Dither

Dither is a component of the PWM signals to control hydraulic valves. It has shown for electromagnetic drives of hydraulic valves that it is much easier for controlling the valves if the control signal (PWM pulse) is superimposed by a certain frequency of the PWM frequency. This dither frequency must be an integer part of the PWM frequency.

→ chapter **What is the dither?**

## Diversity

In technology diversity is a strategy to increase failure safety.

The systems are designed redundantly, however different implementations are used intentionally and not any individual systems of the same design. It is assumed that systems of the same performance, however of different implementation, are sensitive or insensitive to different interference and will therefore not fail simultaneously.

The actual implementation may vary according to the application and the requested safety:

- use of components of several manufacturers,
- use of different protocols to control devices,
- use of totally different technologies, for example an electrical and a pneumatic controller,
- use of different measuring methods (current, voltage),

- two channels with reverse value progression:  
channel A: 0...100 %  
channel B: 100...0 %

## DRAM

DRAM = **D**ynamic **R**andom **A**ccess **M**emory

Technology for an electronic memory module with random access (Random Access Memory, RAM). The memory element is a capacitor which is either charged or discharged. It becomes accessible via a switching transistor and is either read or overwritten with new contents. The memory contents are volatile: the stored information is lost in case of lacking operating voltage or too late restart.

## DTC

DTC = **D**iagnostic **T**rouble **C**ode = error code  
Faults and errors will be managed and reported via assigned numbers – the DTCs.

## E

### ECU

- (1) **E**lectronic **C**ontrol **U**nit = control unit or microcontroller  
(2) **E**ngine **C**ontrol **U**nit = control device of a engine

### EDS-file

EDS = **E**lectronic **D**ata **S**heet, e.g. for:

- File for the object directory in the master
- CANopen device descriptions

Via EDS devices and programs can exchange their specifications and consider them in a simplified way.

### Embedded software

System software, basic program in the device, virtually the operating system.

The firmware establishes the connection between the hardware of the device and the user software. This software is provided by the manufacturer of the controller as a part of the system and cannot be changed by the user.

## EMC

EMC = **E**lectro **M**agnetic **C**ompatibility

According to the EC directive (2004/108/EEC) concerning electromagnetic compatibility (in short EMC directive) requirements are made for electrical and electronic apparatus, equipment, systems or components to operate satisfactorily in the existing electromagnetic environment. The devices must not interfere with their environment and must not be adversely influenced by external electromagnetic interference.

## EMCY

abbreviation for emergency

## Ethernet

Ethernet is a widely used, manufacturer-independent technology which enables data transmission in the network at a speed of 10 or 100 million bits per second (Mbps). Ethernet belongs to the family of so-called "optimum data transmission" on a non exclusive transmission medium. The concept was developed in 1972 and specified as IEEE 802.3 in 1985.

## EUC

EUC = "Equipment Under Control"

EUC is equipment, machinery, apparatus or plant used for manufacturing, process, transportation, medical or other activities (→ IEC 61508-4, section 3.2.3). Therefore, the EUC is the set of all equipment, machinery, apparatus or plant that gives rise to hazards for which the safety-related system is required.

If any reasonably foreseeable action or inaction leads to hazards with an intolerable risk arising from the EUC, then safety functions are necessary to achieve or maintain a safe state for the EUC. These safety functions are performed by one or more safety-related systems.

## F

### Failure

Failure is the termination of the ability of an item to perform a required function.

After a failure, the item has a fault. Failure is an event, fault is a state.

The concept as defined does not apply to items consisting of software only.

### **Failure, dangerous**

A dangerous failure has the potential to put the SRP/SC in a hazardous or fail-to-function state. Whether or not the potential is realized can depend on the channel architecture of the system; in redundant systems a dangerous hardware failure is less likely to lead to the overall dangerous or fail-to-function state.

### **Failure, systematic**

A systematic failure is a failure related in a deterministic way (not coincidental) to a certain cause. The systematic failure can only be eliminated by a modification of the design or of the manufacturing process, operational procedures, documentation or other relevant factors.

Corrective maintenance without modification of the system will usually not eliminate the failure cause.

### **Fault**

A fault is the state of an item characterized by the inability to perform the requested function, excluding the inability during preventive maintenance or other planned actions, or due to lack of external resources.

A fault is often the result of a failure of the item itself, but may exist without prior failure.

In ISO 13849-1 "fault" means "random fault".

### **Fault tolerance time**

The max. time it may take between the occurrence of a fault and the establishment of the safe state in the application without having to assume a danger for people.

The max. cycle time of the application program (in the worst case 100 ms, → **Watchdog behaviour** (→ page 54)) and the possible delay and response times due to switching elements have to be considered.

The resulting total time must be smaller than the fault tolerance time of the application.

### **FiFo**

FiFo (**F**irst **I**n, **F**irst **O**ut) = operation of the stack: the data package which was written into a stack at first will be read at first too. For every identifier there is such one buffer (as a queue) available.

### **Firmware**

System software, basic program in the device, virtually the operating system.

The firmware establishes the connection between the hardware of the device and the user software. This software is provided by the manufacturer of the controller as a part of the system and cannot be changed by the user.

### **First fault occurrence time**

Time until the first failure of a safety element.

The operating system verifies the controller by means of the internal monitoring and test routines within a period of max. 30 s.

This "test cycle time" must be smaller than the statistical first fault occurrence time for the application.

### **Flash memory**

Flash ROM (or flash EPROM or flash memory) combines the advantages of semiconductor memory and hard disks. Just like every other semiconductor memory the flash memory does not require moving parts. And the data is maintained after switch-off, similar to a hard disk.

The flash ROM evolved from the EEPROM (**E**lectrical **E**rasable and **P**rogrammable **R**ead-**O**nly **M**emory). The storage function of data in the flash ROM is identical to the EEPROM. Similar to a hard disk, the data are however written and deleted blockwise in data blocks up to 64, 128, 256, 1024, ... bytes at the same time.

#### **Advantages of flash memories**

- The stored data are maintained even if there is no supply voltage.
- Due to the absence of moving parts, flash is noiseless and insensitive to shocks and magnetic fields.

- In comparison to hard disks, flash memories have a very short access time. Read and write speed are virtually constant across the entire memory area.
- The memory size that can be obtained has no upper limit, due to the simple and space-saving arrangement of the storage cells.

**Disadvantages of flash memories**

- A storage cell can tolerate a limited number of write and delete processes:
  - Multi-level cells: typ. 10 000 cycles
  - Single level cells: typ. 100 000 cycles
- Given that a write process writes memory blocks of between 16 and 128 Kbytes at the same time, memory cells which require no change are used as well.

**FMEA**

FMEA = **F**ailure **M**ode and **E**ffects **A**nalysis

Method of reliability engineering, to find potential weak points. Within the framework of quality or security management, the FMEA is used preventively to prevent faults and increase the technical reliability.

**FRAM**

FRAM, or also FeRAM, means **F**erroelectric **R**andom **A**ccess **M**emory. The storage operation and erasing operation is carried out by a polarisation change in a ferroelectric layer.

Advantages of FRAM as compared to conventional read-only memories:

- non-volatile,
- compatible with common EEPROMs, but:
- access time approx. 100 ns,
- nearly unlimited access cycles possible.

**Functional safety**

Part of the overall safety referred to the →EUC and the EUC control system which depends on the correct functioning of the electric or electronic safety-related system, safety-related systems of other technologies and external devices for risk reduction.

**H****Harm**

Physical injury or damage to health.

**Hazard**

Hazard is the potential source of harm.

A distinction is made between the source of the hazard, e.g.:

- mechanical hazard,
- electrical hazard,

or the nature of the potential harm, e.g.:

- electric shock hazard,
- cutting hazard,
- toxic hazard.

The hazard envisaged in this definition is either permanently present during the intended use of the machine, e.g.:

- motion of hazardous moving elements,
- electric arc during a welding phase,
- unhealthy posture,
- noise emission,
- high temperature,

or the hazard may appear unexpectedly, e.g.:

- explosion,
- crushing hazard as a consequence of an unintended/unexpected start-up,
- ejection as a consequence of a breakage,
- fall as a consequence of acceleration/deceleration.

**Heartbeat**

The participants regularly send short signals. In this way the other participants can verify if a participant has failed. No master is necessary.

**HMI**

HMI = **H**uman **M**achine **I**nterface

**I****ID**

ID = **I**dentifier

Name to differentiate the devices / participants connected to a system or the message packets transmitted between the participants.

**IEC user cycle**

IEC user cycle = PLC cycle in the CoDeSys application program.

**Instructions**

Superordinate word for one of the following terms:

installation instructions, data sheet, user information, operating instructions, device manual, installation information, online help, system manual, programming manual, etc.

**Intended use**

Use of a product in accordance with the information provided in the instructions for use.

**IP address**

IP = Internet Protocol

The IP address is a number which is necessary to clearly identify an internet participant. For the sake of clarity the number is written in 4 decimal values, e.g. 127.215.205.156.

**ISO 11898**

Standard: "Road vehicles – Controller area network"

Part 1: "Data link layer and physical signalling"

Part 2: "High-speed medium access unit"

Part 3: "Low-speed, fault-tolerant, medium dependent interface"

Part 4: "Time-triggered communication"

Part 5: "High-speed medium access unit with low-power mode"

**ISO 11992**

Standard: "Interchange of digital information on electrical connections between towing and towed vehicles"

Part 1: "Physical and data-link layers"

Part 2: "Application layer for brakes and running gear"

Part 3: "Application layer for equipment other than brakes and running gear"

Part 4: "Diagnostics"

**ISO 16845**

Standard: "Road vehicles – Controller area network (CAN) – Conformance test plan"

**L****LED**

LED = Light Emitting Diode

Light emitting diode, also called luminescent diode, an electronic element of high coloured luminosity at small volume with negligible power loss.

**Life, mean**

Mean Time To dangerous Failure = the expectation of the mean time to dangerous failure.

Designation	Range
low	3 years < MTTF <sub>d</sub> < 10 years
medium	10 years < MTTF <sub>d</sub> < 30 years
high	30 years < MTTF <sub>d</sub> < 100 years

Table: Mean time of each channel to the dangerous failure MTTF<sub>d</sub>

**Link**

A link is a cross-reference to another part in the document or to an external document.

**LSB**

Least Significant Bit/Byte

**M****MAC-ID**

MAC = Manufacturer's Address Code  
= manufacturer's serial number

→ID = Identifier

Every network card has a MAC address, a clearly defined worldwide unique numerical code, more or less a kind of serial number. Such a MAC address is a sequence of 6 hexadecimal numbers, e.g. "00-0C-6E-D0-02-3F".

## Master

Handles the complete organisation on the bus. The master decides on the bus access time and polls the →slaves cyclically.

## Mission time $T_M$

Mission time  $T_M$  is the period of time covering the intended use of an SRP/CS.

## Misuse

The use of a product in a way not intended by the designer.

The manufacturer of the product has to warn against readily predictable misuse in his user information.

## MMI

→ **HMI** (→ page [348](#))

## Monitoring

Safety function which ensures that a protective measure is initiated:

- if the ability of a component or an element to perform its function is diminished.
- if the process conditions are changed in such a way that the resulting risk increases.

## MRAM

MRAM means **M**agnetoresistive **R**andom **A**ccess **M**emory. The information is stored by means of magnetic storage elements. The property of certain materials is used to change their electrical resistance when exposed to magnetic fields.

Advantages of MRAM as compared to conventional RAM memories:

- non volatile (like FRAM), but:
- access time only approx. 35 ns,
- unlimited number of access cycles possible.

## MSB

**M**ost **S**ignificant **B**it/**B**yte

## MTBF

**M**ean **T**ime **B**etween **F**ailures (MTBF)

Is the expected value of the operating time between two consecutive failures of items that are maintained.

**!** For items that are NOT maintained the mean life →MTTF is the expected value (mean value) of the distribution of lives.

## MTTF

**M**ean **T**ime **T**o **F**ailure (MTTF) or: mean life.

## MTTF<sub>d</sub>

**M**ean **T**ime **T**o **d**angerous **F**ailure = the expectation of the mean time to dangerous failure.

Designation	Range
low	3 years < MTTF <sub>d</sub> < 10 years
medium	10 years < MTTF <sub>d</sub> < 30 years
high	30 years < MTTF <sub>d</sub> < 100 years

Table: Mean time of each channel to the dangerous failure MTTF<sub>d</sub>

## Muting

Muting is the temporary automatic suspension of a safety function(s) by the SRP/CS.

Example: The safety light curtain is bridged, if the closing tools have reached a finger-proof distance to each other. The operator can now approach the machine without any danger and guide the workpiece.

## N

### NMT

NMT = **N**etwork **M**anagement = (here: in the CAN bus)

The NMT master controls the operating states of the NMT slaves.

## Node

This means a participant in the network.



## Node Guarding

Network participant

Configurable cyclic monitoring of each slave configured accordingly. The master verifies if the slaves reply in time. The slaves verify if the master regularly sends requests. In this way failed network participants can be quickly identified and reported.

## O

### Obj / object

Term for data / messages which can be exchanged in the CANopen network.

### Object directory

Contains all CANopen communication parameters of a device as well as device-specific parameters and data.

### OBV

Contains all CANopen communication parameters of a device as well as device-specific parameters and data.

### Operating system

Basic program in the device, establishes the connection between the hardware of the device and the user software.

### Operational

Operating state of a CANopen participant. In this mode SDOs, NMT commands and PDOs can be transferred.

## P

### PC card

→PCMCIA card

### PCMCIA card

PCMCIA = Personal Computer Memory Card International Association, a standard for expansion cards of mobile computers.

Since the introduction of the cardbus standard in 1995 PCMCIA cards have also been called PC card.

### PDM

PDM = **P**rocess and **D**ialogue **M**odule

Device for communication of the operator with the machine / plant.

### PDO

PDO = **P**rocess **D**ata **O**bject

The time-critical process data is transferred by means of the "process data objects" (PDOs). The PDOs can be freely exchanged between the individual nodes (PDO linking). In addition it is defined whether data exchange is to be event-controlled (asynchronous) or synchronised. Depending on the type of data to be transferred the correct selection of the type of transmission can lead to considerable relief for the CAN bus.

These services are not confirmed by the protocol, i.e. it is not checked whether the message reaches the receiver. Exchange of network variables corresponds to a "1 to n connection" (1 transmitter to n receivers).

### PDU

PDU = **P**rotocol **D**ata **U**nit

The PDU is an item of the CAN protocol SAE J1939. PDU indicates a part of the destination or source address.

### Performance Level

**Performance Level**

According to ISO 13849-1, a specification (PL a...e) of safety-related parts of control systems to perform a safety function under foreseeable conditions.

→ Chapter **Performance Level PL**

## PES

### Programmable Electronic System

A programmable electronic system is a system

- for control, protection or monitoring,
- dependent for its operation on one or more programmable electronic devices,
- including all elements of the system such as input and output devices.

## PGN

PGN = **P**arameter **G**roup **N**umber

PGN = PDU format (PF) + PDU source (PS)

The parameter group number is an item of the CAN protocol SAE J1939. PGN collects the address parts PF and PS.

## Pictogram


Pictograms are figurative symbols which convey information by a simplified graphic representation.

→ chapter [What do the symbols and formats mean?](#) (→ page [7](#))

## PID controller


### P = proportional part

The P controller exclusive consists of a proportional part of the amplification  $K_p$ . The output signal is proportional to the input signal.




### I = integral part

An I controller acts to the manipulating variable by phasing integration of the control deviation with emphasis on the reset time  $T_N$ .



### D = differential part

The D controller doesn't react on the control deviation but only on their speed of change.



## PL

### Performance Level

According to ISO 13849-1, a specification (PL a...e) of safety-related parts of control systems to perform a safety function under foreseeable conditions.

→ Chapter [Performance Level PL](#)

## PLC configuration

Part of the CoDeSys user interface.

- The programmer tells the programming system which hardware is to be programmed.
- > CoDeSys loads the corresponding libraries.
- > Reading and writing the peripheral states (inputs/outputs) is possible.

## PLr

Using the "required performance level"  $PL_r$  the risk reduction for each safety function according to ISO 13849 is achieved.

For each selected safety function to be carried out by a SRP/CS, a  $PL_r$  shall be determined and documented. The determination of the  $PL_r$  is the result of the risk assessment and refers to the amount of the risk reduction.

## Pre-Op

Pre-Op = PRE-OPERATIONAL mode

Operating status of a CANopen participant. After application of the supply voltage each participant automatically passes into this state.



In the CANopen network only SDOs and NMT commands can be transferred in this mode but no process data.

## prepared

Operating status of a CANopen participant. In this mode only NMT commands are transferred.

## Process image

Process image is the status of the inputs and outputs the PLC operates with within one cycle.

- At the beginning of the cycle the PLC reads the conditions of all inputs into the process image.  
During the cycle the PLC cannot detect changes to the inputs.
- During the cycle the outputs are only changed virtually (in the process image).
- At the end of the cycle the PLC writes the virtual output states to the real outputs.

## Programming language, safety-related

Only the following programming languages shall be used for safety-related applications:

- Limited variability language (LVL) that provides the capability of combining predefined, application-specific library functions.  
In CoDeSys these are LD (ladder diagram) and FBD (function block diagram).
- Full variability language (FVL) provides the capability of implementing a wide variety of functions.  
These include e.g. C, C++, Assembler. In CoDeSys it is ST (structured text).
- ▶ Structured text is recommended exclusively in separate, certified functions, usually in embedded software.
- ▶ In the "normal" application program only LD and FBD should be used. The following minimum requirements shall be met.

In general the following minimum requirements are made on the safety-related application software (SRASW):

- ▶ Modular and clear structure of the program. Consequence: simple testability.
- ▶ Functions are represented in a comprehensible manner:
  - for the operator on the screen (navigation)
  - readability of a subsequent print of the document.
- ▶ Use symbolic variables (no IEC addresses).
- ▶ Use meaningful variable names and comments.
- ▶ Use easy functions (no indirect addressing, no variable fields).
- ▶ Defensive programming.
- ▶ Easy extension or adaptation of the program possible.

## Protective measure

Measure intended to achieve risk reduction, e.g.:

- fault-excluding design,
- safeguarding measures (guards),
- complementary protective measures (user information),
- personal protective equipment (helmet, protective goggles).

## PWM

PWM = pulse width modulation

Via PWM a digital output (capability provided by the device) can provide an almost analogue voltage by means of regular fast pulses. The PWM output signal is a pulsed signal between GND and supply voltage.

Within a defined period (PWM frequency) the mark-to-space ratio is varied. Depending on the mark-to-space ratio, the connected load determines the corresponding RMS current.  
→ chapter [PWM signal processing](#) (→ page [214](#))  
→ chapter [What does a PWM output do?](#)

## R

### Ratio

Measurements can also be performed ratiometrically. The input signal generates an output signal which is in a defined ratio to the input signal. This means that analogue input signals can be evaluated without additional reference voltage. A fluctuation of the supply voltage has no influence on this measured value.

→ Chapter **Counter functions for frequency and period measurement** (→ page [198](#))

### RAW-CAN

RAW-CAN means the pure CAN protocol which works without an additional communication protocol on the CAN bus (on ISO/OSI layer 2). The CAN protocol is international defined according to ISO 11898-1 and guarantees in ISO 16845 the interchangeability of CAN chips in addition.

### Redundant

Redundancy is the presence of more than the necessary means so that a function unit performs a requested function or that data can represent information.

Several kinds of redundancy are distinguished:

- Functional redundancy aims at designing safety-related systems in multiple ways in parallel so that in the event of a failure of one component the others ensure the task.
- In addition it is tried to separate redundant systems from each other with regard to space. Thus the risk that they are affected by a common interference is minimised.
- Finally, components from different manufacturers are sometimes used to avoid that a systematic fault causes all redundant systems to fail (diverse redundancy).

The software of redundant systems should differ in the following aspects:

- specification (different teams),
- specification language,
- programming (different teams),
- programming language,
- compiler.

### Remanent

Remanent data is protected against data loss in case of power failure.

The operating system for example automatically copies the remanent data to a flash memory as soon as the voltage supply falls below a critical value. If the voltage supply is available again, the operating system loads the remanent data back to the RAM memory.

The data in the RAM memory of a controller, however, is volatile and normally lost in case of power failure.

### Reset, manual

The manual reset is an internal function within the SRP/CS used to restore manually one or more safety functions before re-starting a machine.

### Residual risk

Risk remaining after protective measures have been taken. The residual risk has to be clearly warned against in operating instructions and on the machine.

### Risk

Combination of the probability of occurrence of harm and the severity of that harm.

### Risk analysis

Combination of ...

- the specification of the limits of the machine (intended use, time limits),
- hazard identification (intervention of people, operating status of the machine, foreseeable misuse) and
- the risk estimation (degree of injury, extent of damage, frequency and duration of the risk, probability of occurrence, possibility of avoiding the hazard or limiting the harm).

### Risk assessment

Overall process comprising risk analysis and risk evaluation.

According to Machinery Directive 2006/42/EU the following applies: "The manufacturer of machinery or his authorised representative must ensure that a risk assessment is carried out in order to determine the health and safety requirements which apply to the machinery. The machinery must then be designed and constructed taking into account the results of the risk assessment." (→ Annex 1, General principles)

## Risk evaluation

Judgement, on the basis of the risk analysis, of whether risk reduction objectives have been achieved.

## ro

RO = read only for reading only

Unidirectional data transmission: Data can only be read and not changed.

## RTC

RTC = Real Time Clock

Provides (batter-backed) the current date and time. Frequent use for the storage of error message protocols.

## rw

RW = read/ write

Bidirectional data transmission: Data can be read and also changed.

## S

### SAE J1939

The network protocol SAE J1939 describes the communication on a CAN bus in commercial vehicles for transmission of diagnosis data (e.g. engine speed, temperature) and control information.

→ CiA DS 402

Standard: "Recommended Practice for a Serial Control and Communications Vehicle Network"

Part 2: "Agricultural and Forestry Off-Road Machinery Control and Communication Network"

Part 3: "On Board Diagnostics Implementation Guide"

Part 5: "Marine Stern Drive and Inboard Spark-Ignition Engine On-Board Diagnostics Implementation Guide"

Part 11: "Physical Layer – 250 kBits/s, Shielded Twisted Pair"

Part 13: "Off-Board Diagnostic Connector"

Part 15: "Reduced Physical Layer, 250 kBits/s, Un-Shielded Twisted Pair (UTP)"

Part 21: "Data Link Layer"

Part 31: "Network Layer"

Part 71: "Vehicle Application Layer"

Part 73: "Application Layer – Diagnostics"

Part 81: "Network Management Protocol"

## Safety function

Function of the machine whose failure can result in an immediate increase of the risk(s). The designer of such a machine therefore has to:

- safely prevent a failure of the safety function,
- reliably detect a failure of the safety function in time,
- bring the machine into a safe state in time in the event of a failure of the safety function.

## Safety-standard types

The safety standards in the field of machines are structured as below:

Type-A standards (basic safety standards) giving basic concepts, principles for design, and general aspects that can be applied to all machinery. Examples: basic terminology, methodology (ISO 12100-1), technical principles (ISO 12100-2), risk assessment (ISO 14121), ...

Type-B standards (generic safety standards) dealing with one safety aspect or one type of safeguard that can be used across a wide range of machinery.

- Type-B1 standards on particular safety aspects. Examples: safety distances (EN 294), hand/arm speeds (EN 999), safety-related parts of control systems (ISO 13849), temperatures, noise, ...
- Type-B2 standards on safeguards. Examples: emergency stop circuits ((ISO 13850), two-hand controls, interlocking devices or electro-sensitive protective equipment (ISO 61496), ...

Type-C standards (machine safety standards) dealing with detailed safety requirements for a particular machine or group of machines.

## SCT

In CANopen safety the **Safeguard Cycle Time** (SCT) monitors the correct function of the periodic transmission (data refresh) of the SRDOs. The data must have been repeated within the set time to be valid. Otherwise the receiving controller signals a fault and passes into the safe state (= outputs switched off).

## SD card

An SD memory card (short for **Secure Digital Memory Card**) is a digital storage medium that operates to the principle of flash storage.

## SDO

SDO = **S**ervice **D**ata **O**bject.

SDO is a specification for a manufacturer-dependent data structure for standardised data access. "Clients" ask for the requested data from "servers". The SDOs always consist of 8 bytes. Longer data packages are distributed to several messages.

### Examples:

- Automatic configuration of all slaves via SDOs at the system start,
- reading error messages from the object directory.

Every SDO is monitored for a response and repeated if the slave does not respond within the monitoring time.

## Self-test

Test program that actively tests components or devices. The program is started by the user and takes a certain time. The result is a test protocol (log file) which shows what was tested and if the result is positive or negative.

## SIL

According to IEC 62061 the safety-integrity level SIL is a classification (SIL CL 1...4) of the safety integrity of the safety functions. It is used for the evaluation of electrical/electronic/programmable electronic

(E/E/EP) systems with regard to the reliability of safety functions. The safety-related design principles that have to be adhered to so that the risk of a malfunction can be minimised result from the required level.

## Slave

Passive participant on the bus, only replies on request of the →master. Slaves have a clearly defined and unique →address in the bus.

## SRDO

Safe data is exchanged via SRDOs (**S**afety-**R**elated **D**ata **O**bjects). An SRDO always consists of two CAN messages with different identifiers:

- message 1 contains the original user data,
- message 2 contains the same data which are inverted bit by bit.

## SRP/CS

### Safety-Related Part of a Control System

Part of a control system that responds to safety-related input signals and generates safety-related output signals. The combined safety-related parts of a control system start at the point where the safety-related input signals are initiated (including, for example, the actuating cam and the roller of the position switch) and end at the output of the power control elements (including, for example, the main contacts of a contactor).

## SRVT

The SRVT (**S**afety-**R**elated **O**bject **V**alidation **T**ime) ensures with CANopen safety that the time between the SRDO-message pairs is adhered to.

Only if the redundant, inverted message has been transmitted after the original message within the SRVT set are the transmitted data valid. Otherwise the receiving controller signals a fault and will pass into the safe state (= outputs switched off).

**State, safe**

The state of a machine is said to be safe when there is no more hazard formed by it. This is usually the case if all possible dangerous movements are switched off and cannot start again unexpectedly.

**Symbols**

Pictograms are figurative symbols which convey information by a simplified graphic representation.

→ chapter **What do the symbols and formats mean?** (→ page [7](#))

**System variable**

Variable to which access can be made via IEC address or symbol name from the PLC.

**T****Target**

The target indicates the target system where the PLC program is to run. The target contains the files (drivers and if available specific help files) required for programming and parameter setting.

**TCP**

The **Transmission Control Protocol** is part of the TCP/IP protocol family. Each TCP/IP data connection has a transmitter and a receiver. This principle is a connection-oriented data transmission. In the TCP/IP protocol family the TCP as the connection-oriented protocol assumes the task of data protection, data flow control and takes measures in the event of data loss. (compare: →UDP)

**Template**

A template can be filled with content.  
Here: A structure of pre-configured software elements as basis for an application program.

**Test rate  $r_t$** 

The test rate  $r_t$  is the frequency of the automatic tests to detect errors in an SRP/CS in time.

**U****UDP**

UDP (**U**ser **D**atagram **P**rotocol) is a minimal connectionless network protocol which belongs to the transport layer of the internet protocol family. The task of UDP is to ensure that data which is transmitted via the internet is passed to the right application.

At present network variables based on CAN and UDP are implemented. The values of the variables are automatically exchanged on the basis of broadcast messages. In UDP they are implemented as broadcast messages, in CAN as PDOs. These services are not confirmed by the protocol, i.e. it is not checked whether the message is received. Exchange of network variables corresponds to a "1 to n connection" (1 transmitter to n receivers).

**Uptime, mean**

**Mean Time Between Failures (MTBF)**

Is the expected value of the operating time between two consecutive failures of items that are maintained.

**I** For items that are NOT maintained the mean life →MTTF is the expected value (mean value) of the distribution of lives.

**Use, intended**

Use of a product in accordance with the information provided in the instructions for use.

**W****Watchdog**

In general the term watchdog is used for a component of a system which watches the function of other components. If a possible malfunction is detected, this is either signalled or suitable program branchings are activated. The signal or branchings serve as a trigger for other co-operating system components to solve the problem.

**wo**

WO = write only

Unidirectional data transmission: Data can only be changed and not read.



# 14 Index

A distinction is made between the following errors:	184	Write DCF	127
About the ifm templates	33	CAN stack	343
About this manual	7	CAN units acc. to SAE J1939	99
Access to the CANopen slave at runtime	148	CAN1_BAUDRATE	79
Access to the OD entries by the application program	148	CAN1_DOWNLOADID	81
Access to the status of the CANopen master	138	CAN1_ERRORHANDLER	82
Access to the structures at runtime of the application	165	CAN1_EXT	91
Activating the PLC configuration (e.g. CR0020)	28	CAN1_EXT_ERRORHANDLER	92
Adapt bitmap graphics	333	CAN1_EXT_RECEIVE	93
Adapting analogue values	192	CAN1_EXT_RECEIVE_ALL	95
Add and configure CANopen slaves	126	CAN1_EXT_TRANSMIT	97
Add missing libraries	46	CAN1_MASTER_EMCY_HANDLER	156
Address	343	CAN1_MASTER_SEND_EMERGENCY	158
Address assignment and I/O operating modes	299	CAN1_MASTER_STATUS	161
Address assignment inputs / outputs	302	CAN1_RECEIVE	84
Address assignment of the inputs	302	CAN1_RECEIVE_RANGE	86
Address assignment of the outputs	302	CAN1_SDO_READ	177
Addresses / variables of the I/Os	300	CAN1_SDO_WRITE	179
Addresses / variables of the inputs	300	CAN1_SLAVE_EMCY_HANDLER	168
Addresses / variables of the outputs	301	CAN1_SLAVE_NODEID	167
Adopt application program?	51	CAN1_SLAVE_SEND_EMERGENCY	170
ANALOG_RAW	190	CAN1_SLAVE_STATUS	173
Annex	298	CAN1_TRANSMIT	89
Application software	343	CAN-ID	74
Applications	199	CANopen error code	313
Architecture	343	CANopen master	120
Automatic configuration of slaves	131	Tab [CAN parameters]	123
Availability of PWM	214	CANopen network configuration, status and	
Available CAN interfaces and CAN protocols	67	error handling	117
Available memory	55	CANopen network variables	149
Base settings		CANopen slave	141
Bus identifier	142	Tab [CAN parameters]	127
Generate EDS file	142	CANopen slave configuration	142
Name of updatetask	142	CANopen status of the node	136, 312
Basic information about bitmap graphics	331	CANopen support by CoDeSys	118
Baud	343	CANopen tables	304
Boot loader	343	CANopen terms and implementation	118
Boot up of the CANopen master	133	CANx_ERRORHANDLER	82
Boot up of the CANopen slaves	135	CANx_EXT_RECEIVE_ALL	95
Bootup message	309	CANx_MASTER_EMCY_HANDLER	156
Bus	343	CANx_MASTER_SEND_EMERGENCY	158
Bus cable length	71	CANx_MASTER_STATUS	161
Calculation examples RELOAD value	218	CANx_RECEIVE	84
Calculation of the RELOAD value	217	CANx_RECEIVE_RANGE	86
CAN	343	CANx_SDO_READ	177
CAN bus level	70	CANx_SDO_WRITE	179
CAN bus level according to ISO 11992-1	70	CANx_SLAVE_EMCY_HANDLER	168
CAN errors	181	CANx_SLAVE_NODEID	167
CAN errors and error handling	181	CANx_SLAVE_SEND_EMERGENCY	170
CAN for the drive engineering	99	CANx_SLAVE_STATUS	173
CAN interfaces	66	CANx_TRANSMIT	89
CAN parameters		Category (CAT)	343
Automatic startup	125	CCF	343
Baud rate	123	Change device settings	16
Communication cycle	128	Change password	19
Communication Cycle Period/Sync. Window Length	124	Change the PDO properties at runtime	148
Create all SDOs	127	Changing the standard mapping by the	
Emergency telegram	128	master configuration	147
Heartbeat	125	Check function of keys and LEDs	21
No initialization	127	Check suitability for use	319
Node ID	124, 127	CHECK_DATA	272
Node reset	127	CiA	343
Nodeguarding / heartbeat settings	128	CiA DS 304	344
Optional device	127	CiA DS 401	344
Sync. COB ID	124	CiA DS 402	344
		CiA DS 403	344

## Index

CiA DS 404 .....	344	CHECK_DATA .....	273
CiA DS 405 .....	344	detailed message documentation .....	101
CiA DS 406 .....	344	Initialisation of CANx_RECEIVE_RANGE in 4 cycles .....	88
CiA DS 407 .....	344	list of variables .....	146
Clamp 15 .....	344	reducing a pixel image .....	332
COB-ID .....	344	short message documentation .....	102
CoDeSys .....	344	Example 1 .....	194
CoDeSys CANopen libraries .....	339	Example 2 .....	194
CoDeSys visualisation elements .....	57	Example of an object directory .....	143
Colours .....	321	Exchange of CAN data .....	73
Communication via interfaces .....	240	Exit PDM setup, restart device .....	22
Configuration of all correctly detected devices .....	130	Failure .....	346
Configuration of CANopen network variables .....	150	Failure, dangerous .....	347
Configurations .....	13	Failure, systematic .....	347
CONTROL_ANALOGCLOCK .....	293	FAST_COUNT .....	212
Controlled system with delay .....	228	Fault .....	347
Controlled system without inherent regulation .....	228	Fault tolerance time .....	347
Controller functions .....	227	FB, FUN, PRG in CoDeSys .....	59
Controlling the cycle time .....	281	FiFo .....	347
Counter functions for frequency and period measurement .....	199	Files for the operating system / runtime system .....	337
CPU frequency .....	53	Firmware .....	347
CRC .....	344	First fault occurrence time .....	347
Create a CANopen project .....	122	First steps .....	46
Create PLC program .....	50	Flash memory .....	347
Create visualisation .....	48	FLASHREAD .....	260
Creating application program .....	63	FLASHWRITE .....	258
Cultural details are often not transferable .....	320	FMEA .....	348
Cycle time .....	344	Folder structure in general .....	33
Cyclical transmission of the SYNC message .....	131	FRAM .....	348
Damping of overshoot .....	229	FRAMREAD .....	264
Data access and data check .....	266	FRAMWRITE .....	262
Data reception .....	76	FREQUENCY .....	201
Data transmission .....	76	Function code / Predefined Connectionset .....	306
DC .....	344	Functional safety .....	348
DELAY .....	231	Functionality of the CANopen slave library .....	141
Demand rate rd .....	345	Functions for controllers .....	230
Demo program for controller .....	40	Further ifm libraries for CANopen .....	176
Demo programs for PDM and BasicDisplay .....	42	General .....	227, 316
Description of the CAN standard program units .....	77	General about CAN .....	65
Device update to new software version .....	51	General information .....	149
Device update with the downloader .....	52	General information about CANopen with CoDeSys .....	118
Diagnosis .....	345	General overview .....	335
Diagnostic coverage .....	345	GET_IDENTITY .....	269
Differentiation from other CANopen libraries .....	120	GET_TEXT_FROM_FLASH .....	255
Directives and standards .....	323	Global variable list	
Dither .....	345	Acknowledgement .....	153
Diversity .....	345	Cyclic transmission .....	153
Do you know the future users? .....	318	List identifier (COB-ID) .....	152
DRAM .....	346	Network type .....	152
DTC .....	346	Pack variables .....	152
ECU .....	346	Read .....	153
EDS-file .....	346	Transmit checksum .....	153
Embedded software .....	346	Transmit on change .....	153
EMC .....	346	Transmit on event .....	153
EMCY .....	346	Write .....	153
EMCY error code .....	185	Global variable of this program .....	286
Emergency messages .....	313	GLR .....	238
Error and diagnosis .....	298	Harm .....	348
Error counter .....	182	Hazard .....	348
Error message .....	181	Heartbeat .....	348
Ethernet .....	346	Heartbeat from the master to the slaves .....	131
EUC .....	346	Hints .....	74
Example		Hints to wiring diagrams .....	44
CANx_MASTER_SEND_EMERGENCY .....	160	HMI .....	348
CANx_MASTER_STATUS .....	164	How is this manual structured? .....	8
CANx_SLAVE_SEND_EMERGENCY .....	172	ID .....	348
		Identifier .....	185
		Identifier acc. to SAE J1939 .....	100

## Index

IDs (addresses) in CANopen.....	119, 304	Manufacturer specific information .....	187
IEC user cycle .....	349	Master .....	350
ifm CANopen libraries.....	116	Master at runtime.....	130
ifm CANopen libraries master / slave .....	338	MEMCPY .....	257
ifm demo programs.....	40	Mission time TM .....	350
ifm device libraries.....	338	Misuse .....	350
ifm library for the CANopen master .....	155	MMI.....	350
ifm library for the CANopen slave .....	166	Monitoring .....	350
ifm weltweit • ifm worldwide • ifm à l'échelle internationale ..	363	MRAM .....	350
Illustrations .....	322	MSB .....	350
Image size vector graphics / pixel graphics.....	332	MTBF .....	350
Important! .....	9	MTTF .....	350
INC_ENCODER .....	209	MTTFd .....	350
Information concerning the device .....	11	Muting .....	350
Information concerning the software .....	11	Network management (NMT) .....	309
Initialisation of the network with RESET_ALL_NODES .....	137	Network management commands.....	309
Input/output functions .....	189	Network states .....	133
Installation of the files and libraries .....	334	Network structure .....	69
Instructions .....	349	NMT .....	350
Intended use.....	349	NMT state .....	310
IP address .....	349	NMT state for CANopen master .....	134, 310
ISO 10646 _ Information technology — Universal multiple-octet coded character set (UCS).....	328	NMT state for CANopen slave.....	135, 311
ISO 11898 .....	349	Node .....	350
ISO 11992 .....	349	Node Guarding .....	351
ISO 13406 _Ergonomic requirements for work with visual displays based on flat panels .....	329	Nodeguarding with lifetime monitoring .....	131
ISO 13407 _ Human-centred design processes for interactive systems .....	329	NORM .....	193
ISO 16845 .....	349	NORM_DINT .....	195
ISO 20282 _ Ease of operation of everyday products .....	330	NORM_REAL .....	197
ISO 7001 _ Graphical symbols - Public information symbols.....	323	Note the cycle time! .....	60
ISO 9126 _ Software engineering - Product quality .....	324	Obj / object .....	351
ISO 9241 _ Ergonomics of human-system interaction .....	326	Object 0x1001 (error register) .....	187, 315
ISO 9241-11 _ Guidance on usability.....	327	Object 0x1003 (error field).....	185
ISO 9241-110 _ Dialogue principles.....	327	Object directory .....	351
J1939_1 .....	104	OBV .....	351
J1939_1 GLOBAL_REQUEST .....	114	Operating mode of the row of LEDs .....	295
J1939_1 RECEIVE .....	106	Operating sequence .....	62
J1939_1_RESPONSE .....	110	Operating system .....	351
J1939_1_SPECIFIC_REQUEST.....	112	Operational .....	351
J1939_1_TRANSMIT .....	108	Optimising the PLC cycle .....	274
J1939_x .....	104	Overview CANopen EMCY codes (CR107n) .....	188
J1939_x GLOBAL_REQUEST .....	114	Overview CANopen error codes.....	186, 314
J1939_x RECEIVE .....	106	Overview of the files and libraries used.....	334
J1939_x_RESPONSE .....	110	Parameters of internal structures .....	163
J1939_x_SPECIFIC_REQUEST .....	112	Participant, bus off.....	183
J1939_x_TRANSMIT.....	108	Participant, error active.....	182
Language as an obstacle .....	319	Participant, error passive.....	182
LED .....	349	Particularities for network variables.....	154
LED, buzzer, visualisation .....	284	PC card .....	351
Libraries .....	61	PCMCIA card.....	351
Libraries for CANopen .....	155	PDM .....	351
Library Instrumente.....	291	PDM_PAGECONTROL .....	289
Life, mean .....	349	PDMsmart_MAIN.....	285
Limitations and programming notes .....	53	PDMsmart_MAIN_MAPPER .....	287
Limitations for PDM360smart .....	55	PDO .....	351
Limits of the device.....	53	PDO-Mapping .....	
Link .....	349	Insert .....	128
Load the application program into the controller .....	52	Properties.....	129
LSB .....	349	PDU .....	351
MAC-ID .....	349	Performance Level .....	351
Manage visualisation .....	284	PERIOD .....	203
Managing the data .....	247	PERIOD_RATIO .....	205
Manual data storage.....	254	PES.....	352
		PGN .....	352
		PHASE .....	207
		Physical connection of CAN .....	69
		Pictogram .....	352



## Index

PID controller .....	352	Saving, reading and converting data in the memory .....	254
PID1 .....	233	SCALE_LED_GRAF .....	294
PID2 .....	235	SCALE_METER .....	296
PL .....	352	SCT .....	356
PLC configuration .....	12, 352	SD card .....	356
PLC configuration file .....	337	SDO .....	356
PLCPRGTC .....	282	SDO abort code .....	308
PLr .....	352	SDO command bytes .....	307
Polling of the slave device type .....	130	Self-regulating process .....	227
Possible operating modes of inputs / outputs .....	301	Self-test .....	356
Pre-Op .....	352	SERIAL_PENDING .....	246
prepared .....	353	SERIAL_RX .....	244
Process image .....	353	SERIAL_SETUP .....	241
Processing input values .....	189	SERIAL_TX .....	243
Processing interrupts .....	274	Set CAN baud rate .....	17
Programming interfaces .....	23	Set CAN download ID .....	17
Programming language, safety-related .....	353	Set CoDeSys communication parameters for the CAN interface .....	25
Programming notes for CoDeSys projects .....	59	Set CoDeSys communication parameters for the serial interface .....	23
Programming via the CAN interface .....	24	Set device parameters (setup) .....	13
Programming via the serial interface RS232 .....	23	Set serial interface .....	18
Programs and functions in the folders of the templates .....	34	Set the brightness / contrast of the display .....	21
Protective measure .....	353	Set up programming system .....	26
PT1 .....	232	Set up programming system manually .....	26
PWM .....	221, 353	Set up programming system via templates .....	30
PWM – introduction .....	215	SET_IDENTITY .....	267
PWM / PWM1000 .....	216	SET_INTERRUPT_I .....	278
PWM channels 0...3 .....	217	SET_INTERRUPT_XMS .....	275
PWM channels 4...7 / 8...11 (if exist) .....	219	SET_PASSWORD .....	271
PWM dither .....	220	Setting control .....	229
PWM frequency .....	216	Setting of the node numbers and the baud rate of a CANopen slave .....	148
PWM functions .....	214	Setting rule for a controller .....	229
PWM functions and their parameters .....	216	Settings in the global variable lists .....	151
PWM signal processing .....	215	Settings in the target settings .....	150
PWM100 .....	223	Setup the target .....	27
PWM1000 .....	225	Show the current device settings .....	15
Ramp function .....	220	Signalling of device errors .....	185
Ratio .....	354	SIL .....	356
RAW-CAN .....	354	Slave .....	356
Reading / writing the system time .....	249	Slave information .....	164
Reading direction .....	322	SOFTRESET .....	248
Reading of the device temperature .....	252	Software reset .....	247
Reception of emergency messages .....	131	Specific ifm libraries .....	340
Recommendations for a user-friendly product design .....	317	SRDO .....	356
Recommendations for user interfaces .....	317	SRP/CS .....	356
Recommended setting .....	237	SRVT .....	356
Recommended settings .....	234	Start of all correctly configured slaves .....	131
Rectify faults and errors .....	298	Start set-up .....	14
Redundant .....	354	Start the network .....	132
Remanent .....	354	Starting the network with GLOBAL_START .....	137
Resample / scale image .....	56	Starting the network with START_ALL_NODES .....	137
Reset device to factory settings .....	20	Start-up of the network without [Automatic startup] .....	137
Reset of all configured slaves on the bus at the system start .....	130	State, safe .....	357
Reset, manual .....	354	Structure Emergency_Message .....	165
Residual risk .....	354	Structure node status .....	164
Risk .....	354	Structure of an EMCY message .....	184
Risk analysis .....	354	Structure of an error message .....	184
Risk assessment .....	354	Structure of CANopen messages .....	305
Risk evaluation .....	355	Structure of the COB ID .....	305
ro .....	355	Structure of the visualisations in the templates .....	36
RTC .....	355	Summary CAN / CANopen .....	75
rw .....	355	Supplement project with further functions .....	37
SAE J1939 .....	355	Symbols .....	322, 357
Safety function .....	355	System configuration .....	68
Safety instructions .....	9		
Safety-standard types .....	355		

## Index

System description .....	11	UDP .....	357
System flags .....	303	Units for SAE J1939 .....	103
System messages and operating states .....	299	Uptime, mean .....	357
System variable .....	357	Use as digital inputs .....	200
Tab [Base settings] .....	142	Use of the serial interface .....	240
Tab [CAN settings] .....	144	Use, intended .....	357
Tab [Default PDO mapping] .....	145	Using CAN .....	65
Tab [Receive PDO-Mapping] and [Send PDO-Mapping] .....	128	Using ifm downloader .....	64
Tab [Service Data Objects] .....	129	Visualisation limits .....	56
Target .....	357	Visualisations in the device .....	316
Target file .....	337	Watchdog .....	357
TCP .....	357	Watchdog behaviour .....	54
Technical about CANopen .....	117	What are the individual files and libraries used for? .....	337
TEMPERATURE .....	253	What do the symbols and formats mean? .....	7
Template .....	357	What is required? .....	51
Test rate rt .....	357	What previous knowledge is required? .....	10
Texts .....	58	Wire cross-sections .....	72
The object directory of the CANopen master .....	139	wo .....	357
TIMER_READ .....	250		
TIMER_READ_US .....	251		
TOGGLE .....	191		
Topology .....	65		
Transmit emergency messages via the application program .....	148		

**ifm Niederlassungen • Sales offices • Agences**

D	ifm electronic gmbh Vertrieb Deutschland Niederlassung Nord • 31135 Hildesheim • Tel. 0 51 21 / 76 67-0 Niederlassung West • 45128 Essen • Tel. 02 01 / 3 64 75 -0 Niederlassung Mitte-West • 58511 Lüdenscheid • Tel. 0 23 51 / 43 01-0 Niederlassung Süd-West • 64646 Heppenheim • Tel. 0 62 52 / 79 05-0 Niederlassung Baden-Württemberg • 73230 Kirchheim • Tel. 0 70 21 / 80 86-0 Niederlassung Bayern • 82178 Puchheim • Tel. 0 89 / 8 00 91-0 Niederlassung Ost • 07639 Tautenhain • Tel. 0 36 601 / 771-0 ifm electronic gmbh • Friedrichstraße 1 • 45128 Essen
A	ifm electronic gmbh • 1120 Wien • Tel. +43 16 17 45 00
AUS	ifm efector Pty Ltd. • Mulgrave Vic 3170 • Tel. +61 3 00 365 088
B, L	ifm electronic N.V. • 1731 Zellik • Tel. +32 2 / 4 81 02 20
BR	ifm electronic Ltda. • 03337-000, Sao Paulo SP • Tel. +55 11 / 2672-1730
CH	ifm electronic ag • 4 624 Härkingen • Tel. +41 62 / 388 80 30
CN	ifm electronic Co. Ltd. • 201210 Shanghai • Tel. +86 21 / 5027 8559
CND	ifm efector Canada inc. • Oakville, Ontario L6K 3V3 • Tel. +1 800-441-8246
CZ	ifm electronic spol. s.r.o. • 25243 Průhonice • Tel. +420 267 990 211
DK	ifm electronic a/s • 2605 BROENDBY • Tel. +45 70 20 11 08
E	ifm electronic s.a. • 08820 El Prat de Llobregat • Tel. +34 93 479 30 80
F	ifm electronic s.a. • 93192 Noisy-le-Grand Cedex • Tél. +33 0820 22 30 01
FIN	ifm electronic oy • 00440 Helsinki • Tel. +358 75 329 5000
GB, IRL	ifm electronic Ltd. • Hampton, Middlesex TW12 2HD • Tel. +44 208 / 213-0000
GR	ifm electronic Monoprosopi E.P.E. • 15125 Amaroussio • Tel. +30 210 / 6180090
H	ifm electronic kft. • 9028 Győr • Tel. +36 96 / 518-397
I	ifm electronic s.a. • 20041 Agrate-Brianza (MI) • Tel. +39 039 / 68.99.982
IL	Astragal Ltd. • Azur 58001 • Tel. +972 3 -559 1660
IND	ifm electronic India Branch Office • Kolhapur, 416234 • Tel. +91 231-267 27 70
J	efector co., ltd. • Togane-shi, Chiba 283-0826 • Tel. +81 475-50-3003
MAL	ifm electronic Pte. Ltd • 80250 Johor Bahru Johor • Tel. +60 7 / 331 5022
MEX	ifm efector S. de R. L. de C. V. • Monterrey, N. L. 64630 • Tel. +52 81 8040-3535
N	Sivilingeniør J. F. Knudtzen A/S • 1396 Billingstad • Tel. +47 66 / 98 33 50
NL	ifm electronic b.v. • 3843 GA Harderwijk • Tel. +31 341 / 438 438
P	ifm electronic s.a. • 4430-208 Vila Nova de Gaia • Tel. +351 223 / 71 71 08
PL	ifm electronic Sp. z o.o. • 40-524 Katowice • Tel. +48 32-608 74 54
RA, ROU	ifm electronic s.r.l. • 1107 Buenos Aires • Tel. +54 11 / 5353 3436
ROK	ifm electronic Ltd. • 140-884 Seoul • Tel. +82 2 / 790 5610
RP	Gram Industrial, Inc. • 1770 Mantilupa City • Tel. +63 2 / 850 22 18
RUS	ifm electronic • 105318 Moscow • Tel. +7 495 921-44-14
S	ifm electronic a b • 512 60 Överlida • Tel. +46 325 / 661 500
SGP	ifm electronic Pte. Ltd. • Singapore 609 916 • Tel. +65 6562 8661/2/3
SK	ifm electronic s.r.o. • 835 54 Bratislava • Tel. +421 2 / 44 87 23 29
THA	Sang Chai Meter Co., Ltd. • Bangkok 10 400 • Tel. +66 2 / 616 80 51
TR	ifm electronic Ltd. Sti. • 34381 Sisli/Istanbul • Tel. +90 212 / 210 50 80
UA	TOV ifm electronic • 02660 Kiev • Tel. +380 44 501 8543
USA	ifm efector inc. • Exton, PA 19341 • Tel. +1 610 / 5 24-2000
ZA	ifm electronic (Pty) Ltd. • 0157 Pretoria • Tel. +27 12 345 44 49

Technische Änderungen behalten wir uns ohne vorherige Ankündigung vor.  
 We reserve the right to make technical alterations without prior notice.  
 Nous nous réservons le droit de modifier les données techniques sans préavis.