



Operating Instructions
IO-Link Master with EtherCAT interface
DataLine
8 Ports
IP 65 / IP 66 / IP 67

AL1332

IO-Link: 1.1.2
ifm firmware: 2.0.35 or higher
LR DEVICE: 1.2.0.107 or higher

English

Contents

1	Preliminary note	5
1.1	Legal and copyright information	5
1.2	Purpose of the document	5
1.3	Symbols and styles used	6
1.4	Modification history	6
2	Safety instructions	7
2.1	General	7
2.2	Required background knowledge	7
2.3	Warnings used	8
2.4	Safety symbols on the device	8
2.5	Tampering with the unit	8
3	Intended use	9
3.1	Permitted use	9
3.2	Prohibited use	9
4	Function	10
4.1	Communication, parameter setting, evaluation	11
4.1.1	IO-Link	11
4.1.2	EtherCAT	11
4.1.3	Internet of Things (IoT)	11
4.1.4	Parameter setting	11
4.1.5	Visual indication	12
4.2	Digital inputs	12
4.3	IO-Link supply	12
5	Mounting	13
5.1	Mount the device	13
6	Electrical connection	14
6.1	Remarks	14
6.2	EtherCAT ports	15
6.3	IoT port	16
6.4	IO-Link ports	17
6.4.1	Input circuit	17
6.4.2	IO-Link circuits	18
6.5	Connect the device	19
7	Operating and display elements	20
7.1	Overview	20
7.2	LED indicators	21
7.2.1	Status LEDs	21
7.2.2	EtherCAT interface	22
7.2.3	IoT port	22
7.2.4	Voltage supply	22
7.2.5	IO-Link ports (Class A)	23

8	Configuration	24
8.1	LR DEVICE	25
8.1.1	Remarks	26
8.1.2	IoT: Configure access rights	27
8.1.3	IoT: Configure IP settings	28
8.1.4	IoT: Configure the interface to the LR SMARTOBSERVER	29
8.1.5	Fieldbus: Configure the EtherCAT port	29
8.1.6	IO-Link ports: Activate data transfer to the LR SMARTOBSERVER	30
8.1.7	IO-Link ports: Configure operating mode	31
8.1.8	IO-Link ports: Set the device validation and data storage	32
8.1.9	Info: Show device information	33
8.1.10	Firmware: Reset device to factory settings	33
8.1.11	Firmware: Reboot the device	33
8.1.12	Configure IO-Link devices	34
8.2	EtherCAT	35
8.2.1	Install ESI file	35
8.2.2	Integrate the AL1332 into the EtherCAT project	36
8.2.3	Configure IO-Link master	36
8.2.4	Configure IO-Link ports	36
8.2.5	Configure cyclic process data	37
8.2.6	Read and write cyclic process data	38
8.2.7	Read diagnostic and status information	39
8.2.8	Configure IO-Link devices	40
8.2.9	EtherCAT: Programmers' notes	41
8.3	IoT Core	43
8.3.1	Configure IoT port	44
8.3.2	Configure the fieldbus port	44
8.3.3	Configure IO-Link ports	45
8.3.4	Set application identification	45
8.3.5	Read / write cyclic process data	45
8.3.6	Read diagnostic data	46
8.3.7	Read device information	46
8.3.8	Read information about IO-Link devices	47
8.3.9	Configure IO-Link devices	47
8.3.10	Control IO-Link master	47
8.3.11	Examples	48
8.3.12	Programmers' notes	51
9	Operation	55
9.1	Identify device	55
9.2	Firmware update	56
9.3	Exchange IO-Link device	57
10	Maintenance	58
11	Factory settings	59
12	Accessories	60
13	Appendix	61
13.1	Technical data	61
13.1.1	Application	61
13.1.2	Electrical data	61
13.1.3	Inputs / outputs	61

Content

13.1.4	Inputs.....	62
13.1.5	Outputs.....	62
13.1.6	Interfaces.....	62
13.1.7	Operating conditions	63
13.1.8	Approvals / tests	63
13.1.9	Mechanical data	63
13.1.10	Electrical connection	64
13.2	EtherCAT	65
13.2.1	Parameter data.....	66
13.2.2	Cyclic data.....	67
13.2.3	Acyclic data	68
13.3	ifm IoT Core	76
13.3.1	Overview: IoT profile	77
13.3.2	Overview: IoT types.....	80
13.3.3	Overview: IoT services	81
14	Index	88
15	ifm weltweit • ifm worldwide • ifm à l'échelle internationale	91

1 Preliminary note

Contents

Legal and copyright information	5
Purpose of the document	5
Symbols and styles used	6
Modification history	6

14801

1.1 Legal and copyright information

1631

© All rights reserved by **ifm electronic gmbh**. No part of this manual may be reproduced and used without the consent of **ifm electronic gmbh**.

- All product names, pictures, companies or other brands used on our pages are the property of the respective rights owners:
- AS-i is the property of the AS-International Association, (→ www.as-interface.net)
- CAN is the property of the CiA (CAN in Automation e.V.), Germany (→ www.can-cia.org)
- CODESYS™ is the property of the 3S – Smart Software Solutions GmbH, Germany (→ www.codesys.com)
- DeviceNet™ is the property of the ODVA™ (Open DeviceNet Vendor Association), USA (→ www.odva.org)
- EtherNet/IP® is the property of the →ODVA™
- EtherCAT® is a registered trade mark and patented technology, licensed by Beckhoff Automation GmbH, Germany
- IO-Link® (→ www.io-link.com) is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- ISOBUS is the property of the AEF – Agricultural Industry Electronics Foundation e.V., Deutschland (→ www.aef-online.org)
- Microsoft® is the property of the Microsoft Corporation, USA (→ www.microsoft.com)
- PROFIBUS® is the property of the PROFIBUS Nutzerorganisation e.V., Germany (→ www.profibus.com)
- PROFINET® is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- Windows® is the property of the →Microsoft Corporation, USA

1.2 Purpose of the document

22044

This document is only for device types "IO-Link master - EtherCAT gateway (DataLine) 8 port IP 65 / IP 66 / IP 67" (art. no.: AL1332).

It is part of the device and contains information about the correct handling of the product.

- Read this document before using the device.
- Keep this document during the service life of the device.

1.3 Symbols and styles used

13839

- ... Instructions
- > ... Reaction, result
- ... Cross-reference or internet link
- 123 Decimal number
- 0x123 Hexadecimal number
- 0b010 Binary number
- [...] Designation of pushbuttons, buttons or indications

1.4 Modification history

21676

Version	Topic	Date
00	New creation of document	12/2017

2 Safety instructions

Contents

General	7
Required background knowledge	7
Warnings used	8
Safety symbols on the device	8
Tampering with the unit	8

213

2.1 General

22068



The plant manufacturer is responsible for the safety of the plant in which the device is installed.

If the device is used in a way that is not intended by the manufacturer, the protection supported by the device may be impaired.

Non-observance of the instructions, operation which is not in accordance with use as prescribed below, wrong installation or incorrect handling can affect the safety of operators and machinery.

- ▶ Observe these operating instructions.
- ▶ Adhere to the warning notes on the product.

2.2 Required background knowledge

22046

This document is intended for specialists. Specialists are people who, based on their relevant training and experience, are capable of identifying risks and avoiding potential hazards that may be caused during operation or maintenance of the product.

The document contains information about the correct handling of the product.

2.3 Warnings used

13685

WARNING

Death or serious irreversible injuries may result.

CAUTION

Slight reversible injuries may result.

NOTICE

Property damage is to be expected or may result.



Important note
Non-compliance may result in malfunction or interference.



Information
Supplementary note.

2.4 Safety symbols on the device

15021



General warning
When this symbol is shown, consult the corresponding section in the operating instructions.

2.5 Tampering with the unit

11242

WARNING

Tampering with the units can affect the safety of operators and machinery!

Tampering with the units is not allowed.

In case of non-compliance our liability and warranty expire.

- ▶ Do not open the devices!
- ▶ Do not insert any objects into the devices!
- ▶ Prevent metal foreign bodies from penetrating!

3 Intended use

Contents

Permitted use	9
Prohibited use.....	9

18761

3.1 Permitted use

22052

The IO-Link master serves as a gateway between intelligent IO-Link devices and the fieldbus. The device is designed for use without a control cabinet.

3.2 Prohibited use

22053

The device may not be used beyond the limits of the technical data (→ **Technical data** (→ p. [61](#)))!

4 Function

Contents

Communication, parameter setting, evaluation	11
Digital inputs	12
IO-Link supply.....	12

7482

4.1 Communication, parameter setting, evaluation

Contents

IO-Link	11
EtherCAT	11
Internet of Things (IoT)	11
Parameter setting	11
Visual indication	12

7485

4.1.1 IO-Link

7773

The device offers the following IO-Link functions:

- IO-Link master (IO-Link revision 1.0 and 1.1)
- 8 IO-Link ports for connection of IO-Link devices
- Provision of process data of the connected IO-Link devices for LR SMARTOBSERVER monitoring software (→ www.ifm.com)

4.1.2 EtherCAT

2259

The device offers the following EtherCAT functions:

- Provision of the functions of a EtherCAT Slave
- 2 port switch for access to the EtherCAT interface (X21/X22)
- Gateway for transmission of the process and parameter data between the connected IO-Link devices and the higher-level EtherCAT controller

4.1.3 Internet of Things (IoT)

8355

The device has an Ethernet port (X23) for Internet-of-Things applications. The interface allows separate access from IT networks to parameters, process and monitoring data of the IO-Link master and the connected IO-Link devices. Different protocols (e.g. TCP/IP JSON) are supported.

4.1.4 Parameter setting

7284

The device provides the following configuration options:

- Parameter setting of the IO-Link master of the AL1332 with LR DEVICE parameter setting software, EtherCAT projection software or ifm IoT-Core services.
- Parameter setting of the connected IO-Link devices (sensors, actuators) with LR DEVICE parameter setting software, EtherCAT projection software or ifm IoT-Core services
- Storage of parameter sets of the connected IO-Link devices for automatic recovery (data storage)

4.1.5 Visual indication

7772

The device has the following visual indicators:

- Status and error indication of the gateway, of the EtherCAT connection and of the system
- Status display of the voltage supply
- Status and activity display of the Ethernet connection
- Status, error and short circuit/overload indication of the IO-Link ports

4.2 Digital inputs

7584

The device has 8 additional digital inputs (type 2 according to EN 61131-2).

The digital inputs are on pin 2 of the IO-Link ports X01 ... X08.

All inputs refer to the potential of the device supply (pin 3).

4.3 IO-Link supply

7623

The device has 8 supplies for IO-Link devices.

The IO-Link ports X01...X08 are ports class A.

Every supply provides short circuit monitoring.

The device ensures fire protection for the connected IO-Link devices by providing a power-restricted circuit at the IO-Link ports (according to IEC61010-1 and Class 2 according to UL1310).

5 Mounting

Contents

Mount the device	13
------------------------	----

22016

5.1 Mount the device

15540



- ▶ Disconnect the system from power before installation.
- ▶ For installation choose a flat mounting surface.
- ▶ Please observe the maximum tightening torque.

- ▶ Fix the unit to the mounting surface using 2 M5 mounting screws and washers.
 - Tightening torque: 1.8 Nm
- ▶ Ground the unit via the two mounting screws of the upper mounting lugs.

6 Electrical connection

Contents

Remarks	14
EtherCAT ports	15
IoT port	16
IO-Link ports	17
Connect the device	19

22017

6.1 Remarks

18076



A qualified electrician must connect the unit.

- Observe the national and international regulations for the installation of electrical equipment.

Device is only suitable for operation on SELV/PELV voltages.

- Observe the information concerning IO-Link circuits (→ **IO-Link circuits** (→ p. 18))!

The device contains components that can be damaged or destroyed by electrostatic discharge (ESD).

- Observe the required safety measures against electrostatic discharge!

The IP rating depends on the individual protection ratings of the unit, the applied connection elements and the corresponding protective covers.

- For UL applications: For connecting the device and the IO-Link devices use UL certificated cables of category CYJV or PVVA with a minimum temperature rating of 100°C.
- Depending on the installation environments apply a cable relief to avoid invalid load of the mounting points and the M12 connectors.
- Ensure a proper fit and correct installation of the M12 connectors. If disregarded the desired protection rating can not be guaranteed.


Wiring: → **Technical data** (→ p. 61)



The communication interfaces are separated from the device supply according to EN61010-1 considering basis isolation as secondary circuit with maximum 30 V DC derived from the applied voltage up to 300 V of overvoltage category II. The communication interfaces are designed for a network environment 0 according to IEC TR62102.

6.2 EtherCAT ports


17849



- ▶ Connect the device via the M12 socket X21 and/or X22 to the EtherCAT network (e.g. EtherCAT PLC, additional EtherCAT device)
 - Tightening torque: 0.6...0.8 Nm
- ▶ To connect the devices, use M12 connectors with protection rating IP 65 / IP 66 / IP 67 or higher (→ **Accessories** (→ p. 60)).
- ▶ Cover the unused sockets with M12 protective caps (→ **Accessories** (→ p. 60)).
 - Tightening torque 0.6...0.8 Nm

6.3 IoT port


11029



- ▶ Connect the device via the M12 socket X23 to the IT network (e.g. laptop/PC with installed LR DEVICE parameter setting software, laptop/PC with installed LR SMARTOBSERVER monitoring software)
 - Tightening torque: 0.6...0.8 Nm
- ▶ To connect the devices, use M12 connectors with protection rating IP 65 / IP 66 / IP 67 or higher (→ **Accessories** (→ p. [60](#))).
- ▶ Cover the unused sockets with M12 protective caps (→ **Accessories** (→ p. [60](#)))
 - Tightening torque 0.6...0.8 Nm

6.4 IO-Link ports

22684



Ports X01...X08: For use as IO-Link port class A:

- ▶ Connect the connector of the IO-Link devices with the M12 sockets X01 ... X08.
 - Tightening torque: 0.6...0.8 Nm
 - Maximum cable length per IO-Link interface: 20 m
- ▶ For the connection, use M12 connectors with protection rating IP 65 / IP 66 / IP 67 or higher (→ Accessories).

Ports X01...X08: For use as IO-Link port class B:

- ▶ Connect the connector of the IO-Link devices via the adapter with the M12 sockets X01 ... X08.
 - Tightening torque: 0.6...0.8 Nm
- ▶ To connect the devices, use M12 connectors with protection rating IP 65 / IP 66 / IP 67 or higher (→ Accessories).
- ▶ Cover the unused sockets with M12 protective caps (→ Accessories).
 - Tightening torque 0.6...0.8 Nm

6.4.1 Input circuit

18629

The inputs of the ports X01...X08 (pin 2) provide a type 2 behaviour according to standard EN61131-2, the connected electronics must be rated for this electrically.

6.4.2 IO-Link circuits

11616

The IO-Link interfaces of the device meet the requirements of the IO-Link specification 1.0 to 1.1.2.



The connected IO-Link devices may only be supplied via the AL1332.

Exception: Connection of IO-Link devices to ports X01...X08 via suitable connection technology for port class B operation (→ **IO-Link ports** (→ p. 17)):

The external supply for port class B operation must be galvanically separated from the circuit of the AL1332 by assuring basic isolation (according to EN61010-1, secondary circuit with maximum 30 V DC derived from applied voltage up to 300 V of overvoltage category II)!

The isolation must be done both for IO-Link devices and for the connection technology.

NOTICE

Risk of material damage


If the requirements of galvanic separation of the circuits are not observed, the fire protection of the device can not be assured.

- Observe the requirements of the electrical connection of IO-Link devices for port class B operation!

Further information: → **Technical data** (→ p. 61)

6.5 Connect the device

2580



- ▶ Disconnect power.
- ▶ Connect the unit via M12 socket X31 to 24 V DC (20...30 V SELV/PELV, for cULus max. 24 V DC; according to EN61010-1, secondary circuit with maximum 30 V DC derived from applied voltage up to 300 V of overvoltage category II).
 - Tightening torque: 0.6...0.8 Nm
 - Maximum cable length: 25 m
- ▶ To connect the device, use M12 connectors with protection rating IP 65 / IP 66 / IP 67 or higher (→ Accessories).

If the port X01...X08 will be used as IO-Link ports Class B:

- ▶ Connect adapter for Port Class B operation to 24 V DC (20...30 V SELV/PELV, for cULus max. 24 V DC; according to EN61010-1, secondary circuit with maximum 30 V DC derived from applied voltage up to 300 V of overvoltage category II) (→ **IO-Link ports** (→ p. [17](#)))
 - Tightening torque: 0.6...0.8 Nm

7 Operating and display elements


Contents

Overview.....	20
LED indicators	21

5440

7.1 Overview

17861



- ① RDY, RUN and ERR status LEDs
→ **Status LEDs** (→ p. [21](#))
- ② Status LEDs L/A of the EtherCAT interfaces 1 (X21) and 2 (X22)
→ **EtherCAT interface** (→ p. [22](#))
- ③ LNK, ACT status-LEDs and IoT LED of the IoT interface (X23)
→ **IoT port** (→ p. [22](#))
- ④ IOL and DI status-LEDs of the IO-Link port (X01...X08)
→ **IO-Link ports (Class A)** (→ p. [23](#))
- ⑤ US status LED of the voltage supply (X31)
→ **Voltage supply** (→ p. [22](#))

7.2 LED indicators

22024

The device only has the following LED indicators:

7.2.1 Status LEDs

1986

The RDY LED indicates the status of the gateway.

The RUN LED indicates the current state of the EtherCAT state machine.

The ERR LED indicates occurring errors.

Status LED			Description
RDY	green	on	Gateway functions properly.
		flashes 1 Hz	Error
		flashes 5 Hz	Firmware update
		off	Gateway does not function; Device reboots
RUN	green	on	Device in OPERATIONAL state
		flashes (2.5 Hz)	Device in PRE-OPERATIONAL state
		flashes (200 ms on, 1000 ms off)	Device in SAFE-OPERATIONAL state
		flashes (10 Hz)	Device is booting and not yet in INIT state or device is in BOOTSRAP state
		off	Device in INIT state
ERR	red	on	Error in application controller
		flashes (10 Hz)	Boot error
		flashes (200 ms on, 200 ms off, 200 ms on, 1000 ms off)	Watchdog error (EtherCAT or process data)
		flashes (200 ms on, 1000 ms off)	Local error
		flashes (2.5 Hz)	Invalid configuration
		off	No error

7.2.2 EtherCAT interface

17852

Each EtherCAT interface (X21, X22) has 1 L/A LED. The LED indicates the status of the Ethernet connection.

Status LED			Description
L/A	green	on	Ethernet connection established
		flashes	Data is transmitted via the Ethernet interface.
		off	No Ethernet connection

7.2.3 IoT port

7722

The IoT port (X23) has the 3 LNK, ACT and IoT LEDs. The LEDs indicate the status of the Ethernet connection and the device identification.

Status LED			Description
LNK	green	on	Ethernet connection established
		off	No Ethernet connection
ACT	yellow	flashes	Data is transmitted via the Ethernet interface.
		off	No data transmission
IoT	green	flashes	Device identification active

7.2.4 Voltage supply

22026

The interface for voltage supply (X31) has the LED that is marked as US. The LED indicates the status of the voltage supply.

Status LED			Description
US	green	on	The supply voltage Us is applied.
		off	No supply voltage is applied or the applied supply voltage is too low.

7.2.5 IO-Link ports (Class A)

22029

Each IO-Link port Class A (X01 ... X08) has 2 LEDs marked as IOL and DI. The LEDs indicate the status of the IO-Link port.

Status LED			Description
IOL	yellow	on	Interface configured as DI/DO: Pin 4 (C/Q) = ON
		off	Interface configured as DI/DO: Pin 4 (C/Q) = OFF
	green	on	IO-Link transmission functions properly
		flashes 1 Hz	Interface configured as IO-Link, but no IO-Link transmission
	red	on	Short circuit or overload in supply voltage
		flashes 1 Hz	Transmission error
DI	yellow	on	Digital input: Pin 2 (DI) = ON
		off	Digital input : Pin 2 (DI) = OFF

8 Configuration

Contents

LR DEVICE.....	25
EtherCAT	35
IoT Core.....	43

22367

8.1 LR DEVICE

Contents

Remarks	26
IoT: Configure access rights	27
IoT: Configure IP settings	28
IoT: Configure the interface to the LR SMARTOBSERVER	29
Fieldbus: Configure the EtherCAT port	29
IO-Link ports: Activate data transfer to the LR SMARTOBSERVER	30
IO-Link ports: Configure operating mode	31
IO-Link ports: Set the device validation and data storage	32
Info: Show device information	33
Firmware: Reset device to factory settings	33
Firmware: Reboot the device	33
Configure IO-Link devices	34

22822

On delivery, the AL1332 is configured with the factory settings (→ **Factory settings** (→ p. [59](#))).

Required software: LR DEVICE (1.2.0.107) (art.-No.: QA0011/QA0012)

8.1.1 Remarks

Contents

Offline parameter setting	26
---------------------------------	----

22369

Offline parameter setting

22405

The AL1332 supports the offline parameter setting. In this context, the user creates and stores a configuration for the unit and the connected IO-Link devices without being connected to the AL1332. The configuration created in this way can be stored as a file (*.lrp) and loaded to the device and activated at a later date.



Further information about offline parameter setting: → Operating instructions of the parameter setting software LR DEVICE

8.1.2 IoT: Configure access rights

16555

The access rights define which instance may read and / or write the parameter data, process data and event/diagnostic messages.

In order to configure the access rights to the IO-Link master:

- ▶ Select [IoT] menu.
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Access Rights]	The access rights to the parameter data, process data and the event/diagnostic messages of the IO-Link master as well as the connected IO-Link devices	[EtherCAT + IoT]	▪ EtherCAT and IoT Core have read and write access rights to parameters and process data ▪ EtherCAT and <IoT Core> have read access rights to events/alarms
		[EtherCAT + IoT (read-only)]	▪ EtherCAT has read and write access rights to parameters and process data ▪ EtherCAT has read access rights to events/alarms ▪ IoT Core only has read access rights to parameters, process data and events/alarms
		[IoT only]	▪ IoT Core has read and write access rights to parameters and process data ▪ IoT has read access rights to events/alarms ▪ EtherCAT has no access rights

- ▶ Save changed values on the device.



If the parameter [Access Rights] = [EtherCAT + IoT]:

Different parameter settings in the EtherCAT projection software and the IoT applications can result in undesired system behaviour. The set values of the EtherCAT projection software apply.



Changes of the parameter [Access Rights] are only effective after restarting the device.

To activate the changed access rights:

- ▶ **Firmware: Reboot the device** (→ p. [33](#))

8.1.3 IoT: Configure IP settings

17713

For access to the IO-Link master via the IT infrastructure the user has to set the IP settings of the IoT port.



To configure the IP settings with DHCP, a DHCP server has to be active in the IT network. If no DHCP server can be reached in the IT network, an IP address is automatically assigned to the IoT port with the Zeroconfig protocol (address range: → Factory settings).

To configure the IP settings of the IoT port:

- ▶ Select [IoT] menu.
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[DHCP]	Activate/deactivate the DHCP client of the device	[Static IP]	IP settings were set by the user
		[DHCP]	IP settings are set by a DHCP server in the network.
[IP address]*	IP address of the IoT port	Factory setting: 169.254.X.X	
[Subnet mask]*	Subnet mask of the Ethernet network	Factory setting: 255.255.0.0	
[Default gateway IP address]*	IP address of the network gateway	Factory setting: 0.0.0.0	
[MAC address]	MAC address of the IoT port	The value is firmly set.	

* ... can only be edited if parameter [DHCP] = [Static IP]

- ▶ Save changed values on the device.

8.1.4 IoT: Configure the interface to the LR SMARTOBSERVER

16552

To enable data transfer between the device and the LR SMARTOBSERVER monitoring software, the LR SMARTOBSERVER monitoring software interface has to be configured.

- Select [IoT] menu.
- > The menu page shows the current settings.
- Set the following parameters as required:

Name	Description	Possible values
[IP address LR SMARTOBSERVER]	IP address of the PC on which the LR SMARTOBSERVER is installed.	Factory setting: 255.255.255.255
[Port LR SMARTOBSERVER]	Port number that is used to send process data to the LR SMARTOBSERVER	0 ... 65535 Factory setting: 35100
[Interval LR SMARTOBSERVER]	Cycle time for the transfer of the process data to the LR SMARTOBSERVER (value in milliseconds)	[Off] no transfer
		500 500 ms ... 2147483647 2147483647 ms
[Application Tag]	Source identifier of the IO-Link master in the structure of the LR SMARTOBSERVER (String32)	Factory setting: AL1332



After changing the parameter [Port LR SMARTOBSERVER] or [Application Tag], it may take 120 seconds before the device establishes a new TCP connection.

To prevent the delay:

- Reboot the device after the parameter change.
- Save changed values on the device.

8.1.5 Fieldbus: Configure the EtherCAT port

22759

The user can assign a name for the identification of the IO-Link master in the EtherCAT projection software.



The address of the EtherCAT port is assigned via the EtherCAT projection software.

To configure the fieldbus port:

- Select [Fieldbus] menu.
- > The menu page shows the current settings.
- > Set the following parameters as required:

Parameter	Description	Possible values
[Hostname]	Name of the device in the EtherCAT network	e.g. al1xxx
[MAC address]	MAC address of the device	The value is firmly set.

- Save changed values on the device.

8.1.6 IO-Link ports: Activate data transfer to the LR SMARTOBSERVER

16551

The user can decide separately for each IO-Link port if the process data of the connected IO-Link devices should be transferred to the LR SMARTOBSERVER.



To transfer process data the interfaces to the LR SMARTOBSERVER have to be correctly configured (→ **IoT: Configure the interface to the LR SMARTOBSERVER** (→ p. [29](#))).

To activate / deactivate data transfer:

- ▶ Select [Port x] menu (x = 1...8).
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Transmission to LR SMARTOBSERVER]	Transfer of process data of the connected IO-Link device to LR SMARTOBSERVER	[Disabled]	Process data is not transferred
		[Enabled]	Process data is transferred

- ▶ Save changed values on the device.

8.1.7 IO-Link ports: Configure operating mode

17439

The IO-Link ports X01...X08 of the device support the following operating modes:

- Digital input (DI): binary input signal at pin 4 (C/Q) of the IO-Link port
- Digital output (DO): binary output signal at pin 4 (C/Q) of the IO-Link port
- IO-Link: IO-Link data transfer via pin 4 (C/Q) of the IO-Link port

The user can set the operating mode separately for each IO-Link port.

To set the operating mode of an IO-Link port:

- ▶ Select [Port x] menu (x = 1...8).
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Mode]	Operating mode of the IO-Link port	[Disabled]	Port deactivated
		[DI]	Operation as digital input
		[DO]	Operation as digital output
		[IO-Link]	Operation as IO-Link interface
[Cycle time actual]**	Current cycle time of the data transfer between IO-Link master and IO-Link device on the port (value in microseconds)	Parameter can only be read	
[Cycle time preset]*	Cycle time of the data transfer between the IO-Link master and the IO-Link device at the port (value in microseconds)	0	The device automatically sets the fastest possible cycle time.
		1	1 microsecond
		...	...
		132800	132800 microseconds
[Bitrate]**	Current transmission rate of the data transfer between the IO-Link master and the IO-Link device on the port	Parameter can only be read	

* ... Parameter only available if [Mode] = [IO-Link]

** ... Parameter only visible if the IO-Link device is connected to the IO-Link port.

- ▶ Save changed values on the device.

8.1.8 IO-Link ports: Set the device validation and data storage

17945

In the operating mode "IO-Link" the user can set the behaviour of the IO-Link port with regard to device validation and the storage / restoration of the parameter data of the connected IO-Link device.

To configure the device validation and the data storage:

- ▶ Select [Port x] menu (x = 1...8).
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Validation / Data Storage]	Supported IO-Link standard and behaviour of the device during connection of a new IO-Link device on port x (x = 1...8)	[No check and clear]	▪ No verification of the vendor ID and device ID ▪ No data storage
		[Type compatible V1.0 device]	▪ IO-Link device is compatible with the V1.0 IO-Link standard ▪ Verification whether it is an IO-Link device of the same type (validation via vendor ID and device ID) ▪ No data storage
		[Type compatible V1.1 device]	▪ IO-Link device is compatible with the V1.1 IO-Link standard ▪ Verification whether it is an IO-Link device of the same type (validation via vendor ID and device ID) ▪ No data storage
		[Type compatible V1.1 device with Backup + Restore]	▪ IO-Link device is compatible with the V1.1 IO-Link standard ▪ Verification whether it is an IO-Link device of the same type (validation via vendor ID and device ID) ▪ The IO-Link master saves the parameter values of the connected IO-Link device; modifications of the parameter values are also saved (observe the note!) ▪ When connecting an IO-Link device with factory settings, the parameter values stored in the IO-Link master are restored automatically on the IO-Link device.
		[Type compatible V1.1 device with Restore]	▪ IO-Link device is compatible with the V1.1 IO-Link standard ▪ Verification whether it is an IO-Link device of the same type (validation via vendor ID and device ID) ▪ The IO-Link master saves the parameter values of the connected IO-Link device once. ▪ When connecting an IO-Link device with factory settings, the parameter values stored in the IO-Link master are restored automatically on the IO-Link device.
[Vendor ID]	ID of the manufacturer that is to be validated	0 ... 65535	Factory setting: 0 ifm electronic: 310
[Device ID]	ID of the IO-Link device that is to be validated	0 ... 16777215	Factory setting: 0

- ▶ Save changed values on the device.

8.1.9 Info: Show device information

12218

To read the general information of the ifm IO-Link master:

- Select [Info] menu.
- > The menu page shows the current settings.

Name	Description	Possible values
[Product code]	Article number of the IO-Link master	AL1332
[Device family]	Device family of the IO-Link master	IO-Link master
[Vendor]	Vendor	ifm electronic gmbh
[SW-Revision]	Firmware of the IO-Link master	
[HW revision]	Hardware version of the IO-Link master	
[Bootloader revision]	Bootloader version of the IO-Link master	
[Serial number]	Serial number	

8.1.10 Firmware: Reset device to factory settings

7209

When the IO-Link master is reset, all parameters are set to the factory settings:

To reset the device to factory settings:

- Select [Firmware] menu.
- > The menu page shows the current settings.
- Click on [Factory Reset] to reset the device.
- > LR DEVICE sets the device to the factory settings.

8.1.11 Firmware: Reboot the device

18105

When rebooting the device, all settings are kept.

To restart the AL1332:

- Select [Firmware] menu.
- > The menu page shows the current settings.
- Click on [Reboot] to reboot the device.
- > LR DEVICE reboots the ifm IO-Link master.

8.1.12 Configure IO-Link devices

11033

To configure the IO-Link devices connected to the device with the LR DEVICE parameter setting software:

Requirements:


- > IO-Link master is correctly installed and connected to the LR DEVICE parameter setting software.
- > The IO-Link device is correctly connected to the AL1332.
- > Operating mode of the IO-Link port is "IO-Link" (→ **IO-Link ports: Configure operating mode** (→ p. 31)).
- > IoT has write access rights to the IO-Link master (→ **IoT: Configure access rights** (→ p. 27)).

1 Select IO-Link master

- ▶ Start LR DEVICE.
- ▶ Update IODD file library
OR:
Import IODD file of the IO-Link device manually.
- ▶ Scan network for devices.
- > LR DEVICE detects IO-Link master.

2 Add IO-Link device

- ▶ Under [ONLINE]: Click on the required IO-Link master.
- > LR DEVICE automatically detects the IO-Link devices connected to the IO-Link master (e.g. ifm sensor KG5065).



3 Configure IO-Link device

- ▶ Mouse click on the port to which the <IO> device is connected.
- > LR DEVICE reads and shows the current parameter values of the IO-Link device.
- ▶ Configure IO-Link device.



Information about the available parameters of the IO-Link device: → IO Device Description (IODD) of the IO-Link device

- ▶ Save the changed configuration on the IO-Link device.

8.2 EtherCAT

Contents

Install ESI file	35
Integrate the AL1332 into the EtherCAT project	36
Configure IO-Link master	36
Configure IO-Link ports	36
Configure cyclic process data	37
Read and write cyclic process data	38
Read diagnostic and status information	39
Configure IO-Link devices	40
EtherCAT: Programmers' notes	41

17299

On the field bus side, the device can be configured with any EtherCAT compatible projection software. The information in the following sections refers to the EtherCAT projection software TwinCAT 3.1.

8.2.1 Install ESI file

12762

To represent the AL1332 in a field bus projection software ifm electronic provides an ESI file. The EDS file can be downloaded from ifm's website. In the ESI file, all parameters, process data and their valid value ranges are defined.

To integrate the ESI file into EtherCAT projection software TwinCAT 3.1:

- ▶ Download ESI file of the device.
- ▶ Copy downloaded file to the following subdirectory of the TwinCAT installation directory:
`..\3.1\Config\Io\EtherCAT`
- ▶ Start TwinCAT.
- > TwinCAT loads the device description to the device catalogue.

8.2.2 Integrate the AL1332 into the EtherCAT project

17297

The device is integrated into the project as EtherCAT slave.

Requirements

- > The ESI file of the AL1332 is installed (→ **Install ESI file** (→ p. 35)).

1 Create/open EtherCAT project

- ▶ Launch EtherCAT projection software.
- ▶ Create a new project.
OR
Open an existing project.

2 Configure EtherCAT PLC and IO periphery

- ▶ Select and configure EtherCAT PLC and requested I/O periphery.
- > Project contains EtherCAT PLC and I/O periphery.

3 Integrate the AL1332 into the project

- ▶ In the Solution Explorer: Right-click on devices to which the AL1332 is connected.
- > Context menu appears.
- ▶ In the context menu: Select [Add new item...].
- > Window [Insert EtherCAT Device] appears.
- ▶ Select the AL1332 in the device tree under [ifm electronic] > [ifm IO-Link master].
- ▶ Click on [OK] to add the selected device to the project.
- > TwinCAT adds AL1332 to the project.

4 Save the project

- ▶ Save the project.

8.2.3 Configure IO-Link master

18602

The IO-Link master is configured via the CoE interface (→ TwinCAT-online help). The configuration is made via the following parameters:

Name	Description	Reference
Current Use Case	Access rights to the IO-Link master	→ Manufacturer Specific Index (0x20 00) (→ p. 69)
Reset To Factory	Reset IO-Link master to factory settings	→ Manufacturer Specific Index (0x20 00) (→ p. 69)

8.2.4 Configure IO-Link ports

17959

The IO-Link ports are configured via the CoE interface (→ TwinCAT-online help). The user can configure each IO-Link port separately. The configuration is made via the following parameters:

Name	Description	Reference
IO Settings	Configuration of the IO-Link ports X01...X08	→ IO Settings (0x8000) (→ p. 72)
Vendor Specific IO Settings	Manufacturer-specific settings of the IO-Link ports X01...X08	→ IO Settings (0x8000) (→ p. 72)

8.2.5 Configure cyclic process data

16556

Type and number of cyclic input and output data on the IO-Link ports are defined via the fieldbus modules (→ **EtherCAT modules** (→ p. 67)). In the factory settings, all slots are configured with the module "IOL_4/4_I/O".

To configure the cyclic process data:

Requirements

- > AL1332 is integrated (→ **Integrate the AL1332 into the EtherCAT project** (→ p. 36)).

1 Open the device editor

- ▶ In the Solution Explorer: Double-click on the node of the AL1332.
- > The window shows the available configuration options.
- ▶ Select the tab [Slots].
- > The window shows the current configuration of the cyclic data.

2 Assign fieldbus modules

- ▶ In the left half of the table: Select click on slot of the requested IO-Link port.
- ▶ In the right half of the table: Click on the requested fieldbus module.
- ▶ Click on [<] to assign the requested fieldbus module to the slot.

3 Configure more IO-Link ports

- ▶ optional: repeat step 1 for further IO-Link ports.
- > Cyclic data is assigned to the fieldbus slots.
- > The Solution Explorer shows the configured modules as subelements of the device node.

4 Save the project

- ▶ Save the project.

8.2.6 Read and write cyclic process data

17960



- To check the validity of the cyclic process data, evaluate the PQI byte (→ **Device status / port status (0xF000)** (→ p. [74](#))).

Even with an interruption of the fieldbus connection the PQI byte indicates that the process data is valid. This can have unintended impact on the control process.

- Take suitable measures to detect an interruption of the fieldbus connection.

The cyclic process data of the IO-Link-Ports X01...X08 is accessible via the following index groups:

Name (Index)	Description	Reference
IO-Link inputs (0x6000)	Cyclic input data at the IO-Link ports X01...X08	→ IO-Link inputs (0x6000) (→ p. 71)
IO-Link outputs (0x7000)	Cyclic output data at the IO-Link ports X01...X08	→ IO-Link outputs (0x7000) (→ p. 71)

During the configuration of the fieldbus slots TwinCAT automatically creates variables for the cyclic input and output data. They are found in groups in the folders under the respective fieldbus modules. The user can link the variables directly with the elements of a global variable list (GVL).

The following variables are created:

Group > Variable	Variable	Description
[TxPDO]	[input byte n]	Byte n of the cyclic input data of the fieldbus module
[RxPDO]	[output byte m]	Byte m of the cyclic output data of the fieldbus module

n = 0...(max. number of bytes on configured input data)-1
m = 0...(max. number of bytes on configured output data)-1

8.2.7 Read diagnostic and status information

17961

Diagnostic and status information is accessible via the following index groups:

Name (Index)	Description	Reference
MDP Standard Information (0x1000)	- Device information via IO-Link master - Identity Object - Diagnostic history	→ MDP Standard Information (0x1000) (→ p. 68)
IO Info Data (0x9000)	Information about IO-Link devices at IO-Link-Ports X01...X08	→ IO Info Data (0x9000) (→ p. 73)
IO Diag Data (0xA000)	Diagnostic data of the IO-Link ports X01...X08	→ IO Diag data (0xA000) (→ p. 73)
Device Status (0xF000)	- Status of the IO-Link devices at the IO-Link port X01...X08 - Port qualifier	→ Device status / port status (0xF000) (→ p. 74)

When the IO-Link master is integrated into a EtherCAT project, TwinCAT automatically creates variables for diagnostic and status information in the Solution Explorer. They are grouped in folders under the device node. The user can link the variables directly with the elements of a global variable list (GVL).

The following variables are created:

Group > Variable	Description
[TxPDO IO-Link Device Status] > [State of IO-Link Ch.n]	Status of the IO-Link device at the IO-Link port X0n
[TxPDO IO-Link Port Qualifier] > [Qualifier of IO-Link Ch.n]	Port qualifier bits of the IO-Link port X0n
[TxPDO New Diagnosis Message available] > [New Message Available Flag]	Notification of new diagnostic messages

n ... 1...8

8.2.8 Configure IO-Link devices

9031

The IO-Link master supports the configuration of the connected IO-Link devices from the EtherCAT projection software. The parameters of an IO-Link device are set via IO-Link index and subindex. The number of the configurable parameters depends on the connected IO-Link device.



Available parameters of the IO-Link devices: → IO Device Description (IODD) of the IO-Link device

The user can read and write IO-Link index and subindex using the following methods:

- Acyclic communication: → **Use acyclic services** (→ p. [41](#))

8.2.9 EtherCAT: Programmers' notes

Contents

Use acyclic services	41
----------------------------	----

17965

Use acyclic services

17958

The AL1332 supports following services for acyclic read and write processes:

- AoE - ADS over EtherCAT (→ **Use ADS over EtherCAT** (→ p. 41))
- CoE - CANopen over EtherCAT (→ **Use CANopen over EtherCAT** (→ p. 42))

Use ADS over EtherCAT

9109

AoE is suited for interruption-free access to the connected IO-Link devices during the operating time of the device. Access to the IO-Link master with AoE is not supported.



The function blocks for using AoE are part of the `tc2_system.libTwinCAT` library.

The following rules apply to the inputs of the ADS function blocks:

Input	Description	Possible values	
PORT	ADS communication port = 0x1000 + IO-Link port number	0x1001 0x1002 ... 0x1008	IO-Link port X01 IO-Link port X02 ... IO-Link port X08
IDXGRP	AoE index group	0xF302	
IDXOFFS	Index Offset		e. g. access to index 21, subindex 0: 0x0021°0x00°0x00
	Bits 0-7:	IO-Link subindex	
	Bits 8-15:	00000000	
	Bits 16-31:	IO-Link index	
ERRID	ADS error code		e. g. access to parameters of the IO-Link device refused: 0x0700°8023
	Bits 0-15:	Error code of the IO-Link device	
	Bits 16-31:	ADS device error = 0x0700	

Use CANopen over EtherCAT

16206

CoE is suited for acyclic access to the IO-Link master and the connected IO-Link devices. CoE uses the fieldbus objects "IO-Link acyclic command" (→ **IO-Link Acyclic Command (0x3100)** (→ p. 70)). A separate fieldbus object is provided for each IO-Link port.

To have acyclic access to the device via CoE the user can use the following function blocks:

- FB_EcCoESdoRead: read SDO of an EtherCAT slave
- FB_EcCoeSdoWrite: write SDO of an EtherCAT slave



The function blocks for using CoE are part of the `Tc2_EtherCAT.library` function library.

► Add `Tc2_EtherCAT.library` function block library to the project

Description of the function blocks: → [Help function of TwinCAT](#)

The following rules apply to the inputs of the CoE function blocks:

Input	Description	Possible values	
sNetId	AMS net ID of the EtherCAT master to which the IO-Link master is connected	depends on the project; e.g. 172.16.2.131.2.1	
nSlaveAddr	EtherCAT address of the IO-Link port on the IO-Link master = 0x1000 + IO-Link port number	0x1001 0x1002 ... 0x1008	IO-Link port X01 IO-Link port X02 ... IO-Link port X08
nSubIndex	IO-Link subindex of the parameter	depends on the device; → IODD	
nIndex	IO-Link index of the parameter	depends on the device; → IODD	

General process of an acyclic request:

1. Write command (subindex 0x1)
2. Enquire about status (subindex 0x2 or 0x3)
3. Optional: read requested values (subindex 0x3)



The AL1332 can only process one CoE request at a time. If during an active request another CoE request is started, the device answers with an error (SDO abort code: 0x06090030).

8.3 IoT Core

Contents

Configure IoT port.....	44
Configure the fieldbus port	44
Configure IO-Link ports	45
Set application identification	45
Read / write cyclic process data	45
Read diagnostic data	46
Read device information	46
Read information about IO-Link devices	47
Configure IO-Link devices	47
Control IO-Link master	47
Examples	48
Programmers' notes	51

17302



The user can access the IoT Core only via IoT port X23 of the ifm IO-Link master.

General notes on the ifm IoT Core: → **Programmers' notes** (→ p. [51](#))

The AL1332 is of type device (→ **Overview: IoT types** (→ p. [80](#))).

It has the following sub-structures:

Structure	Contents
processdatamaster	- Diagnostic data (temperature, voltage, current) - Status of the current / voltage supply
deviceinfo	Device identification
timer[1]	Subscribe to data
timer[2]	Subscribe to data
iotsetup	Parameters of the IoT port (access rights, IP settings, IP settings of the LR SMARTOBSERVER)
fieldbussetup	Parameters of the fieldbus port (IP settings, device identification in fieldbus projection software)
iolinkmaster/port[n]	- Parameters of the IO-Link port (operating mode, transmission rate, cycle time, validation and data storage) - Digital input data (pin 2) - Port event
iolinkmaster/port[n]/iolinkdevice	- Status information IO-Link devices on the IO-Link port - Device information of the IO-Link device - Process data on input/output - Application-specific identification
firmware	- Firmware of the device - Reset devices - Reboot the device

The user can request the available data points and services in the substructures with `gettree`(→ **Service: `gettree`** (→ p. [81](#))). The service returns the device description as tree structure. It shows the services supported by a data point: In the sub-element "subs" each data point lists all services that can be applied to it.

8.3.1 Configure IoT port

16540

The parameters of the IoT port X23 are saved in the `iotsetup` substructure. The user can access the following data points:

Name	Description	Access
<code>iotsetup/accessrights</code>	Access rights to the IO-Link master 0 = EtherCAT + IoT 1 = EtherCAT + IoT (read only) 2 = IoT only	rw
<code>iotsetup/smobip</code>	IP address of the LR SMARTOBSERVER	rw
<code>iotsetup/smobport</code>	Port number of the LR SMARTOBSERVER	rw
<code>iotsetup/smobinterval</code>	Cycle time for (value in milliseconds)	rw
<code>iotsetup/network/dhcp</code>	Configuration of the IP settings of the IoT port 0 = STATIC_IP/OFF 1 = DHCP/ON	rw
<code>iotsetup/network/ipaddress</code>	IP address of the IoT port	rw
<code>iotsetup/network/subnetmask</code>	Subnet mask of the network segment	rw
<code>iotsetup/network/ipdefaultgateway</code>	IP address of the network gateway	rw

rw ... read and write

8.3.2 Configure the fieldbus port

16564

The parameters of the fieldbus port X21/X22 are saved in the `fieldbussetup` substructure. The user can access the following data points:

Name	Description	Access
<code>fieldbussetup/hostname</code>	Name of the IO-Link master in the fieldbus project	rw
<code>fieldbussetup/fieldbusfirmware</code>	Firmware version of the IO-Link master	r

r = read only

rw ... read and write

8.3.3 Configure IO-Link ports

16454

Parameters of the IO-Link ports of the IO-Link master are saved in the `iolinkmaster/port[n]` substructure. There are the following data points for each IO-Link-Port X01...X08 :

Name	Description	Access
<code>iolinkmaster/port[n]/senddatatosmob</code>	Send process data to LR SMARTOBSERVER	rw
<code>iolinkmaster/port[n]/mode</code>	Operating mode of the IO-Link port	rw*
<code>iolinkmaster/port[n]/mastercycletime_preset</code>	Cycle time of the data transfer at the IO-Link port (value in microseconds)	rw
<code>iolinkmaster/port[n]/mastercycletime_actual</code>	Current cycle time of the data transfer at the IO-Link port (value in microseconds)	r
<code>iolinkmaster/port[n]/validation_datastorage_mode</code>	Response of the IO-Link port when a new IO-Link device is connected	rw*
<code>iolinkmaster/port[n]/validation_vendorid</code>	IO-Link ID of the manufacturer that is to be validated	rw*
<code>iolinkmaster/port[n]/validation_deviceid</code>	IO-Link ID of the device that is to be validated	rw*

n ... 1...8)

r = read only

rw ... read and write

* ... only available if EtherCAT PLC is separated from the device

8.3.4 Set application identification

16580

The application name of the IO-Link master is saved in the `devicetag` substructure. The user can access the following data points:

Name	Description	Access
<code>devicetag/applicationtag</code>	Name of the IO-Link master in the fieldbus project (application tag)	rw

rw ... read and write

8.3.5 Read / write cyclic process data

10994

Cyclic process data of the IO-Link ports X01...X08 is saved in the `iolinkmaster/port[n]` substructure. The user can access the following data points:

Name	Description	Access
<code>iolinkmaster/port[n]/pin2in</code>	Digital input signal to pin 2 of the IO-Link port n	r
<code>iolinkmaster/port[n]/iolinkdevice/pdin</code>	IO-Link input signal at pin 4 of the IO-Link port n	r
<code>iolinkmaster/port[n]/iolinkdevice/pdout</code>	IO-Link output signal at pin 4 of the IO-Link port n	rw*

n ... 1...8

r = read only

rw ... read and write

* ... only available if EtherCAT PLC is separated from the device

8.3.6 Read diagnostic data

16571

Diagnostic data is saved in the `processdatamaster` substructure. The user can access the following data points:

Name	Description	Access
<code>processdatamaster/temperature</code>	Temperature of the IO-Link master (value in °C)	r
<code>processdatamaster/voltage</code>	Voltage applied (value in V)	r
<code>processdatamaster/current</code>	Current (value in A)	r
<code>processdatamaster/supervisionstatus</code>	Diagnostic information of the device supply 0 = no error 1 = short circuit 2 = overload 3 = undervoltage	r

r = read only

8.3.7 Read device information

17133

Device information is saved in the `deviceinfo` substructure. The user can access the following data points:

Name	Description	Access
<code>deviceinfo/productcode</code>	Article Number	r
<code>deviceinfo/vendor</code>	Vendor	r
<code>deviceinfo/devicefamily</code>	Device family	r
<code>deviceinfo/hwrevision</code>	Hardware revision	r
<code>deviceinfo/serialnumber</code>	Serial number	r
<code>deviceinfo/swrevision</code>	Firmware version	r
<code>deviceinfo/bootloaderrevision</code>	Bootloader revision	r
<code>deviceinfo/extensionrevisions</code>		r

r = read only

Additional information about the AL1332 can be read with the `getidentity` service (→ **Service: getidentity** (→ p. 83)).

8.3.8 Read information about IO-Link devices

16553

Information about an IO-Link device connected via an IO-Link port is saved in the `iolinkmaster/port[n]/iolinkdevice/` substructure. The user can access the following data points:

Name	Description	Access
<code>iolinkmaster/port[n]/iolinkdevice/status</code>	Status of the connected IO-Link device 0 = SENSOR_NOT_CONNECTED 1 = SENSOR_IN_PREOPERATE 2 = SENSOR_IN_OPERATE 3 = SENSOR_WRONG	r
<code>iolinkmaster/port[n]/iolinkdevice/vendorid</code>	IO-Link ID of the manufacturer	r
<code>iolinkmaster/port[n]/iolinkdevice/deviceid</code>	IO-Link ID of the IO-Link device	r
<code>iolinkmaster/port[n]/iolinkdevice/productname</code>	Product name of the IO-Link device	r
<code>iolinkmaster/port[n]/iolinkdevice/serial</code>	Serial number of the IO-Link device	r
<code>iolinkmaster/port[n]/iolinkdevice/applicationspecifictag</code>	Device-specific identification (application tag)	rw

n ... 1...8

8.3.9 Configure IO-Link devices

11002

The ifm IoT Core supports the configuration of the connected IO-Link devices. A parameter is accessed via IO-Link index and subindex (→ IO Device Description (IODD) of the device)

The user can use the following services:

Service	Description	Access
<code>iolinkmaster/port[n]/iolinkdevice/iolreadacyclic</code>	Acyclic reading of a parameter of an IO-Link device	r
<code>iolinkmaster/port[n]/iolinkdevice/iolwriteacyclic</code>	Acyclic writing of a parameter of an IO-Link device	rw

n ... 1...8

r = read only

rw ... read and write

8.3.10 Control IO-Link master

17963

The device can be controlled via the following services:

Service	Description	Access
<code>firmware/version</code>	Firmware version of the IO-Link master	r
<code>firmware/reboot</code>	Reboot IO-Link master	rw
<code>firmware/factoryreset</code>	Reset IO-Link master to factory settings	rw

r = read only

rw ... read and write

8.3.11 Examples

Contents	
Example: Read process data of an IO-Link device	48
Example: Read several parameter values of the IO-Link master simultaneously.....	48
Example: Change name of the IO-Link master	49
Example: read the parameter value of an IO-Link device	49
Example: change the parameter value of an IO-Link device	50
Example: Subscribe to event.....	50

16577

Example: Read process data of an IO-Link device

16574

Task: Read the current measured value of the ifm temperature sensor TN2531 at IO-Link port X06

Solution: Read the data point for the process input data with the `getdata` service.

- Request object:

```
{"code":10,"cid":4711,"adr":"/iolinkmaster/port[6]/iolinkdevice/pdin/getdata"}
```

- Return object:

```
{"cid": 4711,"data":{"value": "03C9"},"code": 200}
```

The return value is given in hexadecimal format. Besides the temperature value the return value comprises additional information (→ IO Device Description (IODD) of the sensor). The temperature value is shown in bits 2 to 15.

0x03C9 = 0b1111001001

Temperature value: 0b11110010 = 242

Therefore: The current temperature value is 24.2 °C.

Example: Read several parameter values of the IO-Link master simultaneously

17310

Task: The following current values are to be read by the IO-Link master. Temperature, serial number

Solution: Read the current parameter values using the `getdatamult` (data point temperature service: `/processdatamaster/temperature`; Data point serial number: `/deviceinfo/serialnumber`)

Request object:

```
{"code":10,"cid":4711,"adr":"/getdatamulti","data":{"datatosend":["/processdatamaster/temperature"],["/deviceinfo/serialnumber"]}}
```

Return object:

```
{"cid":4711,"data":{"processdatamaster/temperature":{"code":200,"data":44},"deviceinfo/serialnumber":{"code":200,"data":"000174210147"},"code":200}
```


Example: Change name of the IO-Link master

10987

Task: Set the name of the IO-Link master for the representation in the LR SMARTOBSERVER to AL1332.

Solution: Change the parameter [Application Tag] with the setdata service to the value [AL1332].

The data point of the parameter [Application Tag] in the device description object is /devicetag/applicationtag.

- Request object:

```
{"code":10,"cid":4711,"adr":"/devicetag/applicationtag/setdata","data":{"newvalue":"AL1332"}}
```

- Return object:

```
{"cid":4711,"code":200}
```

Example: read the parameter value of an IO-Link device

16546

Task: Read the serial number of the ifm temperature sensor TN2531 at IO-Link port X02

Solution: Read the serial number with the iolreadacyclic service from the IO-Link device (index: 21, subindex: 0)

- Request object:

```
{  
  "code":10,  
  "cid":4711,  
  "adr":"/iolinkmaster/port[2]/iolinkdevice/iolreadacyclic",  
  "data":{"index":21,"subindex":0}  
}
```

- Return object:

```
{  
  "cid":4711,  
  "data":{"value":"4730323134323830373130"},  
  "code":200  
}
```

The returned value is given in hexadecimal format. The conversion of the HEX value in a STRING value is: G0214280710

Example: change the parameter value of an IO-Link device

16578

Task: Set the output configuration OUT1 of the ifm temperature sensor TN2531 at IO-Link port X02 to the value "Hnc / hysteresis function, normally closed".

Solution: Change the parameter [ou1] of the sensor to the value 4 using the `iolwritecyclicdata` service. The parameter can be accessed via IO-Link index 580, subindex 0 (→ IO-Link description of the sensor).

- Request object:

```
{"code":10,"cid":4711,"adr":"/iolinkmaster/port[2]/iolinkdevice/iolwritecyclic","data":{"index":580,"subindex":0,"value":4}}
```

- Response object:

```
{"cid":4711,"code":200}
```

Example: Subscribe to event

17946

Task: The current values of the following parameters should be sent regularly to a network server with IP address 192.168.0.4: product name of the IO-Link device at IO-Link port X02, cyclic input data of the IO-Link device at IO-Link port X02 and the operating temperature of the IO-Link master.

Solution: Subscribe to the required data using the `subscribe` service.

- Request object:

```
{
  "code":80,
  "cid":4711,
  "adr":"/timer[1]/counter/datachanged/subscribe",
  "data":
  {
    "callback":"192.168.0.44/temp",
    "datatosend":[
      "/iolinkmaster/port[2]/iolinkdevice/productname",
      "/iolinkmaster/port[2]/iolinkdevice/pdin",
      "/processdatamaster/temperature"]
  }
}
```

8.3.12 Programmers' notes

Contents

ifm IoT Core: General information	51
Device description	51
Access ifm-IoT Core	52
IoT Core: Diagnostic codes	54

10989

ifm IoT Core: General information

16576

The DataLine device family has one IoT Core. This component allows the user to address the IO-Link master from IT networks and to integrate it into Internet-of-Things applications.

The IoT Core provides the user with the following functions:

- Control device
- Monitoring of process data
- Read / write parameters of the IO-Link master
- Read / write parameters of the connected IO-Link devices
- Collect diagnostic data

Device description

14411

The IoT Core creates a device description on the AL1332. This device description is a structured, machine-readable data object in JSON format. All current values of parameters, diagnostic data and device information are mapped in this data object. The user can access this data object from IT networks.

The complete device description can be read using the gettree (→ service **Service: gettree** (→ p. [81](#))).

Access ifm-IoT Core

17561



To activate the changes of the parameter values the IoT Core must have the respective write access rights to the IO-Link master (→ Parameter [Access Rights]).

The ifm IoT Core supports HTTP requests. The following request methods are available.

GET method

21300

Using the GET method the user has read access to a data point.

The syntax of the request to the IoT Core is:

ip/datapoint/service

Description	Description
ip	IP address of the IoT port X23 of the IO-Link master
data_point	Data point which is to be accessed
service	Service

The syntax of the return of the IoT Core is:

```
{  
  "cid":id,  
  "data":{"value":resp_data},  
  "code":err_code  
}
```

parameter	Description
id	Correlation ID for the assignment of request and return
resp_data	Value of the data point; depending on the data type of the data point
err_code	Error code (→ IoT Core: Diagnostic codes (→ p. 54))

Example:

Request (via browser): 192.168.0.250/devicetag/applicationtag/getdata

Return: {"cid":-1,"data":{"value":"AL1332"}, "code":200}

POST method

16548

Using the POST method the user has read and write access to a data point. A form with the required information is transferred to the IP address of the IO-Link master (IoT port X23).

The syntax of the request to the IoT Core is:

```
{
  "code":code_id,
  "cid":id,
  "adr":"data_point/service",
  "data":{"req_data"}
}
```

Parameter	Description
code_id	ID of the service class
	10 Request
	11 Transaction
	80 Event
id	Correlation ID for the assignment of request and return
data_point	Data point which is to be accessed
service	Service to be performed (→ Overview: IoT services (→ p. 81))
req_data	Data to be transferred to the IoT Core (e.g. new values); indication optional (depending on the service)

The syntax of the return of the IoT Core is:

```
{
  "cid":id,
  "data":{"value":resp_data},
  "code":err_code
}
```

Parameter	Description
id	Correlation ID for the assignment of request and return
resp_data	Value of the data point; depending on the data type of the data point
err_code	Error code (→ IoT Core: Diagnostic codes (→ p. 54))

Example:

Request: {"code":10,"cid":4711, "adr":"devicetag/applicationtag/getdata"}

Return: {"cid":4711,"data":{"value":"AL1332"}, "code":200}

IoT Core: Diagnostic codes

17437

The ifm IoT Core uses the following diagnostic codes:

Code	Description
200	OK
230	OK; but reboot required
231	OK, but block request not yet terminated
232	Data accepted but changed internally
233	IP settings changed; application has to reboot the device; Wait for min. 1 second before the device is rebooted
400	Invalid request
403	Unauthorised access
500	Internal server fault
503	Service not available
530	Requested data is invalid
531	IO-Link error
532	Error in PLC

9 Operation

Contents

Identify device.....	55
Firmware update.....	56
Exchange IO-Link device.....	57

22368

9.1 Identify device

16568

In the online mode, the user can identify the device using the RDY and IoT status LEDs.

- ▶ Start LR DEVICE.
- ▶ Scan network for devices.
- > LR DEVICE recognises the IO-Link master.
- ▶ Click on the selection field next to the device name.
- > The RDY and IoT status LEDs are flashing.

9.2 Firmware update

16582

The new firmware is installed via the device's web interface.



If the firmware update is not successful, deactivate all connections to the EtherCAT PLC, LR SMARTOBSERVER and LR DEVICE and repeat the process.

- ▶ Stop EtherCAT PLC.
- ▶ Set the parameter [IP address SmartObserver] to 255.255.255.255 (→ **IoT: Configure the interface to the LR SMARTOBSERVER** (→ p. 29)).
- ▶ Stop the LRAgent.LRDevice service in the Windows task manager.

To install a new firmware version on the device:

Requirements

- > File with new firmware has been downloaded.
- > Ethernet connection between laptop/PC and device is established.

1 Call up web interface

- ▶ Start web browser.
- ▶ Enter the following into the address field of the browser: and confirm with [ENTER]:
<IP address of the device>/web/update
- > Web browser shows the [Firmware Update] page.

2 Load new firmware to AL1332

- ▶ Click on [Search...].
- > Dialogue window appears.
- ▶ Select the firmware file and click on [Open] in order to adopt the file.
- ▶ Click on [Submit] to start the firmware update.
- > Firmware is being loaded to the device.
- > After successful storage, the success message is displayed.

3 Restart the device

- ▶ Click on [Restart device now] to restart the device.
- > The status LED RDY flashes quickly.
- > Firmware is updating.
- ▶ Follow the instructions in the browser.

9.3 Exchange IO-Link device

7775

To exchange an IO-Link device:

Requirement:

- > IO-Link device is with factory settings.
- > IO-Link device supports IO-Link standard 1.1 or higher.

1 Set data storage

- ▶ Set the following parameters of the IO-Link port:
[Validation / Data Storage] = Type compatible V1.1 device with Restore
OR
[Port x IO-Link Validation / Data Storage] = Type compatible V1.1 device with Restore
- ▶ Save changes.

2 Exchange IO-Link device

- ▶ Disconnect old IO-Link device from AL1332.
- ▶ Connect new IO-Link device with the same IO-Link port of the AL1332.
- > IO-Link master copies parameter values from the data memory to the new IO-Link device.

10 Maintenance

21577

The operation of the unit is maintenance-free.

- ▶ Clean the surface of the unit when necessary. Do not use any caustic cleaning agents for this!
- ▶ After use, dispose of the unit in an environmentally friendly way in accordance with the applicable national regulations.

11 Factory settings

16549

In the factory settings, the device has the following parameter settings:

Parameter	Factory setting
[IP address] (IoT interface)	169.254.X.X
[Subnet mask] (IoT interface)	255.255.0.0
[IP gateway address] (IoT interface)	0.0.0.0
[Host name]	blank
Data memory (data storage)	blank

12 Accessories

17853

List of accessories of AL1332: → www.ifm.com > Product page > Accessories

13 Appendix

Contents

Technical data	61
EtherCAT	65
ifm IoT Core	76

7156

13.1 Technical data

Contents

Application	61
Electrical data	61
Inputs / outputs	61
Inputs	62
Outputs	62
Interfaces	62
Operating conditions	63
Approvals / tests	63
Mechanical data	63
Electrical connection	64

9011

13.1.1 Application

23710

Application	
Application	I/O modules for field applications
Daisy-chain function	Fieldbus interface

13.1.2 Electrical data

22819

Electrical data	
Operating voltage [V]	20...30 DC; (US; to SELV/PELV; cULus: max. 24 DC)
Current Consumption [mA]	300...3900; (US)
Protection class	III
Sensor supply US	
Max. current load total [A]	3.6

13.1.3 Inputs / outputs

23711

Inputs / outputs	
Total number of inputs and outputs	16; (configurable)

13.1.4 Inputs

22820

Inputs	
Number of digital inputs	16; (IO-Link Port Class A: 8 x 2)
Switching level high [V]	11...30 DC
Switching level low [V]	0...5 DC
Digital inputs protected against short circuits	yes

13.1.5 Outputs

22821

Outputs (digital)	
Output function	8; (IO-Link Port Class A: 8 x 1)
Max. current load per output [mA]	200
Short-circuit protection	yes

13.1.6 Interfaces

17947

Interfaces	
Communication interface	Ethernet; IO-Link
Communication interface	IO-Link; TCP/IP; PROFINET IO
Ethernet	
Transmission standard	10Base-T; 100Base-TX
Transmission rate [MBit/s]	10; 100
Protocol	TCP/IP; PROFINET IO
Factory settings	MAC address: see type label
IO-Link master	
Type of transmission	COM 1 / COM 2 / COM 3
IO-Link revision	V1.1
Number of ports Class A	8
IoT interface	
Transmission standard	10Base-T; 100Base-TX
Transmission rate [MBit/s]	10; 100
Protocol	DCP, DCHP, Auto IP
Factory settings	- IP address: 169.254.X.X - Subnet mask: 255.255.0.0 - Gateway IP address: 0.0.0.0 - MAC address: see type label

13.1.7 Operating conditions

22823

Operating conditions	
Applications	Indoor use
Ambient temperature [°C]	-25...60
Storage temperature [°C]	-25...85
Max. perm. relative air humidity [%]	90
Max. height above sea level [m]	2000
Protection rating	IP 65; IP 66; IP 67
Pollution Degree	2

13.1.8 Approvals / tests

22824

Approval / tests	
EMC	▪ EN 61000-6-2 ▪ EN 61000-6-4
MTTF [Years]	90

13.1.9 Mechanical data

22825

Mechanical data	
Weight [g]	378.2
Materials	Housing: PA; socket: brass nickel-plated

13.1.10 Electrical connection

17850

Voltage supply IN X31		
Plug and socket connection	M12	
Wiring	2 1 3 4  1: + 24 V DC (US) 2: - 3: GND (US) 4: -	
Ethernet IN / OUT X21, X22		
Plug and socket connection	M12	
Wiring	1 2 5 4 3  1: TX + 2: RX + 3: TX - 4: RX - 5: -	
IoT X32		
Plug and socket connection	M12	
Wiring	1 2 5 4 3  1: TX + 2: RX + 3: TX - 4: RX - 5: -	
Process connection IO-Link ports Class A X01...X0<IOL_AnzPorts>		
Plug and socket connection	M12	
Wiring	1 2 5 4 3  1: + 24 V DC (US) 2: DI 3: GND (US) 4: C/Q IO-Link 5: -	

13.2 EtherCAT

Contents

Parameter data	66
Cyclic data	67
Acyclic data	68

22433

13.2.1 Parameter data

Contents	
Fieldbus parameters	66
ESI file	66
	1568

Fieldbus parameters

8953

The fieldbus parameters contain information for the integration of the device into the EtherCAT network:

Name	Description	Possible values
EtherCAT address	"Explicit Device ID" of the device	0...65534

ESI file

10277

To represent the AL1332 in a field bus projection software ifm electronic provides an ESI file. The EDS file can be downloaded from ifm's website. In the ESI file, all parameters, process data and their valid value ranges are defined.

13.2.2 Cyclic data

Contents

EtherCAT modules	67
------------------------	----

22429

EtherCAT modules

9461

Module	Description	
IOL_In_4Byte	IO-Link activated	4-byte input data
IOL_In_8Byte		8-byte input data
IOL_In_16Byte		16-byte input data
IOL_In_32Byte		32-byte input data
IOL_Out_4Byte		4-byte output data
IOL_Out_8Byte		8-byte output data
IOL_Out_16Byte		16-byte output data
IOL_Out_32Byte		32-byte output data
IOL_4/4_I/O bytes		4-byte input data / 4-byte output data (default)
IOL_8/8_I/O bytes		8-byte input data / 8-byte output data
IOL_4/16_I/O bytes		4-byte input data / 16-byte output data
IOL_16/4_I/O bytes		16-byte input data / 4-byte output data
IOL_16/16_I/O bytes		16-byte input data / 16-byte output data
IOL_32/32_I/O bytes		32-byte input data / 32-byte output data
Digital_IN	IO-Link deactivated	Digital input
Digital_OUT		Digital output
Deactivated	deactivated	

13.2.3 Acyclic data

22427

Note

16560

The device implements a "Modular Device Profile" with an "IO-Link profile" according to ETG.5001.1.

MDP Standard Information (0x1000)

9043

Identity information about the device and current and available process data constellations

Index	Description	Possible values / reference	Data type / access
0x1000	Device Type	MDP Profile = 0x184C1389	UINT32 / ro
0x1008	Manufacturer Device Name	"<IOL_ECAT_ProdName>"	STRING / ro
0x1009	Manufacturer Hardware Version	e.g. "AA"	STRING / ro
0x100A	Manufacturer Software Version		STRING / ro
0x1018	Identity Object - Subindex 0x1: Vendor ID - Subindex 0x2: Product Code - Subindex 0x3: Revision Number: - Subindex 0x4: Serial Number	0x622 "AL1332"	UINT32 / ro UINT32 / ro UINT32 / ro UINT32 / ro
0x10F3	Diagnostics History - Subindex 0x1: Maximum Messages - Subindex 0x2: Newest Messages - Subindex 0x3: Newest Ack. Message - Subindex 0x4: New Message Available - Subindex 0x5: Flags - Subindex 0x06: Diagnostics Message 01 ... - Subindex 0x45: Diagnostics Message 64		UINT8 / ro UINT8 / ro UINT8 / rw BOOL / rw UINT16 / rw STRING / ro STRING / ro
0x10F8	Timestamp (value in ns)		UINT64 / ro
0x160n	TxPDO Mapping of IO-Link Outputs		ro
0x1A0n	TxPDO Mapping of IO-Link Inputs		ro
0x1A08	TxPDO Mapping of New Messages Available		ro
0x1A09	TxPDO Mapping of Timestamp		ro
0x1A81	TxPDO Mapping of IO-Link Device Status		ro
0x1A82	TxPDO Mapping of IO-Link Port Qualifier		

ro = read only

rw ... read and write

Manufacturer Specific Index (0x20 00)

11011

Manufacturer-specific parameters

Index	Description	Possible values	Data type / access
0x2001	Component Name	"EtherCAT IO-Link Gateway"	STRING / ro
0x2002	Vendor Name	"ifm electronic"	STRING / ro
0x2003	Vendor URL	"www.ifm.com"	STRING / ro
0x2004	Order Number	"AL1332"	STRING / ro
0x2005	Manufacturing Date		STRING / ro
0x2006	QS Date		STRING / ro
0x2007	Installation Location	Location of installation (user-defined)	STRING / rw
0x200A	Equipment ID	Device name (user-defined)	STRING / rw
0x2F00	Reset To Factory	- MSB: 0xA5 - LSB: 0x00 = Factory Reset of System + NVMEM 0x01 = Factory Reset of System	UINT16 / w
0x2F01	Device Localization	0x00: LED RDY flashing for 5 s	UINT8 / w
0x2F02	Current Use Case (Access Rights)	- MSB: 0xA5 - LSB: 0x00: EtherCAT + IoT 0x01: EtherCAT + IoT (read only) 0x02: IoT (only)	UINT16 / rw

ro = read only
 rw ... read and write
 w ... write only

IO-Link inputs (0x6000)

2260

Input data of the IO-Link ports X01...X08

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	Description	Possible values	Data type / access
0x60n0	IO-Link inputs - Subindex 0x01: Byte 1 ... - Subindex 0x20: Byte 32	each byte: 0x00...0xFF	each byte: UINT8 / ro

ro = read only

IO-Link outputs (0x7000)

23089

Output data of the IO-Link ports X01...X08

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	Description	Possible values	Data type / access
0x70n0	IO-Link outputs - Subindex 0x01: Byte 1 ... - Subindex 0x20: Byte 32	per byte: 0x00...0xFF	each byte: UINT8 / ro

ro = read only

IO Settings (0x8000)

16550

Manufacturer-specific settings of the IO-Link ports X01...X08

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	IO-Link parameters	Possible values	Data type / access
0x80n0	IO Settings - Subindex 0x04: Device ID - Subindex 0x05: Vendor ID - Subindex 0x20: IO-Link revision - Subindex 0x22: Cycle Time - Subindex 0x24: Process Data In Length - Subindex 0x25: Process Data Out Length - Subindex 0x028: Master Control	0x000000...0xFFFFFFFF 0x0000...0xFFFF ifm electronic: 0x136 0x10: IO-Link revision 1.0 0x11: IO-Link revision 1.1 0x00: Deactivated 0x01: Digital input 0x02: Digital output 0x03: IO-Link	UINT32 / rw UINT32 / rw UINT8 / rw UINT32 / rw UINT8 / rw UINT8 / rw UINT16 / rw
0x80n8	Vendor Specific IO Settings - Subindex 0x01: Validation ID - Subindex 0x02: Reconfigure - Subindex 0x03: Byte Swap	0x00: No check 0x01: V1.0 device, no DS 0x02: V1.1 device, no DS 0x03: V1.1 device, backup + restore 0x04: V1.1 device, restore 0x00: No action 0xFF: Activate configuration 0x00: No action 0x01: Byte swap	UINT8 / rw UINT8 / rw UINT8 / rw

rw ... read and write

IO Info Data (0x9000)

17300

Current value of the connected IO-Link devices

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	IO-Link parameters	Possible values	Data type / access
0x90n0	IO Info Data - Subindex 0x04: Device ID - Subindex 0x05: Vendor ID - Subindex 0x20: IO-Link revision - Subindex 0x21: Frame capability - Subindex 0x22: Cycle time - Subindex 0x24: PD In length - Subindex 0x25: PD Out length		UINT32 / ro UINT32 / ro UINT8 / ro UINT8 / ro UINT8 / ro UINT8 / ro UINT8 / ro

ro = read only

IO Diag data (0xA000)

16537

The device provides the following diagnostic data for each port:

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	IO-Link parameters	Possible values	Data type / access
0xA0n0	IO Diag Data0 - Subindex 0x01: IO-Link state - Subindex 0x02: Lost frames	0x00: INACTIVE 0x01: DIGINPUT 0x02: DIGOUTPUT 0x08: OPERATE 0x09: STOP	UINT8 / ro UINT8 / ro

ro = read only

Device status / port status (0xF000)

17933

Status of the IO-Link device at the port X01...X08

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	IO-Link parameters	Possible values	Data type / access
0xF000	Module device profile - Subindex 0x01: Module index distance - Subindex 0x02: Maximum number of modules	0x0010 0x0008	UINT16 / ro UINT16 / ro
0xF030	Configured module Ident list		
0xF050	Detected module ident list		
0xF100	Device status - High nibble (0xbbbb) - Low nibble (0xbbbb)	0x0: No error 0x3: Invalid device ID 0x4: Invalid vendor ID 0x7: Invalid cycle time 0x8: Invalid length of PD In 0x9: Invalid length of PD Out 0xA: No device detected 0xB: Supply voltage low or short circuit 0xD: Unspecified error 0x0: Deactivated 0x1: Digital input 0x2: Digital output 0x3: OP: IO-Link, operating state 0x4: STOP: IO-Link, not operating state (fault or no device) 0x5: PreOP: IO-Link, device in PreOP state	UINT8 / ro
0xF101	IO-Link port qualifier - Subindex 0x00: PQI port X01 ... - Subindex 0x0n: PQI port X08	→ Mapping: Port qualifier (0xF101) (→ p. 75)	

ro = read only

Mapping: Port qualifier (0xF101)

14998

Port Qualifier Information (PQI) contains diagnostic information about the IO-Link port. In addition to the process data, the IO-Link master sends the PQI to the EtherCAT controller.

Bit							
7	6	5	4	3	2	1	0
PVI	DE	DA	DACT	PVO	--	DI2	DI4

Legend:

DI4	Signal status of the digital input on pin 4 (if used)	0	OFF
		1	ON
DI2	Signal status of the digital input on pin 2 (if used)	0	OFF
		1	ON
PVO	Port validity output: Validity of the output data of the IO-Link device	0	invalid
		1	valid
DACT	Device deactivated: shows if the IO-Link port is configured and can be used	0	deactivated or not available
		1	activated and can be used
DA	Device available: shows if the IO-Link device has been recognised and if the device is in the "preoperate" or in the "operate" state	0	No device
		1	device detected
DE	Device error: shows if an error or a warning occurred; Note: The user needs to determine the cause of the fault separately via acyclic services.	0	no error
		1	Error
PVI	Port validity input: Validity of the input data of the IO-Link device	0	invalid
		1	valid

13.3 ifm IoT Core

Contents	
Overview: IoT profile.....	77
Overview: IoT types.....	80
Overview: IoT services	81

8988

13.3.1 Overview: IoT profile

Contents

Profile: deviceinfo	77
Profile: devicetag	78
Profile: iolinkmaster	78
Profile: parameter	79
Profile: processdata	79
Profile: service	79
Profile: software	79
Profile: timer	79

17711

Profile: deviceinfo

17135

Element (identifier)	Properties	mandatory	Comments
deviceinfo	- type = structure - profiles = deviceinfo		characterises the element as device information
deviceinfo/devicename	type = data	optional	
deviceinfo/devicefamily	type = data	optional	
deviceinfo/devicevariant	type = data	optional	
deviceinfo/devicesymbol	type = data	optional	
deviceinfo/deviceicon	type = data	optional	
deviceinfo/serialnumber	type = data	mandatory	
deviceinfo/productid	type = data	optional	
deviceinfo/productname	type = data	optional	
deviceinfo/productcode	type = data	mandatory	
deviceinfo/producttext	type = data	optional	
deviceinfo/ordernumber	type = data	optional	
deviceinfo/productiondate	type = data	optional	
deviceinfo/productioncode	type = data	optional	
deviceinfo/hwrevision	type = data	mandatory	
deviceinfo/swrevision	type = data	mandatory	
deviceinfo/bootloaderrevision	type = data	optional	
deviceinfo/vendor	type = data	optional	
deviceinfo/vendortext	type = data	optional	
deviceinfo/vendorurl	type = data	optional	
deviceinfo/vendorlogo	type = data	optional	
deviceinfo/productwebsite	type = data	optional	
deviceinfo/supportcontact	type = data	optional	
deviceinfo/icon	type = data	optional	
deviceinfo/image	type = data	optional	
deviceinfo/standards	type = data	optional	

Profile: devicetag

17438

Element (identifier)	Properties	mandatory	Comments
devicetag	- type = structure - profiles = devicetag		
devicetag/applicationtag	type = data	mandatory	
devicetag/applicationgroup	type = data	optional	
devicetag/machinecode	type = data	optional	
devicetag/tenant	type = data	optional	

Profile: iolinkmaster

14997

Element (identifier)	Properties	mandatory	Comments
masterport	- type = structure - profiles = iolinkmaster		Executable service
masterport/mode	- type = data - profile = parameter	mandatory	
masterport/comspeed	- type = data - profile = parameter	mandatory	
masterport/mastercycletime_actual	- type = data - profile = parameter	mandatory	
masterport/mastercycletime_preset	- type = data - profile = parameter	mandatory	
masterport/validation_datastorage_mode	- type = data - profile = parameter	mandatory	
masterport/validation_vendorid	- type = data - profile = parameter	mandatory	
masterport/validation_deviceid	- type = data - profile = parameter	mandatory	
masterport/additionalpins_in	- type = data - profile = processdata	optional	
masterport/additionalpins_out	- type = data - profile = processdata	optional	
masterport/portevent	type = data	mandatory	
masterport/iolinkdevice	- type = structure - profile = iolinkdevice_full	mandatory	

Profile: parameter

16545

The profile is used to mark the elements of type data as parameters (acyclic data). The profile defines no substructure.

Profile: processdata

16569

The profile is used to mark the elements of type data as process data (cyclic data). The profile does not define a substructure.

Profile: service

16575

Element (identifier)	Properties	mandatory	Comments
service	- type = service - profiles = service		Executable service

Profile: software

10999

Element (identifier)	Properties	mandatory	Comments
software	- type = structure - profiles = software		characterises the element as software
software/version	type = data	mandatory	
software/reboot	type = service	optional	
software/factoryreset	type = service	optional	
software/status	type = structure	optional	
software/diag	type = structure	optional	

Profile: timer

10997

Element (identifier)	Properties	mandatory	Comments
timer	- type = structure - profiles = timer		Executable service
timer/counter	- type = data - profile = parameter	mandatory	
timer/interval	- type = data - profile = parameter	optional	
timer/start	type = service	optional	
timer/start	type = service	optional	

13.3.2 Overview: IoT types

16547

The ifm IoT Core uses the following element types:

Name	Description
structure	Element is a structure element (like a folder in a file system)
service	Element is a service that can be addressed from the network
Event	Element is an event that can be started by the firmware and sends messages.
data	Element is a data point
device	Root element a device represents

13.3.3 Overview: IoT services

Contents	
Service: factoryreset.....	81
Service: gettree	81
Service: getdata.....	82
Service: getdatamulti	82
Service: getidentity	83
Service: getsubscriptioninfo.....	83
Service: iolreadacyclic.....	84
Service: iolwriteacyclic.....	84
Service: reboot	84
Service: setblock	85
Service: setdata.....	85
Service: setelementinfo	86
Service: subscribe	86
Service: unsubscribe	87

17708

Service: factoryreset

12188

Name: factoryreset

Description: The service sets the parameters of the device to the factory settings.

Applicable to: different objects

Request data: none

Return data (data): none

Service: gettree

17435

Name: gettree

Description: The service reads the complete device description of the AL1332 and provides it as JSON object.

Applicable to: Objects of the device type

Request data: none

Return data (data):

Data field	Required field	Data type	Default	Description
Identifier	mandatory	STRING		Identifier of the root element
type	mandatory	STRING		Type of the element
format	optional	JSON object	empty	Format of the data content
uid	optional	STRING	empty	
profiles	optional	JSON array	empty	
subs	mandatory	JSON array		Subelements
hash	optional	STRING		

Service: getdata

12223

Name: getdata

Description: Service reads the value of a data point and provides it.

Applicable to: Objects of the data type

Request data: none

Return data (data):

Data field	Required field	Data type	Default	Description
value	mandatory	STRING		Value of the element/data point

Example: {"code":10,"cid":4711,"adr":"devicetag/applicationtag/getdata"}

Service: getdatamulti

17964

Name: getdatamulti

Description: The service sequentially reads the values of several data points and provides them. The value and the diagnostic code are provided for each data point.

Applicable to: Objects of the data type

Request data:

Data field	Required field	Data type	Default	Description
datatosend	mandatory	ARRAY OF STRINGS		List of data points to be requested; data points must support the service getdata
consistent	optional	BOOL	false	

Return data (data): for each requested data point

Data field	Required field	Data type	Default	Description
Data point	mandatory	STRING		Data point request
code	mandatory	INT		Diagnostic code of the request
data	mandatory	STRING		Value of the data point

Service: getidentity

17134

Name: getidentity

Description: The service reads the complete device description of the AL1332 and provides it as JSON object.

Applicable to: Objects of the device type

Request data: none

Return data (data):

Data field	Required field	Data type	Default	Description
iot		device		Device description as JSON object
iot.name	mandatory	STRING		
iot.uid	optional	STRING		
iot.version	mandatory	STRING		
iot.catalogue	optional	ARRAY OF OBJECTS		
iot.deviceclass	optional	ARRAY OF STRING		
iot.serverlist		ARRAY OF OBJECTS		
device	optional			AL1332
device.serialnumber	optional			Serial number
device.hwrevision	optional			Hardware version
device.swrevision	optional			Software version
device.custom	optional			

Service: getsubscriptioninfo

17436

Name: getsubscriptioninfo

Description: The service provides information about an existing subscription (subscribe).

Applicable to: Objects of the event type

Request data:

Data field	Required field	Data type	Default	Description
subscriptionid	mandatory	INT		ID of the subscription

Return data (data): none

Service: iolreadacyclic

12222

Name: iolreadacyclic

Description: The service acyclically reads the parameter value of an IO-Link device. It is accessed via IO-Link index and subindex.

Applicable to: IO-Link specific objects

Request data:

Data field	Required field	Data type	Default	Description
index	mandatory	NUMBER		IO-Link index of the parameter
subindex	mandatory	NUMBER		IO-Link subindex of the parameter

Return data (data):

Data field	Required field	Data type	Default	Description
value	mandatory	STRING		Value in hexadecimal format

Service: iolwriteacyclic

11035

Name: iolwriteacyclic

Description: The service acyclically writes the parameter value of an IO-Link device. It is accessed via IO-Link index and subindex.

Applicable to: IO-Link specific objects

Request data:

Data field	Required field	Data type	Default	Description
index	mandatory	NUMBER		IO-Link index of the parameter
subindex	mandatory	NUMBER		IO-Link subindex of the parameter
value	mandatory	NUMBER		New value of the parameter

Return data (data): none

Service: reboot

10986

Name: reboot

Description: The service reboots the device.

Applicable to: different objects

Request data: none

Return data (data): none

Service: setblock

12224

Name: setblock**Description:** The service simultaneously sets the values of several data points of a structure.**Applicable to:** Objects of the data type**Request data:**

Data field	Required field	Data type	Default	Description
datatosend	mandatory	ARRAY OF (STRINGS)		List of data points and their new values; data points must support the service setdata
consistent	optional	BOOL	false	

Return data (data): none

Example:

```
{
  "code":10,
  "cid":4711,
  "adr":"/iotsetup/network/setblock",
  "data":{"consistent":true,"datatosend":["ipadresse":"192.168.0.6","ipdefaultgateway":"192.168.0.250"]}
}
```

Service: setdata

11036

Name: setdata**Description:** The service sets the value of the data point.**Applicable to:** Objects of the data type**Request data:**

Data field	Required field	Data type	Default	Description
newvalue	mandatory	STRING		New value of the element/data point

Return data (data): none

Example:

```
{
  "code":10,
  "cid":4711,
  "adr":"/devicetag/applicationtag/setdata",
  "data":{"newvalue":"ifm IO-Link master"}
}
```

Service: setelementinfo

7159

Name: setelementinfo

Description: The service sets the uid of an element.

Applicable to: Objects of the device type

Request data:

Data field	Required field	Data type	Default	Description
url	mandatory	STRING		URL of the element to be changed
uid	optional	STRING		UID to be set
profiles	optional	JSON array		
format	optional	JSON object		

Return data (data):

Data field	Required field	Data type	Default	Description
identifier	mandatory	STRING		Identifier of the element
type	mandatory	STRING		Type of the element
format	optional	JSON object	blank	Format of the data or the service content
uid	optional	STRING	blank	
profiles	optional	JSON array	blank	
hash	optional	STRING	--	

Service: subscribe

10920

Name: subscribe

Description: The service subscribes to the values of data points. The data points to be subscribed are transferred as a list. The IO-Link master sends changes to the data drain defined in callback.

Applicable to: Objects of the event type

Request data:

Data field	Required field	Data type	Default	Description
callback	mandatory	STRING		Address to which IoT Core event notifications are to be sent; complete URL: ipaddress:port/path
datatosend	mandatory	ARRAY OF STRINGS		List from URLs of data elements; elements have to support getdata

Return data (data): none

Service: unsubscribe

16567

Name: unsubscribe

Description: The service deletes an existing subscription. unsubscribe is successful if cid and the callback address are registered for a subscription (subscribe). If the STRING "DELETE" is provided in callback, the IO-Link master deletes all active subscriptions.

Applicable to: Objects of the event type

Request data:

Data field	Required field	Data type	Default	Description
callback	mandatory	STRING		Address to which IoT Core event notifications are to be sent; complete URL: ipaddress:port/path

Return data (data): none

14 Index

A

Access ifm-IoT Core	52
Accessories	60
Acyclic data	68
Appendix	61
Application	61
Approvals / tests	63

C

Communication, parameter setting, evaluation	11
Configuration	24
Configure cyclic process data	37
Configure IO-Link devices	34, 40, 47
Configure IO-Link master	36
Configure IO-Link ports	36, 45
Configure IoT port	44
Configure the fieldbus port	44
Connect the device	19
Control IO-Link master	47
Cyclic data	67

D

Device description	51
Device status / port status (0xF000)	74
Digital inputs	12

E

Electrical connection	14, 64
Electrical data	61
ESI file	66
EtherCAT	11, 35, 65
Programmers' notes	41
EtherCAT interface	22
EtherCAT modules	67
EtherCAT ports	15
Example	48
Change name of the IO-Link master	49
change the parameter value of an IO-Link device	50
Read process data of an IO-Link device	48
Read several parameter values of the IO-Link master simultaneously	48
read the parameter value of an IO-Link device	49
Subscribe to event	50
Examples	48
Exchange IO-Link device	57

F

Factory settings	59
Fieldbus	
Configure the EtherCAT port	29
Fieldbus parameters	66
Firmware	
Reboot the device	33
Reset device to factory settings	33
Firmware update	56
Function	10

G

General	7
GET method	52

I

Identify device	55
ifm IoT Core	76
General information	51
ifm weltweit • ifm worldwide • ifm à l'échelle internationale	91
Info	
Show device information	33
Input circuit	17
Inputs	62
Inputs / outputs	61
Install ESI file	35
Integrate the AL1332 into the EtherCAT project	36
Intended use	9
Interfaces	62
Internet of Things (IoT)	11
IO Diag data (0xA000)	73
IO Info Data (0x9000)	73
IO Settings (0x8000)	72
IO-Link	11
IO-Link Acyclic Command (0x3100)	70
IO-Link circuits	18
IO-Link inputs (0x6000)	71
IO-Link outputs (0x7000)	71
IO-Link ports	17
Activate data transfer to the LR SMARTOBSERVER	30
Configure operating mode	31
Set the device validation and data storage	32
IO-Link ports (Class A)	23
IO-Link supply	12
IoT	
Configure access rights	27
Configure IP settings	28
Configure the interface to the LR SMARTOBSERVER	29
IoT Core	43
Diagnostic codes	54
IoT port	16, 22

L

LED indicators	21
Legal and copyright information	5
LR DEVICE	25

M

Maintenance	58
Manufacturer Specific Index (0x20 00)	69
Mapping	
Port qualifier (0xF101)	75
MDP Standard Information (0x1000)	68
Mechanical data	63
Modification history	6
Mount the device	13
Mounting	13

N

Note	68
------------	----

Index

O

Offline parameter setting	26
Operating and display elements	20
Operating conditions	63
Operation	55
Outputs	62
Overview	20
IoT profile	77
IoT services	81
IoT types	80

P

Parameter data	66
Parameter setting	11
Permitted use	9
PI controller	5
POST method	53
Preliminary note	5
Profile	
deviceinfo	77
devicetag	78
iolinkmaster	78
parameter	79
processdata	79
service	79
software	79
timer	79
Programmers' notes	51
Prohibited use	9
Purpose of the document	5

R

Read / write cyclic process data	45
Read and write cyclic process data	38
Read device information	46
Read diagnostic and status information	39
Read diagnostic data	46
Read information about IO-Link devices	47
Remarks	14, 26
Required background knowledge	7

S

Safety instructions	7
Safety symbols on the device	8
Service	
factoryreset	81
getdata	82
getdatamulti	82
getidentity	83
getsubscriptioninfo	83
gettree	81
iolreadacyclic	84
iolwriteacyclic	84
reboot	84
setblock	85
setdata	85
setelementinfo	86
subscribe	86
unsubscribe	87
Set application identification	45
Status LEDs	21

Symbols and styles used	6
-------------------------------	---

T

Tampering with the unit	8
Technical data	61

U

Use acyclic services	41
Use ADS over EtherCAT	41
Use CANopen over EtherCAT	42

V

Visual indication	12
Voltage supply	22

W

Warnings used	8
---------------------	---

15 ifm weltweit • ifm worldwide • ifm à l'échelle internationale

Version: 2017-12-18

8310

ifm electronic gmbh • Friedrichstraße 1 • 45128 Essen

www.ifm.com • Email: info@ifm.com

Service hotline: 0800 / 16 16 16 (only Germany, Mo-Fr 07.00...18.00 h)

ifm Niederlassungen • Sales offices • Agences

D	Niederlassung Nord • 31135 Hildesheim • Tel. 05121 7667-0 Niederlassung West • 45128 Essen • Tel. 0201 36475 -0 Niederlassung Mitte-West • 58511 Lüdenscheid • Tel. 02351 4301-0 Niederlassung Süd-West • 64646 Heppenheim • Tel. 06252 7905-0 Niederlassung Baden-Württemberg • 73230 Kirchheim • Tel. 07021 8086-0 Niederlassung Bayern • 82178 Puchheim • Tel. 089 80091-0 Niederlassung Ost • 07639 Tautenhain • Tel. 036601 771-0
AE	ifm electronic FZC • Saif Zone, Sharjah • phone +971- 6-5573601
AR	ifm electronic s.r.l. • 1107 Buenos Aires • phone +54 11 5353-3436
AT	ifm electronic gmbh • 1120 Wien • phone +43 / 1 / 617 45 00
AU	ifm efector pty ltd. • Mulgrave Vic 3170 • phone +61 1300 365 088
BE	ifm electronic n.v./s.a. • 1731 Zellik • phone +32 2 481 0220
BG	ifm electronic eood • 1202 Sofia • phone +359 2 807 59 69
BR	ifm electronic Ltda. • 03337-000 Sao Paulo / SP • phone +55-11-2672-1730
CA	ifm efector Canada inc. • Mississauga, ON L5N 2X7 • phone +1 855-436-2262
CH	ifm electronic ag • 4624 Härkingen • phone +41 / 800 88 80 33
CL	ifm electronic SpA • Oficina 5041 Comuna de Conchalí • phone +56-2-32239282
CN	ifm electronic (Shanghai) Co. Ltd. • 201203 Shanghai • phone +86 21 3813 4800
CZ	ifm electronic, spol. s.r.o. • 140 00 Praha 4 • phone +420 267 990 211
DK	ifm electronic a/s • 2605 Brøndby • phone +45 70 20 11 08
ES	ifm electronic s.a. • 08820 El Prat de Llobregat • phone +34 93 479 30 80
FI	ifm electronic oy • 00440 Helsinki • phone +358 75 329 5000
FR	ifm electronic s.a. • 93192 Noisy-le-Grand Cedex • phone +33 0820 22 30 01
GB	ifm electronic Ltd. • Hampton, Middlesex TW12 2HD • phone +44 / 20 / 8213 0000
GR	ifm electronic monoprosofi E.P.E. • 15125 Amaroussio • phone +30 210 61 800 90
HU	ifm electronic kft. • 9028 Győr • phone +36-96 / 518-397
IN	ifm electronic India Private Limited • Kolhapur, 416234 • phone +91 / 231 / 267 27 70
IE	ifm electronic (Ireland) Ltd. • Dublin 22 • phone +353 / 1 / 461 32 00
IT	ifm electronic s.r.l. • 20864 Agrate Brianza (MB) • phone +39 39-6899982
JP	efector co., ltd. • Chiba-shi, Chiba 261-7118 • phone +81 043-299-2070
KR	ifm electronic Ltd. • 04420 Seoul • phone +82 2-790-5610
MX	ifm efector S. de R.L. de C.V. • San Pedro Garza Garcia, N.L. 66269 • phone +52-81-8040-3535
MY	ifm electronic Pte. Ltd • 47100 Puchong, Selangor • phone +603 8066 9853
NA	ifm electronic (pty) Ltd • 25 Dr. W. Kulz Street Windhoek • phone +264 61 300984
NL	ifm electronic b.v. • 3843 GA Harderwijk • phone +31 341-438 438
NZ	ifm efector pty ltd • 930 Great South Road Penrose, Auckland • phone +64 / 95 79 69 91
PL	ifm electronic sp. z o.o. • 40-106 Katowice • phone +48 32 70 56 400
PT	ifm electronic s.a. • 4410-137 São Félix da Marinha • phone +351 223 71 71 08
RO	ifm electronic s.r.l. • Sibiu 557260 • phone +40 269 224 550
RU	ifm electronic • 105318 Moscow • phone +7 495 921-44-14
SG	ifm electronic Pte Ltd • 609 916 Singapore • phone +65 6562 8661
SK	ifm electronic s.r.o. • 831 06 Bratislava • phone +421 244 872 329
SE	ifm electronic ab • 412 50 Göteborg • phone +46 31-750 23 00
TR	ifm electronic Ltd. Sti. • 34381 Sisli, Istanbul • phone +90 212 210 50 80
TW	ifm electronic • Kaohsiung City, 806, Taiwan R.O.C. • phone +886 7 3357778
UA	TOV ifm electronic • 02660 Kiev • phone +380 44 501-85-43
US	ifm efector inc. • Malvern, PA 19355 • phone +1 800-441-8246
VN	ifm electronic Vietnam Co., Ltd. • 700000 Ho Chi Minh City • phone +84-28-2253.6715
ZA	ifm electronic (Pty) Ltd. • 0157 Pretoria • phone +27 12 450 0412

Technische Änderungen behalten wir uns ohne vorherige Ankündigung vor.

We reserve the right to make technical alterations without prior notice.

Nous nous réservons le droit de modifier les données techniques sans préavis.