

CE

Brief instructions Connection of analogue cameras to the PDM360 NG process and dialogue module in CODESYS

ecomatioo





Contents

1	Preliminary note	 	 	4 4 4
2	Safety instructions2.1 General.2.2 Target group2.3 Electrical connection2.4 Tampering with the device2.5 Electromagnetic compatibility	· · · · · · · · ·	· · · · · · · ·	5 5 5 5 5 5 5 5 5
3	Functions and features 3.1 Application example 3.2 Connection and mounting accessories 3.3 3.3 General electrical connection 3.3.1 Cover all unused connectors 3.4 Ethernet interface 3.5 Analogue video inputs	· · · · · · · · · · ·	· · · · · · · ·	6 6 8 8 8 8 9 9
4	Set-up4.1 General.4.2 Getting started4.3 Set-up4.4 Required documentation	· · · · · · ·	· · · · · ·	9 9 10 10 11
5	Operation of analogue camera(s) on the PDM.5.1 Configure the camera bitmap in the dialogue [Bitmap Configuration]5.2 Features of analogue cameras.5.3 Display modes5.4 Capture mode.5.5 Overlay mode.5.6 Configure analogue camera image5.6.1 Create bitmap for camera image5.6.2 Set scaling / image section size and image position5.6.4 Rotate the camera image.	· · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	.11 12 12 13 14 14 14 17 18 18
6	Note on the use of analogue camera images in CODESYS.			19
7	Execute program		•	19
8	Check activity of the camera.		•	20
9	Provide camera error messages	· · · ·		21 21

UK

This document is the original instructions.

Licences and trademarks

Microsoft[®], Windows[®], Windows XP[®] and Windows Vista[®] are registered trademarks of Microsoft Corporation. All trademarks and company names are subject to the copyright of the respective companies.

1 Preliminary note

This document applies to devices of the type "PDM360 NG" (art. no.: CR1083 and CR1087). These instructions are an integral part of the device.

This document is intended for specialists. These specialists are people who are qualified by their appropriate training and their experience to see risks and to avoid possible hazards that may be caused during operation or maintenance of the device. The document contains information about the correct handling of the device.

Read this document before use to familiarise yourself with operating conditions, installation and operation. Keep this document during the entire duration of use of the device.

Adhere to the safety instructions.

1.1 Symbols used

- Instructions
- > Reaction, result
- [...] Designation of keys, buttons or indications
- \rightarrow Cross-reference



Important note

Non-compliance may result in malfunction or interference.



Information Supplementary note

1.2 Warning signs used

Warning of serious personal injury. Death or serious irreversible injuries may result.

Warning of personal injury. Slight reversible injuries may result.

NOTE

Warning of damage to property.

2 Safety instructions

2.1 General

These instructions contain texts and figures concerning the correct handling of the device and must be read before installation or use.

Observe the operating instructions. Non-observance of the instructions, operation which is not in accordance with use as prescribed below, wrong installation or incorrect handling can seriously affect the safety of operators and machinery.

2.2 Target group

These instructions are intended for authorised persons according to the EMC and low-voltage directives. The device must only be installed, connected and put into operation by a qualified electrician.

2.3 Electrical connection

Disconnect the unit externally before handling it. If necessary, also disconnect any independently supplied output load circuits.

If the device is not supplied by the mobile on-board system (12/24 V battery operation), it must be ensured that the external voltage is generated and supplied according to the criteria for safety extra-low voltage (SELV) as this voltage is supplied without further measures to the connected controller, the sensors and the actuators.

The wiring of all signals in connection with the SELV circuit of the device must also comply with the SELV criteria (safety extra-low voltage, safe electrical isolation from other electric circuits).

If the supplied SELV voltage is externally grounded (SELV becomes PELV), the responsibility lies with the user and the respective national installation regulations must be complied with. All statements in this document refer to the device the SELV voltage of which is not grounded.

The connections may only be supplied with the signals indicated in the technical data and/or on the device label and only the approved accessories of ifm may be connected.

2.4 Tampering with the device

In case of malfunctions or uncertainties please contact the manufacturer. Any tampering with the device can seriously affect the safety of operators and machinery. This is not permitted and leads to the exclusion of any liability and warranty claims.

2.5 Electromagnetic compatibility

This is a class A product. It can cause radio interference in domestic areas. In this case the operator is requested to take appropriate measures.

3 Functions and features

The PDM360 NG process and dialogue module is a programmable graphic display for controlling, parameter-setting and operation of mobile machines and plants.

Communication with other system components, e.g. decentralised I/O modules, is handled via a CAN interface using the CANopen protocol.

Ethernet and USB interfaces are also available for use during programing or for service tasks.

Together with the Linux operating system they form a universal platform for networking and communication with other CAN devices, networks or PCs.

The PDM360 NG process and dialogue module is not approved for any personnel related safety tasks.

The O2M20x camera allows for the monitoring of areas outside of the field of view in mobile machines and utility vehicles. The connection and the visualisation of the images are made via dialogue modules with graphics capabilities.

3.1 Application example



Connection of an O2M20x analogue camera to a PDM360 NG

- 1. PDM360 NG (e.g. CR1083)
- 2. Analogue camera (e.g. O2M20x)
- 3. Adapter cable (e.g. E2M200)
- 4. Connection cable (e.g. E2M203)



Connection of 2 O2M20x analogue cameras to a PDM360 NG

- 5. PDM360 NG (e.g. CR1083)
 6. Analogue camera (e.g. 2 x O2M20x)
 7. Y adapter cable (e.g. E2M201)
 8. Connection cable (e.g. 2 x E2M203)

7

Connection and installation

3.2 Connection and mounting accessories

You can find more information about the available accessories at: www.ifm.com \rightarrow New search \rightarrow Article number \rightarrow Accessories or

www.ifm.com \rightarrow Product line \rightarrow Connection technology

3.3 General electrical connection

Connection of the M12 connectors to the device:

www.ifm.com \rightarrow New search \rightarrow Article number \rightarrow Operating instructions \rightarrow Installation Instructions



- 1: Supply, input/output
- 2: CAN1
- 3: USB
- 4: Ethernet
- 5: N/A
- 6: N/A
- 7: Analogue video input
- 8: N/A
- 9: Connect GND on the Display dialogue module.

M12 connectors (back of the unit)

NOTE

Wrong connection may cause damage to the device.
▶ Observe the safety instructions (→ 2).

- Basically all supply and signal cables must be laid separately.
- Lay supply and signal cables away from the device using the shortest possible route.
- All connected cables must be provided with a strain relief.

3.3.1 Cover all unused connectors

NOTE

Moisture penetrating through unused or unprotected connectors may destroy the device.

Cover unused connectors with protective caps.

3.4 Ethernet interface

Use a shielded CAT5 cable.
 STP, shielded twisted pair, to EIA/TIA-568.
 Max. length 25 m



The max. cable length depends for example on the bus topology, the selected operating mode (10/100 Mbits/s) or the quality of the connectors.

- Use screened connector housings and connect the screen of the Ethernet cable to the connector housing.
- Do not lay the Ethernet cable in parallel to live cables.
 - Interference due to external influences Faulty or insufficient radio interference suppressors in other electrical equipment, such as inverters or generators, as well as voltage fluctuations when switching on/off electric loads may lead to problems with the data transmission.

3.5 Analogue video inputs

When using the analogue video inputs, please provide all connection cables with ferrite sleeves.
Decommondation: Impedance 224 O (100 MUT)

Recommendation: Impedance 321 Ω (100 MHz)



The ferrite sleeves ensure CE/E1 conformity and suppress conducted interference.

4 Set-up

4.1 General

As delivered the device is prepared for programming with CODESYS version 2.3 or higher.

Factory setting: IP address: 192.168.82.247 Subnet mask: 255.255.255.0



The user is responsible for the safe function of the application programs which he created himself. If necessary, he must obtain an approval from the corresponding supervisory and test organisations according to the national regulations.

4.2 Getting started

- ► Connect the device to the notebook/PC via the Ethernet interface.
- Switch on the notebook/PC; check the IP settings of the notebook/PC and change them if necessary.

Internet protocol: TCP/IP IP address: 192.168.82.xxx (except for .247, s.a.) Subnet mask: 255.255.255.0 Gateway IP address: 192.168.100.1

- Switch on the operating voltage to the dialogue module.
- Shortly after switch-on of the unit the start image is shown for approx. 10 to 15 seconds.
 During this time booting is running in the background.

After booting the set-up program opens automatically.

4.3 Set-up

The set-up allows the setting of the device parameters.

The menu items are selected using the function keys or via a connected USB keyboard.

Function	USB keyboard	Meaning
SELECT TAB		Select menu item
SAVE	F3	Save entries
UP	Arrow up	Increase value or variable
DOWN	Arrow down	Decrease value or variable
ENTER	ENTER	Open selected menu item
EXIT	ESC	Leave set-up Leave menu item Entries will not be saved

After leaving the set-up a project can be loaded.

Libraries (.lib) are available for the use of the operating elements, interfaces and other internal functions of the device. They have to be integrated into the application program.

4.4 Required documentation

In addition to the CODESYS programming system, the following documents are required for programming and set-up of the device:

- Programming manual CODESYS V2.3 (alternatively as online help)
- PDM360 NG system manual (alternatively as online help)
- Operating instructions for the robust O2M20x camera system

The manuals can be downloaded from the internet: www.ifm.com \rightarrow Data sheet search \rightarrow e.g. CR1083 \rightarrow More information

CODESYS and PDM360 NG online help: www.ifm.com \rightarrow Service \rightarrow Download \rightarrow Control systems*

*) Download area with registration

5 Operation of analogue camera(s) on the PDM

5.1 Configure the camera bitmap in the dialogue [Bitmap Configuration]

The terms which are used in the dialogue [Bitmap Configuration] have another meaning when used for the camera configuration.

Category	Field	Value / variable	Example
Text	Content	Camera input	Camera0: video signal FBAS1 Camera1: video signal FBAS2 (Note capital / small letters!)
Variables	Conversion base	Boolean type variable (input)	NOT for the analogue camera in the overlay mode (\rightarrow 5.3): TRUE: Mirror the image at its
			FALSE: Do not mirror the image *)
Variables	Change color	Boolean type variable (input)	TRUE: Represent the analogue camera image in the overlay mode
			FALSE: Represent the analogue camera image in the capture mode
Motion absolute	Angle	INT type variable (input)	NOT for the analogue camera in the overlay mode (\rightarrow 5.3):
			Rotate the camera image by 0° *), 90°, 180° or 270°. Other values are not supported.

Overview:

*) Status which also applies to a non-defined variable (= set as default).

5.2 Features of analogue cameras

Example O2M20x:

System standard	Number of image lines	Number of image columns	Aspect ratio
PAL	720	576	5:4
NTSC	720	480	3:2

5.3 Display modes

- Capture mode
- Overlay mode

Differences of the representation modes:

Capture mode	Overlay mode
The image can only be represented as a whole (Image 1: Original camera image, page 13).	The image section can be represented up to max. 100 % of the original image.
	The centre of the image section is identical with the centre of the original image (Image 1: Original camera image, page 13).
Any scaling of the image is possible (Image 2: Images scaled in width or height, page 13).	The image cannot be scaled.
Any scaling of the aspect ratio is possible The image representation may be distorted	The image is represented in the original aspect ratio.
Low image repetition rate Reason: long processing time!	High image repetition rate
Define the representation mode:	Define the representation mode:
 Set the field [Change color] in the category "Variables" to FALSE. 	 Set the field [Change color] in the category [Variables] to TRUE.

As from firmware version 01.03.00: The representation mode can be changed in the course of the program.



Position the camera image only in the visible area of the display (800 x 480 pixels)! Positions outside the visible area will be ignored.



Image 1: Original camera image

5.4 Capture mode



The original image can only be scaled in any manner as full-size image, also asymmetrically.

Image 2: Images scaled in width and height



UK

Width was scaled

Height was scaled

5.5 Overlay mode

ນີ

The image cannot be scaled.

The centre of the image section is identical with the centre of the original image.

Image 3: Image sections of the original camera image



In images 3 a) and b) the marking of the centre shows clearly that scaling always means cropping the image sides. Cropping does not generate scaling!

Information about the subject "Scaling an image" or "Creation of an image section" (\rightarrow 5.6.2 Set scaling / image section size and image position).

5.6 Configure analogue camera image

- ► Start CODESYS.
- ► Create or open project.

5.6.1 Create bitmap for camera image

- U ×
▼
<u> </u>
-
OV READ



The file "camera.bmp" is any substitutional image to insert and configure the camera image in a visualisation.



Enter "Camera0" for the signal FBAS1 (video1). Enter "Camera1" for the signal FBAS2 (video2).

Note capital / small letters!

ฏ

5.6.2 Set scaling / image section size and image position

Depending on the Boolean variable, scaling or the dimensions are defined by entering the width and height in the field "Change color" (\rightarrow 5.1 Configure the camera bitmap in the dialogue [Bitmap Configuration]).





The values "X:" and "Y:" define the position of the upper left corner of the image on the screen raster.

Recommended image resolution (PAL): width = 360, height = 288.

Maximum image resolution (PAL): width = 720, height = 576.



If both types of representation are needed in one project, it is necessary to create a bitmap for each mode (capture / overlay mode) (\rightarrow 5.6.1 Create bitmap for camera image)

5.6.3 Mirroring the camera image

ſ	0	٦
L	ก	
ι	25	

<u>í</u>

The function "Mirror the image of the camera at its vertical axis" is only allowed in the capture mode.

 Dialogue "Bitmap Configuration". 	Bitmap Configuration (#0) Category:	×
 Select the category "Variables" (1.). 	Bitmap Text Text variables Colorvariables Line with 1	OK Cancel
 Enter a Boolean type variable in the field "Conversion base" (2.) (in this example the variable: PLC_PRG. mirror). (→ 5.1 Configure the camera bitmap in the dialogue [Bitmap Configuration]) 	Motion relative disable: Motion relative Change color: Input Text for tooltip Security Programmability Conversion PLC_PRG.mirror Conversion Factor: Tooltip- display:	
 Click on [OK]. 		

5.6.4 Rotate the camera image

The camera image can be rotated by the angle values 0, 90, 180 or 270. Other values are not permitted.

This function is only permitted in the capture mode.

 Dialogue "Bitmap Configuration". 	Bitmap Configuration (#0) Calegory:	×
 Select the category "Motion absolute" (1.). 	Bitmap Text Text variables 1. Line width	OK Cancel
 Enter a variable of type INT in the field "Angle" (2.) (in this example the variable: PLC_PRG. camangle). Click on [OK]. 	Motion absolute Motion relative Variables Input Text for tooltip Security Programmability	

6 Note on the use of analogue camera images in CODESYS

!

Note:

Only one camera image can be displayed at a time.

The cameras are automatically switched off before each change of image. If the cameras are needed on the new camera image, the user must explicitly activate them.

Only the visible area of the display (800 x 480 pixels) can be used for the camera image. Positions outside this area (in the non-visible area) are ignored.

7 Execute program

When the program and the respective visualisation for the representation of the analogue camera image have been created, take the following steps:

PDM360 NG:

- Select the menu "LOAD APPLICATION" at the PDM360NG process and dialogue module.
- > The screen of the PDM360 NG turns white.

CODESYS:

- Select "Project" in the menu bar.
- Select "Clean all".
- Select "Rebuild all".
- > The program is rebuilt.
- Click on [Login].
- Acknowledge all system questions.
- ► Click on [Start].
- > Project starts on PMD360 NG.
- ► Create boot project.

8 Check activity of the camera

The process and dialogue module PDM360 NG shows at a glance if the camera is active. If it is active, the live ticker (1.) rotates in the camera image at the top right.



In particular in static scenes it can be quickly checked with the live ticker if the camera is active and functions.

9 Provide camera error messages

If any errors occur when external cameras are used, the system automatically generates error messages. They help to diagnose the cause(s) of the error.

The following settings have to be made to visualise the error messages:

- ► Declare a global variable of type STRING in CODESYS, e.g. ErrorMessage.
- Select the visualisation object that contains the camera bitmap in the tab [Visualization].
- > The visualisation object of the camera is displayed.
- ► Right-click on the camera bitmap.
- > The context menu appears.
- ► Select the sub-menu [Configure].
- > "Bitmap configuration..." appears.

Select [Variables] (1.).	Bitmap Configuration (#0)	×
 Enter the name of the STRING variable in the field [Tooltip display] (2.) (in this example: PLC_PRG. ErrorMessage). Click on [OK]. 	Category: Bitmap Text variables Text variables Colorvariables Input Motion relative Variables Input Motion relative Variables Input Change color: Text for tooltip Security Programmability Conversion Factor: Tooltip- Golip- Golip- Tooltip- Security Programmability Programmability	OK Cancel

9.1 Error messages

Error message	Camera type	Possible cause	Measure
invalid target area	Analogue	The camera image is not completely in the visible area of the display	Check the settings of the camera $(\rightarrow 5.6.1$ Create bitmap for camera image).
invalid rotation angle	Analogue	The indicated angle of rotation is invalid	Check the settings of the camera. Valid angles: 0° , 90° , 180° and 270° (\rightarrow 5.6.4 Rotate the camera image).
framebuffer or plane can't be used exclusively	Analogue	During set-up of the analogue camera an Ethernet camera is already running in the overlay mode (the analogue camera is not switched on)	Set the Boolean variable for switching the analogue camera on and off to FALSE