


ifm electronic



Operating Instructions
IO-Link Master with EtherNet/IP interface
StandardLine
4 Ports
IP 65 / IP 67

AL1120

ifm firmware: 1.1.22 or higher
LR DEVICE: 1.1.0.87 or higher
IO-Link: 1.1.2

English

Contents

1	Preliminary note	5
1.1	Legal and copyright information	6
1.2	Purpose of the document	6
1.3	Symbols and styles used	6
1.4	Modification history	7
2	Safety instructions	8
2.1	General	9
2.2	Required background knowledge	9
2.3	Warnings used	9
2.4	Safety symbols on the device	10
2.5	Tampering with the unit	10
3	Functions and features	11
3.1	Permitted use	11
3.2	Prohibited use	11
4	Function	12
4.1	Communication, parameter setting, evaluation	13
4.1.1	IO-Link	14
4.1.2	EtherNet/IP	14
4.1.3	Parameter setting	14
4.1.4	Visual indication	14
4.2	Digital inputs	15
4.3	IO-Link supply	15
5	Mounting	16
5.1	Mount the device	16
6	Electrical connection	17
6.1	Ethernet ports	18
6.2	IO-Link ports	19
6.2.1	Input circuit	19
6.2.2	IO-Link circuits	20
6.3	Connect the device	21
7	Operating and display elements	22
7.1	Overview	23
7.2	LED indicators	24
7.2.1	Status LEDs	24
7.2.2	Ethernet interface	24
7.2.3	Voltage supply	25
7.2.4	IO-Link ports (Class A)	25

8	Configuration	26
8.1	Remarks	27
8.1.1	Supported configuration options	28
8.1.2	Connection possibilities	28
8.1.3	Offline parameter setting	31
8.1.4	VPN connection	31
8.2	LR DEVICE: Configure the device	32
8.2.1	Configure the Ethernet interface	33
8.2.2	Configure communication profile	34
8.2.3	Configure the interface to the SmartObserver	35
8.2.4	Set the operating mode of the IO-Link ports	36
8.2.5	Set device validation and data storage	37
8.2.6	Reset IO-Link master to factory settings	39
8.3	LR DEVICE: Configure IO-Link devices	40
8.3.1	Offline parameter setting: Add IO-Link devices manually	41
8.4	EtherNet/IP: Configure the device	42
8.4.1	Registration of the EDS file	43
8.4.2	Integrate the AL1120 into the EtherNet/IP network	43
8.4.3	Configure AL1120	44
8.4.4	Configure IO-Link ports	45
8.5	EtherNet/IP: Configure IO-Link devices	47
8.6	EtherNet/IP: Programmers' notes	47
8.6.1	Read cyclic input data	48
8.6.2	Write cyclic output data	48
8.6.3	Execute acyclic commands	49
8.6.4	Read diagnostic and status information	51
9	Operation	52
9.1	Read device information	53
9.1.1	Web interface: Read device and diagnostic information	54
9.1.2	LR DEVICE: Read device information	55
9.1.3	EtherNet/IP: Read device information	55
9.2	Reboot the device	56
9.3	Error detection and elimination	56
9.4	Firmware update	57
9.5	Exchange IO-Link device	58
10	Maintenance	59
11	Factory Settings	60
12	Appendix	61
12.1	Technical data	62
12.1.1	Application	63
12.1.2	Electrical data	63
12.1.3	Inputs / outputs	63
12.1.4	Inputs	63
12.1.5	Outputs	63
12.1.6	Interfaces	64
12.1.7	Operating conditions	64
12.1.8	Approvals / tests	64
12.1.9	Mechanical data	65
12.1.10	Electrical connection	65

Content

12.2	EtherNet/IP.....	66
12.2.1	Parameter data.....	67
12.2.2	Cyclic data.....	71
12.2.3	Acyclic data.....	77
13	Index	108
14	ifm weltweit • ifm worldwide • ifm à l'échelle internationale	111

1 Preliminary note

Contents

Legal and copyright information	6
Purpose of the document	6
Symbols and styles used	6
Modification history	7

14801

1.1 Legal and copyright information

1631

© All rights reserved by **ifm electronic gmbh**. No part of this manual may be reproduced and used without the consent of **ifm electronic gmbh**.

All product names, pictures, companies or other brands used on our pages are the property of the respective rights owners:

- AS-i is the property of the AS-International Association, (→ www.as-interface.net)
- CAN is the property of the CiA (CAN in Automation e.V.), Germany (→ www.can-cia.org)
- CODESYS™ is the property of the 3S – Smart Software Solutions GmbH, Germany (→ www.codesys.com)
- DeviceNet™ is the property of the ODVA™ (Open DeviceNet Vendor Association), USA (→ www.odva.org)
- EtherNet/IP® is the property of the →ODVA™
- EtherCAT® is a registered trade mark and patented technology, licensed by Beckhoff Automation GmbH, Germany
- IO-Link® (→ www.io-link.com) is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- ISOBUS is the property of the AEF – Agricultural Industry Electronics Foundation e.V., Deutschland (→ www.aef-online.org)
- Microsoft® is the property of the Microsoft Corporation, USA (→ www.microsoft.com)
- PROFIBUS® is the property of the PROFIBUS Nutzerorganisation e.V., Germany (→ www.profibus.com)
- PROFINET® is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- Windows® is the property of the →Microsoft Corporation, USA

1.2 Purpose of the document

22044

This document is only for device types "IO-Link master - EtherNet/IP gateway (StandardLine) 4 port IP 65 / IP 67" (art. no.: AL1120).

It is part of the device and contains information about the correct handling of the product.

- Read this document before using the device.
- Keep this document during the service life of the device.

1.3 Symbols and styles used

13839

...	Instructions
> ...	Reaction, result
→ ...	Cross-reference or internet link
123	Decimal number
0x123	Hexadecimal number
0b010	Binary number
[...]	Designation of pushbuttons, buttons or indications

1.4 Modification history

21676

Version	Topic	Date
00	New creation of document	30.05.2017

2 Safety instructions

Contents	
General	9
Required background knowledge	9
Warnings used	9
Safety symbols on the device	10
Tampering with the unit	10

2.1 General

22068



The plant manufacturer is responsible for the safety of the plant in which the device is installed.

If the device is used in a way that is not intended by the manufacturer, the protection supported by the device may be impaired.

Non-observance of the instructions, operation which is not in accordance with use as prescribed below, wrong installation or incorrect handling can affect the safety of operators and machinery.

- ▶ Observe these operating instructions.
- ▶ Adhere to the warning notes on the product.

2.2 Required background knowledge

22046

This document is intended for specialists. Specialists are people who, based on their relevant training and experience, are capable of identifying risks and avoiding potential hazards that may be caused during operation or maintenance of the product.

The document contains information about the correct handling of the product.

2.3 Warnings used

13685



WARNING

Designation of pushbuttons, buttons or indications



CAUTION

Slight reversible injuries may result.

NOTICE

Property damage is to be expected or may result.



Important note
Non-compliance may result in malfunction or interference.



Information
Supplementary note.

2.4 Safety symbols on the device

15021



General warning

When this symbol is shown, consult the corresponding section in the operating instructions.

2.5 Tampering with the unit

11242



WARNING

Tampering with the units can affect the safety of operators and machinery!

Tampering with the units is not allowed.

In case of non-compliance our liability and warranty expire.

- ▶ Do not open the devices!
- ▶ Do not insert any objects into the devices!
- ▶ Prevent metal foreign bodies from penetrating!

3 Functions and features

Contents

Permitted use	11
Prohibited use.....	11

18761

3.1 Permitted use

22052

The device has been designed for use without a control cabinet in plant construction.

3.2 Prohibited use

22053

The device may not be used beyond the limits of the technical data (→ **Technical data** (→ p. [62](#)))!

4 Function

Contents

Communication, parameter setting, evaluation	13
Digital inputs	15
IO-Link supply.....	15

7482

4.1 Communication, parameter setting, evaluation

Contents	
IO-Link	14
EtherNet/IP	14
Parameter setting	14
Visual indication.....	14

7485

4.1.1 IO-Link

7773

The device offers the following IO-Link functions:

- IO-Link master for connection of up to 4 IO-Link devices (sensors, actuators) according to IO-Link standard 1.0 and 1.1.
- Provision of process data of the connected IO-Link devices for LR SmartObserver monitoring software (→ www.ifm-datalink.com)

4.1.2 EtherNet/IP

2259

The device offers the following EtherNet/IP functions:

- Provision of the functions of a EtherNet/IP Device
- 2 port switch for access to the EtherNet/IP interface (X21/X22)
- Gateway for transmission of the process and parameter data between the connected IO-Link devices and the higher-level EtherNet/IP controller

4.1.3 Parameter setting

7771

The device provides the following configuration options:

- Parameter setting of the IO-Link master of the AL1120 with parameter setting software LR DEVICE and/or EtherNet/IP projection software
- Parameter setting of the connected IO-Link devices (sensors, actuators) with parameter setting software LR DEVICE and/or EtherNet/IP projection software
- Storage of parameter sets of the connected IO-Link devices for automatic recovery (data storage)

4.1.4 Visual indication

7772

The device has the following visual indicators:

- Status and error indication of the gateway, of the EtherNet/IP connection and of the system
- Status display of the voltage supply
- Status and activity display of the Ethernet connection
- Status, error and short circuit/overload indication of the IO-Link ports

4.2 Digital inputs

7584

The device has 4 digital inputs (type 2 according to EN 61131-2).

The digital inputs are on pin 2 of the IO-Link ports X01 ... X04.

All inputs refer to the potential of the device supply (pin 3).

4.3 IO-Link supply

7623

The device has 4 supplies for IO-Link devices (sensors, actuators).

The IO-Link ports X01...X04 are ports class A.

Every supply provides short circuit monitoring.

The device ensures fire protection for the connected IO-Link devices by providing a power-restricted circuit at the IO-Link ports (according to IEC61010-1).

5 Mounting

Contents

Mount the device	16
------------------------	----

22016

5.1 Mount the device

15540



- ▶ Disconnect the system from power before installation.
 - ▶ For installation choose a flat mounting surface.
 - ▶ Please observe the maximum tightening torque.
-
- ▶ Fix the unit to the mounting surface using 2 M5 mounting screws and washers.
 - Tightening torque: 1.8 Nm
 - ▶ Ground the unit via the two mounting screws of the upper mounting lugs.

6 Electrical connection

Contents

Ethernet ports	18
IO-Link ports	19
Connect the device	21

22017



A qualified electrician must connect the unit.

- Observe the national and international regulations for the installation of electrical equipment.

Device is only suitable for operation on SELV/PELV voltages.

- Observe the information concerning IO-Link circuits (→ **IO-Link circuits** (→ p. 20))!

The device contains components that can be damaged or destroyed by electrostatic discharge (ESD).

- Observe the required safety measures against electrostatic discharge!

The IP rating depends on the individual protection ratings of the unit, the applied connection elements and the corresponding protective covers.

- For UL applications: For connecting the device and the IO-Link devices use UL certificated cables of category CYJV or PVVA.


Wiring: → **Electrical connection** (→ p. 65)

6.1 Ethernet ports

22683




Notes on connection possibilities: → **Connection possibilities** (→ p. [28](#))



- ▶ Connect the unit via the M12 socket X21 and/or X22 with the EtherNet/IP network (e.g. EtherNet/IP PLC, additional EtherNet/IP device)
 - Tightening torque: 0.6...0.8 Nm
- ▶ Connect the unit via the M12 socket X21 and/or X22 to the industrial Ethernet network (e.g. laptop/PC with installed parameter setting software LR DEVICE, laptop/PC with installed monitoring software LR SmartObserver)
 - Tightening torque: 0.6...0.8 Nm
- ▶ For the connection, use M12 connectors with protection rating IP 65 / IP 67 or higher (e.g. E12492).
- ▶ Cover the unused sockets with M12 protective caps (art. no.: E73004).
 - Tightening torque 0.6...0.8 Nm

6.2 IO-Link ports

22684



Ports X01...X04: For use as IO-Link port class A:

- ▶ Connect the connector of the IO-Link devices with the M12 sockets X01 ... X04.
 - Tightening torque: 0.6...0.8 Nm
 - Maximum cable length per IO-Link interface: 20 m
- ▶ For the connection, use M12 connectors with protection rating IP 65 / IP 67 or higher (e.g. EVC493).

Ports X01...X04: For use as IO-Link port class B:

- ▶ Connect the connector of the IO-Link devices via the adapter with the M12 sockets X01 ... X04.
 - Tightening torque: 0.6...0.8 Nm
- ▶ To connect the devices, use M12 connectors with protection rating IP 65 / IP 67 or higher (e.g. EVC693).
- ▶ Cover the unused sockets with M12 protective caps (art. no.: E73004).
 - Tightening torque 0.6...0.8 Nm

6.2.1 Input circuit

18629

The inputs of the M12 sockets 4 (pin 2) provide a type 2 behaviour according to standard EN61131-2, the connected electronics must be rated for this electrically.

6.2.2 IO-Link circuits

11616

The IO-Link interfaces of the device meet the requirements of the IO-Link specification 1.0 to 1.1.2.



The connected IO-Link devices may only be supplied via the AL1120.

Exception: Connection of IO-Link devices to ports X01...X04 via suitable connection technology for port class B operation (→ **IO-Link ports** (→ p. [19](#))):

The external supply for port class B operation must be galvanically separated from the circuit of the AL1120 by assuring basic isolation (according to EN61010-1, secondary circuit with maximum 30 V DC derived from applied voltage up to 300 V of overvoltage category II)!

The isolation must be done both for IO-Link devices and for the connection technology.

NOTICE

Risk of material damage


If the requirements of galvanic separation of the circuits are not observed, the fire protection of the device can not be assured.

- Observe the requirements of the electrical connection of IO-Link devices for port class B operation!

Further information: → **Technical data** (→ p. [62](#))

6.3 Connect the device

2580



- ▶ Disconnect power.
- ▶ Connect the device via M12 socket X31 to 24 V DC (20...30 V SELV/PELV; according to EN61010-1, secondary circuit with maximum 30 V DC derived from applied voltage up to 300 V of overvoltage category II).
 - Tightening torque: 0.6...0.8 Nm
 - Maximum cable length: 25 m
- ▶ To connect the device, use M12 connectors with protection rating IP 65 / IP 67 or higher (e.g. EVC708).

If the port X01...X04 will be used as IO-Link ports Class B:

- ▶ Connect adapter for Port Class B operation to 24 V DC (20...30 V SELV/PELV) (→ **IO-Link ports** (→ p. [19](#)))

7 Operating and display elements


Contents

Overview	23
LED indicators	24

5440

7.1 Overview

22025



- ① Status LEDs RDY, NET und MOD
→ **Status LEDs** (→ p. [24](#))
- ② Status LEDs LNK and ACT of the EtherNet/IP ports 1 (X21) and 2 (X22)
→ **Ethernet interface** (→ p. [24](#))
- ③ Status LED US of the power supply (X31)
→ **Voltage supply** (→ p. [25](#))
- ④ Status LEDs IOL and DI of the IO-Link ports Class A (X01...X04)
→ **IO-Link ports (Class A)** (→ p. [25](#))

7.2 LED indicators

22024

The device only has the following LED indicators:

7.2.1 Status LEDs

7707

The RDY LED indicates the status of the gateway.

The NET LED (Network Status) indicates the status of the network.

The MOD LED (Module Status) indicates the status of the EtherNet/IP module.

Status LED			Description
RDY	green	on	Gateway functions properly
		flashes 1 Hz	Error
		flashes 5 Hz	Firmware update
		off	Gateway does not function; Device reboots
NET	green	on	Connection with the EtherNet/IP PLC
		off	No IP address
	red	on	IP address is used twice
		flashes	No connection with the EtherNet/IP PLC
MOD	green	on	No error
		off	Voltage too low
	red	on	Module failed
		flashes	Configuration of the module has been changed

7.2.2 Ethernet interface

22027

Each Ethernet interface (X21, X22) has 2 LEDs (LNK and ACT). The LEDs indicate the status of the Ethernet connection.

Status LED			Description
LNK	green	on	Ethernet connection established
		off	No Ethernet connection
ACT	yellow	flashes	Data is transmitted via the Ethernet interface.
		off	No data transmission

7.2.3 Voltage supply

22026

The interface for voltage supply (X31) has the LED that is marked as US. The LED indicates the status of the voltage supply.

Status LED			Description
US	green	on	The supply voltage Us is applied.
		off	No supply voltage is applied or the applied supply voltage is too low.

7.2.4 IO-Link ports (Class A)

22029

Each IO-Link port Class A (X01 ... X04) has 2 LEDs marked as IOL and DI. The LEDs indicate the status of the IO-Link port.

Status LED			Description
IOL	yellow	on	Interface configured as DI/DO: Pin 4 (C/Q) =ON
		off	Interface configured as DI/DO: Pin 4 (C/Q) = OFF
	green	on	IO-Link transmission functions properly
		flashes 1 Hz	Interface configured as IO-Link, but no IO-Link transmission
	red	on	Short circuit or overload in supply voltage
		flashes 1 Hz	Transmission error
DI	yellow	on	Digital input: Pin 2 (DI) = ON
		off	Digital input : Pin 2 (DI) = OFF

8 Configuration

Contents

Remarks	27
LR DEVICE: Configure the device	32
LR DEVICE: Configure IO-Link devices	40
EtherNet/IP: Configure the device	42
EtherNet/IP: Configure IO-Link devices	47
EtherNet/IP: Programmers' notes.....	47

22367

8.1 Remarks

Contents	
Supported configuration options.....	28
Connection possibilities.....	28
Offline parameter setting	31
VPN connection.....	31

22369

8.1.1 Supported configuration options

1989

The AL1120 can be configured using the following options:

- Parameter setting software LR DEVICE (version 1.1.0.87 or higher) (art. no.: QA0011/QA0012)
- EtherNet/IP projection software

8.1.2 Connection possibilities

12742

Via the two EtherNet/IP interfaces X21 and X22, the AL1120 can be simultaneously connected with the EtherNet/IP control level (PLC) and the IT infrastructure level (monitoring/parameter setting). The following connection possibilities exist:

Operation without EtherNet/IP connection

4364

Operation as independent IO-Link master with connected IO-Link devices. As an option, several IO-Link masters can be coupled via the EtherNet/IP interfaces. If necessary, the IO-Link masters can be coupled with the IT infrastructure via industrial Ethernet in order to enable monitoring of the process data of the connected IO-Link devices.

Parameter setting

- IO-Link master: LR DEVICE
- IO-Link device: LR DEVICE


Monitoring (optional):

LR SmartObserver

Topology (example):

 LINERECORDER DEVICE

 SMARTOBSERVER



Operation with EtherNet/IP connection (without LR DEVICE)

7396

Operation of the IO master as EtherNet/IP IO device. As an option, several IO-Link masters can be coupled via the Ethernet interfaces X21 and X22. The complete monitoring of the process data and processing of alarms takes place via EtherNet/IP mechanisms.

Parameter setting


- IO-Link master: EtherNet/IP projection software
- IO-Link device: EtherNet/IP projection software (acyclic services)

Monitoring:

EtherNet/IP projection software

Topology (example):

Feldbus



Operation with EtherNet/IP connection and LR DEVICE/LR SmartObserver

7398

The AL1120 can be connected via the two Ethernet interfaces X21 and X22 simultaneously with the EtherNet/IP control level (PLC) and the IT infrastructure level (monitoring/parameter setting).


Parameter setting

- IO-Link master: LR DEVICE and/or EtherNet/IP projection software
- IO-Link device: LR DEVICE and/or EtherNet/IP projection software

Monitoring:

LR SmartObserver and/or EtherNet/IP projection software

Topology (example):



8.1.3 Offline parameter setting

SYS_OBJECTID>

The AL1120 supports the offline parameter setting. In this context, the user creates and stores a configuration for the unit and the connected IO-Link devices without being connected to the AL1120. The configuration created in this way can be stored as a file (*.lrp) and loaded to the device and activated at a later date.



Further information about offline parameter setting: → Operating instructions of the parameter setting software LR DEVICE

8.1.4 VPN connection

22762



An active VPN connection blocks the access of the parameter setting software LR DEVICE to the EtherNet/IP interface of the AL1120.

- Deactivate the VPN connection in order to be able to access the AL1120 with the LR DEVICE.

8.2 LR DEVICE: Configure the device

Contents

Configure the Ethernet interface	33
Configure communication profile	34
Configure the interface to the SmartObserver	35
Set the operating mode of the IO-Link ports	36
Set device validation and data storage	37
Reset IO-Link master to factory settings	39

7948

On delivery, the AL1120 is configured with the → **Factory Settings** (→ p. 60) configured.



Further information about operation and functions of the LR DEVICE parameter setting software:

- Use the help function of the parameter setting software LR DEVICE!

Requirements

- > The device is properly connected with the LR DEVICE laptop/PC via the EtherNet/IP interface.
- > LR DEVICE is correctly installed (→ Software manual LR DEVICE).

1 Start LR DEVICE.

- Start LR DEVICE.
- > Web browser shows LR DEVICE user interface.

2 Scan network

- Scan network for new IO-Link masters.
- > Under [ONLINE], the article number and the IP address of the device appear.

3 Set network parameters

- Under [ONLINE]: Click on the AL1120.
- > LR DEVICE shows the following sections:

Section	Functions
[Alle]	all available functions
[Network]	→ Configure the Ethernet interface (→ p. 33)
[LineRecorder]	→ Configure communication profile (→ p. 34) → Configure the interface to the SmartObserver (→ p. 35)
[Port x]*	→ Set the operating mode of the IO-Link ports (→ p. 36) → Set device validation and data storage (→ p. 37)
[Setup]	→ LR DEVICE: Read device information (→ p. 55) → Reset IO-Link master to factory settings (→ p. 39) → Reboot the device (→ p. 56)

* ... x = 1...4

8.2.1 Configure the Ethernet interface

8000

To set the parameters of the Ethernet interface (X21/X22):

- Select the [Network] menu.
- The page shows the current settings.
- Set the following parameters as required:

Name	Description	Possible values
[IP address]	IP address of the device	e.g. 172.18.65.50
[Subnet mask]	Subnet mask of the IP network	e.g. 255.255.255.0
[IP gateway address]	IP address of the gateway	e.g. 172.18.65.1
[Host name]	Name of the device in the EtherNet/IP network	e.g. al1xxx
[MAC address]	MAC address of the device	The value is fixed

- Store changed values on the device.

8.2.2 Configure communication profile

22061

In order to copy the access rights to the device:

- ▶ Select the [LineRecorder] menu.
- > The page shows the current settings.
- ▶ Set the following parameter as required:

Parameter	Description	Possible values	
[Communication Profile]	Access rights to the parameter data, process data and event/diagnostic messages of the IO-Link master and the connected IO-Link devices	EtherNet/IP + LineRecorder	▪ EtherNet/IP and LR DEVICE have read and write access rights to parameters and process data ▪ EtherNet/IP and LR DEVICE have read access rights to events/alarms
		EtherNet/IP + LineRecorder (ro)	▪ EtherNet/IP has read and write access rights to parameters and process data ▪ EtherNet/IP has read access rights to events/alarms ▪ LR DEVICE only has read access rights to parameters, process data and events/alarms
		LineRecorder only	▪ LR DEVICE has read and write access rights to parameters and process data ▪ LR DEVICE has read access rights to events/alarms ▪ EtherNet/IP has no access rights
		keep setting	Previous settings are valid

- ▶ Store changed values on the device.



If parameter [Communication Profile] = EtherNet/IP + LineRecorder:

Different parameter settings in the EtherNet/IP projection software and the LR DEVICE may cause undesired system behaviour. Parameter settings applied by the EtherNet/IP projection software always overrule the settings applied by LR DEVICE.



Changes of the parameter [Access Rights] are only effective after restarting the device.

To activate the changed access rights:

- ▶ → **Reboot the device** (→ p. 56)

8.2.3 Configure the interface to the SmartObserver

12743

In order to set the parameters of the interface to the SmartObserver:

- ▶ Select the [LineRecorder] menu.
- > The page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[IP address SmartObserver]	IP address of the laptop/PC where the SmartObserver is installed	e.g. 192.168.0.100	
[Port SmartObserver]	Port address that is used to send process data to the SmartObserver	1 ... 65535	Default value: 35100
[Source ID SmartObserver]	Source identifier with which the process data of the device is indicated in the SmartObserver (String32)		
[Port x. LR events]	Operating mode of the IO-Link port (x = 1...4)	Disabled	Cyclic transfer of the process data
		Enabled	Event-based transfer of the process data
[Port x. LR cycle time (ms)]*	Cycle time of the IO-Link interface for cyclic transmission of the process data between the IO-Link master and the SmartObserver (x = 1...4)	Disabled	no data transmission
		1000 ... 60000	1000 ms ... 60000 ms

* ... parameter only valid if parameter [PortX. LR events] = Disabled



After changing the parameter [Port SmartObserver] or [Source ID SmartObserver], it can take 120 seconds before the device establishes a new TCP connection.

To prevent the delay:

- ▶ Reboot the device after the parameter change.
- ▶ Store changed values on the device.

8.2.4 Set the operating mode of the IO-Link ports

8714

The IO-Link ports X01...X04 of the device support the following operating types:

- Digital input (DI): binary input signal on pin 4 (C/Q) of the IO-Link port
- Digital output (DO): binary output signal on pin 4 (C/Q) of the IO-Link port
- IO-Link interface (IO-Link): IO-Link data transfer via pin 4 (C/Q) of the IO-Link port

The user can set the operating mode of each IO-Link port separately at any time.

- ▶ Select [Port x] menu.
- > The page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Port x mode]	Operating mode of the IO-Link port (x = 1...4)	IO-Link	Operation as IO-Link interface
		DI	Operation as digital input
		DO	Operation as digital output
		Disabled	Interface deactivated
[Port x IO-Link. Cycle time]*	Cycle time of the data transmission between the IO-Link master and the IO-Link device	As fast as possible	The device automatically sets the fastest possible cycle time
		2.0 ms	2 milliseconds
		... 128.0 ms	... 128 milliseconds

* ... Parameter only available, if [Port x mode] = IO-Link

- > Store the changed values on the AL1120.

8.2.5 Set device validation and data storage

7165

In operating mode "IO-Link" the user can set the behaviour of the IO-Link ports regarding device validation and backup/restore of parameter data of the connected IO-Link devices.

To configure the device validation and data storage settings:

- ▶ Select [Port x] menu.
- > The page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Port x IO-Link Validation / Data Storage]	Supported IO-Link standard and behaviour of the device when a new IO-Link device is connected to IO-Link port x (x = 1...4)	No check and clear	▪ No verification of the vendor ID and device ID ▪ No data storage
		Type compatible V1.0 device	▪ IO-Link device is compatible with the V1.0 IO-Link standard ▪ Verification whether it is an IO-Link device of the same type (validation via vendor ID and device ID) ▪ No data storage
		Type compatible V1.1 device	▪ IO-Link device is compatible with the V1.1 IO-Link standard ▪ Verification whether it is an IO-Link device of the same type (validation via vendor ID and device ID) ▪ no data storage
		Type compatible V1.1 device with Backup + Restore	▪ IO-Link device is compatible with the V1.1 IO-Link standard ▪ Verification whether it is an IO-Link device of the same type (validation via vendor ID and device ID) ▪ The IO-Link master saves the parameter values of the connected IO-Link device; modifications of the parameter values are also stored (observe the note!) ▪ When connecting an IO-Link device with factory settings, the parameter values stored in the IO-Link master are restored automatically on the IO-Link device.

Configuration

Name	Description	Possible values	
		Type compatible V1.1 device with Restore	- IO-Link device is compatible with the V1.1 IO-Link standard - Verification whether it is an IO-Link device of the same type (validation via vendor ID and device ID) - The IO-Link master saves the parameter values of the connected IO-Link device once. - When connecting an IO-Link device with factory settings, the parameter values stored in the IO-Link master are restored automatically on the IO-Link device.
[Port x IO-Link. Vendor ID]	ID of the manufacturer that is to be validated	0 ... 65535	ID of the manufacturer of the IO-Link device (ifm electronic: 310)
[Port x IO-Link. Device ID]	ID of the IO-Link device that is to be validated	0 ... 16777215	ID of the IO-Link device

- Store the changed values on the AL1120.

8.2.6 Reset IO-Link master to factory settings

12740

When resetting the AL1120, all parameters are reset to the → **Factory Settings** (→ p. [60](#))

To reset the device to factory settings:

- ▶ Select [Setup] menu.
- > The page shows the current settings.
- ▶ Click on [Factory Reset] to reset the AL1120.
- > LR DEVICE sets the AL1120 factory settings.

8.3 LR DEVICE: Configure IO-Link devices

22403

In order to configure the IO-Link devices connected to the AL1120 using the parameter setting software LR DEVICE:

Requirements:

- > AL1120 is correctly installed and connected to the LR DEVICE software via the EtherNet/IP interface (X21/X22).
- > The IO-Link device is connected correctly with the AL1120.
- > The operating mode of the IO-Link interface is "IO-Link" (parameter [Port x mode] = IO-Link)
- > Parameter [Access rights] is configured with one of the following values:
 - EtherNet/IP + LineRecorder
 - LineRecorder only


1 Select IO-Link master

- ▶ Start LR DEVICE.
- ▶ Update IODD file library
OR:
Import IODD file of the IO-Link device manually.
- ▶ Scan network for devices.
- > LR DEVICE recognises all IO-Link masters of the EtherNet/IP network.



2 Add IO-Link device

- ▶ Under [ONLINE]: Click on the required AL1120.
- > LR DEVICE automatically detects the IO-Link devices connected to the AL1120 (e.g. ifm Sensor KG5065).



3 Configure IO-Link device

- ▶ Mouse click on the port to which the IO-Link device is connected.
- > LR DEVICE reads and shows the current parameter values of the IO-Link device.
- ▶ Configure IO-Link device.



Information about the available parameters of the IO-Link device: → Operating instructions of the IO-Link device

- ▶ Store changed configuration on the IO-Link device.

8.3.1 Offline parameter setting: Add IO-Link devices manually

22817


The AL1120 supports the automatic recognition of IO-Link devices that are connected to the IO-Link interfaces. In addition to the automatic recognition of IO-Link devices in the online mode, the user can also manually add IO-Link devices to the device configuration (e.g. → **Offline parameter setting** (→ p. 31)).

1 Set up offline configuration

- ▶ Start LR DEVICE.
- ▶ Add AL1120 to an offline configuration.
- > LR DEVICE shows AL1120 in [OFFLINE] section.

2 Add IO-Link device to configuration.

- ▶ Under [OFFLINE]: Click on [AL1120].
- > LR DEVICE shows the available parameters of the AL1120.
- ▶ Click on the symbol at the required port.



- > The dialogue window [Gerät auswählen] appears.
- ▶ Select the required IO-link device from the list.
- ▶ Click on [OK] to add the selected IO-Link device to the device configuration.
- > IO-Link device appears at the selected port.

3 Configure IO-Link device

- ▶ Mouse click on the port to which the IO-Link device is connected.
- > LR DEVICE shows the available parameters of the IO-Link device.
- ▶ Configure IO-Link device.



Information about the available parameters of the IO-Link device: → Operating instructions of the IO-Link device

- ▶ Store changed configuration on the IO-Link device.
- ▶ Click on [AL1120].

8.4 EtherNet/IP: Configure the device

Contents

Registration of the EDS file	43
Integrate the AL1120 into the EtherNet/IP network.....	43
Configure AL1120.....	44
Configure IO-Link ports	45

1987

On the field bus side, the device can be configured with any EtherNet/IP compatible projection software.

The information in the following sections refers to the EtherNet/IP projection software RSLogix 5000.

8.4.1 Registration of the EDS file

1979

ifm provides an EDS file to integrate the AL1120 in a EtherNet/IP projection software. The user can download the EDS file from the ifm website (→ the EDS file, all parameters, process data, and their valid value ranges are defined).

To add the AL1120 to the device catalogue of RSLogix5000:

- ▶ Download the EDS file of the AL1120 from the ifm website.
- ▶ Start RSLogix5000.
- ▶ Select [Tools] > [EDS Hardware Installation Tool].
- > EDS Wizard appears.
- ▶ Register the downloaded EDS file of the AL1120 with the EDS Wizard.
- > EDS Wizard installs the EDS file and adds the AL1120 to the device catalogue.

8.4.2 Integrate the AL1120 into the EtherNet/IP network

8015

The device is integrated as module of an I/O scanner in the EtherNet/IP network.

Requirements:

- > The EDS file of the AL1120 is installed (→ **Registration of the EDS file** (→ p. 43)).

1 Create/open EtherNet/IP project

- ▶ Start RSLogix 5000.
- ▶ Create new EtherNet/IP project.
- OR
- ▶ Open an existing EtherNet/IP project.

2 Configure EtherNet/IP PLC and IO scanner

- ▶ Select and configure EtherNet/IP controller and IO scanner.
- > EtherNet/IP project includes a EtherNet/IP controller and an IO scanner.

3 Integrate AL1120 in project

- ▶ In the Controller Organizer: Right mouse click on the IO scanner.
- > Context menu appears.
- ▶ In the context menu: Select [New Module...].
- > The window [Select Module Type] appears.
- ▶ Select AL1120 and click on [Create].
- > The [New Module] window appears.
- ▶ Enter name and IP address of the AL1120.
- ▶ Click on [OK] to adopt the entered values.
- > RSLogix 5000 adds AL1120 as sub-element of the IO scanner to the project.

4 Save the project

- ▶ Save EtherNet/IP project

8.4.3 Configure AL1120

8019

The AL1120 is configured via the controller tags.

Requirements:

- > AL1120 is correctly integrated in the EtherNet/IP project (→ **Integrate the AL1120 into the EtherNet/IP network** (→ p. 43)).

1 Open controller tags

- ▶ In the Controller Organizer: Double click on [Controller Name_of_Project] > [Controller Tags]
- > [Controller Tags] window appears.
- ▶ In the tree view: Click on [AL1120:C].
- > Controller tags for the configuration of the device appear.

2 Configure AL1120

- ▶ Set the following controller tags as required:

Name	Description	Possible values	
[AL1120:C.Communication_Profile]	The access rights to the parameter data, process data and events/diagnostic messages of the IO-Link master and the connected IO-Link devices	0x00	<Feldbus> + LineRecorder ▪ EtherNet/IP and LR DEVICE have read and write access rights to parameters and process data ▪ EtherNet/IP and LR DEVICE have read access rights to events/alarms
		0x01	EtherNet/IP + LineRecorder (ro) ▪ EtherNet/IP has read and write access rights to parameters and process data ▪ EtherNet/IP has read access rights to events/alarms ▪ LR DEVICE only has read access rights to parameters, process data and events/alarms
		0x02	EtherNet/IP only ▪ EtherNet/IP has read and write access rights to parameters and process data ▪ EtherNet/IP has read access rights to events/alarms ▪ LR DEVICE has no access rights (parameters, process data, events/alarms, web interface, firmware update)
		0x03	Continue in Use Case previous setting is valid
[AL1120:C.Port_Process_Data_Size]	Length of the process input data and process output data	0x00	2 bytes input, 2 bytes output
		0x01	4 bytes input, 4 bytes output
		0x02	8 bytes input, 8 bytes output
		0x03	16 bytes input, 16 bytes output
		0x04	32 bytes input, 32 bytes output

- ▶ Save EtherNet/IP project

8.4.4 Configure IO-Link ports

11810

The IO-Link ports are configured via the controller tags. The user can configure each IO-Link port separately.

To configure the IO-Link ports:

Requirements:

- > AL1120 is correctly integrated in the EtherNet/IP project (→ **Integrate the AL1120 into the EtherNet/IP network** (→ p. 43)).

1 Open controller tags

- ▶ In the Controller Organizer: Double click on [Controller Name_of_Project] > [Controller Tags]
- > [Controller Tags] window appears.
- ▶ In the tree view: Click on [AL1120:C].
- > Controller tags for the configuration of the device appear.

2 Configure IO-Link ports

- ▶ Configure the following tags for each IO-Link port at will:

Name	Description	Possible values	
[AL1120:C.Port_Mode_Port_x]	Operating mode of the IO-Link port	0x00	Interface deactivated
		0x01	Operation as digital input (DI)
		0x02	Operation as digital output (DO)
		0x03	Operation as IO-Link interface
[AL1120:C.Port_Cycle_Time_Port_x]	Cycle time of the data transmission between the IO-Link master and the IO-Link device	0x00	The device automatically sets the fastest possible cycle time
		0x01	2 milliseconds
		0x02	4 milliseconds
		0x03	8 milliseconds
		0x04	16 milliseconds
		0x05	32 milliseconds
		0x06	64 milliseconds
		0x07	128 milliseconds
[AL1120:C.Swap_Port_x]	Visualisation of the process data (EtherNet/IP uses Little Endian Format (Intel), IO-Link uses Big Endian Format (Motorola))	0x00	Byte swapping for IO-Linkdata deactivated
		0x01	Byte swapping for IO-Linkdata activated
[AL1120:C.Validation_Data_Storage_Port_x]	Supported IO-Link standard and behaviour of the IO-Link master when connecting new IO-Link devices to the IO-Link port	0x00	No validation
		0x01	Type compatible V1.0 device
		0x02	Type compatible V1.1 device
		0x03	Type compatible V1.1 device with Backup + Restore
		0x04	Type compatible V1.1 device with Restore
[AL1120:C.Vendor_ID_Port_x]	Vendor ID of the manufacturer of the device on the IO-Link port	0x0000...0xFFFF ifm electronic: 0x136	

Configuration

Name	Description	Possible values	
[AL1120:C.Device_ID_Port_x]	Device ID of the device on the IO-Link port	0x000000...0xFFFFFFFF	
[AL1120:C.Fail_Safe_Mode_Port_x]	Fail-safe mode for output data when the EtherNet/IP connection is interrupted	0x00	No Failsafe
		0x01	Failsafe Reset Value
		0x02	Failsafe Old Value
		0x03	Failsafe with Pattern
[AL1120:C.Fail_Safe_Value_DO_Port_x]	Fail-safe value for the operating mode "digital output (DO)"	0x00	Failsafe Reset Value
		0x01	Failsafe Old Value
		0x02	Failsafe Set Value

x = 1...4

- <Save EtherNet/IP project.

8.5 EtherNet/IP: Configure IO-Link devices

23106

The AL1120 supports the configuration of the connected IO-Link devices from the EtherNet/IP projection software. For this, ifm offers the EtherNet/IP object "IO-Link Request" (→ **IO-Link requests (object class: 0x80)** (→ p. 97)). The object enables direct read and write access to IO-Link objects of the IO-Link device. The extent of the configurable parameters depends on the IO-Link device.

The following services are available:

Name	Description	Reference
Read request	Send a request to read an IO-Link object	→ Read_ISDU (→ p. 98)
Write request	Send a request to write an IO-Link object	→ Write_ISDU (→ p. 101)



Information for the execution of acyclic commands: → **Execute acyclic commands** (→ p. 49)

Available parameters of the IO-Link devices: → Operating instructions of the IO-Link device

8.6 EtherNet/IP: Programmers' notes

12761

The programmer can access on the following data from the PLC application:

- Read device information of the AL1120
- Read diagnostics and alarms
- Set parameters of the connected IO-Link devices

The following sections show the available options.



Further information about the functional/operational blocks: → Help function of the EtherNet/IP projection software

8.6.1 Read cyclic input data

8518

The user can access the cyclic input data of the connected sensors and IO-Link devices via the controller tags of the AL1120.

To access the input data:

- ▶ Starting RSLogix5000.
- ▶ Open a EtherNet/IP project.
- ▶ In the project tree: Mouse click on [Controller Tags] > [AL1120.I]
- > The window shows the data structure with cyclic input data ([AL1120.I:Data])



Mapping of the inputs on the data structure [AL1120.I:Data]: → **Input assembly** (→ p. [72](#))

8.6.2 Write cyclic output data

8570

The user can access the cyclic output data of the connected actuators and IO-Link devices via the controller tags of the AL1120.

To access the cyclic output data:

- ▶ Starting RSLogix5000.
- ▶ Open a EtherNet/IP project.
- ▶ In the project tree: Mouse click on [Controller Tags] > [AL1120.O]
- > The window shows the data structure with cyclic input data ([AL1120.O:Data])



Mapping of the outputs on the data structure [AL1120.C:O]: → **Output assembly** (→ p. [76](#)).

8.6.3 Execute acyclic commands

22633

The AL1120 offers the following options to execute acyclic commands:

Command channels in cyclic process data

16384

Within the cyclic input and output data, special areas are available for the acyclic data transmission. Both read and write access can be implemented via the areas.

Principle of the command channels

9002

A cyclic command consists of a request and a response. The command request is transmitted in the Output Assembly. The command response of the IO-Link master is transmitted in the Input Assembly. The following table shows the general process of an acyclic communication via the acyclic command channel.

Step	Output assembly	Input assembly
1	▶ [Trigger] = 0 > The data in the request area is invalid.	--
2	▶ Write the data of the request area: - Port (bytes 4 and 5) - Index (bytes 6 and 7) - Sub-index (bytes 8 and 9) - Command (byte 10) - Data (11...43)	--
3	▶ [Trigger] = 1 > Command is transmitted	> [Handshake] = 0
4	--	▶ Read [Handshake]. - If [Handshake] = 0x0: > The data in the response area is invalid. ▶ Continue with step 4 - If [Handshake] = 0x1: > The data in the response area is valid. ▶ Continue with step 5
5	--	▶ Read [Result] byte (byte 11) - If [Result] = 0x00 > Command has been processed without errors - If [Result] = 0x01: > An error occurred during the processing of the command. ▶ Read diagnostic codes (byte 13) ▶ Eliminate the error and repeat the execution of the command

Configuration

Acyclic port commands

12063

For the acyclic access to the configuration of the IO-Link ports of the AL1120, the following commands are available:


Command	Description	Reference
Set mode	Set the operating type of the IO-Link port	→ Command 0x10 – set mode (→ p. 82)
Set Validation ID / Data Storage	Adjust the supported IO-Link standard and the behaviour of the IO-Link master when connecting a new IO-Link device to the IO-Link port	→ Command 0x20 – set validation ID / data storage (→ p. 84)
Set fail-safe data pattern	Behaviour of the outputs when the EtherNet/IP connection is interrupted and setting of the corresponding fail-safe values	→ Command 0x30 – set fail-safe data pattern (→ p. 86)

The port commands use the same mechanisms as the acyclic command channel (→ **Acyclic command channel** (→ p. [77](#))).

EtherNet/IP mechanisms for acyclic commands

7102

Acyclic commands can be executed with the EtherNet/IP command Message (MSG).



Parameters of the available field bus objects: → **Field bus objects** (→ p. [88](#))

For detailed information about the Message (MSG) command: → Operating instructions RSLogix 5000

8.6.4 Read diagnostic and status information

10235

Diagnostic and status information is a part of the cyclically transmitted process data (mapping: → **Input assembly** (→ p. 72)). the input assembly includes the following diagnostic information of the IO-Link ports and the status information of the transmitted data:

Byte	Content
2	Indication of short circuit/overload of the IO-Link ports X01...X04
3	Status indication of the voltage supply of the device
43	Status information IO-Link port X01
58	Status information IO-Link port X02
73	Status information IO-Link port X03
88	Status information IO-Link port X04

To access the cyclically transmitted diagnostic and status information:

- ▶ Starting RSLogix5000.
- ▶ Open a EtherNet/IP project.
- ▶ In the project tree: Mouse click on [Controller Tags] > [AL1120.I]
- > The window shows cyclic input data (Input Assembly).
- ▶ Link diagnostic and status information with variables.

9 Operation

Contents

Read device information.....	53
Reboot the device.....	56
Error detection and elimination.....	56
Firmware update.....	57
Exchange IO-Link device.....	58

22368

9.1 Read device information

12741

In order to get information about the current status of the hardware and software components of the device, the user can use the following possibilities:

- **Web interface: Read device and diagnostic information** (→ p. [54](#))
- **LR DEVICE: Read device information** (→ p. [55](#))
- **EtherNet/IP: Read device information** (→ p. [55](#))

9.1.1 Web interface: Read device and diagnostic information

12744

In order to read the diagnostic information about the current device status via the web interface:

- ▶ Connect laptop/PC and AL1120 via the Ethernet internet.
- ▶ Start web browser.
- ▶ Enter the following into the address field of the browser: and confirm with [ENTER]:
<IP address of the device>
- > Web browser shows the web interface of the device.
- > The page shows the following data:
 - Table with connected IO-Link devices

Name	Description
[Port]	Number of the IO-Link interface
[Mode]	Operating mode of the IO-Link interface
[Comm. Mode]	Baud rate of the IO-Link interface
[MasterCycleTime]	Cycle time
[Vendor ID]	ID of the manufacturer of the IO-Link device
[Device ID]	ID of the IO-Link device
[Name]	Article number of the IO-Link device ▪ For ifm articles: This article number is stored along with a link to the produkt page on the ifm website.
[Serial]	Serial number of the IO-Link device
[LR Interval]	Cycle time for the communication with the SmartObserver

- Version information of the installed firmware components

Name	Description
[Firmware version]	Firmware version
[FirmwareCN Version]	Version of the firmware container
[Bootloader Version]	Version of the boot loader
[NETX Firmware Version]	Version of the EtherNet/IP firmware

- Diagnostic information of the device

Name	Description
[Current]	Current (in mA)
[Voltage]	Voltage (in mV)
[Short Circuit]	Number of detected short circuits
[Temperature]	Device temperature (in °C)



The page of the device is constantly updated. This is why the data is always up-to-date.

9.1.2 LR DEVICE: Read device information

11614

To show information about the AL1120:

- ▶ Start LR DEVICE.
- ▶ Scan network for devices.
- > LR DEVICE shows recognised AL1120.
- ▶ Mouse click on AL1120
- > The header shows the following information:

Name	Description	Possible values
Device name	Article number of the device	AL1120
Manufacturer	Manufacturer of the device	ifm electronic gmbh
Device ID	IO-Link ID of the device	
Serial number	Serial number of the device	
Revision	Hardware revision / software revision of the unit	
Type of unit	Name of the device	IO-Link master StandardLine EtherNet/IP 4 ports IP 65 / IP 67
Device status	Current status of the slave	☐ no information about the condition
		☒ OK: no errors, no warning, no information
		☒ OK: no errors, no warning, information
		☒ Warning
		☒ Error

9.1.3 EtherNet/IP: Read device information

7639

The user can read information about the device via the field bus object "Identity Object" (→ **Field bus objects** (→ p. [88](#))).

9.2 Reboot the device

12760

When restarting the device, all settings are kept.

To restart the AL1120:

- ▶ Start LR DEVICE.
- ▶ Scan the network for devices.
- > LR DEVICE recognises the AL1120.
- ▶ Under [ONLINE]: Click on [AL1120]
- ▶ Select the [Setup] section.
- > LR DEVICE shows available parameters.
- ▶ Click on [Restart] to restart the device.
- > LR DEVICE restarts the AL1120.

9.3 Error detection and elimination

20926

In order to recognise and eliminate errors, the user can use the following resource:

- Status LED of the unit (→ **LED indicators** (→ p. [24](#)))
- Cyclic diagnostic and status information (→ **Input assembly** (→ p. [72](#)))

9.4 Firmware update

The new firmware is installed via the device's web interface.



If the firmware update is not successful, deactivate all connections to the EtherNet/IP PLC, LR SmartObserver and LR DEVICE and repeat the process.

- ▶ Stop EtherNet/IP PLC.
- ▶ Set the parameter [IP address SmartObserver] to 255.255.255.255 (→ **Configure the interface to the SmartObserver** (→ p. 35)).
- ▶ Stop the LRAgent.LRDevice service in the Windows task manager.

To install a new firmware version on the device:

Requirements

- > File with new firmware has been downloaded.
- > Ethernet connection between laptop/PC and device is established.

1 Call up web interface

- ▶ Start web browser.
- ▶ Enter the following into the address field of the browser: and confirm with [ENTER]:
<IP-Adresse des Geräts>/update
- > Web browser shows the [Firmware Update] page.

2 Load new firmware to AL1120

- ▶ Click on [Datei auswählen].
- > Dialogue window appears.
- ▶ Select the firmware file and click on [Öffnen] in order to adopt the file.
- ▶ Click on [Submit] to start the firmware update.
- > Firmware is being loaded to the device.
- > After successful storage, the success message is displayed

3 Restart the device

- ▶ Click on [Restart device now] to restart the device.
- > The status LED RDY flashes quickly.
- > Firmware is updating.
- ▶ Follow the instructions in the browser.

9.5 Exchange IO-Link device

7775

To exchange an IO-Link device:

Requirement:

- > IO-Link device is with factory settings.
- > IO-Link device supports IO-Link standard 1.1 or higher.

1 Set data storage

- ▶ Set the following parameters of the IO-Link port:
[Validation / Data Storage] = Type compatible V1.1 device with Restore
OR
[Port x IO-Link Validation / Data Storage] = Type compatible V1.1 device with Restore
- ▶ Save changes.

2 Exchange IO-Link device

- ▶ Disconnect old IO-Link device from AL1120.
- ▶ Connect new IO-Link device with the same IO-Link port of the AL1120.
- > IO-Link master copies parameter values from the data memory to the new IO-Link device.

10 Maintenance

21577

The operation of the unit is maintenance-free.

- ▶ Clean the surface of the unit when necessary. Do not use any caustic cleaning agents for this!
- ▶ After use, dispose of the unit in an environmentally friendly way in accordance with the applicable national regulations.

11 Factory Settings

23489

In the factory settings, the device has the following parameter settings:

Parameter	Factory setting
[IP address]	192.168.1.250
[Subnet mask]	255.255.255.0
[IP gateway address]	0.0.0.0
[Host name]	blank
Data memory (Data Storage)	blank

12 Appendix

Contents

Technical data	62
EtherNet/IP	66

7156

12.1 Technical data

Contents	
Application	63
Electrical data	63
Inputs / outputs	63
Inputs	63
Outputs	63
Interfaces	64
Operating conditions	64
Approvals / tests	64
Mechanical data	65
Electrical connection	65

9011

12.1.1 Application

23710

Application	
Application	I/O modules for field applications
Daisy-chain function	Communication interface

12.1.2 Electrical data

22819

Electrical data	
Operating voltage	20...30 DC; (US; to SELV/PELV)
Current Consumption [mA]	300...3900; (US)
Protection class	III
Sensor supply US	
Max. current load total [A]	3.6

12.1.3 Inputs / outputs

23711

Inputs / outputs	
Total number of inputs and outputs	8; (configurable)

12.1.4 Inputs

22820

Inputs	
Number of digital inputs	8; (IO-Link Port Class A: 4 x 2; IO-Link Port Class B: 4 x 1)
Switching level high [V]	11...30 DC
Switching level low [V]	0...5 DC
Digital inputs protected against short circuits	yes

12.1.5 Outputs

22821

Outputs (digital)	
Output function	4; (IO-Link Port Class A: 4 x 1)
Max. current load per output [mA]	200
Short-circuit protection	yes

12.1.6 Interfaces

22630

Interfaces	
Communication interface	Ethernet; IO-Link
Communication interface	IO-Link; TCP/IP; PROFINET IO
Ethernet	
Transmission standard	10Base-T; 100Base-TX
Transmission rate	10; 100
Protocol	TCP/IP; PROFINET IO
Factory settings	- IP address: 192.168.1.250 - Subnet mask: 255.255.255.0 - Gateway IP address: 0.0.0.0 - MAC address: see type label
IO-Link Master	
Transmission type	COM 1 / COM 2 / COM 3
IO-Link revision	V1.1
Number of ports class A	4

12.1.7 Operating conditions

22823

Operating conditions	
Applications	Indoor use
Ambient temperature [°C]	-25...60
Storage temperature [°C]	-25...85
Max. perm. relative air humidity [%]	90
Max. height above sea level [m]	2000
Protection rating	IP 65; IP 67
Pollution Degree	2

12.1.8 Approvals / tests

22824

Approval / tests	
EMC	- EN 61000-6-2 - EN 61000-6-4
MTTF [Years]	90




12.1.9 Mechanical data

22825

Mechanical data	
Weight [g]	261.2
Materials	Housing: PA; socket: brass nickel-plated

12.1.10 Electrical connection

22826

Voltage supply IN X31											
Connector	M12										
Wiring	 <table> <tr> <td>1:</td><td>+ 24 V DC (US)</td></tr> <tr> <td>2:</td><td>-</td></tr> <tr> <td>3:</td><td>GND (US)</td></tr> <tr> <td>4:</td><td>-</td></tr> </table>	1:	+ 24 V DC (US)	2:	-	3:	GND (US)	4:	-		
1:	+ 24 V DC (US)										
2:	-										
3:	GND (US)										
4:	-										
Ethernet IN / OUT X21, X22											
Connector	M12										
Wiring	 <table> <tr> <td>1:</td><td>TX +</td></tr> <tr> <td>2:</td><td>RX +</td></tr> <tr> <td>3:</td><td>TX -</td></tr> <tr> <td>4:</td><td>RX -</td></tr> <tr> <td>5:</td><td>-</td></tr> </table>	1:	TX +	2:	RX +	3:	TX -	4:	RX -	5:	-
1:	TX +										
2:	RX +										
3:	TX -										
4:	RX -										
5:	-										
Process connection IO-Link Ports Class A X01...X0<IOL_AnzPorts>											
Connector	M12										
Wiring	 <table> <tr> <td>1:</td><td>+ 24 V DC (US)</td></tr> <tr> <td>2:</td><td>DI</td></tr> <tr> <td>3:</td><td>GND (US)</td></tr> <tr> <td>4:</td><td>C/Q IO-Link</td></tr> <tr> <td>5:</td><td>-</td></tr> </table>	1:	+ 24 V DC (US)	2:	DI	3:	GND (US)	4:	C/Q IO-Link	5:	-
1:	+ 24 V DC (US)										
2:	DI										
3:	GND (US)										
4:	C/Q IO-Link										
5:	-										

12.2 EtherNet/IP

Contents

Parameter data	67
Cyclic data	71
Acyclic data	77

22433

12.2.1 Parameter data

Contents

Configuration Assembly.....	68
-----------------------------	----

1568

Configuration Assembly

10233



The values of the Configuration Assembly are set in RSLogix 5000 via the controller tags of the EtherNet/IP project.

Byte	Content
0	Communication profile (→ Communication profile (→ p. 69))
1	Process data length (→ Process data length (→ p. 69))
2	X01: Operating mode (→ Port configuration (→ p. 70))
3	X01: Cycle time IO-Link master - IO-Link device (→ Port configuration (→ p. 70))
4	X01: Byte swap (→ Port configuration (→ p. 70))
5	X01: Data storage and validation (→ Port configuration (→ p. 70))
6	X01: Vendor ID (LSB) (→ Port configuration (→ p. 70))
7	X01: Vendor ID (MSB) (→ Port configuration (→ p. 70))
8	X01: Device ID (LSB) (→ Port configuration (→ p. 70))
9	X01: Device ID (→ Port configuration (→ p. 70))
10	X01: Device ID (MSB) (→ Port configuration (→ p. 70))
11	X01: reserved
12	X01: Fail safe mode (→ Port configuration (→ p. 70))
13	X01: Fail safe value of DO (pin 4) (→ Port configuration (→ p. 70))
14...25	X02: Parameters of the IO-Link ports (→ lines 2...13)
26...37	X03: Parameters of the IO-Link port (→ lines 2...13)
38...49	X04: Parameters of the IO-Link port (→ lines 2...13)

Communication profile

23072

name	Description	Possible values	
[Communication profile]	The access rights to the parameter data, process data and the events/diagnostic messages of the IO-Link master as well as the connected IO-Link devices.	0x00	EtherNet/IP + LineRecorder
		0x01	EtherNet/IP + LineRecorder (ro)
		0x02	EtherNet/IP only
		0x03	Continue in Use Case

Process data length

23016

Name	Description	Possible values	
[Process data length]	Length of the process input data and process output data Controller Tag: []	0x00	2 bytes input data, 2 bytes output data ▪ Input assembly: 126 bytes ▪ Output assembly: 54 bytes
		0x01	4 bytes input data, 4 bytes output data ▪ Input assembly: 134 bytes ▪ Output assembly: 62 bytes
		0x02	8 bytes input data, 8 bytes output data ▪ Input assembly: 150 bytes ▪ Output assembly: 78 bytes
		0x03	16 bytes input data, 16 bytes output data ▪ Input assembly: 182 bytes ▪ Output assembly: 110 bytes
		0x04	32 bytes input data, 32 bytes output data ▪ Input assembly: 246 bytes ▪ Output assembly: 172 bytes

Appendix

Port configuration

7423

Name	Description	Possible values	
[X0n: Port Mode]	Operating mode of the IO-Link port	0x00	Interface deactivated
		0x01	Operation as digital input (DI)
		0x02	Operation as digital output (DO)
		0x03	Operation as IO-Link interface
[X0n: Master Cycle Time]	Cycle time of the data transmission between the IO-Link master and the IO-Link device	0x00	The device automatically sets the fastest possible cycle time
		0x01	2 milliseconds
		0x02	4 milliseconds
		0x03	8 milliseconds
		0x04	16 milliseconds
		0x05	32 milliseconds
		0x06	64 milliseconds
		0x07	128 milliseconds
[X0n: Byte Swap]	Visualisation of the process data (EtherNet/IP uses Little Endian Format (Intel), IO-Link uses Big Endian Format (Motorola))	0x00	Byte swapping for IO-Link process data deactivated
		0x01	Byte swapping for IO-Link process data activated
[X0n: Validation ID]	Supported IO-Link standard and behaviour of the IO-Link master when connecting new IO-Link devices to the IO-Link port	0x00	No validation
		0x01	Type compatible V1.0 device
		0x02	Type compatible V1.1 device
		0x03	Type compatible V1.1 device with Backup + Restore
		0x04	Type compatible V1.1 device with Backup
[X0n: VID (LSB)]	Vendor ID of the manufacturer of the device on the IO-Link port	per byte: 0x00...0xFF 0xYYZZ - YY = VID (MSB) - ZZ = VID (LSB)	
[X0n: VID (MSB)]			
[X0n: DID (LSB)]	Device ID of the device on the IO-Link port	per byte: 0x00...0xFF 0xXXYYZZ - XX = DID (MSB) - YY = DID - ZZ = DID (LSB)	
[X0n: DID]			
[X0n: DID (MSB)]			
[X0n: Fail-safe Mode]	Fail-safe mode for output data when the EtherNet/IP connection is interrupted	0x00	No Failsafe
		0x01	Failsafe Reset Value
		0x02	Failsafe Old Value
		0x03	Failsafe with Pattern
[X0n: Fail-safe Value of DO Pin 4]	Fail-safe value for the operating mode "digital output (DO)"	0x00	Failsafe Reset Value
		0x01	Failsafe Old Value
		0x02	Failsafe Set Value

12.2.2 Cyclic data

Contents

Input assembly	72
Output assembly.....	76

22429

Input assembly

11135

Byte	Content
0	Digital inputs of the IO-Link ports in the DI operating mode (→ Mapping: digital input data (DI) (→ p. 73))
1	
2	
3	Status information (→ Mapping: Status information (→ p. 73))
4...45	Acyclic command area: Response channel (→ Response channel (→ p. 79))
46...63	Port X01: Diagnostic, vendor ID, device ID, events (→ Mapping: IO-Link port information (→ p. 74))
64...81	Port X02: Diagnostic, vendor ID, device ID, results (→ Mapping: IO-Link port information (→ p. 74))
82...99	Port X03: Diagnostic, vendor ID, device ID, events (→ Mapping: IO-Link port information (→ p. 74))
100...117	Port X04: Diagnostic, vendor ID, device ID, events (→ Mapping: IO-Link port information (→ p. 74))
118	Port X01: Cyclic input data (n bytes)
118+n	Port X02: Cyclic input data (n bytes)
118+2n	Port X03: Cyclic input data (n bytes)
118+3n	Port X04: Cyclic input data (n bytes)

Legend:

n = [2,4,8,16,32]; is determined by the parameter [Prozess_Data_Length] (→ **Process data length** (→ p. [69](#)))

Mapping: digital input data (DI)

23008

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
reserved	reserved	reserved	reserved	X04: Pin 4	X03: Pin 4	X02: Pin 4	X01: Pin 4
reserved	reserved	reserved	reserved	X04: Pin 2	X03: Pin 2	X02: Pin 2	X01: Pin 2

Legend:

X0n: Pin 4	Signal level on pin 4 of the IO-Link port	1 bit	0x0 = OFF 0x1 = ON
X0n: Pin 2	Signal level on pin 2 of the IO-Link port	1 bit	0x0 = OFF 0x1 = ON

Mapping: Status information

23006

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
reserved	reserved	reserved	reserved	X04: Short / OL	X03: Short / OL	X02: Short / OL	X01: Short / OL
reserved	reserved	reserved	reserved	reserved	reserved	Sensor PWR	AUX PWR

Legend:

X0n: Short / OL	Occurrence of a short circuit or of an overvoltage on the IO-Link port	1 bit	0x0 = without errors 0x1 = short circuit or overvoltage detected
Sensor PWR	Status of the supply voltage US	1 bit	0x0 = supply voltage US not available 0x1 = supply voltage US available
AUX power	Status of the supply voltage UA	1 bit	0x0 = supply voltage UA not available 0x1 = supply voltage UA not available

Mapping: IO-Link port information

23465

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
reserved	Wrong PD Output Length	Wrong PD Input Length	Wrong Cycle Time	Wrong VID / DID	Invalid Data Bit	Device Conn	IOL Mode
reserved							
VID (LSB)							
VID (MSB)							
DID (LSB)							
DID							
DID (MSB)							
reserved							
Event Mode		Event Type		Event Source	Event Instance		
Event Code 1							
Event Code 2							
Event Mode		Event Type		Event Source	Event Instance		
Event Code 1							
Event Code 2							
Event Mode		Event Type		Event Source	Event Instance		
Event Code 1							
Event Code 2							
reserved							

Legend:

IOL mode	Operating mode of the IO-Link port	1 bit	0x0 = IO-Link inactive 0x1 = IO-Link active
Device Conn	Connection of the device	1 bit	0x0 = not available 0x1 = available
Invalid Data Bit	Status of the process input data on the IO-Link port	1 bit	0x0 = data valid 0x1 = data invalid
Wrong VID / DID	Status of the vendor ID / device ID	1 bit	0x0 = VID / DID are correct 0x1 = wrong VID or DID
Wrong Cycle Time	Status of the cycle time	1 bit	0x0 = cycle time is correct 0x1 = wrong cycle time
Wrong PD Input Length	Status of the length of the process input data	1 bit	0x0 = length is correct 0x1 = configuration of the length of the input data is wrong
Wrong PD Output Length	Status of the length of the process output data	1 bit	0x0 = length is correct 0x1 = configuration of the length of the output data is wrong
VID	Vendor ID of the connected IO-Link device	16 bits	0x0000...0xFFFF 0xXXYY - XX = VID (MSB) - YY = VID (LSB)
DID	Device ID of the connected IO-Link device	24 bits	0x000000...0xFFFFFF 0xXXYYZZ - XX = DID (MSB) - YY = DID - ZZ = DID (LSB)
Event Mode	Event mode	2 bits	depends on the device (→ operating instructions of the IO-Link

Appendix

Event Type	Event type	2 bits	device)
Event Source	Events source	1 bit	
Event Instance	Event instance	3 bits	
Event Code 1	Event code	8 bits	
Event Code 2	Event code	8 bits	



© ifm electronic gmbh

www.ifm.com

Appendix

Output assembly

11126

Byte	Content
0	Digital output data of the IO-Link ports in the DO operating mode (→ Mapping: Digital output data (DO) (→ p. 76))
1	reserved
2	reserved
3	reserved
4...45	Acyclic command area: Request channel (→ Request channel (→ p. 78))
46	Port X01: Acyclic output data (n bytes)
46+n	Port X02: Acyclic output data (n bytes)
46+2n	Port X03: Acyclic output data (n bytes)
46+3n	Port X04: Acyclic output data (n bytes)

Legend:

n = [2,4,8,16,32]; is determined by the parameter [Prozess_Data_Length] (→ **Process data length** (→ p. 69))

Mapping: Digital output data (DO)

23005

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
reserved	reserved	reserved	reserved	X04: Pin 4	X03: Pin 4	X02: Pin 4	X01: Pin 4

Legend:

X0n: Pin 4 Signal level on pin 4 of the IO-Link port 1 bit 0x0 = OFF
0x1 = ON

12.2.3 Acyclic data

22427

Acyclic command channel

10236

In the cyclic process data, command channels for the transmission of acyclic data is available.

Object	Contents	Bytes	Access
Output assembly	Request channel (field bus PLC >>> IO-Link master) → Request channel (→ p. 78)	4...45	r/w
Input assembly	Response channel (IO-Link master >>> fieldbus PLC) → Response channel (→ p. 79)	4...45	r

Legend:

r = only read access rights
r/w = read and write access rights

Appendix

Request channel

17657

Byte	Content	
4	Port no. (LSB)	
5	Port no. (MSB)	
6	Index (LSB)	
7	Index (MSB)	
8	Sub-index (LSB)	
9	Sub-index (MSB)	
10	Trigger	Command
11	Length of the user data (number of bytes)	
12	Data (byte 0)	
13	Data (byte 1)	
..	...	
43	Data (byte 31)	
44	reserved	
45	reserved	

Legend:

Port no. (LSB)	Number of the IO-Link port (low byte)	8 bits	0x01 = port X01 0x02 = port X02 ... 0x04 = port X04
	- Port no. = 0xXXYY - Port no. (LSB) = 0xYY		
Port no. (MSB)	Number of the IO-Link port (high byte)	8 bits	0x00
	- Port no. = 0xXXYY - Port no. (MSB) = 0xXX		
Index (LSB)	Index of the IO-Link object (low byte)	8 bits	0x00...0xFF
	- Index = 0xXXYY - Index (LSB) = 0xYY		
Index (MSB)	Index of the IO-Link object (high byte)	8 bits	0x00...0xFF
	- Index = 0xXXYY - Index (MSB) = 0xXX		
Sub-index (LSB)	Sub-index of the IO-Link object (low byte)	8 bits	0x00...0xFF
	- Sub-index = 0xXXYY - Sub-index (LSB) = 0xYY		
Sub-index (MSB)	Sub-index of the IO-Link object (high byte)	8 bits	0x00...0xFF
	- Sub-index = 0xXXYY - Sub-index (MSB) = 0xXX		
Trigger	Control of the command execution	1 bit	0x0 = do not process command 0x1 = execute command
Command	Command number	7 bits	0x01 = read 0x02 = write
Length of the user data	Number of bytes that contain relevant user data	8 bits	0x00 = 0 bytes ... 0x20 = 32 bytes
Data (byte n)	User data	8 bits	0x00...0xFF

Appendix

Response channel

8468

Byte	Content	
4	Port no. (LSB)	
5	Port no. (MSB)	
6	Index (LSB)	
7	Index (MSB)	
8	Sub-index (LSB)	
9	Sub-index (MSB)	
10	Handshake	Command
11	Result	
12	Length of the response data (number of bytes)	
13	Data (byte 0) or diagnostic data	
14	Data (byte 1)	
...	...	
44	Data (byte 31)	
45	reserved	

Legend:

Port no. (LSB)	Number of the IO-Link port (low byte)	8 bits	0x01 = port X01 0x02 = port X02 ... 0x04 = Port X04
	- Port no. = 0xXXYY - Port no. (LSB) = 0xYY		
Port no. (MSB)	Number of the IO-Link port (high byte)	8 bits	0x00
	- Port no. = 0xXXYY - Port no. (MSB) = 0xXX		
Index (LSB)	Index of the IO-Link object (low byte)	8 bits	0x00...0xFF
	- Index = 0xXXYY - Index (LSB) = 0xYY		
Index (MSB)	Index of the IO-Link object (high byte)	8 bits	0x00...0xFF
	- Index = 0xXXYY - Index (MSB) = 0xXX		
Sub-index (LSB)	Sub-index of the IO-Link object (low byte)	8 bits	0x00...0xFF
	- Sub-index = 0xXXYY - Sub-index (LSB) = 0xYY		
Sub-index (MSB)	Sub-index of the IO-Link object (high byte)	8 bits	0x00...0xFF
	- Sub-index = 0xXXYY - Sub-index (MSB) = 0xXX		
Handshake	Validity of the response data	1 bit	0x0 = invalid data 0x1 = data is invalid
Command	Command number	7 bits	0x01 = read 0x02 = write
Result	Status of the command processing	8 bits	0x00 = command processed without errors 0x01 = errors occurred
Length of the response data	Number of bytes that contain relevant user data	8 bits	0x00 = 0 bytes ... 0x20 = 32 bytes

Appendix

Data (byte 0) or diagnostic data User data (byte 0) or error codes 8 bits User data: 0x00...0xFF
Error codes: → **Failure codes** (→ p. [80](#))

Data (byte n) User data (byte n) 8 bits 0x00...0xFF

Failure codes

15475

Error code	Description
0x71	Service not available (unknown command has been sent to the IO-Link port)
0x72	Port blocked (another cyclic process accesses the IO-Link port)
0x74	Invalid data (wrong parameter has been sent in the command)
0x76	Wrong port (wrong port number)
0x77	Wrong port function (wrong port function or wrong parameter has been sent to the device)
0x78	Invalid length (set length is > 0x20)
0x80	Error in the device application

Acyclic commands

Contents

Command 0x10 – set mode	82
Command 0x20 – set validation ID / data storage	84
Command 0x30 – set fail-safe data pattern	86

22631

Command 0x10 – set mode

23461

The command changes the operating mode of an IO-Link port of the AL1120.



Corresponding parameter: [Port Mode] (→ **Port configuration** (→ p. [70](#)))

Command request

22990

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4	Port no. (LSB)							
5	Port no. (MSB)							
6	reserved							
7	reserved							
8	reserved							
9	reserved							
10	Trigger	0x10						
11	Target mode							
12...45	reserved							

Legend:

Port no. (LSB)	Number of the IO-Link port (low byte)	8 bits	0x01 = port X01 0x02 = port X02 ... 0x04 = port X04
	Port no. = 0xXXYY		
	▪ Port no. (LSB) = 0xYY		
Port no. (MSB)	Number of the IO-Link port (high byte)	8 bits	0x00
	Port no. = 0xXXYY		
	▪ Port no. (MSB) = 0xXX		
Trigger	Control of the command execution	1 bit	0x0 = do not process command 0x1 = execute command
Target mode	Operating type of the IO-Link port	8 bits	0x00 = deactivated 0x01 = operation as digital input (DI) 0x02 = operation as digital output (DO) 0x03 = operation as IO-Link intervals

Appendix

Command response

8039

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4	Port no. (LSB)							
5	Port no. (MSB)							
6	reserved							
7	reserved							
8	reserved							
9	reserved							
10	Handshake	0x10						
11	Result							
12	Target Mode							
13...45	reserved							

Legend:

Port no. (LSB)	Number of the IO-Link port (low byte) Port no. = 0xXXYY ▪ Port no. (LSB) = 0xYY	8 bits	0x01 = port X01 0x02 = port X02 ... 0x04 = Port X04
Port no. (MSB)	Number of the IO-Link port (high byte) Port no. = 0xXXYY ▪ Port no. (MSB) = 0xXX	8 bits	0x00
Handshake	Status of the execution of the command	1 bit	0x0 = command is executed 0x1 = execution of the command was successful
Result	Error indication	8 bits	0x00 = no errors 0x01 = errors occurred
Target mode	Operating type of the IO-Link port	8 bits	0x00 = deactivated 0x01 = operation as digital input (DI) 0x02 = operation as digital output (DO) 0x03 = operation as IO-Link intervals

Command 0x20 – set validation ID / data storage

23462

The command sets the behaviour of the IO-Link master when connecting a new IO-Link device to an IO-Linkport of the device.



Corresponding parameter: [Validation ID] (→ **Port configuration** (→ p. [70](#)))

Command request

7337

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4	Port no. (LSB)							
5	Port no. (MSB)							
6	reserved							
7	reserved							
8	reserved							
9	reserved							
10	Trigger	0x20						
11	Validation ID							
9...42	reserved							

Legend:

Port no. (LSB)	Number of the IO-Link port (low byte)	8 bit	0x01 = port X01 0x02 = port X02 ... 0x04 = port X04
	Port no. = 0xXXYY		
	▪ Port no. (LSB) = 0xYY		
Port no. (MSB)	Number of the IO-Link port (high byte)	8 bits	0x00
	Port no. = 0xXXYY		
	▪ Port no. (MSB) = 0xXX		
Trigger	Control command execution	1 bit	0x0 = do not process command 0x1 = execute command
Validation ID	Behaviour of the IO-Link master when connecting an IO-Link device to the IO-Link port	8 bits	0x00 = No check 0x01 = Type compatible V1.0 device 0x02 = Type compatible V1.1 device 0x03 = Type compatible V1.1 device with Backup + Restore 0x04 = Type compatible V1.1 device with Restore

Appendix

Command response

20764

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4	Port no. (LSB)							
5	Port no. (MB)							
6	reserved							
7	reserved							
8	reserved							
9	reserved							
10	Handshake	0x20						
11	Result							
12	Validation ID							
13..45	reserved							

Legend:

Port no. (LSB)	Number of the IO-Link port (low byte) Port no. = 0xXXYY ▪ Port no. (LSB) = 0xYY	8 bits	0x01 = port X01 0x02 = port X02 ... 0x04 = port X04
Port no. (MSB)	Number of the IO-Link port (high byte) Port no. = 0xXXYY ▪ Port no. (MSB) = 0xXX	8 bits	0x00
Handshake	Status of the execution of the command	1 bit	0x0 = command is executed 0x1 = execution of the command was successful
Result	Error indication	8 bits	0x00 = no errors 0x01 = errors occurred
Validation ID	Behaviour of the IO-Link master when connecting an IO-Link device to the IO-Link port	8 bits	0x00 = No check 0x01 = Type compatible V1.0 Device 0x02 = Type compatible V1.1 Device 0x03 = Type compatible V1.1 Device with Backup + Restore 0x04 = Type compatible V1.1 Device with Restore

Command 0x30 – set fail-safe data pattern

23464

The command sets the behaviour of the outputs when the EtherNet/IP connection and the corresponding fail-safe values are interrupted.



Corresponding parameter: [Fail-safe Mode] (→ **Port configuration** (→ p. 70))

The number of the required fail-safe values results from the size of the output data (→ **Process data length** (→ p. 69)).

Command request

23527

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4	Port no. (LSB)							
5	Port no. (MSB)							
6	reserved							
7	reserved							
8	reserved							
9	reserved							
10	Trigger	0x30						
11	Fail-safe mode							
12	Byte Length N							
13	Fail-safe data (byte 0)							
...	...							
44	Fail-safe data (byte 31)							
45	reserved							

Legend:

Port no. (LSB)	Number of the IO-Link port (low byte)	8 bits	0x01 = port X01 0x02 = port X02 ... 0x04 = port X04
	Port no. = 0xXXYY		
	▪ Port no. (LSB) = 0xYY		
Port no. (MSB)	Number of the IO-Link port (high byte)	8 bits	0x00
	Port no. = 0xXXYY		
	▪ Port no. (MSB) = 0xXX		
Fail-safe mode	Behaviour of the outputs when the EtherNet/IP connection is interrupted and setting of the corresponding fail-safe values	8 bits	0x00 = No Fail-safe 0x01 = Fail-safe Reset Value 0x02 = Fail-safe Old Value 0x03 = Fail-safe with Pattern
Trigger	Control command execution	1 bit	0x0 = do not process command 0x1 = execute command
Byte Length N	Number of the bytes that contain fail-safe values	8 bits	0x00 = 0 bytes ... 0x20 = 32 bytes
Fail-safe data (byte n)	Fail-Safe value n (n = 0...31)	8 bits	0x00...0xFF

Appendix

Command response

23529

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
4	Port no. (LSB)							
5	Port no. (MSB)							
6	reserved							
7	reserved							
8	reserved							
9	reserved							
10	Handshake	0x30						
11	Result							
12	Fail-safe mode							
13...45	reserved							

Legend:

Port no. (LSB)	Number of the IO-Link port (low byte) Port no. = 0xXXYY ▪ Port no. (LSB) = 0xYY	8 bits	0x01 = port X01 0x02 = port X02 ... 0x04 = port X04
Port no. (MSB)	Number of the IO-Link port (high byte) Port no. = 0xXXYY ▪ Port no. (MSB) = 0xXX	8 bits	0x00
Handshake	Status of the execution of the command	1 bit	0x0 = command is executed 0x1 = execution of the command was successful
Result	Error indication	8 bits	0x00 = no errors 0x01 = errors occurred
Fail-safe mode	Behaviour of the outputs when the EtherNet/IP connection is interrupted	8 bits	0x00 = No Fail-safe 0x01 = Fail-safe Reset Value 0x02 = Fail-safe Old Value 0x03 = Fail-safe with Pattern

Field bus objects

Contents	
CIP class services	89
CIP object classes	89
Identity Object (object class: 0x01)	90
Message Router Object (object class: 0x02).....	92
Assembly Object (object class: 0x04)	93
Connection Manager Object (object class: 0x06)	94
Device Level Ring Object (object class: 0x47)	95
Quality of Service (object class: 0x48)	96
IO-Link requests (object class: 0x80)	97
TCP/IP object (object class: 0xF5)	104
Ethernet Link Object (object class: 0xF6).....	106

22640

CIP class services

23651

The device supports the following class and instance services:

Class code		Service	Description
dec	hex		
01	01	Get Attribute All	Read all attribute values of the class or instance
02	02	Set Attribute All	Change all attribute values of the class or instance
05	05	Reset	Reset
09	09	Delete	Delete
14	0E	Get Attribute Single	Read single attribute value of the class or instance
16	10	Set Attribute Single	Change single attribute value of the class or instance
75	4B	Read ISDU	Read ISDU
76	4C	Write ISDU	Write ISDU
78	4E	Forward Close	Close connection
84	54	Forward Open	Open new connection

CIP object classes

23652

The device supports the following CIP object classes:

Class code		Object type	Reference
dec	hex		
01	01	Identity Object	→ Identity Object (object class: 0x01) (→ p. 90)
02	02	Message Router Object	→ Message Router Object (object class: 0x02) (→ p. 92)
04	04	Assembly Object	→ Assembly Object (object class: 0x04) (→ p. 93)
06	06	Connection Manager Object	→ Connection Manager Object (object class: 0x06) (→ p. 94)
71	47	Device Level Ring Object	→ Device Level Ring Object (object class: 0x47) (→ p. 95)
72	48	Quality of Service	→ Quality of Service (object class: 0x48) (→ p. 96)
128	80	IO-Link Requests	→ IO-Link requests (object class: 0x80) (→ p. 97)
245	F5	TCP/IP Object	→ TCP/IP object (object class: 0xF5) (→ p. 104)
246	F6	Ethernet Link Object	→ Ethernet Link Object (object class: 0xF6) (→ p. 106)

Appendix

Identity Object (object class: 0x01)

23119

The Identity Object contains the general information about the device.

Class attributes

23648

Attr. ID	Access	Name	Data type	Description	Value
1	Get	Revision	UINT	Revision of the object	1
2	Get	Max instance	UINT	Max. number of instances of the object	1
6	Get	Maximum ID Number Class Attributes	UINT	ID of the last class attribute	7
7	Get	Maximum ID Number Instance Attributes	UINT	ID of the last instance attribute	9

Instance attributes

23649

Attr. ID	Access	Name	Data type	Description	Preset
1	Get	Vendor ID	UINT	Manufacturer ID	322
2	Get	Device type	UINT	Type of unit	12
3	Get	Product code	UINT	Identification of a particular product of a vendor	AL1120
4	Get	Revision	STRUCT	Revision of the article that is represented by the Identity Object	1.1
		▪ Major revision	USINT	Main revision (1...127)	1
		▪ Minor revision	USINT	Side revision (3 digits, if necessary with zeros in the beginning)	1
5	Get	Status	WORD	Status of the device	
6	Get	Serial number	UDINT	Serial number of the device	
7	Get	Product Name	SHORT STRING	Readable device designation (max. 32 ASCII characters)	IO-Link Master SL EIP 4P IP67
8	Get	State	USINT	Current status of the device (according to status transition diagram)	
				0	Nonexistent
				1	Device Self Testing
				2	Standby
				3	Operational
				4	Major Recoverable Fault
				5	Major Unrecoverable Fault
				6...254	Reserved
				255	Default for Get_Attributes_All service
9	Get	Configuration Consistency Value	UINT	The content shows the configuration of the device	0

Supported services

23667

Service code		Name	Class	Attribute	Description
dec	hex				
01	01	Get_Attribute_All	yes	yes	Read all attributes
05	05	Reset	yes	yes	Reset
14	0E	Get_Attribute_Single	yes	yes	Read single attribute
16	10	Set_Attribute_Single	yes	yes	Change single attribute

If an Identity Object receives a reset request, it carries out the following actions:

- It checks if it supports the requested reset type.
- It responds to the request.
- It tries to execute the requested reset type.

Supported reset types:

- 0 Reboot the device (obligatory for all EtherNet/IP devices).
- 1 Restore factory settings and reboot the device.

Message Router Object (object class: 0x02)

23694

The Message Router Object provides an access with which an EtherNet/IP client can address a service to any object class or instance in the physical device.

Class attributes

23695

Attr. ID	Access	Name	Data type	Description	Value
1	Get	Revision	UINT	Revision of the object	1
2	Get	Max instance	UINT	Max. number of instances of the object	1
3	Get	Number of Instances	UINT	Number of instances	1
6	Get	Maximum ID Number Class Attributes	UINT	ID of the last class attribute	7
7	Get	Maximum ID Number Instance Attributes	UINT	ID of the last instance attribute	0

Instance attributes

23696

The object has no instance attributes.

Supported services

23697

Service code		Name	Class	Attribute	Description
dec	hex				
14	0E	Get_Attribute_Single	yes	no	Read single attribute value

Appendix

Assembly Object (object class: 0x04)

23690

The Assembly Object combines attributes of several objects to allow data to be sent to or received from each object via one connection.

Class attributes

23691

Attr. ID	Access	Name	Data type	Description	Value
1	Get	Revision	UINT	Revision of the object	2
2	Get	Max instance	UINT	Max. number of instances of the object	0x00C7
3	Get	Number of Instances	UINT	Number of instances	3
6	Get	Maximum ID Number Class Attributes	UINT	ID of the last class attribute	7
7	Get	Maximum ID Number Instance Attributes	UINT	ID of the last instance attribute	4

Instance attributes

23692

Attr. ID	Access	Name	Data type	Description	Preset
100	Get	Input assembly	STRUCT	Cyclic input data (→ Input assembly (→ p. 72))	--
150	Get, Set	Output assembly	STRUCT	Cyclic output data (→ Output assembly (→ p. 76))	--
199	Get, Set	Configuration assembly	STRUCT	Configuration data (→ Configuration Assembly (→ p. 68))	--

Supported services

23693

Service code		Name	Class	Attribute	Description
dec	hex				
14	0E	Get_Attribute_Single	yes	yes	Read attribute value
16	10	Set_Attribute_Single	no	yes	Change attribute value

Connection Manager Object (object class: 0x06)

23698

The Connection Manager Object structures and manages the internal resources that are used for the connection.

Class attributes

23699

Attr ID	Access	Name	Data type	Description	Value
1	Get	Revision	UINT	Revision of the object	1
2	Get	Max instance	UINT	Max. number of instances of the object	1
3	Get	Number of Instances	UINT	Number of instances	3
6	Get	Maximum ID Number Class Attributes	UINT	ID of the last class attribute	7
7	Get	Maximum ID Number Instance Attributes	UINT	ID of the last instance attribute	0

Instance attributes

23696

The object has no instance attributes.

Supported services

23701

Service code		Name	Class	Attribute	Description
dec	hex				
14	0E	Get_Attribute_Single	yes	yes	Read single attribute
16	10	Set_Attribute_Single	no	yes	Change single attribute
78	4E	Forward_Close	yes	no	Close connection
84	54	Forward_Open	yes	no	Open new connection

Appendix

Device Level Ring Object (object class: 0x47)

23657

The Device Level Ring (DLR) Object represents the interface for configuration and status information.

Class attributes

23658

Attr ID	Access	Name	Data type	Description	Value
1	Get	Revision	UINT	Revision of the object	3
2	Get	Max instance	UINT	Max. number of instances of the object	1
6	Get	Maximum ID Number Class Attributes	UINT	ID of the last class attribute	7
7	Get	Maximum ID Number Instance Attributes	UINT	ID of the last instance attribute	12

Instance attributes

23659

Attr. ID	Access	Name	Data type	Description	Preset
1	Get	Network Topology	USINT	current network topology	0
2	Get	Network status	USINT	current network status	0
10	Get	Active Supervisor	STRUCT of	Identification of the supervisor	0
			▪ UDINT	IP address of the supervisor	
			▪ ARRAY of 6 USINTs	MAC address of the supervisor	
12	Get	Capability Flags	DWORD	DLR functions of the device	0x82
				Bit 0	Announced-based ring node
				Bit 1	Beacon-based ring node
				Bit 2...4	reserved
				Bit 5	Supervisor capable
				Bit 6	Redundant Gateway capable
				Bit 7	Flush_Table frame capable
				Bit 8..31	reserved

Supported services

23660

Service code		Name	Class	Attribute	Description
dec	hex				
1	01	Get_Attribute_All	no	yes	Read all attribute values
14	0E	Get_Attribute_Single	yes	yes	Read single attribute value

Quality of Service (object class: 0x48)

23661

Quality of Service (QoS) enables prioritising of Ethernet frames. The priorities of the Ethernet frames can be influenced with the attributes "Differentiate Service Code Points" (DSCP) or "802.1Q Tag".

Class attributes

23662

Attr ID	Access	Name	Data type	Description	Value
1	Get	Revision	UINT	Revision of the object	3
2	Get	Max instance	UINT	Max. number of instances of the object	1
6	Get	Maximum ID Number Class Attributes	UINT	ID of the last class attribute	7
7	Get	Maximum ID Number Instance Attributes	UINT	ID of the last instance attribute	8

Instance attributes

23663

Attr ID	Access	Name	Data type	Description	Value
1	Get	802.1Q tagRevision	USINT	Current network topology	0
2	Get, Set	DSCP PTP Event	USINT	DSCP value for PTP event frames	59
3	Get, Set	DSCP PTP general	USINT	DSCP value for PTP general frames	47
4	Get, Set	DSCP PTP Urgent	USINT	DSCP value for implicit messages with "urgent" priority	55
5	Get, Set	DSCP Scheduled	USINT	DSCP value for implicit messages with "scheduled" priority	47
6	Get, Set	DSCP High	USINT	DSCP value for implicit messages with "high" priority	43
7	Get, Set	DSCP Low	USINT	DSCP value for implicit messages with "low" priority	31
8	Get, Set	DSCP explicit	USINT	DSCP value for explicit messages with "scheduled" priority	27

Supported services

23664

Service code		Name	Class	Attribute	Description
dec	hex				
01	01	Get_Attribute_All	yes	yes	Read all attribute values
14	0E	Get_Attribute_Single	no	yes	Read single attribute value

IO-Link requests (object class: 0x80)

23121

The manufacturer-specific object "IO-Link Requests" enables read and write access to the IO-Link objects of an IO-Link device connected to a AL1120 via ISDU (Index Service Data Unit). The object projects the mechanisms of the CIP addressing on the IO-Link protocol.

Class attributes

23668

Attr ID	Access	Name	Data type	Description	Value
1	Get	Revision	UINT	Revision of the object	4
2	Get	Max instance	UINT	Max. number of instances of the object	2
6	Get	Maximum ID Number Class Attributes	UINT	Number of instances of the object	8

Instance attributes

23669

The required IO-Link port of the device is addressed via the instance attribute.

Supported services

23670

Service code		Name	Class	Attribute	Description
dec	hex				
75	4B	→ Read_ISDU (→ p. 98)	no	yes	Read ISDU
76	4C	→ Write_ISDU (→ p. 101)	no	yes	Read ISDU

Read_ISDU

23118

With Read_ISDU, parameters of a connected IO-Link device can be read.

Read Request

23702

Attribute determines the IO-Link port to which the IO-Link device is connected. The area "User Specific Service Data" contains the IO-Link index and the IO-Link sub-index of the IO-Link object whose value is to be read:

CIP format	Data type	MSG Config	IO-Link mapping
Class ID	UINT	0x80	IO-Link acyclic access
Instance ID	UINT	0x01	IO-Link master
Attributes	USINT	0x01...0x08	Port number
Service code ID	USINT	0x4B	Read Request (ISDU_Read)
User specific service data	UINT	Index	IO-Link ISDU object index
	USINT	Subindex	IO-Link ISDU object sub-index

Read response

23114

• Positive response

If the service has been executed successfully (Error Code = 0), the read data are returned bit by bit (User Specific Service Data). The answer has the following format:

CIP format	Data type	MSG Config	IO-Link mapping
Class ID	UINT	0x80	IO-Link acyclic access
Instance ID	UINT	1	IO-Link master
Attributes	USINT	1...8	Port number
Service code ID	USINT	0x4C	Read response
Error code	USINT	0	--
Extended error code	USINT	0	--
User specific service data	USINT	e.g. 0xAB	Data (byte 0)
	USINT	e.g. 0xCD	Data (byte 1)
	...		...
	USINT	e.g. 0xEF	Data (byte n)



The read data is in the IO-Link format. If necessary, the user needs to adapt the byte arrangement of the read data to the CIP format.

Appendix

• Negative response

If an error occurs while executing the service (Error Code $\neq$ 0), an extended error code is transmitted. The answer has the following format:

CIP format	Data type	MSG Config	IO-Link mapping
Class ID	UINT	128	IO-Link acyclic access
Instance ID	UINT	1	IO-Link master
Service code ID	USINT	0x4B	Read response
Attributes	USINT	1...8	port number
Error code	USINT	$\neq$ 0	--
Extended error code	USINT	0	--
User specific service data	USINT		IO-Link error code (if error code = 0x1E)
	USINT		Additional code (if error code = 0x1E)

Error code:

Code	Description
0x02	Resource not available: The IO-Link port is busy processing another acyclic service.
0x05	Invalid class ID or instance ID
0x08	Wrong service ID: only service code 0x4B or 0x4C is permitted
0x09	Wrong attribute ID: wrong port number
0x20	Invalid parameter value (e.g. invalid length)
0x1E	Embedded service, error: Error occurred during an IO-Link service. Byte 0 and byte 1 of the User Specific Service Data contain the IO-Link error code and an additional code that are returned by the IO-Link master (see below).

IO-Link error code:

Code	Description
0x00	RESULT_SUCCESS
0x01	RESULT_STATE_CONFLICT
0x02	RESULT_NOT_SUPPORTED
0x03	RESULT_SERVICE_PENDING
0x04	RESULT_WRONG_PARAMETER
0x05	RESULT_NO_COMMUNICATION
0x06	RESULT_MIN_CYCLE_TIME
0x07	RESULT_NO_RESOURCES
0x08	RESULT_ABORT
0x1E	RESULT_UNKNOWN_COMMAND
0x1F	RESULT_NOT_CONNECTED
0x20	RESULT_NOT_ALLOWED
0x21	RESULT_WRONG_LENGTH
0x22	RESULT_WRONG_TYPE

Example: reading the parameter value of an IO-Link device

23110

Task: reading the value of the parameter X of an IO-Link device

- IO-Link device in the port: 0x02
- Parameter X in the object directory of an IO-Link device: Index: 90, sub-index 3

From this, the following results for the configuration of the EtherNet/IP command Message (MSG):

CIP format	Data type	MSG Config	Description
Class ID	UINT	0x80	IO-Link acyclic access
Instance ID	UINT	0x01	IO-Link master
Attributes	USINT	0x02	Port number
Service code ID	USINT	0x4B	Service "ISDU_Read"
User specific service data	UINT	0x005A	IO-Link ISDU object index
	USINT	0x03	IO-Link ISDU object sub-index

After successful execution of the request, the response area has the following content:

CIP format	Data type	MSG Config	Description
Class ID	UINT	0x80	Object class "IO-Link Requests"
Instance ID	UINT	0x01	IO-Link master
Attributes	USINT	0x02	Port number
Service code ID	USINT	0x4B	Service "ISDU_Read"
Error code	USINT	0x00	Request processed successfully
Extended error code	USINT	0x00	--
User specific service data	USINT	e.g. 0x12	Parameter value that has been read (byte 0)
	USINT	e.g. 0x34	Parameter value that has been read (byte 1)

If an error occurs while the request is executed, the response area has the following content:

CIP format	Data type	MSG Config	Description
Class ID	UINT	0x80	Object class "IO-Link Requests"
Instance ID	UINT	0x01	IO-Link master
Attributes	USINT	0x02	Port number
Service code ID	USINT	0x4B	Service "ISDU_Read"
Error code	USINT	9x1E	Error code: Embedded service error
Extended error code	USINT	0x00	--
User specific service data	USINT	e.g. 0x04	IO-Link error code: wrong parameter
	USINT	e.g. 0x27	Additional code

Appendix

Write_ISDU

23111

With Write_ISDU, the parameters of a connected IO-Link device can be changed.

Write Request

23703

Attribute determines the IO-Link port to which the IO-Link device is connected. The area "User Specific Service Data" contains the IO-Link index, the IO-Link sub-index of the IO-Link object whose value is to be changed. It is followed, bit by bit, by the value that is to be assigned to the parameter.

CIP format	Data type	MSG Config	IO-Link mapping
Class	UINT	0x80	IO-Link acyclic access
Instance	UINT	0x1	IO-Link master
Attribute	USINT	0x01...0x08	Port number
Service code ID	USINT	0x4C	Write Request (ISDU_Write)
User specific service data	UINT	Index	IO-Link ISDU object index
	USINT	Subindex	IO-Link ISDU object sub-index
	USINT	e.g. 0xAB	IO-Link ISDU data (byte 0)
	USINT	e.g. 0xBC	IO-Link ISDU data (byte 1)

Write response

23115

- **Positive response**

If the service has been executed successfully (Error Code = 0), the area "User Specific Data" stays empty. The answer has the following format:

CIP format	Data type	MSG Config	IO-Link mapping
Class	UINT	0x80	IO-Link acyclic access
Instance	UINT	0x01	IO-Link master
Attribute	USINT	0x01...0x08	Port number
Service code ID	USINT	0x4C	Service "ISDU_Write"
Error code	USINT	0	--
Extended error code	USINT	0	--

Appendix

• Negative response

If an error occurs while executing the service (Error Code $\neq$ 0), an extended error code is transmitted. The answer has the following format:

CIP format	Data type	MSG Config	IO-Link mapping
Class ID	UINT	128	IO-Link acyclic access
Instance ID	UINT	1	IO-Link master
Service code ID	USINT	0x4B	Read response
Attributes	USINT	1...8	Port number
Error code	USINT	$\neq$ 0	--
Extended error code	USINT	0	--
User specific service data	USINT		IO-Link error code (if error code = 0x1E)
	USINT		Additional code (if error code = 0x1E)

Error code:

Code	description
0x02	Resource not available: The IO-Link port is busy processing another acyclic service.
0x05	Invalid class ID or instance ID
0x08	Wrong service ID: only service code 0x4B or 0x4C is permitted
0x09	Wrong attribute ID: wrong port number
0x20	Invalid parameter value (e.g. invalid length)
0x1E	Embedded service, error: Error occurred during an IO-Link service. Byte 0 and byte 1 of the User Specific Service Data contain the IO-Link error code and an additional code that are returned by the IO-Link master (see below).

IO-Link error code:

Code	description
0x00	RESULT_SUCCESS
0x01	RESULT_STATE_CONFLICT
0x02	RESULT_NOT_SUPPORTED
0x03	RESULT_SERVICE_PENDING
0x04	RESULT_WRONG_PARAMETER
0x05	RESULT_NO_COMMUNICATION
0x06	RESULT_MIN_CYCLE_TIME
0x07	RESULT_NO_RESOURCES
0x08	RESULT_ABORT
0x1E	RESULT_UNKNOWN_COMMAND
0x1F	RESULT_NOT_CONNECTED
0x20	RESULT_NOT_ALLOWED
0x21	RESULT_WRONG_LENGTH
0x22	RESULT_WRONG_TYPE

Example: changing the parameter value of an IO-Link device

23109

Task: changing the parameter X of an IO-Link device

- IO-Link device in the port: 0x03
- Parameter X in the object directory of an IO-Link device: Index: 91, sub-index 5
- new parameter value: 0xABCD

From this, the following results for the configuration of the EtherNet/IP command Message (MSG):

CIP format	Data type	MSG Config	Description
Class ID	UINT	0x80	IO-Link acyclic access
Instance ID	UINT	0x01	IO-Link master
Attributes	USINT	0x03	Port number
Service code ID	USINT	0x4C	Service "ISDU_Write"
User specific service data	UINT	0x005B	IO-Link ISDU object index
	USINT	0x05	IO-Link ISDU object sub-index
	USINT	0xAB	New parameter value (MSB)
	USINT	0xCD	New parameter value (LSB)

After successful execution of the request, the response area has the following content:

CIP format	Data type	MSG Config	Description
Class ID	UINT	0x80	Object class "IO-Link Requests"
Instance ID	UINT	0x01	IO-Link master
Attributes	USINT	0x03	Port number
Service code ID	USINT	0x4B	Service "ISDU_Write"
Error code	USINT	0x00	Request processed successfully
Extended error code	USINT	0x00	--

If an error occurs while the request is executed, the response area has the following content:

CIP format	Data type	MSG Config	Description
Class ID	UINT	0x80	Object class "IO-Link Requests"
Instance ID	UINT	0x01	IO-Link master
Attributes	USINT	0x03	Port number
Service code ID	USINT	0x4B	Service "ISDU_Write"
Error code	USINT	0x1E	Error code: Embedded Service Error
Extended error code	USINT	0x00	--
User specific service data	USINT	e.g. 0x04	IO-Link error code: wrong parameter
	USINT	e.g. 0x27	Additional code

Appendix

TCP/IP object (object class: 0xF5)

23127

TCP/IP Interface Object enables the configuration of the physical network interface of the device.

Class attributes

23647

Attr ID	Access	Name	Data type	Description	Value
1	Get	Revision	UINT	Revision of the object	4
2	Get	Max instance	UINT	Max. number of instances of the object	1

Instance attributes

23650

Attr. ID	Access	Name	Data type	Description	Preset
1	Get	Status	DWORD	Status of the TCP/IP interface	
				Bit 0...3 Configuration status of the interface	
				Bit 4 Mcast pending (always 0)	
				Bit 5 Interface configuration pending	
				Bit 6 ACD Status	
				Bit 7 ACD Fault	
				Bit 8...31 reserved	
2	Get	Configuration Capability	DWORD	Functions of the interface (flags)	0x95 (BOOTP, DHCP Client, TCP/IP configurable, ACD capable)
				Bit 0 BOOTP Client	
				Bit 1 reserved	
				Bit 2 DHCP Client	
				Bit 3 reserved	
				Bit 4 TCP/IP configurable via EtherNet/IP	
				Bit 5 reserved	
				Bit 6 reserved	
				Bit 7 ACD Capable	
				Bit 8...31 reserved	
3	Get/Set	Configuration Control	DWORD	Interface control (control flags):	0
				Bit 0...3 Start-up configuration	
				0 Static IP configuration	
				1 Configuration via BOOTP	
				2 Configuration via DHCP	
				Bit 4 reserved	
				Bit 5...31 reserved	
4	Get	Physical Link Object path	STRUCT:	Logical path to the physical communication interface: the Ethernet Link object	

Appendix

Attr. ID	Access	Name	Data type	Description	Preset
		▪ Path Size	▪ UINT	Length (in Little Endian Format as WORD)	02 00
		▪ Path	▪ Padded EPATH	Path	20 F6 24 01
				Class ID = 0xF6 Ethernet Link Object	
				Instance ID = 1	
5	Get/Set	Interface Configuration	STRUCT:	TCP/IP configuration	
		▪ IP Address	▪ UDINT	IP address	192.168.1.250
		▪ Network mask	▪ UDINT	Subnet mask	255.255.255.0
		▪ Gateway address	▪ UDINT	Default gateway address	0.0.0.0
		▪ Name Server	▪ UDINT	1. Name Server	0.0.0.0
		▪ Name Server 2	▪ UDINT	2. Name Server	0.0.0.0
		▪ Domain Name	▪ STRING	Default domain name	0
6	Get, Set	Host name	STRING	Host name	0
				0 no name configured	
8	Get	TTL value		TTL value	1
9	Get	Mcast Config			0
10	Get/Set	SelectAcd	BOOL	activate ACD	1
				0 deactivate	
				1 activate	
11	Get/Set	Last Conflict Detected	STRUCT:	Structure with information via the latest detected conflict	0
			▪ USINT	Condition of the ACD activity with the latest detected conflict	
				0 Noconflictdelected	
				1 Probelpv4Address	
				2 OngoingDetection	
				3 SemiActiveProbe	
			▪ ARRAY of 6 USINT	MAC address	
			▪ ARRAY of 28 USINT	Copy of the data of the ARP PDU in which the conflict was detected	
13	Get/Set	Encapsulation Inactivity Timeout	UINT	Inactivity before the TCP connection is deactivated (in seconds)	120

Supported services

23666

Service code		Name	Class	Attribute	Description
dec	hex				
01	01	Get_Attribute_All	no	yes	Read all attributes
14	0E	Get_Attribute_Single	yes	yes	Read single attribute
16	10	Set_Attribute_Single	no	yes	Change single attribute

Ethernet Link Object (object class: 0xF6)

23129

The Ethernet Link Object contains status information of the Ethernet interface.

Class attributes

23645

Attr ID	Access	Name	Data type	Description	Value
1	Get	Revision	UINT	Revision of the object	4
2	Get	Max Instance	UINT	Max. number of instances of the object	2
3	Get	Number of Instances	UINT	Number of instances of the object	2

Instance attributes

23646

Attr. ID	Access	Name	Data type	Description	Preset
1	Get	Interface Speed	UDINT	Current data rate (in bytes/s) 10 Mbps,100 Mbps.	100
2	Get	Interface Status Flags	DWORD	Status flag of the interface	0x20
				Bit 0	Link status
				Bit 1	Half/full duplex
				Bit 2...4	Auto negotiation status
				Bit 5	Manual setting requires reset
				Bit 6	Local Hardware Fault
				Bit 7...31	reserved
3	Get	Physical Address	ARRAY of 6 USINTs	MAC address	
4	Get	Interface Counters	STRUCT of 11 UDINTs	Interface-specific counter	
5	Get	Media counters	STRUCT of 12 UDINTs	Medium-specific counter	
6	Get, Set	Interface control	STRUCT of	Control bits: Bit 0: Auto negotiate Bit 1: Forced Duplex Mode (full 1, half 0)	0
				Control bits of the interface	
			WORD	Bit 0	
				0 = auto-negotiation active 1 = auto-negotiation inactive	
				Bit 1	
				0 = Half duplex 1 = Full duplex	
				Bit 2..15	
				reserved	
			UINT	Data rate of the interface	
				10	
				100	
				10 Mbps 100 Mbps	
7	Get	Interface Type	USINT	Physical interface type	2

Appendix

Attr. ID	Access	Name	Data type	Description		Preset
				0	unknown	
				1	Internal interface	
				2	Twisted pair	
				3	Optical fibre	
				4...255	reserved	
8	Get	Interface state	USINT	Current status of the interface		0
				0	unknown	
				1	active; ready for transmission and reception	
				2	not active	
				3	Test mode	
				4...255	reserved	
9	Get	Admin State	USINT	Control of the access to the interface		1
				0	reserved	
				1	Activate interface	
				2	Deactivate interface	
				3...255	reserved	
10	Get	Interface label	SHORT_STRING	Designation of the interface		"X21" (instance 1) "X22" (instance 2)
11	Get	Interface capability	STRUCT of	Capabilities of the interface		
				▪ DWORD	Transmission rate	
			10		10 Mbps	
			100		100 Mbps	
			▪ DWORD	Duplex mode		
				HD	Half duplex	
FD	Full duplex					
300	Get, Set	MDIX	???	MDIX configuration		3
				0		
				1	MDI	
				2	MDIX	
				3	autoMDI	
				4...255	reserved	

Supported services

23665

Service code		Name	Class	Attribute	Description
dec	hex				
01	01	Get_Attribute_All	no	yes	Read all attribute values
14	0E	Get_Attribute_Single	yes	yes	Read single attribute value
16	10	Set_Attribute_Single	no	yes	Change single attribute value

13 Index

A

Acyclic command channel	77
Acyclic commands	81
Acyclic data	77
Acyclic port commands	50
Appendix	61
Application	63
Approvals / tests	64
Assembly Object (object class 0x04)	93

C

CIP class services	89
CIP object classes	89
Class attributes	90, 92, 93, 94, 95, 96, 97, 104, 106
Command 0x10 – set mode	82
Command 0x20 – set validation ID / data storage	84
Command 0x30 – set fail-safe data pattern	86
Command channel	37
Command channels in cyclic process data	49
Command request	82, 84, 86
Command response	83, 85, 87
Communication profile	69
Communication, parameter setting, evaluation	13
Configuration	26
Configuration Assembly	68
Configure AL1120	44
Configure communication profile	34
Configure IO-Link ports	45
Configure the Ethernet interface	33
Configure the interface to the SmartObserver	35
Connect the device	21
Connection Manager Object (object class 0x06)	94
Connection possibilities	28
Cyclic data	71

D

Device Level Ring Object (object class 0x47)	95
Digital inputs	15

E

Electrical connection	17, 65
Electrical data	63
Error detection and elimination	56
Ethernet interface	24
Ethernet Link Object (object class 0xF6)	106
Ethernet ports	18
EtherNet/IP	14, 66
Configure IO-Link devices	47
Configure the device	42
Programmers' notes	47
Read device information	55
EtherNet/IP mechanisms for acyclic commands	50
Example	

changing the parameter value of an IO-Link device	103
reading the parameter value of an IO-Link device	100
Exchange IO-Link device	58
Execute acyclic commands	49

F

Factory Settings	60
Failure codes	80
Field bus objects	88
Firmware update	57
Function	12
Functions and features	11

G

General	9
---------------	---

I

Identity Object (object class 0x01)	90
ifm weltweit • ifm worldwide • ifm à l'échelle internationale	111
ifm_HYDRAULIC_Vxxyzz.Lib	67
Input assembly	72
Input circuit	19
Inputs	63
Inputs / outputs	63
Instance attributes	90, 92, 93, 94, 95, 96, 97, 104, 106
Integrate the AL1120 into the EtherNet/IP network	43
Interfaces	64
IO-Link	14
IO-Link circuits	20
IO-Link ports	19
IO-Link ports (Class A)	25
IO-Link requests (object class 0x80)	97
IO-Link supply	15

L

LED indicators	24
Legal and copyright information	6
LR DEVICE	
Configure IO-Link devices	40
Configure the device	32
Read device information	55

M

Maintenance	59
Mapping	
digital input data (DI)	73
Digital output data (DO)	76
IO-Link port information	74
Status information	73
Mechanical data	65
Message Router Object (object class 0x02)	92
Modification history	7
Mount the device	16
Mounting	16

O

Offline parameter setting	31
---------------------------------	----

Index

Add IO-Link devices manually	41
Operating and display elements	22
Operating conditions	64
Operation	52
Operation with EtherNet/IP connection (without LR DEVICE)	29
Operation with EtherNet/IP connection and LR DEVICE/LR SmartObserver	30
Operation without EtherNet/IP connection	28
Output assembly	76
Outputs	63
Overview	23

P

Parameter data	67
Parameter setting	14
Permitted use	11
PI controller	6
Port configuration	70
Preliminary note	5
Principle of the command channels	49
Process data length	69
Prohibited use	11
Purpose of the document	6

Q

Quality of Service (object class 0x48)	96
--	----

R

Read cyclic input data	48
Read device information	53
Read diagnostic and status information	51
Read Request	98
Read response	98
Read_ISDU	98
Reboot the device	56
Registration of the EDS file	43
Remarks	27
Request channel	78
Required background knowledge	9
Reset IO-Link master to factory settings	39
Response channel	79

S

Safety instructions	8
Safety symbols on the device	10
Set device validation and data storage	37
Set the operating mode of the IO-Link ports	36
Status LEDs	24
Supported configuration options	28
Supported services	91, 92, 93, 94, 95, 96, 97, 105, 107
Symbols and styles used	6

T

Tampering with the unit	10
TCP/IP object (object class 0xF5)	104
Technical data	62

U

UTIL.Lib	67
----------------	----

V

Visual indication	14
Voltage supply	25
VPN connection	31

W

Warnings used	9
Web interface	
Read device and diagnostic information	54
Write cyclic output data	48
Write Request	101
Write response	101
Write_ISDU	101

14 ifm weltweit • ifm worldwide • ifm à l'échelle internationale

Version: 2016-11-29

8310

ifm electronic gmbh • Friedrichstraße 1 • 45128 Essen

www.ifm.com • Email: info@ifm.com

Service hotline: 0800 / 16 16 16 (only Germany, Mo-Fr 07.00...18.00 h)

ifm Niederlassungen • Sales offices • Agences

D	Niederlassung Nord • 31135 Hildesheim • Tel. 0 51 21 / 76 67-0 Niederlassung West • 45128 Essen • Tel. 02 01 / 3 64 75 -0 Niederlassung Mitte-West • 58511 Lüdenscheid • Tel. 0 23 51 / 43 01-0 Niederlassung Süd-West • 64646 Heppenheim • Tel. 0 62 52 / 79 05-0 Niederlassung Baden-Württemberg • 73230 Kirchheim • Tel. 0 70 21 / 80 86-0 Niederlassung Bayern • 82178 Puchheim • Tel. 0 89 / 8 00 91-0 Niederlassung Ost • 07639 Tautenhain • Tel. 0 36 601 / 771-0
A, SL	ifm electronic gmbh • 1120 Wien • Tel. +43 16 17 45 00
AUS	ifm efector Pty Ltd. • Mulgrave Vic 3170 • Tel. +61 3 00 365 088
B, L	ifm electronic N.V. • 1731 Zellik • Tel. +32 2 / 4 81 02 20
BG	ifm electronic eood • 1202 Sofia • Tel. +359 2 807 59 69
BR	ifm electronic Ltda. • 03337-000, Sao Paulo SP • Tel. +55 11 / 2672-1730
CH	ifm electronic ag • 4 624 Härkingen • Tel. +41 62 / 388 80 30
CL	ifm electronic SpA • Oficina 5032 Comuna de Conchalí • Tel. +55 11 / 2672-1730
CN	ifm electronic (Shanghai) Co. Ltd. • 201203 Shanghai • Tel. +86 21 / 3813 4800
CND	ifm efector Canada inc. • Oakville, Ontario L6K 3V3 • Tel. +1 800-441-8246
CZ	ifm electronic spol. s.r.o. • 25243 Průhonice • Tel. +420 267 990 211
DK	ifm electronic a/s • 2605 BROENDBY • Tel. +45 70 20 11 08
E	ifm electronic s.a. • 08820 El Prat de Llobregat • Tel. +34 93 479 30 80
F	ifm electronic s.a. • 93192 Noisy-le-Grand Cedex • Tél. +33 0820 22 30 01
FIN	ifm electronic oy • 00440 Helsinki • Tel. +358 75 329 5000
GB, IRL	ifm electronic Ltd. • Hampton, Middlesex TW12 2HD • Tel. +44 208 / 213-0000
GR	ifm electronic Monoprosopi E.P.E. • 15125 Amaroussio • Tel. +30 210 / 6180090
H	ifm electronic kft. • 9028 Győr • Tel. +36 96 / 518-397
I	ifm electronic s.a. • 20041 Agrate-Brianza (MI) • Tel. +39 039 / 68.99.982
IL	Astragal Ltd. • Azur 58001 • Tel. +972 3 -559 1660
IND	ifm electronic India Branch Office • Kolhapur, 416234 • Tel. +91 231-267 27 70
J	efector co., ltd. • Chiba-shi, Chiba 261-7118 • Tel. +81 043-299-2070
MAL	ifm electronic Pte. Ltd • 47100 Puchong Selangor • Tel. +603 8063 9522
MEX	ifm efector S. de R. L. de C. V. • Monterrey, N. L. 64630 • Tel. +52 81 8040-3535
N	Sivilingeniør J. F. Knudtzen A/S • 1396 Billingstad • Tel. +47 66 / 98 33 50
NA	ifm electronic (pty) Ltd • 25 Dr. W. Kulz Street Windhoek • Tel. +264 61 300984
NL	ifm electronic b.v. • 3843 GA Harderwijk • Tel. +31 341 / 438 438
NZ	ifm efector Pty Ltd • 930 Great South Road Penrose, Auckland • Tel. +64 95 79 69 91
P	ifm electronic s.a. • 4410-136 São Félix da Marinha • Tel. +351 223 / 71 71 08
PL	ifm electronic Sp. z o.o. • 40-106 Katowice • Tel. +48 32-608 74 54
RA, ROU	ifm electronic s.r.l. • 1107 Buenos Aires • Tel. +54 11 / 5353 3436
RO	ifm electronic s.r.l. • Sibiu 557260 • Tel. +40 269 224550
ROK	ifm electronic Ltd. • 140-884 Seoul • Tel. +82 2 / 790 5610
RUS	ifm electronic • 105318 Moscow • Tel. +7 495 921-44-14
S	ifm electronic a b • 41250 Göteborg • Tel. +46 31 / 750 23 00
SGP	ifm electronic Pte. Ltd. • Singapore 609 916 • Tel. +65 6562 8661/2/3
SK	ifm electronic s.r.o. • 835 54 Bratislava • Tel. +421 2 / 44 87 23 29
THA	SCM Alliances Co., Ltd. • Bangkok 10 400 • Tel. +66 02 615 4888
TR	ifm electronic Ltd. Sti. • 34381 Sisli/Istanbul • Tel. +90 212 / 210 50 80
UA	TOV ifm electronic • 02660 Kiev • Tel. +380 44 501 8543
USA	ifm efector inc. • Exton, PA 19341 • Tel. +1 610 / 5 24-2000
VN	ifm electronic • Ho Chi Minh city 700000 • Tel. +84-8-35125177
ZA	ifm electronic (Pty) Ltd. • 0157 Pretoria • Tel. +27 12 345 44 49

Technische Änderungen behalten wir uns ohne vorherige Ankündigung vor.

We reserve the right to make technical alterations without prior notice.

Nous nous réservons le droit de modifier les données techniques sans préavis.