




Device manual  
Ethernet camera  
for mobile applications

UK

**efector 250<sup>®</sup>**

**O2M113**



## Content

1 Preliminary note . . . . .	3
1.1 Symbols used . . . . .	3
1.2 Warning signs used . . . . .	3
2 Safety instructions . . . . .	4
2.1. General . . . . .	4
2.2 Target group . . . . .	4
2.3 Electrical connection . . . . .	4
2.4 Tampering with the unit . . . . .	4
3 Functions and features . . . . .	5
3.1 Features at a glance . . . . .	5
4 Mounting . . . . .	5
4.1 Mounting accessories . . . . .	5
4.2 Mounting dimensions . . . . .	6
4.3 Mounting location . . . . .	6
5 Electrical connection . . . . .	7
5.1 Ethernet camera . . . . .	7
5.1.1 Ethernet connection . . . . .	7
5.1.2 Interference due to external influences . . . . .	7
5.2 PC / notebook . . . . .	8
5.3. Connection without hub / switch . . . . .	9
5.4 Connection with hub / switch . . . . .	10
6 Operation display . . . . .	11
7 Set-up . . . . .	12
7.1 IP addresses . . . . .	12
7.2 IP address allocation cameras . . . . .	12
7.2.1 Checking the IP address . . . . .	17
8 Technical data . . . . .	18
9 Maintenance, repair and disposal . . . . .	19
10 Approvals / standards . . . . .	19

### Licences and trademarks



Microsoft®, Windows®, Windows XP® and Windows Vista® are registered trademarks of Microsoft Corporation. All trademarks and company names are subject to the copyright of the respective companies.

### Open source software

This unit contains (maybe modified) Open Source software, which is subject to special licensing terms. For copyright information and licensing terms please refer to: [www.ifm.com/int/GNU](http://www.ifm.com/int/GNU)  
For software subject to the GNU General Public License or the GNU Lesser General Public License the source code can be requested against payment of the copying and shipping costs.

# 1 Preliminary note

## 1.1 Symbols used

- ▶ Instruction
- > Reaction, result
- [...] Designation of pushbuttons, buttons or indications
- Cross-reference
-  Important note  
Non-compliance can result in malfunctions or interference.
-  Information  
Supplementary note

UK

## 1.2 Warning signs used

### WARNING

Warning of serious personal injury.  
Death or serious irreversible injuries may result.

### CAUTION

Warning of personal injury.  
Slight reversible injuries may result.

### NOTE

Warning of damage to property.

## **2 Safety instructions**

### **2.1. General**

These instructions are part of the device. It contains information and illustrations about the correct handling of the device and must be read before installation or use

Observe the operating instructions. Non-observance of the instructions, operation which is not in accordance with use as prescribed below, wrong installation or incorrect handling can seriously affect the safety of people and machinery.

### **2.2 Target group**

These instructions are intended for authorised persons according to the EMC and low-voltage directives. The device must only be installed, connected and put into operation by a qualified electrician.

### **2.3 Electrical connection**

Disconnect the device externally before handling it. If necessary, also disconnect any independently supplied output load circuits.

If the device is not supplied by the mobile on-board system (12/24 V battery operation), it must be ensured that the external voltage is generated and supplied according to the criteria for safety extra-low voltage (SELV) as this voltage is supplied without further measures to the connected controller, the sensors and the actuators.

The wiring of all signals in connection with the SELV circuit of the device must also comply with the SELV criteria (safety extra-low voltage, safe electrical separation from other electric circuits).

If the supplied SELV voltage is externally grounded (SELV becomes PELV), the responsibility lies with the user and the respective national installation regulations must be complied with. All statements in this document refer to the device the SELV voltage of which is not grounded.

The connection terminals may only be supplied with the signals indicated in the technical data and/or on the device label and only the approved accessories of ifm electronic gmbh may be connected.

### **2.4 Tampering with the unit**

In case of malfunctions or uncertainties please contact the manufacturer.

Tampering with the unit can seriously affect the safety of operators and machinery. It is not permitted and leads to the exclusion of any liability and warranty claims.

### 3 Functions and features

The Ethernet camera serves for monitoring of areas outside of the field of view in mobile vehicles and utility vehicles. Connection, control and visualisation of the images is carried out via a process and dialogue module with colour display.

The camera operates as a server and permanently transmits images to the connected dialogue module.

Applications are for example:

- Rear area or blind spot monitoring for municipal vehicles
- Machine monitoring in construction machinery
- Rear view camera on vehicles

UK

#### 3.1 Features at a glance


- 10/100 Mbit/s Ethernet interface  
(10Base-T/100Base-TX according to IEEE 802.3/802.3u)
- Sealed diecast zinc housing
- Protection rating IP 69K
- Regulated lens heating (can be deactivated)
- CMOS image sensor, resolution ¼ VGA, 320 x 240 pixels
- Angle of aperture 115°
- Operation display via integrated LED

### 4 Mounting

#### 4.1 Mounting accessories

The device is supplied without mounting accessories.

Depending on the intended location and type of mounting the following mounting accessories are available:

Mounting accessories (examples)		Art. no.
	Mounting set for shaft Ø 12 mm (clamp cylinder and fixing element for the types O2D, O2M)	E2D110
	Shaft, straight Ø 12 mm, length 130 mm, M10	E20938
	Shaft, angled Ø 12 mm, length 200 mm, M10	E20940
	Mounting set for shaft Ø 14 mm (clamp cylinder and fixing element for the types O2D, O2M)	E2D112
	Shaft, straight Ø 14 mm, length 130 mm, M12	E20939
	Shaft, angled Ø 14 mm, length 200 mm, M12	E20941

You can find more information about the available accessories at:

[www.ifm.com](http://www.ifm.com) → Data sheet direct → e.g. E2D110

## 4.2 Mounting dimensions


Mounting is done using two M4 x L screws.

Mounting dimensions of the camera → 8 Technical data (data sheet).

## 4.3 Mounting location

► Mount the camera in front of or above the area to be monitored.

The size of the area to be monitored depends on the operating distance:






operating distance and field of view size

1. operating distance [m]
2. width of field of view [m]
3. height of field of view [m]

- To avoid adverse effects on the image detection, avoid installation in heavily polluting areas of the machine (e.g. splashing water, tyre abrasion, etc.).
- Avoid back light.
- Do not position lighting elements directly facing the camera lens.
- Mount the device in such a way that the cables / connectors are connected from below.
- The connected cables must be provided with a strain relief.

## 5 Electrical connection

### 5.1 Ethernet camera

	Supply voltage (1)									
	M12 connector, A-coded, 4 poles									
		<table><tr><td>1</td><td>8...32 V DC</td></tr><tr><td>2</td><td>n.c.</td></tr><tr><td>3</td><td>0 V</td></tr><tr><td>4</td><td>n.c.</td></tr></table>	1	8...32 V DC	2	n.c.	3	0 V	4	n.c.
	1	8...32 V DC								
	2	n.c.								
3	0 V									
4	n.c.									
Ethernet (2)										
M12 socket, D-coded, 4 poles										
	<table><tr><td>1</td><td>Ethernet TxD +</td></tr><tr><td>2</td><td>Ethernet RxD +</td></tr><tr><td>3</td><td>Ethernet TxD -</td></tr><tr><td>4</td><td>Ethernet RxD -</td></tr></table>	1	Ethernet TxD +	2	Ethernet RxD +	3	Ethernet TxD -	4	Ethernet RxD -	
1	Ethernet TxD +									
2	Ethernet RxD +									
3	Ethernet TxD -									
4	Ethernet RxD -									

UK

For information about available connectors please go to:

[www.ifm.com](http://www.ifm.com) → Products → Accessories → Connection technology → Selector



The supply voltage is electrically separated from the housing.

#### 5.1.1 Ethernet connection

- ▶ Use a shielded CAT5 cable.  
(STP, Shielded Twisted Pair, according to EIA/TIA-568). Max. length 100 m
- ▶ Use screened connector housings
- ▶ Connect the screen of the Ethernet cable to the connector housing.
- ▶ Avoid transmission problems caused by induction.
- ▶ Do not lay the Ethernet connection cable in parallel to current-carrying cables.
- ▶ Lay supply and signal cables away from the camera using the shortest possible route.


#### 5.1.2 Interference due to external influences



Faulty or insufficient radio interference suppressors in electrical equipment, such as inverters or generators, as well as voltage fluctuations when switching on/off electric loads may lead to problems with the image transmission.

## 5.2 PC / notebook

Connection to a PC or to a notebook may be necessary for service purposes (e.g. setting of the IP address).

Ethernet interface		
8-pole RJ45 connector		
	1	TxD+ Pair 1
	2	TxD- "
	3	RxD+ Pair 2
	6	RxD- "




The IP address range (Net ID) of the PC must correspond to the IP address range of the camera. For the PC / notebook the setting is carried out in the Control Panel → Network Connections → Properties.

(also see → 7.2 IP address allocation Ethernet cameras)



### 5.3. Connection without hub / switch

- Use a crosslink cable.



UK


Connection principle without hub / switch

One camera at a display or at a PC / notebook (e.g. service mode)



Crosslink cable = crossover cable = for the direct connection of network participants

Crosslink cable principle




Cross link cable (example)	Art. no.
Ethernet connection cable, 2 m M12 connector (4 poles, D coded) - RJ45 (8 poles)	E11898

For further information about the connector go to:

[www.ifm.com](http://www.ifm.com) → Data sheet direct: → E11898

## 5.4 Connection with hub / switch

- Use a patch cable.




Connection principle with hub / switch  
Several cameras at one display



Patch cable = uncrossed cable = 1:1 wiring = straight-through cable = point-to-point

Patch cable principle




- Adhere to the documentation of the switch manufacturer.



Some switches have an "autocrossing" function.  
The transmit and receive wires are automatically recognised by these devices.

In this case, 1:1 patch cables are not compulsory.

## 6 Operation display

	LED green (1)	
	Status	Description
	ON	supply voltage ok camera ready for operation
	OFF	no supply voltage power supply interrupted

Operation display O2M113

## 7 Set-up

### 7.1 IP addresses


The address ranges of all network participants must be identical. This range of the IP address is also called Net ID.

Network participant	Address range (Net ID)	Host ID
Ethernet camera *	192.168.82	<b>15</b>
Display (example)		<b>247</b>
PC / notebook (example)		<b>100</b>

\*) Factory setting (subnet mask 255.255.255.0, class C)

### 7.2 IP address allocation cameras

- When using several cameras, set the IP addresses of the cameras via the "Hypertext Transfer Protocol" (HTTP).  
To do so, use standard programs such as Microsoft Internet Explorer, Mozilla Firefox or Opera.



IP address allocation when using 4 cameras (example)

Ethernet camera 1	192.168.82.15 (factory setting)
Ethernet camera 2	192.168.82.16
Ethernet camera 3	192.168.82.17
Ethernet camera 4	192.168.82.18
Display	192.168.82.247

Procedure:

- Check the IP settings of the PC / notebook and change them if necessary.  
Internet protocol: TCP / IP  
IP address: 192.168.82.xxx (except 15)

Subnet mask: 255.255.255.0


Gateway IP address: 192.168.82.15

Speed and duplex: automatically (auto negotiation)

The settings of the LAN connection and the configuration of the network adapter can be found at: Start → Control → Network Connections → LAN connection.

- ▶ Establish an Ethernet connection between the camera and the PC / notebook.
- ▶ Connect the camera to supply voltage.  
Do not interrupt the supply voltage during IP address allocation!  
Avoid voltage fluctuations during IP address allocation!
- ▶ Open the internet browser.
- ▶ Enter the preset IP address of the camera in the address line of the browser and confirm with [Enter] (http://192.168.82.15/).
- > In the browser appears the "O2M1xxx WebConfig" start window.
- ▶ Click on [Change IP address]

UK



Start window "O2M1xx WebConfig"

- Enter the new address in the field [IP address] and click on [Submit] to send it to the camera.

ifm O2M1xx WebConfig - Mozilla Firefox

Datei Bearbeiten Ansicht Chronik Lesezeichen Extras Hilfe

http://192.168.82.15/ Google

**ifm electronic** **O2M1xx WebConfig**

## O2M1xx IP Configuration

IP Address  
192.168.82.16

Netmask  
255.255.255.0

Gateway  
192.168.82.201

☒ Force Ethernet Speed

☐ 100Mbit-HD

☐ 100Mbit-FD

☒ Auto-negotiation

Submit

[Back](#)

Fertig

O2M1xx IP configuration




The factory settings in [Netmask], [Gateway] and [Force Ethernet Speed] can be adopted.

- > A confirmation appears if the address was successfully written to the flash memory of the camera.

ifm O2M1xx WebConfig - Mozilla Firefox

Datei Bearbeiten Ansicht Chronik Lesezeichen Extras Hilfe

http://192.168.82.15/ Google

 **O2M1xx WebConfig**

**O2M1xx IP Configuration**

IP Address  
192.168.82.16

Netmask  
255.255.255.0

Gateway  
192.168.82.201


☒ Force Ethernet Speed

☐ 100Mbit-HD

☐ 100Mbit-FD

☒ Auto-negotiation

Submit

Changes saved and will be activated at restart. 

[Reboot](#)

[Back](#)

Fertig

UK

Confirmation of the address change

- > An error message appears if you have tried to send an invalid address to the camera.

ifm O2M1xx WebConfig - Mozilla Firefox

Datei Bearbeiten Ansicht Chronik Lesezeichen Extras Hilfe

http://192.168.82.15/ Google

**ifm electronic** **O2M1xx WebConfig**

## O2M1xx IP Configuration

IP Address  
192.168.2.16 192.928.2.xx is not a valid ip address! ←

Netmask  
255.255.255.0

Gateway  
192.168.82.201

☒ Force Ethernet Speed

☐ 100Mbit-HD

☐ 100Mbit-FD

☒ Auto-negotiation

Submit

[Back](#)

Fertig

Error message in case of invalid IP address (e.g. wrong address range)

- In case of an error message correct the entered IP address and send it again to the camera with [Submit].




## 7.2.1 Checking the IP address



An inadvertent, wrong address allocation makes subsequent communication with the camera impossible. For this reason, the following final test must be carried out.

- ▶ Click on [Reboot].
- ▶ Enter the new IP address of the camera in the address line of the browser and confirm with [Enter] (here e.g.: <http://192.168.82.16/>).



UK

Reboot request to check the allocated IP address

- > If the address corresponds to the previously allocated address, the "O2M1xxx WebConfig" start window appears again.



The new camera IP address will become effective on reboot.  
(camera supply voltage off/on).

- ▶ Repeat chapters 7.2 and 7.2.1 with further cameras.


## 8 Technical data

### O2M113

Ethernet camera

Angle of aperture 115°

Lens heating



#### Electrical design

Operating distance	[m]
Field of view size	[m]

Operating voltage	[V]
Power consumption	[W]
Lens heating	[W]

Type of sensor	
Image repetition rate	[Hz]
Protocol	
Data format	

Readiness for operation	[LED]
Operating temperature	[°C]
Storage temperature	[°C]

Protection	
Standards, tests	
Materials	

Interface	
Transmission rate	
IP address (default)	

Wiring

#### DC

-	1	2	5	-	-
-	3.1 x 1.8	6.2 x 3.7	15.7 x 9.3	-	-

8...32 DC

typ. 4 (excl. lens heating)

typ. 6

CMOS image sensor colour, QVGA resolution 320 x 240

min. 15

image transmission via UDP/IP  
8-bit Windows® bitmap format / image format QVGA

green

-30...75

-40...85

IP 69K, III

DIN EN 61326 / IEC 60255-5 / DIN EN 61373 cat. 1B / Automotive Directive 05/49/EC (e1)

housing: diecast zinc / coating: cathodic dip painting (KTL)  
front lens: glass

Ethernet 10Base-T / 100Base-TX

10/100 Mbits/s (adjustable)

192.168.82.15

#### Power supply connection: M12, 4-pole

1: U+  
2: not connected  
3: 0 V  
4: not connected

#### Parameter setting connection: M12, 4-pole, D-coded

1: TD+  
2: RD+  
3: TD-  
4: RD-

## 9 Maintenance, repair and disposal



Keep the lens window of the camera free from soiling.  
Soiling may considerably affect the image quality!

- ▶ To clean the lens window, do not use any detergents or solvents which might damage the front glass.
- ▶ Do not open the housing, as the device does not contain any components which must be maintained by the user. The device must only be repaired by the manufacturer.
- ▶ Dispose of the device in accordance with the national environmental regulations.

**UK**

## 10 Approvals / standards

Test standards and regulations → 8 Technical data.