



EtherNet/IP®

Programming Manual  
AS-i Gateway AC14  
with fieldbus interfaces

AC1401/02  
AC1411/12  
AC1421/22

Firmware release: 4.2.x  
CODESYS release: 3.5.9.73 or higher

English

## Contents

<b>1</b>	<b>Preliminary note</b>	<b>4</b>
1.1	Legal and copyright information .....	4
1.2	Purpose of the document .....	4
1.3	Symbols and styles used .....	5
1.4	Overview: User documentation for AS-i Gateway AC14 .....	5
1.5	Overview: CODESYS documentation of 3S .....	6
1.6	Modification history .....	6
<b>2</b>	<b>Safety instructions</b>	<b>7</b>
2.1	General safety instructions .....	7
2.2	Required background knowledge .....	7
2.3	Warnings used .....	8
<b>3</b>	<b>System requirements</b>	<b>9</b>
3.1	Hardware .....	9
3.2	Software .....	9
3.3	Licensing .....	10
<b>4</b>	<b>Installation</b>	<b>11</b>
4.1	CODESYS programming software .....	11
4.1.1	Install CODESYS Development System .....	11
4.2	ifm AS-i Package .....	12
4.2.1	Components of the ifm package .....	12
4.2.2	Install the ifm package .....	13
4.2.3	Update ifm package .....	13
4.2.4	Uninstall the ifm package .....	14
<b>5</b>	<b>Getting started</b>	<b>15</b>
5.1	Create CODESYS project .....	16
5.1.1	Create new project with AS-i Gateway AC14 .....	17
5.1.2	Overview: Project structure with AS-i Gateway AC14 .....	18
5.2	Use CODESYS online help .....	19
5.3	Set the programming interface .....	20
5.3.1	Set communication path to PLC .....	20
<b>6</b>	<b>System configuration</b>	<b>21</b>
6.1	Configure PLC .....	21
6.2	Configure Ethernet interface .....	22
6.2.1	Available fieldbus stacks .....	22
6.2.2	Add fieldbus stack .....	23
<b>7</b>	<b>Programming</b>	<b>24</b>
7.1	Objects of a PLC application .....	24
7.2	Create PLC application .....	25
7.2.1	Use remanent variables .....	25
7.2.2	Supported programming languages .....	26
7.2.3	Change system time of the device .....	26

<b>7.3</b>	<b>Access input and output data.....</b>	<b>27</b>
7.3.1	Options to access input and output data .....	27
7.3.2	Validity of the interface data .....	28
7.3.3	Process data of the AS-i slaves.....	29
7.3.4	Fieldbus data.....	31
<b>7.4</b>	<b>Use functions of the ifm package.....</b>	<b>33</b>
7.4.1	Control interface of the ifm function blocks.....	33
7.4.2	Configure system .....	35
7.4.3	Configure AS-i master .....	35
7.4.4	Configure AS-i slaves .....	35
7.4.5	Manage AS-i network .....	36
7.4.6	Send commands to the system and the AS-i master.....	39
<b>7.5</b>	<b>Use visualisations .....</b>	<b>40</b>
7.5.1	Supported visualisation types.....	40
7.5.2	Add visualisation to a project.....	41
7.5.3	Create a visualisation .....	42
7.5.4	Configure visualisation .....	43
<b>7.6</b>	<b>Configure task processing .....</b>	<b>45</b>
7.6.1	Configure main task .....	45
7.6.2	Set parameters for visualisation task.....	45
<b>7.7</b>	<b>Testing the PLC application .....</b>	<b>46</b>
<b>8</b>	<b>Operation</b>	<b>47</b>
<b>8.1</b>	<b>Transfer CODESYS project to device.....</b>	<b>48</b>
8.1.1	Activate CODESYS PLC .....	49
8.1.2	Download the application to the device .....	50
8.1.3	Delete application from AS-i Gateway AC14 .....	50
8.1.4	Delete boot application via SD card .....	51
<b>8.2</b>	<b>Operating states of the PLC.....</b>	<b>52</b>
8.2.1	Operating mode of the PLC .....	52
8.2.2	States of the PLC application .....	52
8.2.3	Switch operating states .....	53
<b>8.3</b>	<b>Reset.....</b>	<b>54</b>
8.3.1	Supported reset variants .....	54
8.3.2	Reset the application (warm) .....	55
8.3.3	Reset the application (cold) .....	55
8.3.4	Reset the application (origin) .....	55
<b>8.4</b>	<b>Display web visualisation .....</b>	<b>56</b>
<b>8.5</b>	<b>Display target visualisation .....</b>	<b>57</b>
<b>9</b>	<b>Appendix</b>	<b>58</b>
<b>9.1</b>	<b>Library ACnnnn_Utils.library .....</b>	<b>59</b>
9.1.1	Overview: AS-i functions (FB_ASi) .....	60
9.1.2	Overview: System functions (FB_System) .....	106
9.1.3	Enumeration types and complex variables .....	113
<b>9.2</b>	<b>Library ACnnnn_SYS_CMD.library .....</b>	<b>121</b>
9.2.1	ACnnnn_SysCmd .....	121
<b>10</b>	<b>Index</b>	<b>129</b>
<b>11</b>	<b>ifm weltweit • ifm worldwide • ifm à l'échelle internationale</b>	<b>131</b>

# 1 Preliminary note

## Contents

Legal and copyright information .....	4
Purpose of the document .....	4
Symbols and styles used .....	5
Overview: User documentation for AS-i Gateway AC14 .....	5
Overview: CODESYS documentation of 3S .....	6
Modification history .....	6

14801

## 1.1 Legal and copyright information

1631

© All rights reserved by **ifm electronic gmbh**. No part of this manual may be reproduced and used without the consent of **ifm electronic gmbh**.

- All product names, pictures, companies or other brands used on our pages are the property of the respective rights owners:
- AS-i is the property of the AS-International Association, (→ [www.as-interface.net](http://www.as-interface.net))
- CAN is the property of the CiA (CAN in Automation e.V.), Germany (→ [www.can-cia.org](http://www.can-cia.org))
- CODESYS™ is the property of the 3S – Smart Software Solutions GmbH, Germany (→ [www.codesys.com](http://www.codesys.com))
- DeviceNet™ is the property of the ODVA™ (Open DeviceNet Vendor Association), USA (→ [www.odva.org](http://www.odva.org))
- EtherNet/IP® is the property of the →ODVA™
- EtherCAT® is a registered trade mark and patented technology, licensed by Beckhoff Automation GmbH, Germany
- IO-Link® (→ [www.io-link.com](http://www.io-link.com)) is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- ISOBUS is the property of the AEF – Agricultural Industry Electronics Foundation e.V., Deutschland (→ [www.aef-online.org](http://www.aef-online.org))
- Microsoft® is the property of the Microsoft Corporation, USA (→ [www.microsoft.com](http://www.microsoft.com))
- PROFIBUS® is the property of the PROFIBUS Nutzerorganisation e.V., Germany (→ [www.profibus.com](http://www.profibus.com))
- PROFINET® is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- Windows® is the property of the →Microsoft Corporation, USA

## 1.2 Purpose of the document

18872

This document applies to the following devices of the type "AS-i Gateway AC14":

- AS-i Gateway AC14 with Profinet device interface (AC1401/AC1402)
- AS-i Gateway AC14 with Profibus slave interface (AC1411/AC1412)
- SmartSPS AC14 with EtherNet/IP device interface (AC1421/AC1422)

It is part of the device and contains information about the correct handling of the product.

- Read this document before using the device.
- Keep this document during the service life of the device.

## 1.3 Symbols and styles used

13839

- ▶ ... Instructions
- > ... Reaction, result
- ... Cross-reference or internet link
- 123 Decimal number
- 0x123 Hexadecimal number
- 0b010 Binary number
- [...] Designation of pushbuttons, buttons or indications

## 1.4 Overview: User documentation for AS-i Gateway AC14

6998

ifm electronic provides the following user documentation for the models of the device class "AS-i Gateway AC14":

Document	Content / Description
Data sheet	Technical data of the device as a table
Operating instructions *	<ul style="list-style-type: none"> <li>▪ Notes on mounting and electrical installation of the device</li> <li>▪ Set-up, description of the operating and display elements, maintenance information, scale drawing</li> </ul>
Device manual	<ul style="list-style-type: none"> <li>▪ Notes on operation of the device via GUI and web interface</li> <li>▪ Error elimination</li> <li>▪ Description of the fieldbus data</li> </ul>
Supplement device manual	<ul style="list-style-type: none"> <li>▪ Description of the acyclic data sets and the command interface</li> </ul>
Programming manual	<ul style="list-style-type: none"> <li>▪ Creation of a project with the device using CODESYS</li> <li>▪ Configuration of the device using CODESYS</li> <li>▪ Programming of the PLC of the device</li> <li>▪ Description of the device-specific CODESYS function libraries</li> </ul>

\*... The operating instructions are supplied with the device.



The user can download all documents from the ifm website.

## 1.5 Overview: CODESYS documentation of 3S

18296

3S GmbH provides the following user documentation for programming PLC of AC4S:

Document	Content / Description
Online help	<ul style="list-style-type: none"> <li>▪ Context-sensitive help</li> <li>▪ Description of the CODESYS programming system</li> <li>▪ Description of components and function libraries</li> </ul>
CODESYS installation and first steps	<ul style="list-style-type: none"> <li>▪ Remarks about the installing of the CODESYS programming system</li> <li>▪ First steps for handling the CODESYS programming system</li> </ul>

After the installation of the CODESYS 3.5 programming system all documents are stored on the hard disk of the PC/laptop and can be accessed:

- Online help:  
... \Program Files\3S CoDeSys\CoDeSys\Online-Help
- CODESYS installation and first steps:  
... \Program Files\3S CoDeSys\CoDeSys\Documentation

## 1.6 Modification history

21676

Version	Topic	Date
00	New creation of document	xx/201x

## 2 Safety instructions

### Contents

General safety instructions .....	7
Required background knowledge .....	7
Warnings used.....	8

213

### 2.1 General safety instructions

8516

Read this document before setting up the product and keep it during the entire service life.

Only use the product for its intended purpose.

If the operating instructions or the technical data are not adhered to, personal injury and/or damage to property may occur.

Improper or non-intended use may lead to malfunctions of the device, to unwanted effects in the application or to a loss of the warranty claims.

The manufacturer assumes no liability for any consequences caused by tampering with the device or incorrect use by the operator.

- Observe these operating instructions.
- Adhere to the warning notes on the product.

### 2.2 Required background knowledge

13323

This document is intended for people with knowledge of control technology and PLC programming to IEC 61131-3.

To program the PLC, these people should also be familiar with the CODESYS software.

This document is intended for specialists. Specialists are people who, based on their relevant training and experience, are capable of identifying risks and avoiding potential hazards that may be caused during operation or maintenance of the product. The document contains information about the correct handling of the product.

- Read this document before use to familiarise yourself with operating conditions, installation and operation. Keep this document during the entire duration of use of the device.
- Follow the safety instructions.

## 2.3 Warnings used

13685

### **WARNING**

Death or serious irreversible injuries may result.

### **CAUTION**

Slight reversible injuries may result.

### **NOTICE**

Property damage is to be expected or may result.



Important note  
Non-compliance may result in malfunction or interference.



Information  
Supplementary note.

## 3 System requirements

### Contents

Hardware .....	9
Software.....	9
Licensing.....	10

16903

### 3.1 Hardware

16904

- Device of the AS-i Gateway AC14 product family with firmware V4.2.x
- PC/laptop for CODESYS development system (→ system requirements CODESYS development system V3.x)
- Ethernet connection between CODESYS-PC/laptop and configuration interface (X3) of the device

### 3.2 Software

16905

To program the device-internal PLC of the AS-i Gateway AC14, the following software components are required:

Component	Description	Release
CODESYS Development System	Programming software CODESYS Development System für PLC programming according to norm IEC 61131-3	3.5 SP9 Patch 7 Hotfix 3
Package "CODESYS for ifm SmartPLC StandardLine"	<ul style="list-style-type: none"> <li>▪ Device and interface description of AS-i Gateway AC14</li> <li>▪ Function libraries for programming of the PLC</li> </ul>	1.6.4.14



The assured characteristics and functions described in this manual are only accessible with the indicated releases of the software components!

ifm electronic provides the software components for downloading on its website:  
→ [www.ifm.com](http://www.ifm.com) > Service > Download > Industrial communication

### 3.3 Licensing

16906

All models of the device family AS-i Gateway AC14, to be programmed using the CODESYS Development System 3.5 SP9 Patch 7 Hotfix 3, must be licensed. A valid license label can be purchased from ifm electronic.

Article description	Article no.
1x CODESYS V3 license AS-i Gateway AC14	E71400

-  Use of the device-internal CODESYS PLC of AS-i Gateway AC14 without valid license constitutes a violation of applicable law!

## 4 Installation

### Contents

CODESYS programming software .....	11
ifm AS-i Package .....	12

17146

### 4.1 CODESYS programming software

7282

The CODESYS Development System (short: CODESYS) is a platform for the creation of PLC applications according to the standard IEC 61131-3.

#### 4.1.1 Install CODESYS Development System

18596

To install the software "CODESYS Development System":

- Install the programming system CODESYS 3.5 SP9 Patch 7 Hotfix 3 (→ CODESYS installation and first steps).
- > CODESYS 3.5 SP9 Patch 7 Hotfix 3 is installed on the programming PC/laptop.

## 4.2 ifm AS-i Package

### Contents

Components of the ifm package .....	12
Install the ifm package .....	13
Update ifm package .....	13
Uninstall the ifm package .....	14

17679



- ▶ Familiarise yourself with the following CODESYS functions!
  - Package Manager  
→ Online help > CODESYS Development System > Manage packages and licences

### 4.2.1 Components of the ifm package

17552

To program the AS-i Gateway AC14, ifm provides the CODESYS package "CODESYS for ifm SmartPLC StandardLine" (short: ifm package). The ifm package (file: `ifm_SmartPLC_StandardLine_V1_6_4_14.package`) contains the following components:

Component	Description
AC14SL.devdesc.xml	Device description of the basic module
ACnnnn_EthernetAdapterSL.devdesc.xml	Device description of Ethernet interface
ACnnnn_Modbus_Master.devdesc.xml	Device description of the Modbus master (extension of the Ethernet interface)
ACnnnn_Modbus_Slave.devdesc.xml	Device description of the Modbus slave device (extension of the Ethernet interface)
ACnnnn_Utils.library	Function library with AS-i Gateway AC14 specific CODESYS function blocks and data structures
ACnnnn_SYS_CMD.library	Function library with function block for access to the command interface of AS-i Gateway AC14 from a CODESYS application
AC14SL.template	Template for AC14 StandardLine
AC14SL.template.project	Template for AC14 StandardLine project
AC14.ico	Symbol image of the AC14

## 4.2.2 Install the ifm package

7283

To install the package "CODESYS for ifm SmartPLC StandardLine":

**Requirements:**

- > CODESYS 3.5 SP9 Patch 7 Hotfix 3 is installed on the programming PC/notebook.

**1 Start CODESYS**

- Start CODESYS with administrator rights.
- > CODESYS programming interface appears.

**2 Install the ifm package in CODESYS**

- Select [Tools] > [Package Manager].
- > Window [Package Manager] is displayed.
- Click on [Install...] to start the installation dialogue.
- Select the downloaded ifm package and carry out a complete installation.
- > The [Package Manager] window displays the installed ifm package.
- Press [Exit] to close the package manager.

## 4.2.3 Update ifm package

12267

To update an installed package "CODESYS for ifm SmartPLC StandardLine":

**1 Download new version of the ifm package**

- Got to the product page of the device on the ifm website.
- Download ifm\_SmartPLC\_StandardLine\_V1\_6\_4\_14.package and save it on the CODESYS PC/laptop.

**2 Uninstall the old version of the ifm package**

- → **Uninstall the ifm package** (→ p. [14](#))

**3 Install a new version of the ifm package**

- → **Install the ifm package** (→ p. [13](#))

**4 Update device libraries**

- In the device tree: Click on [Device (ifm\_SmartPLC\_StandardLine)].
- Select [Project] > [Update Device].
- > [Update Device] windows appears.
- Click on [Update Device] to start the update process.
- > New device libraries are loaded.
- > Project tree view is updated.
- Click on [Exit] to close the Package Manager.
- Save the project.

## 4.2.4 Uninstall the ifm package

12270

To uninstall the package "CODESYS for ifm SmartPLC StandardLine":

**1 Start CODESYS**

- ▶ Start CODESYS with administrator rights.
- > CODESYS programming interface appears.

**2 Uninstall the ifm package**

- ▶ Select [Tools] > [Package Manager] to access the package manager.
- > Window [Package Manager] shows the installed packages.
- ▶ Activate [Display version] checkbox.
- > The window shows the version numbers of the installed packages.
- ▶ Select the package version to be uninstalled
- ▶ Click on [Uninstall...] to uninstall the selected package.
- > The selected package version is uninstalled.
- ▶ Click on [Exit] to close the Package Manager.

## 5 Getting started

### Contents

Create CODESYS project .....	16
Use CODESYS online help .....	19
Set the programming interface .....	20

15858

© ifm electronic gmbh



## 5.1 Create CODESYS project

### Contents

Create new project with AS-i Gateway AC14.....	17
Overview: Project structure with AS-i Gateway AC14.....	18

17129



- ▶ Familiarise yourself with the following CODESYS functions!
  - Create CODESYS project  
→ Online help > CODESYS Development System > Create and configure project
  - Objects of the user interface  
→ Online help > CODESYS Development System > Reference user interface

## 5.1.1 Create new project with AS-i Gateway AC14

17682




To avoid errors during manual system configuration, it is explicitly recommended to use the project template from ifm electronic when creating the AS-i Gateway AC14 project in CODESYS.

### Qualifications

- > All required software components are correctly installed (→ **Installation** (→ p. [11](#))).
- > CODESYS successfully started.

#### 1 Create a new project

- Select [File] > [New Project...].
- > The window to enter the project properties appears:



- Set the following values:
  1. [Templates]: Select [ifm\_SmartPLC\_StandardLine Projekt].
  2. [Name]: Enter project name
  3. [Location]: Select the storage location of the project file.
- Click on [OK] to verify the entered values.
- > CODESYS creates a new project with AS-i Gateway AC14.
- > The window [Devices] shows the device tree of the project (→ **Overview: Project structure with AS-i Gateway AC14** (→ p. [18](#))).


## 2 Save the project

- Select [File] > [Save Project].
- > CODESYS saves the project.

### 5.1.2 Overview: Project structure with AS-i Gateway AC14

17132

A CODESYS project contains all components for the programming and administration of PLC applications. All components of a project are shown in the window [Devices] in a hierachic tree view. CODESYS projects with an AS-i Gateway AC14 have the following structure:



- ① [Device (AC14)] represents the AS-i Gateway AC14 in the CODESYS project.  
→ [Configure PLC](#) (→ p. 21)
- ② [PLC Logic] contains the PLC applications of the AS-i Gateway AC14.  
→ [Objects of a PLC application](#) (→ p. 24)
- ③ [ASi\_Master\_1] contains the process data images of the AS-i slaves at AS-i master 1  
→ [Access input and output data](#) (→ p. 27)
- ④ [ASi\_Master\_2] contains the process data images of the slaves at AS-i master 2  
→ [Access input and output data](#) (→ p. 27)
- ⑤ [Fieldbus\_Interface] provides access to the inputs and outputs of the fieldbus interface.  
→ [Access input and output data](#) (→ p. 27)
- ⑥ [Ethernet] represents the configuration node Ethernet adapter of the device.  
→ [Configure Ethernet interface](#) (→ p. 22)

## 5.2 Use CODESYS online help

6989

This manual only describes the integration, configuration and the programming of the AS-i Gateway AC14 using the CODESYS development system.

For the description of user actions and user interface elements the CODESYS terminology will be used.

Standard functions and methods of CODESYS will not be described. At the beginning of each section there will be a reference to the corresponding chapters of the CODESYS online help.

To access the online help of the CODESYS development system:

- ▶ Start CODESYS.
- > The CODESYS user interface appears.
- ▶ Press [F1].
- > Online help of the CODESYS development system appears.



- ▶ Familiarise yourself with the CODESYS development system! In particular with the following topics:
  - Names and functions of the user interface elements
  - Basic menu functions
  - Programming techniques and methods for data retention



## 5.3 Set the programming interface

18494

To download the created projects and applications to the device a valid network path between the CODESYS programming system and the PLC of the device has to be selected.

### 5.3.1 Set communication path to PLC

18500

To configure the connection between CODESYS programming software and the PLC of the AS-i Gateway AC14:

#### 1 Preparations

- ▶ Connect CODESYS PC/laptop and configuration interface (X3) of the device.
- ▶ Optional: Adjust IP settings of the Ethernet interfaces.

#### 2 Select communication settings


- ▶ In the device tree: Double click on [Device ifm\_SmartPLC\_StandardLine]
- ▶ In the editor window: Click on [Communication Settings] tab.
- > Editor window shows the communication settings of the device.

#### 3 Select gateway

- ▶ Select the required gateway from the [Gateway] list.
- ▶ List shows the selected gateway.

#### 4 Select network path

- ▶ Press [Scan network...].
- > [Select Device] window appears.
- ▶ Select gateway and press [Scan network] to start the scanning process.
- > CODESYS scans the Ethernet network for accessible devices.
- > Window shows network path and detected devices.



- ▶ Select the [AS-i Gateway AC14] node.
- > Information field displays detailed information of the selected node.
- ▶ Press [OK] to select the network path to the PLC.
- > CODESYS is able to download data to the PLC of the AS-i Gateway AC14.

## 6 System configuration

### Contents

Configure PLC .....	21
Configure Ethernet interface.....	22

18498


### 6.1 Configure PLC

18961



- ▶ Familiarise yourself with the following CODESYS functions!
  - Generic device editor
    - Online help > CODESYS Development System > Reference user interface > Objects> object 'device' and generic device editor

The PLC is configured via the "Generic Device Editor" of the CODESYS programming system. The programmer can access the device editor of the PLC via the following node in the device tree:



To configure the device-internal PLC:

- ▶ In the device tree: Double-click on [ifm\_SmartPLC\_StandardLine]
- > The editor window shows device editor of the device-internal PLC.
- ▶ Configure PLC.
- ▶ Save the project to apply changes.

## 6.2 Configure Ethernet interface

### Contents

Available fieldbus stacks .....	22
Add fieldbus stack .....	23

17701



- ▶ Familiarise yourself with the following CODESYS functions!
  - Menu command "Attach device"  
→ Online help > CODESYS Development System > Devices > Attach Device...
  - Configure EtherCAT (master)  
→ Online help > Fieldbus support > EtherCAT Configuration Editor
  - Configure modbus TCP (master/slave)  
→ Online help > Fieldbus support > Modbus Configuration Editor

### 6.2.1 Available fieldbus stacks

18518

The Ethernet internet (X3) of the device can be declared and operated as an additional fieldbus interface. For this, a fieldbus stack must be assigned to the interface in CODESYS. Presently, the device supports the following fieldbus stacks:

Designation	Fieldbus	Manufacturer
Modbus TCP Master	Modbus TCP	3S - Smart Software Solutions GmbH
Modbus TCP Slave	Modbus TCP	3S - Smart Software Solutions GmbH

## 6.2.2 Add fieldbus stack

18659

- !** ► Familiarise yourself with the following CODESYS functions!
- Modbus configurator  
→ Online help > Fieldbus support > Modbus configurator

To declare the Ethernet interface as a fieldbus interface:

- 1 **Create/load CODESYS project**
  - Create or load CODESYS project with the AS-i Gateway AC14.
- 2 **Add fieldbus stack**
  - In the device tree: Right-click on [X3 (Ethernet)].
  - In the context menu: Select [Add Device...].
  - > Window [Add device] appears.
  - Set the following values:
    1. [Vendor]: Select [<All vendors>].
    2. In table: Select the requested fieldbus stack in the [Name] column.
    3. [Name]: Enter name of the fieldbus stack.
  - Click on [Add Device] to add the requested fieldbus stack to the project.
  - > In the device tree: CODESYS adds the selected fieldbus stack as sub-element of the Ethernet interface.
- 3 **Configure the fieldbus stack**
  - Configure added fieldbus device.
  - Save the project to apply changes.

# 7 Programming

## Contents

Objects of a PLC application .....	24
Create PLC application.....	25
Access input and output data .....	27
Use functions of the ifm package .....	33
Use visualisations.....	40
Configure task processing .....	45
Testing the PLC application.....	46

7074

This chapter provides information about the programming of the PLC of the device.




- Familiarise yourself with the programming according to the standard IEC 61131-3!

## 7.1 Objects of a PLC application

7143

All objects of a PLC application are listed as subelements of the node [Application] in the device tree. In the basic configuration a PLC application contains the following objects:



- ① [Application] is the container of the PLC application
- ② [Library manager] provides access to the standard and device-specific function libraries.
- ③ [PLC\_PRG (PRG)] provides access to the program editor of the application  
→ [Create PLC application](#) (→ p. [25](#))
- ④ [Task configuration] provides access to the settings of the task processing  
→ [Configure main task](#) (→ p. [45](#))

If needed, the programmer can add additional objects to the PLC application (→ [Add visualisation to a project](#) (→ p. [41](#))).


## 7.2 Create PLC application

17691

- !** ► Familiarise yourself with the following CODESYS functions!
- Program application  
→ Online help > CODESYS Development System > Program application
  - Programming reference  
→ Online help > CODESYS Development System > reference programming

To create a PLC application:

- In device tree: Double-click on [PLC\_PRG (PRG)]
- > The editor window shows the programming surface:



- Program the application in the editor.

### 7.2.1 Use remanent variables

18522

The PLC of the device supports the use of remanent variables. Variables declared as VAR RETAIN are stored in a memory area that is also maintained when the device is switched off.

The declaration of a variable as RETAIN also influences its behaviour when the PLC application is reset (→ **Supported reset variants** (→ p. 54)).

- !** The memory area for RETAIN variables comprises 4072 bytes.
- Pay attention to the maximum size of the RETAIN memory area when declaring RETAIN variables!

## 7.2.2 Supported programming languages

18034

The following table shows which programming languages according to IEC 61131 are supported by the ifm function libraries:

Library	Function Block Diagram (FBD)	Sequential Function Chart (SFC)	Instruction List (IL)	Continuous Function Chart (CFC)	Ladder Diagram (LD)	Structured Text (ST)
ACnnnn_Utils.library	X	X	X	X	X	X
ACnnnn_SYS_CMD.library	X	X	X	X	X	X

Legend:  
X ... is supported

## 7.2.3 Change system time of the device

18271

### WARNING

Risk of undesired system behaviour!

The use of the CODESYS function SysTimeRtcSet for setting the time may lead to malfunction.

- To set the system time (date, time) of the device only use the following device-specific commands:
  - Function block Set\_DateTime (→ [Set\\_TimeDate](#) (→ p. [111](#)))
  - System command 0x1109 with function block ACnnnn\_SysCmd (→ [ACnnnn\\_SysCmd](#) (→ p. [121](#)))

## 7.3 Access input and output data

### Contents

Options to access input and output data .....	27
Validity of the interface data .....	28
Process data of the AS-i slaves .....	29
Fieldbus data .....	31

17447



- ▶ Familiarise yourself with the following CODESYS functions!
  - Addresses according to IEC standard 61131-3:  
→ Online help > CODESYS Development System > Programming Reference > Operanden > Addresses
  - Access to IEC address via AT declaration:  
→ Online help > CODESYS Development System > Programming Reference > Declaration > AT Declaration
  - Definition of an ALIAS for an IEC address:  
→ Online help > CODESYS Development System > Programming Reference > Data Types > References
  - Coupling of a program variable to an address (mapping):  
→ Online help > CODESYS Development System > Configuring I/O Links

### 7.3.1 Options to access input and output data

17621

In a CODESYS project, each input and output has a physical address according to the IEC standard (e.g. %IW5). CODESYS offers the following options to access this address from a PLC application and thereby to access the input and outputs data of the device:

- Direct access to IEC address
- Access to IEC address via AT declaration
- Definition of an ALIAS for an IEC address
- Link a program variable to an IEC address (mapping)

## 7.3.2 Validity of the interface data

18413

In order to facilitate the access to inputs and outputs of AS-i slaves, AS-i Gateway AC14 projects offer clearly defined interfaces in the device tree (→ **Overview: Project structure with AS-i Gateway AC14** (→ p. 18)).

Depending on the active instance for accessing the outputs of the AS-i slaves (Manual, Gateway, PLC), the CODESYS data mapper only updates certain address areas of the interfaces. The following table shows which address areas of the i/o interfaces provide valid data values while in a certain operating mode:

Output control	I/O interfaces	Updated address areas / channels
<b>Manual</b>	[ASi_Master_1]	AS-i 1 Input (%IB, %IW)
	[ASi_Master_2]*	AS-i 2 Input (%IB, %IW)
	[Fieldbus_Interface]	<ul style="list-style-type: none"> <li>▪ AS-i 1 Output (%IB, %IW)</li> <li>▪ AS-i 2 Output (%IB, %IW)</li> </ul>
<b>Gateway</b>	[ASi_Master_1]	ASi 1 Input (%IB, %IW)
	[ASi_Master_2]*	AS-i 2 Input (%IB, %IW)
	[Fieldbus_Interface]	<ul style="list-style-type: none"> <li>▪ AS-i 1 Output (%IB, %IW)</li> <li>▪ AS-i 2 Output (%IB, %IW)</li> </ul>
<b>PLC</b>	[ASi_Master_1]	<ul style="list-style-type: none"> <li>▪ AS-i 1 Input (%IB, %IW)</li> <li>▪ AS-i 1 Output (%QB, %QW)</li> </ul>
	[ASi_Master_2]*	<ul style="list-style-type: none"> <li>▪ AS-i 2 Input (%IB, %IW)</li> <li>▪ AS-i 2 Output (%QB, %QW)</li> </ul>
	[Fieldbus_Interface]	<ul style="list-style-type: none"> <li>▪ AS-i 1 Output (%IB, %IW)</li> <li>▪ AS-i 2 Output (%IB, %IW)</li> </ul>

\* ... only available for devices with 2 AS-i masters



- When linking variables with inputs and outputs, only use interfaces in the project tree, that are updated by the CODESYS data mapper!

### 7.3.3 Process data of the AS-i slaves

17584

The project tree offers direct access to the cyclically updated process images of the inputs and outputs of the AS-i slaves.



- (1) Digital input and output data of the slave at AS-i master 1: → [Digital input and output data](#) (→ p. 30)
- (2) Analogue input and output data of the slaves at AS-i master 1: → [Analogue input and output data](#) (→ p. 30)
- (3) Digital input and output data of the slave at AS-i master 2: → [Digital input and output data](#) (→ p. 30)
- (4) Analogue input and output data of the slaves at AS-i master 2: → [Analogue input and output data](#) (→ p. 30)



Consider validity of the interface data (→ [Validity of the interface data](#) (→ p. 28))!



The function library ACnnnn\_Utils.library contains the complex variable ASi\_NET. The variable represents all inputs and outputs of a completely developed AS-i network. The programmer can use this data structure to store the process images of the inputs and outputs of an AS-i network. (→ [ASi\\_NET \(STRUCT\)](#) (→ p. 117))

## Digital input and output data

17625

To access the digital process data of the slaves at AS-i master 1:

- In the device tree: Double click on [ASi\_1\_binaryIO]
- > The editor window shows a structured list of the digital inputs and outputs of the AS-i slaves.

Variable	Mapping	Channel	Address	Type
		ASi Input bin	%IB1	
		Digital S(A) Slave	%IB1	ARRAY [1..31] OF BYTE
		Digital B Slave	%IB32	ARRAY [1..31] OF BYTE
		ASi Output bin	%QB1	
		Digital S(A) Slave	%QB1	ARRAY [1..31] OF BYTE
		Digital B Slave	%QB32	ARRAY [1..31] OF BYTE

- In column [Variable]: Mouse click on to make individual variables visible.

- To access the digital process data of the slaves at AS-i master 2 in a system with 2 AS-i masters:
- Double click on [ASi\_2\_binaryIO]

## Analogue input and output data

17626

To access the analogue process data of the slaves at AS-i master 1:

- In the device tree: Double-click on [ASi\_1\_analogIO]
- > Editor window shows a structured list of the analogue inputs and outputs of the AS-i slaves.

Variable	Mapping	Channel	Address	Type
		ASi Input	%IW32	ARRAY [1..31] OF SLAVEaANAaINaTYPE
		ASi Output	%QW32	ARRAY [1..31] OF SLAVEaANAaOUTaTYPE


- In column [Variable]: Mouse click on to make individual variables visible.

- To access the analogue process data of the slaves at AS-i Master2 in a system with 2 AS-i masters:
- Double-click on [ASi\_2\_analogIO]

## 7.3.4 Fieldbus data

17585

The device tree offers direct access to the data that is transmitted between fieldbus and device.



- ① Data that the fieldbus transmits/receives via the fieldbus.  
→ **Input and output data of the fieldbus interface** (→ p. [31](#))
  - ② Output data of the AS-i slaves at AS-i master 1 and AS-i master 2 that is transmitted by the higher-level fieldbus PLC.  
→ **Outputs data of the AS-i slaves** (→ p. [32](#))
- !** Consider validity of the interface data (→ **Validity of the interface data** (→ p. [28](#)))!

### Input and output data of the fieldbus interface

17619

The input and output data of the fieldbus interface is transmitted in cycles of 120 words each. The programmer can access this data via IEC addresses.

To access the input and output data of the fieldbus interface:

- Device window: In the project tree, double-click on [FieldBusData\_]
- > Editor window shows a structured list of the inputs and outputs:

Variable	Mapping	Channel	Address	Type
		Inputs from fieldbus	%IW373	ARRAY [0..119] OF WORD
		Outputs to fieldbus	%QW373	ARRAY [0..119] OF WORD

- In column [Variable]: Mouse click on to make individual variables visible.

## Output data of the AS-i slaves

17620

The area contains all data, the higher-level Fieldbus controller cyclically sends to the outputs of the AS-i slaves via the fieldbus network. The data is structure like an AS-i network. The programmer can access this data via IEC addresses.



If the output access of the device is set to "PLC", the programmer can use the data bundled in this area to process the target values sent by the higher-level fieldbus controller to the CODESYS PLC.

## Digital output data

17630

To access the digital output data of the slaves at AS-i master 1:

- Device window: In the project tree, double-click on [ASi\_1\_binaryIO]
- > Editor window shows a structured list of the digital output data:

Variable	Mapping	Channel	Address	Type
		FB ASi Output bin	%IB986	
		Digital S(A) Slave	%IB986	ARRAY [1..31] OF BYTE
		Digital B Slave	%IB1017	ARRAY [1..31] OF BYTE

- In column [Variable]: Mouse click on to make individual variables visible.



To access the digital output data of the slaves at AS-i master 2 in a system with 2 AS-i masters:

- Double-click on [ASi\_2\_binaryIO]

## Analogue output data

17631

To access the analogue output data of the slaves at AS-i master 1:

- Device window: In the project tree, double-click on [ASi\_1\_analogOut]
- > Editor window shows the structured list of the analogue output data:

Variable	Mapping	Channel	Address	Type
		FB ASi Output ana	%IW524	ARRAY [1..31] OF SLAVEaANAAaINaTYPE

- In column [Variable]: Mouse click on to make individual variables visible.



To access the analogue output data of the slaves at AS-i master 2 in a system with 2 AS-i masters:

- Double-click on [ASi\_2\_analogOut]

## 7.4 Use functions of the ifm package

18489

The CODESYS package "CODESYS for ifm SmartPLC StandardLine" offers different functions for the programming of the device-internal CODESYS controller. In the following sections, these functions will be briefly described. To make orientation easier, the functions are grouped according to corresponding subjects and provided with a cross-reference to a detailed explanation in the document's appendix.

### 7.4.1 Control interface of the ifm function blocks

17660

All function blocks (FB) of the libraries ACnnnn\_Utils.library and ACnnnn\_SYS\_CMD.library have inputs and outputs for control signals. The inputs activate the execution of the function block. The outputs provide information about the internal condition of the function block. Thanks to the signals, the programmer can create a control structure for a targeted processing of the FB and react to possible errors.

Number and designation of the FB control signals provide information about the type of FB execution:


#### FB with one-time execution

17140

These function blocks perform their function exactly once after activation. To execute the function once again, the FB needs to be reactivated. FBs of this kind feature a control interface with the following inputs and outputs:

Designation	Type	Data type	Description	Possible values	
xExecute	Input	BOOL	Control FB execution	FALSE	Stop FB execution
				TRUE	Start FB execution
xReady	Output	BOOL	Indication of whether execution of the FB has been completed	FALSE	FB execution not yet completed
				TRUE	FB execution completed
xBusy	Output	BOOL	Indication of whether FB is active	FALSE	Function block is inactive
				TRUE	FB is active
xError	Output	BOOL	Indication of whether faults have occurred during execution of the FB	FALSE	FB executed correctly
				TRUE	Error occurred during execution of the FB
wDiagnostic	Output	WORD	Error code	FB specific	

The following figure shows the relation between the connections of the control signals:



- (1) xExecute = TRUE:  
xBusy = TRUE: Rising edge (FALSE → TRUE) starts execution of the FB.  
FB execution has been started, but has not yet been completed.
- (2) xReady = TRUE:  
xBusy = FALSE:  
xError = FALSE: FB execution completed; there are valid values on the data outputs.  
FB is no longer active.  
FB execution without faults.
- (3) xExecute = FALSE: All signal outputs are set to FALSE and all internal states are reset.
- (4) → (1)
- (5) xReady = TRUE:  
xBusy = FALSE:  
xError = TRUE: FB execution is terminated.  
FB is no longer active.  
Errors occurred during FB execution; wDiagnostic provides error code.
- (6) → (3)
- (7) → (1)
- (8) xExecute = FALSE: FB execution interrupted prior to completion; All signal outputs are set to FALSE and all internal states are reset.

## FB with cyclic execution

17141

Function blocks which, when activated, cyclically perform their function until they are deactivated have the following control inputs and outputs:

Designation	Type	Data type	Description	Possible values	
xEnable	Input	BOOL	Control FB execution	FALSE	Stop FB execution
				TRUE	Start FB execution
xActive	Output	BOOL	Indication of whether execution of the FB has been completed	FALSE	FB execution not yet completed
				TRUE	FB execution completed
xError	Output	BOOL	Indication of whether faults have occurred during execution of the FB	FALSE	FB executed correctly
				TRUE	Error occurred during execution of the FB
wCycleCount	Output	WORD	Counters for the FB cycles	Integer value (hexadecimal representation)	
wDiagnostic	Output	WORD	Error code	FB specific	

## 7.4.2 Configure system

17450

To configure the system of the device, use the following function blocks:

Name	Description	Reference
QuickSetupASi_Master	Execute quick setup routine on an AS-i master	→ <a href="#">QuickSetupASi_Master</a> (→ p. <a href="#">109</a> )
Set_TimeDate	Set system time (date, time) of the system	→ <a href="#">Set_TimeDate</a> (→ p. <a href="#">111</a> )
Get_FieldbusInfo	Read fieldbus type, the status of the field bus connection and the parameters of the fieldbus interface	→ <a href="#">Get_FieldbusInfo</a> (→ p. <a href="#">107</a> )

## 7.4.3 Configure AS-i master

17448

To configure the AS-i masters of the device, use the following function blocks:

Name	Description	Reference
Set_Mode	Set operating mode of the AS-i master (projecting mode or protected operation)	→ <a href="#">Set_Mode</a> (→ p. <a href="#">93</a> )
Set_ASi_Config	Set diagnostic functions of the AS-i master (double address recognition, earth fault detection)	→ <a href="#">Set_ASi_Config</a> (→ p. <a href="#">89</a> )
Set_AdressMode	Set automatic addressing of the AS-i master	→ <a href="#">Set_AddressMode</a> (→ p. <a href="#">87</a> )

## 7.4.4 Configure AS-i slaves

17449

To configure the AS-i slaves, that are connected to the device, use the following function blocks:

Name	Description	Reference
Set_SlaveAddress	Change address of an AS-i slave	→ <a href="#">Set_SlaveAddress</a> (→ p. <a href="#">98</a> )
Set_SlaveParameter	Change I/O configuration and ID codes (IO, ID, ID1, ID2) of an AS-i slave	→ <a href="#">Set_SlaveParameter</a> (→ p. <a href="#">102</a> )
Set_SlaveExtendedID1	Extended ID1 of an AS-i slave	→ <a href="#">Set_SlaveExtendedID1</a> (→ p. <a href="#">100</a> )

## 7.4.5 Manage AS-i network

17126

To manage the AS-i networks controlled by AS-i Gateway AC14, use the following function blocks:

### Use complex variables

18528

There are different complex variables (STRUCT) at the programmer's disposal. They bundle logically associated data sets. Thereby, they facilitate the organisation of the data storage in the application and at the same time reduce the error rate when variables are declared.

The following complex variables are available:

Name	Description	Reference
ASI_NET	The complex variable contains the complete process image (inputs and outputs) of an AS-i network.	→ <a href="#">ASI_NET (STRUCT)</a> (→ p. <a href="#">117</a> )
ASI_DATA	The complex variable contains the following components: <ul style="list-style-type: none"> <li>▪ Slave lists (LPS, LDS, LAS, LPF, LCE, LCEMS, LCEAS, LDAE)</li> <li>▪ Parameter images (PI, PP)</li> <li>▪ Configuration data of the AS-i slaves (CDI, PCD)</li> </ul>	→ <a href="#">ASI_DATA (STRUCT)</a> (→ p. <a href="#">115</a> ) → <a href="#">Get_ASi_Data</a> (→ p. <a href="#">104</a> )

### Change network settings

17568

Name	Description	Reference
Set_ProjectAll	Execute projection adaptation on one AS-i master	→ <a href="#">Set_ProjectAll</a> (→ p. <a href="#">97</a> )
Set_LPS	Change list of the projected slaves (LDS)	→ <a href="#">Set_LPS</a> (→ p. <a href="#">91</a> )
Set_PCD	Change permanent projecting data (IO, ID, ID1, ID2) of all slaves on the AS-i master	→ <a href="#">Set_PCD</a> (→ p. <a href="#">95</a> )

## Read network settings

18532

To read the network settings cyclically and offer them in the application:

Name	Description	Reference
Get_ASi_Data	Read the following datasets for network management in batches and cycles: <ul style="list-style-type: none"> <li>▪ List of activated slaves (LAS)</li> <li>▪ List of detected slaves (LDS)</li> <li>▪ List of projected slaves (LPS)</li> <li>▪ List of peripheral faults (LPF)</li> <li>▪ List of configuration errors (LCE)</li> <li>▪ List of configuration errors, missing slaves (LCEMS)</li> <li>▪ List of configuration errors - additional slaves (LCEAS)</li> <li>▪ List of double address errors (LDAE)</li> <li>▪ Configuration data image (CDI)</li> <li>▪ Permanent configuration data (PCD)</li> <li>▪ Input parameters (PI)</li> <li>▪ Output parameters (PP)</li> </ul>	→ <a href="#">Get_ASi_Data</a> (→ p. <a href="#">104</a> )

Alternatively, this data can be read separately with the following FB:

## Read parameter images

17569

Name	Description	Reference
Get_InputParameter	Read parameters of the inputs of the slaves at the AS-i master (PI)	→ <a href="#">Get_InputParameter</a> (→ p. <a href="#">83</a> )
Get_OutputParameter	Read parameters of the outputs of the slaves on the AS-i master (PP)	→ <a href="#">Get_OutputParameter</a> (→ p. <a href="#">85</a> )

## read slave lists

18530

Name	Description	Reference
Get_LPS	Read list of projected slaves (LPS)	→ <a href="#">Get_LPS</a> (→ p. <a href="#">67</a> )
Get_LDS	Read list of detected slaves (LDS)	→ <a href="#">Get_LDS</a> (→ p. <a href="#">65</a> )
Get_LAS	Read list of activated slaves (LAS)	→ <a href="#">Get_LAS</a> (→ p. <a href="#">63</a> )
Get_LPF	Read list of peripheral faults (LPF)	→ <a href="#">Get_LPF</a> (→ p. <a href="#">77</a> )
Get_LCE	Read list of configuration errors (LCE)	→ <a href="#">Get_LCE</a> (→ p. <a href="#">69</a> )
Get_LCEMS	List of configuration errors - read missing slaves (LCEMS)	→ <a href="#">Get_LCEMS</a> (→ p. <a href="#">73</a> )
Get_LCEAS	Read of the configuration errors - read additional slave (LCEAS)	→ <a href="#">Get_LCEAS</a> (→ p. <a href="#">71</a> )
Get_LDAE	Read list of double address errors (LDAE)	→ <a href="#">Get_LDAE</a> (→ p. <a href="#">75</a> )

## Read configuration data of the slaves

18533

Name	Description	Reference
Get_CDI	Read configuration data image (IO, ID, ID1, ID2) of all slaves on the AS-i master	→ <a href="#">Get_CDI</a> (→ p. <a href="#">79</a> )
Get_PCD	Read permanent configuration data of all slaves (IO, ID, ID1, ID2) on the AS-i master	→ <a href="#">Get_PCD</a> (→ p. <a href="#">81</a> )

## Read status of the voltage supply

18529

Name	Description	Reference
Get_ASi_PHY_Dat	Determine voltage supply status of the AS-i network	→ <a href="#">Get_ASi_PHY_Dat</a> (→ p. <a href="#">61</a> )

## 7.4.6 Send commands to the system and the AS-i master

17659


Similar to the acyclic transmission command channels and data sets of the device, the programmer can send commands to the system or an AS-i master with the FB ACnnnn\_SysCmd (→ **ACnnnn\_SysCmd** (→ p. [121](#))).

- System command overview: → **Table: System commands** (→ p. [122](#))
- Overview AS-i master commands: → **Table: AS-i master commands** (→ p. [123](#))



By default, the FB ACnnnn\_SysCmd is hidden. To add the FB to a program module:

- ▶ Highlight the required network and add an empty function block with [FBD/LD/IL] > [Insert Empty Block].
- > Network shows empty FB.
- > Double-click on the name field of the FB
- > Enter designation ACnnnn\_SysCmd and confirm with [ENTER].



## 7.5 Use visualisations

### Contents

Supported visualisation types .....	40
Add visualisation to a project .....	41
Create a visualisation .....	42
Configure visualisation .....	43

17059



- ▶ Familiarise yourself with the following CODESYS functions!
  - Visualisations in CODESYS  
→ Online help > CODESYS visualisation

### 7.5.1 Supported visualisation types

17661

The AS-i Gateway AC14 supports the following CODESYS visualisation types:


- **Web visualisation (WebVisu)**  
A WebVisu allows graphic representation of selected process and control data of the device in a web browser by means of a user-specific visualisation.
- **Target visualisation (TargetVisu)**  
A TargetVisu allows graphic representation of selected process and control data of the device on the display of the device by means of a user-specific visualisation.

## 7.5.2 Add visualisation to a project

17060

To add a visualisation to a CODESYS project:

- Open CODESYS project.  
OR:  
Create new CODESYS project. (→ **Create new project with AS-i Gateway AC14** (→ p. [17](#)))
- In the device tree: Click on [Application].
- Select [Project] > [Add Object] > [Visualization...]
- > [Add Visualization] window appears.
- Enter a designation for the visualization in the [Name] field and click on [Add] to apply.
- > CODESYS adds the following elements to the device tree:



- ① [VISU\_TASK] provides access to the visualisation task properties (→ **Set parameters for visualisation task** (→ p. [45](#)))
- ② [Visualization Manager] provides access to the visualisation properties (→ **Configure visualisation** (→ p. [43](#)))
- ③ [MyVisu] contains the area for the creation of the visualisation objects (→ **Create a visualisation** (→ p. [42](#)))


### 7.5.3 Create a visualisation

17061

- !** Create a separate visualisation object for each target and web visualisation.

To create a visualisation for a PLC application:

- In the device tree: double-click on [Visualization]
- > The visualisation editor with a tool box appears:



- Create the visualisation using the tools.
- Save the project to apply changes.

## 7.5.4 Configure visualisation

6953

In order to change the properties of the created visualisations, choose one of the following options:


- **Change properties of the web visualisation** (→ p. [43](#))
- **Change the properties of the target visualisation** (→ p. [44](#))

### Change properties of the web visualisation

17065

To change the attributes of the web visualisation:

- In device tree: Double click on [Web-Visualisierung]
- > The editor window shows attributes of the web visualisation:



- Set the following values:
  1. Field [Start Visualization]: Select the created web visualisation.
  2. Field [Name of .htm file]: Enter name for HTML file (→ Note).
  3. Area [Scaling Options]: Enter fixed width and height as shown.



In the field [Name of .htm file] enter the name by which the web visualisation is to be accessible in the web browser (→ **Display web visualisation** (→ p. [56](#))).


- Use only lower case when entering the name!
- Save the project to apply changes.

## Change the properties of the target visualisation

17064

To change the properties of the target visualisation:

- In device tree: Double-click on [TargetVisu]
- > Editor window shows properties of the target visualisation.



- Set the following values:
  1. [Start Visualization] field: Select the created target visualisation.
  2. [Scaling options] area: Enter fixed width and height as illustrated.
- Save the project to apply changes.

## 7.6 Configure task processing

4109

-  ► Familiarise yourself with the following CODESYS functions!
- Task configuration
    - Online help > CODESYS Development System > application programmable > task configuration

The processing of the tasks is controlled by parameters. The user can set the parameters for each task separately

CODESYS automatically creates the following tasks and visualisations during project creation:

Name	Description	Note
[MainTask]	Configuration of the main task (e.g. for main program [PLC_PRG (PRG)])	→ <b>Configure main task</b> (→ p. <a href="#">45</a> )
[VISU_TASK]	Configuration of the task for processing visualisation	→ <b>Set parameters for visualisation task</b> (→ p. <a href="#">45</a> )

### 7.6.1 Configure main task

18412

The basic settings of the task characteristics cover the requirements of many applications. In the event of non-optimum device performance the user must determine and set the optimum task characteristics himself.

To change parameters of a task:

- In device tree: Double click on [Taskkonfiguration] > [MainTask]
- > The editor window shows the configuration of the main task.
- Set the parameters as requested.
- > Selected value is applied.

### 7.6.2 Set parameters for visualisation task

17066

-  ► Execute the visualisation task (VISU\_TASK) with a priority that is as low as possible to avoid interruption of other tasks that are important for the core functions of the application.
- Execute the VISU\_TASK in appropriate cyclic intervals to save the resources of the device-internal CODESYS PLC of the fieldbus network.

Each visualisation is executed separately from the program code in a separate task. To set the properties of the visualisation task:

- In the device tree: Double-click on [Task configuration] > [VISU\_TASK]
- > Editor window shows parameters of the visualisation task.
- Set the parameters as required.
- Save the project to apply changes.

## 7.7 Testing the PLC application

18594

-  ► Familiarise yourself with the following CODESYS functions!
- Test and fault elimination  
→ Online help > CODESYS Development System > Testing and Debugging

To ensure permanent operation without errors in industrial environments, the created PLC application must be tested in detail and possible faults must be remedied.

## 8 Operation

### Contents

Transfer CODESYS project to device .....	48
Operating states of the PLC .....	52
Reset .....	54
Display web visualisation.....	56
Display target visualisation .....	57

18492

© ifm electronic gmbh

## 8.1 Transfer CODESYS project to device

### Contents

Activate CODESYS PLC .....	49
Download the application to the device.....	50
Delete application from AS-i Gateway AC14.....	50
Delete boot application via SD card .....	51

18490



- ▶ Familiarise yourself with the following CODESYS functions!
  - Compile project/application and transfer it to device  
→ Online help > CODESYS Development System > Transferring Applications to the PLC

To save the CODESYS project on the device the following component must be transferred to the device:

- application "Application" (→ **Download the application to the device** (→ p. 50))



- ▶ Observe notes on the operating modes of the PLC of the device!  
→ **Operating states of the PLC** (→ p. 52)  
  
ifm system solutions and CODESYS applications created by the user must not be saved and executed on the device at the same time!
- ▶ Before loading an application to the device delete all ifm system solutions saved on the device (→ Device manual, Uninstall ifm apps)!  
  
To be able to use an ifm system solution in a user project the functions must be integrated into the project via libraries to be ordered separately.
- ▶ Contact the AS-i specialist of ifm electronic!

## 8.1.1 Activate CODESYS PLC

17692

To enable the processing of the created PLC application, the device-internal CODESYS PLC must be activated in the setup menu of AS-i Gateway AC14.

If the PLC application is to have a write access to the outputs of the AS-i slaves, the CODESYS PLC must be activated additionally as controller instance of the AS-i slave outputs.

The following table shows the possible combinations of the parameters [Output access] and [Use PLC] as well as the rights of the CODESYS PLC resulting thereof.

List [Output access]	Checkbox [Use PLC]	CODESYS PLC		
		Programmable	Access to AS-i inputs	Access to AS-i outputs
Gateway	<input type="checkbox"/>	no	yes	no
	<input checked="" type="checkbox"/>	yes	yes	no
Manual	<input type="checkbox"/>	no	yes	no
	<input checked="" type="checkbox"/>	yes	yes	no
PLC	<input checked="" type="checkbox"/> *	yes	yes	yes

Legend:

\* ... Value fixed (greyed out)

To set the operating mode of the device:

1 **Select menu page**



- ▶ > Select [System settings] tab.

2 **Set the controller instance of the outputs**

- ▶ Select the requested controller instance of the AS-i outputs in the [Output access] list.
- ▶ Press [Accept selection] to activate the selection.

3 **Activate CODESYS PLC**

- ▶ Activate [Use PLC] checkbox.
- ▶ CODESYS PLC is active.

4 **Optional: Adjust device cycle**

- ▶ Select the requested device cycle time in the [Device cycle] list.
- ▶ Press [Accept selection] to activate the selected value.

## 8.1.2 Download the application to the device

18593

To transfer the created application as boot project to the device:

**Requirements:**

- > Network path is set (→ **Set communication path to PLC** (→ p. [20](#))).
- > Project tested.
- > All ifm system solutions stored on the devie are deleted (→ device manual: **Uninstall ifm apps**)

**1 Build application**

- In the device tree: Highlightt application as active application.
- Use [Build] > [Rebuild] to compile the active application.
- > CODESYS generates program code.

**2 Load application on the device**

- Use [Online] > [Login] to connect with the device.
- > Active application is transferred to the device (download).
- > application on the device is in STOP state.

**3 Create boot application**

- Use [Online] > [Create boot application] to make the application bootable.
- > application storage is non-volatile.

**4 Start boot application**

- Use [Debug] > [Start] to start the application.
- > application goes to the RUN state.

## 8.1.3 Delete application from AS-i Gateway AC14

18030

To delete an application stored on the device:

**1 Connect with the device**

- In the device tree: highlight application as active application.
- Use [Online] > [Login] to establish connection to the device.
- > CODESYS is in the online mode.

**2 Delete application**

- In the editor window: Select [Device] > [Applications] tab.
- Press [Refresh List] to refresh the view.
- > List shows the applications that are stored on the device.
- Delete all applications in the device with [Remove All].  
OR:  
Highlight requested application and press [Remove] to delete it from the device.
- > Selected application will be deleted.

## 8.1.4 Delete boot application via SD card

15970

If after the start of a complex boot application the device is overloaded and does not respond any more to user inputs or login attempts, the boot application on the device needs to be forcibly deleted.

To delete the boot application on the device:

- ▶ Disable the write protection of the SD card.
  - ▶ Create a file named `KillBootApp.txt` in the root directory of the SD card.
  - ▶ Insert the SD card into the SD card slot of the device.
  - ▶ Restart the device.
- > Boot application on the device-internal PLC is deleted.  
> The file `KillBootApp.txt` on the SD card is renamed in `KillBootApp.rdy`.



With this method the following data on the device-internal PLC is removed:

- all files of the boot application
- all CRC files
- directory with web and/or target visualisations
- data in the memory area F-RAM



## 8.2 Operating states of the PLC

17544

This section provides information about the operating states of the device and the states of the PLC of the device as well as information about the states of the applications.

### 8.2.1 Operating mode of the PLC

13769

The PLC of the device can be operated in the following modes:

- **Offline mode**  
In the offline mode the user is logged out of the PLC or there is no connection between CODESYS and the PLC (e.g. connection loss).
- **Online mode**  
In the online mode the user is logged in to the PLC.

### 8.2.2 States of the PLC application

4136

The applications saved on the device are executed independently in separate tasks. A application can have the following states:

- **Unload**  
No application is saved on the PLC.
- **RUN**  
The application is executed (cyclically processed).
- **STOP**  
The application is not executed.

### Display operating state of the application

10272

To display the current operating state of the PLC choose one of the following options:

- **CODESYS:**
  - > In the device tree: Node of the application indicates the current state.  
OR:
  - > In online mode the CODESYS status bar shows the current state of the application.
- **GUI / web interface of the device:**
  -  >  > 
  - Select the **[Applications]** tab.
  - > The page displays the operating states of the PLC applications saved on the device.

## 8.2.3 Switch operating states

10264

To switch between the operating states of the application choose one of the following options:

### Start PLC application

18027

To start a PLC application stored on the device:

- **CODESYS:**

- ▶ In the device tree: highlight application as active application.
- ▶ Use [Online] > [Login] to establish the connection with the CODESYS PLC.
- ▶ Use [Debug] > [Start] to start the processing of the active application.
- > Application goes to RUN state.
- ▶ Optional: repeat process for additional applications.

- **GUI / web interface:**



- ▶ Select the [Applications] tab.
- ▶ Use [▲] / [▼] to select the required application.
- > Page shows the operating status of the selected application.
- ▶ Press [Start] function key to start the processing of the selected application.
- > Application goes to RUN state.
- ▶ Optional: repeat process for additional applications.

### Stop PLC application

18029

To stop a PLC application stored on the device:

- **CODESYS:**

- ▶ In the device tree: highlight application as active application.
- ▶ Use [Online] > [Login] to establish the connection with the CODESYS PLC.
- ▶ Use [Debug] > [Stop] to stop the processing of the active application.
- > Application goes to STOP state.
- ▶ Optional: repeat process for additional applications.

- **GUI / web interface:**



- ▶ Select [Applications] tab.
- ▶ Use [▲] / [▼] to select the required application.
- > Page shows the operating status of the selected application.
- ▶ Press [Stop] function key to stop the processing of the selected application.
- > Application goes to STOP state.
- ▶ Optional: repeat process for additional applications.

## 8.3 Reset

### Contents

Supported reset variants .....	54
Reset the application (warm).....	55
Reset the application (cold) .....	55
Reset the application (origin).....	55

18025

### 8.3.1 Supported reset variants

18613

The following table shows the reset variants supported by the device-internal CODESYS PLC and the resulting system behaviour:

Type of reset	System behaviour	Triggering actions
<b>Reset (warm)</b>	<ul style="list-style-type: none"> <li>▪ application goes to STOP state.</li> <li>▪ Standard variables (VAR) of the application are initialised.</li> <li>▪ Remanent variables (VAR RETAIN) of the application keep their current values.</li> </ul>	→ <b>Reset the application (warm)</b> (→ p. <a href="#">55</a> )
<b>Reset (cold)</b>	<ul style="list-style-type: none"> <li>▪ application changes to the STOP state.</li> <li>▪ All variables (VAR, VAR RETAIN) of the application are initialised.</li> </ul>	→ <b>Reset the application (cold)</b> (→ p. <a href="#">55</a> )
<b>Reset (default)</b>	<ul style="list-style-type: none"> <li>▪ application goes to STOP state.</li> <li>▪ The application on the PLC is deleted.</li> <li>▪ All variables (VAR, VAR RETAIN) of the application are initialised.</li> <li>▪ PLC is reset to the default state.</li> </ul>	→ <b>Reset the application (origin)</b> (→ p. <a href="#">55</a> )



A variable that has been declared without an initialisation value is initialised with the variable-specific standard value (e.g. INT = 0).

### 8.3.2 Reset the application (warm)

13131  
9069

To reset the application on the PLC, choose one of the following options:

- **CODESYS: command [Reset (warm)]**
  - ▶ In the device tree:  
Highlight the required application as active application.
  - ▶ Select [Online] > [Login] to establish a connection to the CODESYS PLC.
  - > CODESYS switches to online mode.
  - ▶ Select [Online] > [Reset warm] to reset the application.
- **GUI: command [Reset]**

  - ▶ > 
  - ▶ Select [All Applications] tab.
  - ▶ Use [Reset] to reset all applications.
- **GUI: command [Restart]**

  - ▶ > 
  - ▶ Select [System-reset] tab.
  - ▶ Use [Restart] to reboot the device.

### 8.3.3 Reset the application (cold)

15687

To reset the application on the PLC, choose one of the following options:

- **Download the application to the device**
  - ▶ → **Download the application to the device** (→ p. 50)
- **CODESYS: command "Reset (cold)"**
  - ▶ In the device tree:  
Highlight the required application as active application.
  - ▶ Select [Online] > [Login] to establish a connection to the CODESYS PLC.
  - > CODESYS switches to online mode.
  - ▶ Select [Online] > [Reset cold] to reset the application.

### 8.3.4 Reset the application (origin)

18962

To reset the application on the PLC:

- **CODESYS: command "Reset (origin)"**
  - ▶ In the device tree:  
Highlight the required application as active application.
  - ▶ Select [Online] > [Login] to establish a connection to the CODESYS-PLC.
  - > CODESYS switches to online mode.
  - ▶ Select [Online] > [Reset origin] to reset the application.

## 8.4 Display web visualisation

17063

To display the created web visualisation:

**Requirements:**

- > PC/laptop is connected to the configuration interface (X3) of the device (→ device manual: [Configuration interface: connection concepts](#))

**CODESYS PLC application**

- ▶ Download PLC application with web visualisation to the device and start it (→ [Download the application to the device](#) (→ p. [50](#))).
- ▶ On PC/laptop: Start web browser.
- ▶ Enter the following in the address line and press [ENTER] to confirm:  
<IP address-of-the-device>:<8080>/myvisu.htm



myvisu is the user-defined name of the visualisation (→ [Change properties of the web visualisation](#) (→ p. [43](#))).

- > Web browser shows the web visualisation of the device.

**ifm system solution**

- ▶ Install the ifm system solution on the device and start it (→ device manual, [Install single/basic app](#) or [Install multi app](#)).
- ▶ Display informationen about the installed ifm app (→ device manual, [Show information about installed ifm apps](#)).
- ▶ Call hyperlink of the ifm app.
- > Web browser shows the web visualisation of the ifm system solution.

## 8.5 Display target visualisation

After compilation of the project and download to the device the user has to start the target visualisation:

- **CODESYS / higher-level Fieldbus controller:**
  - ▶ Execute system command [Display target visualisation] (→ Device manual, [Command 0x0110 – Display target visualisation](#))
- **GUI / web interface:**
  - ▶ Activate target visualisation via the menu (→ Device manual: [Show target visualisation](#))  
OR:  
Switch between target visualisation and menu with the key combination [**◀**] + [**▶**].



If the device does not react to the pressing of [**◀**] + [**▶**], the key combination is deactivated.

- ▶ Activate the key combination with the system command [Display target visualisation].  
After a restart of the device the menu view of the GUI appears by default.
  - ▶ With the FB **ACnnnn SysCmd** (→ p. [121](#)) execute the system command [Display target visualisation] at the start of the PLC application.

Further information: → Device manual: [Command 0x0110 – Display target visualisation](#)"

## 9 Appendix

### Contents

Library ACnnnn_Utils.library .....	59
Library ACnnnn_SYS_CMD.library .....	121
	7156

## 9.1 Library ACnnn\_Utils.library

### Contents

Overview: AS-i functions (FB_ASi) .....	60
Overview: System functions (FB_System) .....	106
Enumeration types and complex variables.....	113

17722



## 9.1.1 Overview: AS-i functions (FB\_ASi)

### Contents

Get_ASi_PHY_Dat .....	61
Get_LAS .....	63
Get_LDS .....	65
Get_LPS .....	67
Get_LCE .....	69
Get_LCEAS .....	71
Get_LCEMS .....	73
Get_LDAE .....	75
Get_LPF .....	77
Get_CDI .....	79
Get_PCD .....	81
Get_InputParameter .....	83
Get_OutputParameter .....	85
Set_AddressMode .....	87
Set_ASi_Config .....	89
Set_LPS .....	91
Set_Mode .....	93
Set_PCD .....	95
Set_ProjectAll .....	97
Set_SlaveAddress .....	98
Set_SlaveExtendedID1 .....	100
Set_SlaveParameter .....	102
Get_ASi_Data .....	104

17459


## Get\_ASi\_PHY\_Dat

16005

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



### Description

16040

The FB reads the physical data of the selected AS-i master and provides the values.

### Input parameters

16041

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16042

Parameter	Data type	Description	Possible values	
xPS	BOOL	Voltage source (Power Source)	FALSE	Unit is supplied via Aux.
			TRUE	Unit is supplied via AS-i.
xPM	BOOL	Power24-Modul (PM)	FALSE	Power24 module missing.
			TRUE	Power24 module is inserted.
xEF	BOOL	Earth fault	FALSE	No earth fault
			TRUE	Supply voltage is asymmetric, earth fault suspected.
xSE	BOOL	Status of the earth fault detection	FALSE	Earth fault detection does not provide valid data (e.g. when AS-i voltage is lacking).
			TRUE	Earth fault detection provides valid data.
xPF1	BOOL	Voltage <22.5 V (power fail 22.5 V)	FALSE	No AS-i power fault (Classic APF)
			TRUE	AS-i power fail (Classic APF), i.e. AS-i voltage is below 22.5 V
xPF2	BOOL	Voltage <19.0V (power fail 19V)	FALSE	No AS-i power fail (24V-APF)
			TRUE	AS-i power fail (24V-APF), i.e. AS-i voltage is below 19.0 V
wVoltage1	WORD	Voltage AS-i+ to AS-i- in mV		
wVoltage2	WORD	Voltage FE to AS-i in mV		
iSymmetry	INT	Symmetry in % (-100% ... +100%)	0xFF9C ... 0x0000 ... 0x0064	-100% ... 0% ... +100%
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set

## Get\_LAS

16008

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



### Description

16068

The FB reads the list of activated slaves (LAS) of the selected AS-i master and provides the values.

### Input parameters

16069

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16070

Parameter	Data type	Description	Possible values	
dwLAS_SA_Slaves	DWORD	List of the active S/A slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = address 0</li><li>... ...</li><li>Bit 31 (MSB) = address 31/31A</li></ul>	Per bit:	
			0	No single/A slave available
			1	Single/A slave available
dwLAS_B_Slaves	DWORD	List of the active B slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = not used</li><li>▪ Bit 1 = address 1B</li><li>... ...</li><li>Bit 31 (MSB) = address 31B</li></ul>	Per bit:	
			0	No B slave available
			1	B slave available
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing


## Get\_LDS

16013

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



### Description

16118

The FB reads the list of detected slaves (LDS) of the selected AS-i master and provides the values.

### Input parameters

16119

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16120

Parameter	Data type	Description	Possible values	
dwLDS_SA_Slaves	DWORD	List of detected S/A slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = address 0</li><li>... </li><li>▪ Bit 31 (MSB) = address 31/31A</li></ul>	Per bit:	
			0	no slave detected
			1	slave detected
dwLDS_B_Slaves	DWORD	List of detected B slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = not used</li><li>▪ Bit 1 = address 1B</li><li>... </li><li>▪ Bit 31 (MSB) = address 31B</li></ul>	Per bit:	
			0	No slave detected
			1	Slave detected
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing


## Get\_LPS

16015

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16130

The FB reads the list of projected slaves (LPS) at the selected AS-i master and provides the values.

## Input parameters

16131

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16132

Parameter	Data type	Description	Possible values	
dwLPS_SA_Slaves	DWORD	List of the projected S/A slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = address 0</li><li>... </li><li>▪ Bit 31 (MSB) = address 31/31A</li></ul>	Per bit:	
			0	Slave not projected
			1	Slave projected
dwLPS_B_Slaves	DWORD	List of the projected B slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = not used</li><li>▪ Bit 1 = address 1B</li><li>... </li><li>▪ Bit 31 (MSB) = address 31B</li></ul>	Per bit:	
			0	slave not projected
			1	slave projected
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing

## Get\_LCE

16009

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16075

The FB reads the list of configuration errors (LCE) of the selected AS-i master and provides the values.

## Input parameters

16076

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16077

Parameter	Data type	Description	Possible values	
dwLCE_SA_Slaves	DWORD	List of configuration errors of the S/A slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = address 0</li><li>... </li><li>Bit 31 (MSB) = address 31/31A</li></ul>	Per bit:	
			0	No configuration error
			1	Configuration error
dwLCE_B_Slaves	DWORD	List of configuration errors of the B slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = not used</li><li>▪ Bit 1 = address 1B</li><li>... </li><li>Bit 31 (MSB) = address 31B</li></ul>	Per bit:	
			0	No configuration error
			1	Configuration error
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing

## Get\_LCEAS

16010

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



### Description

16098

The FB reads the list of existing but not projected slaves (List of Configuration Error – Additional Slave = LCEAS) of the selected AS-i master and provides the values.

### Input parameters

16099

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16100

Parameter	Data type	Description	Possible values	
dwLCEAS_SA_Slaves	DWORD	List of configuration errors of the S/A slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = address 0</li><li>... </li><li>Bit 31 (MSB) = address 31/31A</li></ul>	Per bit:	
			0	No configuration error - additional slave
			1	Slave exists, but not projected
dwLCEAS_B_Slaves	DWORD	List of configuration errors of the B slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = not used</li><li>▪ Bit 1 = address 1B</li><li>... </li><li>Bit 31 (MSB) = address 31B</li></ul>	Per bit:	
			0	No configuration error - additional slave
			1	Slave exists, but not projected
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing


## Get\_LCEMS

16011

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



### Description

16106

The FB reads the list of projected but missing slaves (List of Configuration Error – Missing Slave = LCEMS) at the selected AS-i master and provides the values.

### Input parameters

16107

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16108

Parameter	Data type	Description	Possible values	
dwLCEMS_SA_Slaves	DWORD	List of configured but missing S/A slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = address 0</li><li>... ...</li><li>Bit 31 (MSB) = address 31/31A</li></ul>	Per bit:	
			0	No configuration error - missing slave
			1	Slave is projected but not available
sdwLCEMS_B_Slaves	DWORD	List of the configured but non-existing B slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = not used</li><li>▪ Bit 1 = address 1B</li><li>... ...</li><li>Bit 31 (MSB) = address 31B</li></ul>	Per bit:	
			0	No configuration error - missing slave
			1	Slave is projected but not available
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing

## Get\_LDAE

16012

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16112

The FB reads the double address errors (LDAE) of the selected AS-i master and provides the values in a list.

## Input parameters

16113

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16114

Parameter	Data type	Description	Possible values	
dwLDAE_SA_Slaves	DWORD	List of the double address errors. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = address 0</li><li>... ...</li><li>Bit 31 (MSB) = address 31/31A</li></ul>	Per bit:	
			0	No double address error
			1	Double address error
dwLDAE_B_Slaves	DWORD	List of double address errors. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = not used</li><li>▪ Bit 1 = address 1B</li><li>... ...</li><li>Bit 31 (MSB) = address 31B</li></ul>	Per bit:	
			0	No double address error
			1	Double address error
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing

## Get\_LPF

16014

**Function block type:** Function block (FB)

**Library:** ACnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16124

The FB reads the list of peripheral faults (LPF) of the selected AS-i master and provides the values.

## Input parameters

16125

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16126

Parameter	Data type	Description	Possible values	
dwLPF_SA_Slaves	DWORD	List of peripheral faults on S/A slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = address 0</li><li>... ...</li><li>Bit 31 (MSB) = address 31/31A</li></ul>	Per bit:	
			0	No peripheral fault
			1	Peripheral fault detected
dwLPF_B_Slaves	DWORD	List of peripheral faults on B slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"><li>▪ Bit 0 (LSB) = not used</li><li>▪ Bit 1 = address 1B</li><li>... ...</li><li>Bit 31 (MSB) = address 31B</li></ul>	Per bit:	
			0	No peripheral fault
			1	Peripheral fault detected
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing

## Get\_CDI

16006

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16045

The FB reads the configuration data (Configuration Data Image = CDI) of the slaves at the selected AS-i master and provides the values in an array. The configuration data of a slave consists of the registers IO, ID, ID1 and ID2.

## Input parameters

16046

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16047

Parameter	Data type	Description	Possible values	
awCDI	ARRAY [0..63] OF WORD	Configuration data of the slaves at the selected AS-i master	Per Word: Bits 0...3: I/O-Code Bits 4...7: ID-Code Bits 8...11: ID1-Code Bits 12...15: ID2-Code	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing


## Get\_PCD

16017

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16141

The FB reads the projected configuration data (Projected Configuration Data Image = PCD) of the slaves on the selected AS-i master and provides the values in an array.

## Input parameters

16142

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16143

Parameter	Data type	Description	Possible values	
awPCD	ARRAY [0...63] OF WORD	Permanent configuration files of the slaves on the selected AS-i master	per word: Bits 0...3: I/O-Code Bits 4...7: ID-Code Bits 8-11: ID1-Code Bits 12-15: ID2-Code  Data in Word 0 is invalid!	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing


## Get\_InputParameter

16007

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



### Description

16056

The FB reads the input parameters of the slaves on the selected AS-i master and provides the values in 2 arrays for single A slaves and B slaves.

### Input parameters

16057

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16058

Parameter	Data type	Description	Possible values	
abList_SA_Slave	ARRAY[0..31] OF BYTE	List of output parameters of S/A slaves in the selected AS-i master. Each byte contains the output parameters of an AS-i slave. – byte 0 (LSB) = res. – byte 1 = slave with address 1(A) ... – byte 31 = slave with address 31(A)	Per byte: Bits 0...3: P0-P3	
abList_B_Slave	ARRAY[0..31] OF BYTE	List of output parameters of B slaves in the selected AS-i master. Each byte contains the output parameters of an AS-i slave. – byte 0 (LSB) = res. – byte 1 = slave with address 1B ... – byte 31 = slave with address 31B	Per byte: Bits 0...3: P0-P3	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing


## Get\_OutputParameter

16016

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



### Description

16136

The FB reads the output parameters of the slaves on the selected AS-i master and provides the values for S/A slaves and B slaves in 2 separate arrays.

### Input parameters

16137

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

16138

Parameter	Data type	Description	Possible values	
abList_SA_Slave	ARRAY[0..31] OF BYTE	List of output parameters of S/A slaves in the selected AS-i master. Each byte contains the output parameters of an AS-i slave. – byte 0 (LSB) = res. – byte 1 = slave with address 1(A) ... – byte 31 = slave with address 31(A)	Per byte: Bits 0...3: P0-P3	
abList_B_Slave	ARRAY[0..31] OF BYTE	List of output parameters of B slaves in the selected AS-i master. Each byte contains the output parameters of an AS-i slave. – byte 0 (LSB) = res. – byte 1 = slave with address 1B ... – byte 31 = slave with address 31B	Per byte: Bits 0...3: P0-P3	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing

## Set\_AddressMode

16018

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16146

The FB activates/deactivates the parameter "Automatic addressing" for the selected AS-i master.

## Input parameters

16147

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2
enAuto_Address_Mode	ASI_ADDRESS_MODE	Parameter activates/deactivates the automatic addressing mode.	Auto_address_disable	Automatic addressing inactive
			Auto_address_enable	Automatic addressing active

## Output parameters

17017

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000                  No specific error is set

## Set\_ASi\_Config

16019

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16149

The FB activates/deactivates the parameters "double address recognition" and "earth fault detection" for the selected AS-i master.

## Input parameters

16150

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2
xDoubleAdrDetection	BOOL	Activate/deactivate "Double address recognition"	FALSE	Double address recognition inactive
			TRUE	Double address recognition active
xEarthFaultDetection	BOOL	Activate/deactivate "Earth-fault detection"	FALSE	Earth-fault detection inactive
			TRUE	Earth-fault detection active

## Output parameters

17015

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0001 Wrong parameter transferred, setting was not adopted.


## Set\_LPS

16020

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16153

The FB changes the list of projected slaves (LPS) in the selected AS-i master.

## Input parameters

16154

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2
dwLPS_SA_Slaves	DWORD	List of the projected S/A slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"> <li>▪ Bit 0 (LSB) = address 0</li> <li>...</li> <li>▪ Bit 31 (MSB) = address 31/31A</li> </ul>	Per bit:	
			0	Slave not projected
			1	Slave projected
dwLPS_B_Slaves	DWORD	List of the projected B slaves. Each bit represents an AS-i address: <ul style="list-style-type: none"> <li>▪ Bit 0 (LSB) = not used</li> <li>▪ Bit 1 = address 1B</li> <li>...</li> <li>▪ Bit 31 (MSB) = address 31B</li> </ul>	Per bit:	
			0	slave not projected
			1	slave projected

## Output parameters

17016

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0019 Master not in the projecting mode

## Set\_Mode

16021

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16155

The FB changes the operating mode (protected operation, projection mode) of the selected AS-i master.

## Input parameters

16156

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2
enMode_ASi_Master	ASI_MASTER_MODE	Operating mode of the AS-i master	Closed_mode	protected mode active
			Project_mode	projection mode active

## Output parameters

17018

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0003 Slave with address 0 found (slave not detected)


## Set\_PCD

16022

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16151

The FB changes the configuration file (Permanent Configuration Data = PCD) of the slaves at the selected AS-i master.

## Input parameters

16160

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2
awPCD	ARRAY [0..63] OF WORD	Permanent configuration files of the slaves on the selected AS-i master	per word: Bits 0..3: I/O-Code Bits 4..7: ID-Code Bits 8-11: ID1-Code Bits 12-15: ID2-Code Data in Word 0 is invalid!	

## Output parameters

15574

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0019 Master not in the projecting mode

## Set\_ProjectAll

16023

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16161

The FB starts the projection adaptation on the selected AS-i master.

## Input parameters

16125

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2

## Output parameters

17020

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

## Diagnostic codes:

- 0x0000 No specific error is set
- 0x0003 Slave with address 0 found (slave not detected)
- 0x0019 Master not in the projecting mode

## Set\_SlaveAddress

16024

**Function block type:** Function block (FB)

**Library:** ACnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16162

The FB changes the address of the selected AS-i slaves.

## Input parameters

16165

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2
enASi_Slave	ASI_SLAVE	Address of the AS-i slave	Slave_n	AS-i slave to address n (n = 1 ... 31)
enASi_SlaveTyp	ASI_SLAVE_TYP	Type of the AS-i slave	SA_Slave	Single or A slave
			B_Slave	B-Slave
enASi_Slave_new	ASI_SLAVE	New address of the AS-i slave	Slave_n	AS-i slave at address n (n = 1 ... 31)
enASi_SlaveTyp_new	ASI_SLAVE_TYP	New type of the AS-i slave	SA_Slave	single slave or A slave
			B_Slave	B slave

## Output parameters

17021

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0001 Slave does not respond or change to offline mode during FB execution
- 0x0002 Slave with old address not found (slave not detected)
- 0x0003 Slave with address 0 found (slave not detected)
- 0x0004 Slave with new address found
- 0x0005 Error during deletion of the old address (Delete Error)
- 0x0006 ExtendedID1 could not be read after writing (Read Error)
- 0x0007 Error when writing ExtendedID1 (Set Error)
- 0x0008 New address temporary stored
- 0x0009 ExtendedID1 stored temporarily
- 0x0018 Master is not in normal operation.

## Set\_SlaveExtendedID1

16025

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16169

The FB changes the Extended ID1 of the selected AS-i slave.

## Input parameters

16170

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2
enASi_Slave	ASI_SLAVE	Address of the AS-i slave	Slave_n	AS-i slave to address n (n = 1 ... 31)
enASi_SlaveTyp	ASI_SLAVE_TYP	Type of the AS-i slave	SA_Slave	Single or A slave
			B_Slave	B-Slave
bExtendedID1	BYTE	Extended ID1 code of the selected AS-i slave	Extended ID1 code (hexadecimal representation)	

## Output parameters

16148

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0003 Slave with address 0 found (slave not detected)
- 0x0005 Error during deletion of the old address (Delete Error)
- 0x0006 ExtendedID1 could not be read after writing (Read Error)
- 0x0007 Error when writing ExtendedID1 (Set Error)
- 0x0009 ExtendedID1 stored temporarily
- 0x000E Invalid slave address (e.g. 0 or 0B specified)
- 0x0018 Master is not in normal operation.
- 0x0021 Invalid ExtendedID1 code


## Set\_SlaveParameter

16026

**Function block type:** Function block (FB)

**Library:** ACnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16172

The FB changes the parameters of the selected AS-i slave.

## Input parameters

16173

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2
enASi_Slave	ASI_SLAVE	Address of the AS-i slave	Slave_n	AS-i slave to address n (n = 1 ... 31)
enASi_SlaveTyp	ASI_SLAVE_TYP	Type of the AS-i slave	SA_Slave	Single or A slave
			B_Slave	B-Slave
enASi_SlaveParam	BYTE	Parameters of the selected AS-i slave	Slave parameters (hexadecimal representation)	

## Output parameters

17025

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0001 Slave does not respond or change to offline mode during FB execution
- 0x000A Slave not in LAS
- 0x000B Data content invalid (e.g. parameter value >7 for A/B slaves)
- 0x000E Invalid slave address (e.g. 0 or 0B specified)
- 0x0018 Master is not in normal operation.

## Get\_ASi\_Data

16000

**Function block type:** Function block (FB)

**Library:** ACnnn\_Utils.library

**Symbol in CODESYS:**



## Description

16033

The FB reads the following data from the selected AS-i master and stores the values in a structure variable of data type ASI\_DATA (→ **ASI\_DATA (STRUCT)** (→ p. 115)):

- List of activated slaves – LAS
- List of detected slaves – LDS
- List of projected slaves – LPS
- List of configuration errors – LCE
- List of configuration errors - additional slave – LCEAS
- List of configuration errors - missing slave – LCEMS
- List of peripheral faults – LPF
- List of double address errors – LDAE
- Configuration data image – CDI
- Projected configuration data – PCD
- Input parameters of the AS-i slaves
- Outputs parameters of the AS-i slaves

## Input parameters

16034

Parameter	Data type	Description	Possible values	
xEnable	BOOL	Control activiy of the FB	TRUE	FB is enabled
			FALSE	FB is disabled
enASi_Master	ASI_MASTER	Select AS-i master	Master_1	AS-i master 1
			Master_2	AS-i master 2
pASi_Data	POINTER TO ASI_DATA	Structure variable in which the read data is to be stored.	Variable must be declared!	

## Output parameters

16035

Parameter	Data type	Description	Possible values	
xActive	BOOL	Signal confirms the FB execution	FALSE	Function block is inactive
			TRUE	FB is active (=is executed)
wCycleCount	WORD	Counter for FB cycles that were fully run through	Number in hexadecimal representation	
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0xnF01 Unknown error <sup>1</sup>
- 0xnF02 Unknown/invalid target <sup>1</sup>
- 0xnF03 Unknown command ID <sup>1</sup>
- 0xnF04 Unknown parameters <sup>1</sup>
- 0xnF05 Timeout during processing <sup>1</sup>

### Legend:

<sup>1</sup> Get\_ASi\_Data executes the FB ACnnn\_SysCmd sequentially with different command IDs in order to determine the individual elements of the complex variable. In the returned error code, the nibble n indicates the command request where the error occurred. n can have the following values:

- 1 = error with "Get LAS, LDA, LPF, LCE"
- 2 = error with "Get LPS"
- 3 = error with "Get CDI"
- 4 = error with "Get PCD"
- 5 = error with "Get Input Parameter"
- 6 = error with "Get Output Parameter"
- 7 = error with "Get LCEMS, LCEAS, LDAE"

## 9.1.2 Overview: System functions (FB\_System)

### Contents

Get_FieldbusInfo .....	107
QuickSetupASI_Master .....	109
Set_TimeDate .....	111

17460

## Get\_FieldbusInfo

17453

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

17454

The FB reads information about the fieldbus and provides the values in a list. The following information are read:

- Status of the fieldbus
- Fieldbus type
- Status of the Ethernet connection at port X6 and X7
- MAC addresses
- IP address of the fieldbus host

## Input parameters

17455

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution

## Output parameters

17456

Parameter	Data type	Description	Possible values	
aw_InfoList	ARRAY[0...18] OF WORD	Fieldbus information	Position of the data within the individual words → <b>DS18: Fieldbus information</b>	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0F01 Unknown error
- 0x0F02 Unknown/invalid target
- 0x0F03 Unknown command ID
- 0x0F04 Invalid parameters
- 0x0F05 Timeout during processing

## QuickSetupASi\_Master

15999

**Function block type:** Function block (FB)

**Library:** ACnnn\_Utils.library

**Symbol in CODESYS:**



### Description

15902

The FB executes the quick setup routine on the selected AS-i masters.

### Input parameters

15903

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
xMaster1	BOOL	Select AS-i master 1 for quick setup	FALSE	No execution of quick setup, AS-i configuration remains unchanged.
			TRUE	Execution of quick set up on AS-i master
xMaster2	BOOL	Select AS-i master 2 for quick setup	FALSE	No execution of quick setup, AS-i configuration remains unchanged.
			TRUE	Execution of quick set up on AS-i master

## Output parameters

15920

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0003 Slave with address 0 found (slave not detected)


## Set\_TimeDate

15998

**Function block type:** Function block (FB)

**Library:** ACnnnn\_Utils.library

**Symbol in CODESYS:**



## Description

15949

The FB sets the system time (time and date) of the device using the transmitted input values.

## Input parameters

15988

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
bDay	BYTE	Day	0x01 ... 0x1F	1 ... 31
bMonth	BYTE	Month	0x01 ... 0x0C	January ... December
wYear	WORD	Year	0x07B3 ... 0x07F5	1971 ... 2037
bHour	BYTE	Hour	0x00 ... 0x17	0 ... 23
bMinute	BYTE	Minute	0x00 ... 0x3B	0 ... 59
bSecond	BYTE	Second	0x00 ... 0x3B	0 ... 59

## Output parameters

15990

Parameter	Data type	Description	Possible values	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xBusy	BOOL	Signal indicates if the FB is executed.	FALSE	FB is deactivated or FB execution is terminated.
			TRUE	FB execution is started but not yet terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
wDiagnostic	WORD	Diagnostic information	→ List below (Diagnostic codes)	

### Diagnostic codes:

- 0x0000 No specific error is set
- 0x0001 Transferred values for date/time are invalid and could not be set.
- 0x0002 NTP active, time could not be adopted.

## 9.1.3 Enumeration types and complex variables

### Contents

Enumeration types (ENUM).....	113
Complex variables (STRUCT) .....	115

15986

In addition to the standard data types, the CODESYS package from ifm electronic also features the following enumeration types (ENUM) and complex variables (STRUCT):

### Enumeration types (ENUM)

16176

The library ACnnnn\_Utils provides the following enumeration types (ENUM):

#### ASI\_ADDRESS\_MODE (ENUM)

16177

Designation	Description	Variable	Data type	Value
ASI_ADDRESS_MODE	AS-i autoaddressing mode	▪ Auto_address_enable	INT	0
		▪ Auto_address_disable	INT	1

#### ASI\_MASTER (ENUM)

16178

Designation	Description	Variable	Data type	Value
ASI_MASTER	Identifier for AS-i masters	▪ Master_1	INT	1
		▪ Master_2	INT	2

#### ASI\_MASTER\_MODE (ENUM)

16179

Designation	Description	Variable	Data type	Value
ASI_MASTER_MODE	Operating mode of the AS-i master	▪ Closed_mode	INT	0
		▪ Project_mode	INT	1

**ASI\_SLAVE (ENUM)**

16180

<b>Designation</b>	<b>Description</b>	<b>Variable</b>	<b>Data type</b>	<b>Value</b>
ASI_SLAVE	Identifier for AS-i slaves	▪ Slave_1	INT	1
		▪ Slave_2	INT	2
		▪ Slave_3	INT	3
		▪ Slave_4	INT	4
		▪ Slave_5	INT	5
		▪ Slave_6	INT	6
		▪ Slave_7	INT	7
		▪ Slave_8	INT	8
		▪ Slave_9	INT	9
		▪ Slave_10	INT	10
		▪ Slave_11	INT	11
		▪ Slave_12	INT	12
		▪ Slave_13	INT	13
		▪ Slave_14	INT	14
		▪ Slave_15	INT	15
		▪ Slave_16	INT	16
		▪ Slave_17	INT	17
		▪ Slave_18	INT	18
		▪ Slave_19	INT	19
		▪ Slave_20	INT	20
		▪ Slave_21	INT	21
		▪ Slave_22	INT	22
		▪ Slave_23	INT	23
		▪ Slave_24	INT	24
		▪ Slave_25	INT	25
		▪ Slave_26	INT	26
		▪ Slave_27	INT	27
		▪ Slave_28	INT	28
		▪ Slave_29	INT	29
		▪ Slave_30	INT	30
		▪ Slave_31	INT	31

**ASI\_SLAVE\_TYP (ENUM)**

16181

<b>Designation</b>	<b>Description</b>	<b>Variable</b>	<b>Data type</b>	<b>Value</b>
ASI_SLAVE_TYP	Type of the AS-i slave	▪ SA_Slave	INT	0
		▪ B_Slave	INT	1

## Complex variables (STRUCT)

15991

The library ACnnnn\_Utils.library provides complex variables of the data type STRUCT. They are used by the FBs, but they can also be used by the programmer in CODESYS projects for the device-internal PLC.

### ASI\_DATA (STRUCT)

15992



Name	Data type	Description	Possible values
▪ LDS_SA_Slave	DWORD	List of the active S/A slaves	Each bit represents an AS-i address: 0 = no slave active 1 = slave active → <b>DS9 – Slave lists LAS, LDS, LPF, LCE,</b> words 4...7
▪ LDS_B_Slave	DWORD	List of active B slaves	
▪ LAS_SA_Slave	DWORD	List of active S/A slaves	Each bit represents an AS-i address: 0 = no active slave 1 = active slave
▪ LAS_B_Slave	DWORD	List of active B slaves	→ <b>DS9 – Slave lists LAS, LDS, LPF, LCE,</b> words 0...3
▪ LPF_SA_Slave	DWORD	List of peripheral faults (S/A slaves)	Each bit represents an AS-i address: 0 = no peripheral fault 1 = peripheral fault
▪ LPF_B_Slave	DWORD	List of peripheral faults (B slaves)	→ <b>DS9 – Slave lists LAS, LDS, LPF, LCE,</b> words 8...11
▪ LCE_SA_Slave	DWORD	List with configuration errors (S/A slaves)	Each bit represents an AS-i address: 0 = no configuration error 1 = configuration error
▪ LCE_B_Slave	DWORD	List with configuration errors (B slaves)	→ <b>DS9 – Slave lists LAS, LDS, LPF, LCE,</b> words 12...15
▪ LPS_SA_Slave	DWORD	List of projected S/A slaves	Each bit represents an AS-i address: 0 = no projected slave 1 = projected slave
▪ LPS_B_Slave	DWORD	List of active B slaves	→ <b>DS10 – Slave list LPS</b>
▪ LCEMS_SA_Slave	DWORD	List of configuration errors: projected, but missing S/A slave	Each bit represents an AS-i address: 0 = no configuration error 1 = configuration error
▪ LCEMS_B_Slave	DWORD	List of configuration errors: projected, but missing B slave	→ <b>DS17 – AS-i master: Error lists LCEMS, LCEAS, LDAE,</b> words 0...3
▪ LCEAS_SA_Slave	DWORD	List of configuration errors: additional S/A slave	Each bit represents an AS-i address: 0 = no error 1 = error
▪ LCEAS_B_Slave	DWORD	List of configuration errors: additional B slave	→ <b>DS17 – AS-i master: Error lists LCEMS, LCEAS, LDAE,</b> words 4...7
▪ LDAE_SA_Slave	DWORD	List of double address errors (S/A slaves)	Each bit represents an AS-i address: 0 = no double address error 1 = double address error
▪ LDAE_B_Slave	DWORD	List of double address errors (B slaves)	→ <b>DS17 – AS-i master: Error lists LCEMS, LCEAS, LDAE,</b> words 8...11
▪ CDI	ARRAY[0..63] OF WORD	Image of the current configuration data (CDI = Configuration Data Image)	One word is available per slave: Bits 0...3 = IO code Bits 4...7 = ID code Bits 8...11 = Extended ID1 code Bits 12...15 = Extended ID2 code → <b>DS11 – Actual configuration data (CDI)</b>

Name	Data type	Description	Possible values
▪ PCD	ARRAY[0..63] OF WORD	Image of the projected configuration data (PCD = Projected Configuration Data)	Each word contains data of one slave: Bits 0...3 = IO Bits 4...7 = ID Bits 8...11 = ID1 Bits 12...15 = ID2 → <b>DS12 – Projected configuration data (PCD)</b>
▪ InputParam_SA_Slave	ARRAY[0..31] OF BYTE	Input parameters of the S/A slaves	Each byte contains parameters of one S/A slave: Bits 0...3 = P0-P3 Bits 4...7 = reserved → <b>DS13 – Image of the input parameters of the slaves (PI)</b> , words 0...15
▪ InputParam_B_Slave	ARRAY[0..31] OF BYTE	Input parameters of the B slaves	Each byte contains parameters of one B slave: Bits 0...3 = P0-P3 Bits 4...7 = reserved → <b>DS13 – Image of the input parameters of the slaves (PI)</b> , words 16...31
▪ OutputParam_SA_Slave	ARRAY[0..31] OF BYTE	Output parameters of the S/A slaves	Each byte contains parameters of one S/A slave: Bits 0...3 = P0-P3 Bits 4...7 = reserved → <b>DS14 – Image of the output parameters of the slaves (PP)</b> , words 0...15
▪ OutputParam_B_Slave	ARRAY[0..31] OF BYTE	Output parameters of the B slaves	Each byte contains parameters of one B slave: Bits 0...3 = P0-P3 Bits 4...7 = reserved → <b>DS14 – Image of the output parameters of the slaves (PP)</b> , words 16...31

## ASI\_NET (STRUCT)

15993

The structure contains the complete process image (inputs and outputs) of an AS-i network.

Name	Data type	Description	Possible values
▪ binIO	ASI_BIN_IO	Binary input and output data	→ <b>ASI_BIN_IO (STRUCT)</b> (→ p. <a href="#">117</a> )
▪ analIO	ASI_ANA_IO	Analogue input and output data	→ <b>ASI_ANA_IO (STRUCT)</b> (→ p. <a href="#">118</a> )

## ASI\_BIN\_IO (STRUCT)

16002

The structure contains the process data of the digital input and output slaves:

Name	Data type	Description	Possible values
▪ bin_IN_Slaves	ASI_BIN_IN	Input data of the digital AS-i slaves	→ <b>ASI_BIN_IN (STRUCT)</b> (→ p. <a href="#">118</a> )
▪ bin_OUT_Slaves	ASI_BIN_OUT	Output data of the digital AS-i slaves	→ <b>ASI_BIN_OUT (STRUCT)</b> (→ p. <a href="#">118</a> )

## ASI\_BIN\_IN (STRUCT)

16004

The structure contains the input data of the digital AS-i slaves:

Name	Data type	Description	Possible values
▪ SA_Slave	ARRAY[1...31] OF BYTE	Input data of the digital S/A slaves, 1 byte per S/A slave	corresponds to the 1st to 15th word of the acyclic data record 2 (DS2) → DS2 – Digital inputs of the slaves and master flags
▪ B_Slave	ARRAY[1...31] OF BYTE	Input data of the digital B slaves, 1 byte per B slave	corresponds to the 16th to 31st word of the acyclic data record 2 (DS2) → DS2 – Digital inputs of the slaves and master flags

## ASI\_BIN\_OUT (STRUCT)

16003

The structure contains the output data of the digital AS-i slaves.

Name	Data type	Description	Possible values
▪ SA_Slave_bin_OUT	ARRAY[1...31] OF BYTE	Output data of the digital S/A slaves (1 byte per S/A slave)	corresponds to the 1st to 15th word of the acyclic data record 5 (DS5) → DS5 – Digital outputs of the slaves
▪ B_Slave_bin_OUT	ARRAY[1...31] OF BYTE	Output data of the digital B slaves (1 byte per B slave)	corresponds to the 16th to 31st word of the acyclic data record 5 (DS5) → DS5 – Digital outputs of the slaves

## ASI\_ANA\_IO (STRUCT)

16001

The structure contains the process data of the analogue input and output slaves.

Name	Data type	Description	Possible values
▪ ana_IN_Slave	ARRAY[1..31] OF ASI_ANALOG_IN	Input data and status flags of the analogue AS-i slaves	→ ASI_ANALOG_IN (STRUCT) (→ p. 119)
▪ ana_OUT_Slave	ARRAY[1..31] OF ASI_ANALOG_OUT	Output data and status flags of the analogue AS-i slaves	→ ASI_ANALOG_OUT (STRUCT) (→ p. 120)

## ASI\_ANALOG\_IN (STRUCT)

15994

The structure contains the process data of the analogue input slave as well as the transmitted status flags.

Designation	Data type	Description	Possible values
▪ chan_1	INT	Analogue value channel 1: S or A input slave	corresponds to the 1st to 4th word of an area comprising 5 words in the acyclic data records 3 and 4 (DS3+4) → DS3 – Analogue inputs of slaves 1(A)...15(B) → DS4 – Analogue inputs of slaves 16(A)...31(B)
▪ chan_2	INT	Analogue value channel 2: S or A input slave	
▪ chan_3	INT	Analogue value channel 3: S or B input slave	
▪ chan_4	INT	Analogue value channel 4: S or B input slave	
▪ flags	ASI_ANALOG_OUT_FLAGS	Status flags	→ ASI_ANALOG_IN_FLAGS (STRUCT) (→ p. <a href="#">119</a> )

## ASI\_ANALOG\_IN\_FLAGS (STRUCT)

15996

The structure contains the status flags of the analogue input slave.

Name	Data type	Description	Possible values
▪ V0	BOOL	Valid bit, channel 1	corresponds to the fifth word of an area comprising 5 words in the acyclic data records 3 and 4 (DS3+4) → DS3 – Analogue inputs of slaves 1(A)...15(B) → DS4 – Analogue inputs of slaves 16(A)...31(B)
▪ O0	BOOL	Overflow bit, channel 1	
▪ V1	BOOL	Valid bit, channel 2	
▪ O1	BOOL	Overflow bit, channel 2	
▪ V2	BOOL	Valid bit channel 3	
▪ O2	BOOL	Overflow bit, channel 3	
▪ V3	BOOL	Valid bit, channel 4	
▪ O3	BOOL	Overflow bit, channel 5	
▪ na1	BOOL	--	
▪ TOA	BOOL	Transfer output, S/A slave	
▪ na2	BOOL	--	
▪ TOB	BOOL	Transfer output, B slave	
▪ na3	BOOL	--	
▪ TIA	BOOL	Transfer input, S/A slave	
▪ na4	BOOL	--	
▪ TIB	BOOL	Transfer input, B slave	

## ASI\_ANALOG\_OUT (STRUCT)

15995

The structure represents the process data of the analogue output slaves as well as the transmitted flags.

Designation	Data type	Description	Possible values
▪ chan_1	INT	Analogue value channel 1: S or A output slave	corresponds to the acyclic data records 6 and 7 (DS6, DS7) → <b>DS6 – Analogue outputs of slaves 1(A)...15(B)</b> → <b>DS7 – Analogue outputs of slaves 16(A)...31(B)</b>
▪ chan_2	INT	Analogue value channel 2: S or A output slave	
▪ chan_3	INT	Analogue value channel 3: S or B output slave	
▪ chan_4	INT	Analogue value channel 4: S or B output slave	
▪ flags	ASI_ANALOG_OUT_FLAGS	Status flags	→ <b>ASI_ANALOG_OUT_FLAGS (STRUCT)</b> (→ p. <a href="#">120</a> )

## ASI\_ANALOG\_OUT\_FLAGS (STRUCT)

15997

The structure contains the status flags of the analogue output slave.

Name	Data type	Description	Possible values
▪ na1	BOOL	--	corresponds to the acyclic data record 8 (DS8) → <b>DS8 – Status flags of analogue output data of the slaves 1...31</b>
▪ na2	BOOL	--	
▪ na3	BOOL	--	
▪ na4	BOOL	--	
▪ na5	BOOL	--	
▪ na6	BOOL	--	
▪ na7	BOOL	--	
▪ na8	BOOL	--	
▪ OVA	BOOL	Output valid, S/A slave	
▪ na9	BOOL	--	
▪ OVB	BOOL	Output valid, B slave	
▪ n10	BOOL	--	
▪ TOA	BOOL	Transfer Output, S/A slave	
▪ na11	BOOL	--	
▪ TOB	BOOL	Transfer Output, B slave	
▪ na12	BOOL	--	

## 9.2 Library ACnnnn\_SYS\_CMD.library

### Contents


ACnnnn_SysCmd .....	121
	17723

### 9.2.1 ACnnnn\_SysCmd

15890

**Function block type:** Function block (FB)  
**Library:** ACnnnn\_SYS\_CMD.library

**Symbol in CODESYS:**



### Description

15893

Using the FB, individual commands can be sent to the system or to an AS-i master.

Each command refers to the data structures of one of the following elements:

- Command request channel: → **Example: Change language setting of the device** (→ p. [126](#))
- Command response channel: → **Example: Date / time / read NTP settings** (→ p. [127](#))
- Acyclic data record (DSx): → **Example: Read LCEMS, LCEAS and LDAE of AS-i master 2** (→ p. [128](#))

## Input parameters

15895

Parameter	Data type	Description	Possible values	
xExecute	BOOL	Control execution of the FB	FALSE	Stop FB execution
			TRUE	Start one-time FB execution
uCommandID	WORD	ID of the command to be executed	→ <b>Table: System commands</b> (→ p. 122) → <b>Table: AS-i master commands</b> (→ p. 123)	
uTarget	INT	Device component to which the command is to be sent	0	system
			1	AS-i master 1
			2	AS-i master 2
pDataIn	POINTER TO WORD	Buffer for data that is assigned to the command as input parameters.	Command parameter described in the command request channel (word 3 to 120)	
uSizeIn	WORD	Size of the buffer for the input parameters (number of bytes)		
pDataOut	POINTER TO WORD	Buffer for data that is returned as output parameters (results)	Return values described in the command reply channel (data as of word 5)	
uSizeOut	WORD	Size of the buffer for the output parameters (number of bytes)		

**Table: System commands**

17053

uCommandID	Description
0x0001	DS1 – System information
0x1101	Command 0x0101 – Quick set-up AS-i masters 1 + 2
0x1103	Command 0x0103 – Select user language
0x1104	Command 0x0104 – Change display settings
0x1105	Command 0x0105 – Set output control
0x1109	Command 0x0109 – Set date / time
0x110A	Command 0x010A – Configure the NTP server settings
0x110B	Command 0x010B – Read date / time / NTP settings
0x110C	Command 0x010C – Reboot system
0x110D	Command 0x010D – Read fieldbus info
0x1110	Command 0x0110 - Display target visualisation



Only execute system commands with the input parameter uTarget = 0!



Detailed information about the acyclic data sets and the command interface is given in the supplement to the device manual of the AS-i Gateway AC14 (→ **Overview: User documentation for AS-i Gateway AC14** (→ p. 5)).

**Table: AS-i master commands**

17054

<b>uCommandID</b>	<b>Description / corresponding command</b>
0x0002	DS2 – Digital slave inputs and master flags
0x0003	DS3 – Analogue inputs of the slaves 1(A)...15(B)
0x0004	DS4 – Analogue inputs of the slaves 16(A)...31(B)
0x0005	DS5 – Digital slave outputs
0x0006	DS6 – Analogue outputs of the slaves 1(A)...15(B)
0x0007	DS7 – Analogue outputs of the slaves 16(A)...31(B)
0x0008	DS8 – Status flags of the analogue outputs of slaves 1...31
0x0009	DS9 – Slave lists LAS, LDS, LPF, LCE
0x000A	DS10 – Slave list LPS
0x000B	DS11 – Current configuration data (CDI)
0x000C	DS12 – Projected configuration data (PCD)
0x000D	DS13 – Image of the input parameters of the slaves (PI)
0x000E	DS14 – Image of the outputs parameters of the slaves (PP)
0x000F	DS15 – Slave error counter, configuration error counter, AS-i cycle counter
0x0011	DS17 – AS-i master: Error lists LCEMS, LCEAS, LDAE
0x1001	Command 0x0001 – Change AS-i slave parameters
0x1003	Command 0x0003 – Project current AS-i network
0x1004	Command 0x0004 – Change LPS
0x1005	Command 0x0005 – Change the operating mode of the AS-i master
0x1006	Command 0x0006 – Change AS-i slave address
0x1007	Command 0x0007 - Set auto address mode of the AS-i master
0x1009	Command 0x0009 – Change extended ID1 in the AS-i slave
0x100A	Command 0x000A - Change PCD
0x100D	Command 0x000D – AS-i master supply voltage, symmetry, earth fault
0x1015	Command 0x0015 – Read ID string of an AS-i profile (S-7.4)
0x101A	Command 0x001A – Read AS-i master info
0x101C	Command 0x001C – Deactivate slave reset when changing to the protected mode
0x1021	Command 0x0021 - Read diagnostics string of an AS-i slave (S-7.4)
0x1022	Command 0x0022 - Read parameter string of an AS-i slave (S-7.4)
0x1023	Command 0x0022 - Write parameter string of an AS-i slave (S-7.4)
0x1024	Command 0x0024 – CTT2 standard read
0x1025	Command 0x0025 – CTT2 standard write
0x1026	Command 0x0026 – CTT2 vendor specific read
0x1027	Command 0x0027 – CTT2 vendor specific selective write
0x1040	Command 0x0040 – CTT2 device group read
0x1041	Command 0x0041 – CTT2 device group write
0x1042	Command 0x0042 – CTT2 vendor specific selective read from buffer
0x1043	Command 0x0043 – CTT2 vendor specific selective write from buffer

uCommandID	Description / corresponding command
0x1044	Command 0x0044 – CTT2 vendor specific selective read
0x1045	Command 0x0045 – CTT2 vendor specific selective write
0x1046	Command 0x0046 – CTT2 device group selective read
0x1047	Command 0x0047 – CTT2 device group selective write
0x1049	Command 0x0049 – CTT2 vendor specific exchange
0x104A	Command 0x004A – CTT2 device group exchange
0x104B	Command 0x004B – CTT2 device group selective read from buffer
0x104C	Command 0x004C – CTT2 device group selective write from buffer
0x1050	Command 0x0050 – Set AS-i master settings
0x1051	Command 0x0051 – Reset error counter



Only execute AS-i master commands with input parameter uTarget = 1 or 2!



Detailed information about the acyclic data sets and the command interface is given in the supplement to the device manual of the AS-i Gateway AC14 (→ **Overview: User documentation for AS-i Gateway AC14** (→ p. 5)).

## Output parameters

15897

Parameter	Data type	Description	Possible values	
uCount	WORD	Number of valid bytes in pDataOut (uCount <= uSizeOut)	integer value in hexadecimal representation	
xReady	BOOL	Signal indicates if the execution of the FB is terminated.	FALSE	FB is inactive or being executed.
			TRUE	FB execution is terminated.
xError	BOOL	Signal indicates if errors occurred while the FB was executed.	FALSE	FB is disabled or presently executed or FB was executed without error.
			TRUE	An error occurred when the FB was executed.
uErrorCode	WORD	Error code of the executed command	Command error code of the corresponding command channel OR: → List below (Diagnostic codes)	

### Diagnostic codes:

- 0xF01 Unknown error <sup>1</sup>
- 0xF02 Unknown/invalid target
- 0xF03 Unknown command ID
- 0xF04 Invalid parameters
- 0xF05 Timeout during processing

## Example: Change language setting of the device

17051

**Task:** Set the language of the graphic user surface of the device to "Spanish" with the FB ACnnn\_SysCmd.

**Command type:** Command request channel

**Input parameters of the FB:**

Parameter	Value	Explanation
uCommandID	0x1103	Corresponding command channel: → <b>Command 0x0103 – Select user language</b> (→ device manual supplement)
uTarget	0	System command
pDataIn	arDataIn	<ul style="list-style-type: none"> <li>▪ Variable of the data type Array of Words</li> <li>▪ arDataIn contains the command parameters</li> </ul>
uSizeIn	0x0001	arDataIn only consists of 1 line since word 1 and 2 as well as 4 to 120 of the command request channel are not considered.
pDataOut	--	irrelevant since command request channel
uSizeOut	--	irrelevant since command request channel

**Content of arDataIn:**

Word no.	Contents	Explanation
1	0x4553	Spanish

## Example: Date / time / read NTP settings

17423

**Task:** Read the current system time and the NTP settings with the FB ACnnn\_SysCmd.

**Command type:** Command reply channel

**Input parameters of the FB:**

Parameter	Value	Declaration
uCommandID	0x110B	Corresponding command channel: → <b>Command 0x010B – Read date / time / NTP settings</b> (→ device manual supplement)
uTarget	0	System command
pDataIn	--	irrelevant, since command reply channel
uSizeIn	--	irrelevant, since command reply channel
pDataOut	arDataOut	<ul style="list-style-type: none"> <li>▪ variable of the data type Array of Words</li> <li>▪ contains the return values of the reply channel</li> </ul>
uSizeOut	0x0007	Array consists of 7 lines since the reply channel returns 7 words (words 5 ... 11).

**Content of arDataOut:**

Word no.	Content	
1	Month	Day
2	Year	Year
3	Minutes	Hours
4	reserved	Seconds
5	NTP offset	NTP status
6 ... 7	IP address NTP server	

## Example: Read LCEMS, LCEAS and LDAE of AS-i master 2

17424

**Task:** Read the error lists LCEMS, LCEAS and LDAE of the AS-i master 2 with the FB ACnnnn\_SysCmd.

**Command type:** acyclic data set

**Input parameters of the FB:**

Parameter	Value	Declaration
uCommandID	0x0011	Corresponding acyclic data set: → DS17 – AS-i master: Error lists LCEMS, LCEAS, LDAE (→ device manual supplement)
uTarget	1	Master command (1 = AS-i master 2))
pDataIn	--	irrelevant
uSizeIn	--	irrelevant
pDataOut	arDataOut	<ul style="list-style-type: none"> <li>▪ Variable of the data type Array of Words</li> <li>▪ contains the return values</li> </ul>
uSizeOut	0x000C	Array consists of 12 lines since the data set DS17 has exactly 12 words

**Content of arDataOut:**

Word no.	Content
1 ... 4	LCEMS (list of configuration errors - missing slaves)
5 ... 8	LCEAS (list of configuration errors - additional slaves)
9 ... 12	LDAE (list of double address errors)

# 10 Index

## A

Access input and output data .....	27
ACnnn_SysCmd .....	121
Activate CODESYS PLC .....	49
Add fieldbus stack .....	23
Add visualisation to a project .....	41
Analogue input and output data .....	30
Analogue output data .....	32
Appendix .....	58
ASI_ADDRESS_MODE (ENUM) .....	113
ASI_ANA_IO (STRUCT) .....	118
ASI_ANALOG_IN (STRUCT) .....	119
ASI_ANALOG_IN_FLAGS (STRUCT) .....	119
ASI_ANALOG_OUT (STRUCT) .....	120
ASI_ANALOG_OUT_FLAGS (STRUCT) .....	120
ASI_BIN_IN (STRUCT) .....	118
ASI_BIN_IO (STRUCT) .....	117
ASI_BIN_OUT (STRUCT) .....	118
ASI_DATA (STRUCT) .....	115
ASI_MASTER (ENUM) .....	113
ASI_MASTER_MODE (ENUM) .....	113
ASI_NET (STRUCT) .....	117
ASI_SLAVE (ENUM) .....	114
ASI_SLAVE_TYP (ENUM) .....	114
Available fieldbus stacks .....	22

## C

Change network settings .....	36
Change properties of the web visualisation .....	43
Change system time of the device .....	26
Change the properties of the target visualisation .....	44
CODESYS programming software .....	11
Complex variables (STRUCT) .....	115
Components of the ifm package .....	12
Configure AS-i master .....	35
Configure AS-i slaves .....	35
Configure Ethernet interface .....	22
Configure main task .....	45
Configure PLC .....	21
Configure system .....	35
Configure task processing .....	45
Configure visualisation .....	43
Control interface of the ifm function blocks .....	33
Create a visualisation .....	42
Create CODESYS project .....	16
Create new project with AS-i Gateway AC14 .....	17
Create PLC application .....	25

## D

Delete application from AS-i Gateway AC14 .....	50
Delete boot application via SD card .....	51
Description 61, 63, 65, 67, 69, 71, 73, 75, 77, 79, 81, 83, 85, 87, 89, 91, 93, 95, 97, 98, 100, 102, 104, 107, 109, 111, 121	
Digital input and output data .....	30
Digital output data .....	32
Display operating state of the application .....	52

Display target visualisation .....	57
Display web visualisation .....	56
Download the application to the device .....	50

## E

Enumeration types (ENUM) .....	113
Enumeration types and complex variables .....	113
Example	
Change language setting of the device .....	126
Date / time / read NTP settings .....	127
Read LCEMS, LCEAS and LDAE of AS-i master 2 .....	128

## F

FB with cyclic execution .....	34
FB with one-time execution .....	33
Fieldbus data .....	31

## G

General safety instructions .....	7
Get_Asi_Data .....	104
Get_Asi_PHY_Dat .....	61
Get_CDI .....	79
Get_FieldbusInfo .....	107
Get_InputParameter .....	83
Get_LAS .....	63
Get_LCE .....	69
Get_LCEAS .....	71
Get_LCEMS .....	73
Get_LDAE .....	75
Get_LDS .....	65
Get_LPF .....	77
Get_LPS .....	67
Get_OutputParameter .....	85
Get_PCD .....	81
Getting started .....	15

## H

Hardware .....	9
----------------	---

## I

ifm AS-i Package .....	12
ifm weltweit • ifm worldwide • ifm à l'échelle internationale .....	131
Input and output data of the fieldbus interface .....	31
Input parameters ... 61, 63, 65, 67, 69, 71, 73, 75, 77, 79, 81, 83, 85, 87, 89, 91, 93, 95, 97, 98, 100, 102, 104, 107, 109, 111, 122	
Install CODESYS Development System .....	11
Install the ifm package .....	13
Installation .....	11

## L

Legal and copyright information .....	4
Library ACnnn_SYS_CMD.library .....	121
Library ACnnn_Utils.library .....	59
Licensing .....	10

## M

Manage AS-i network .....	36
Modification history .....	6

**O**

Objects of a PLC application .....	24
Operating mode of the PLC .....	52
Operating states of the PLC .....	52
Operation .....	47
Options to access input and output data .....	27
Output parameters .....	62, 64, 66, 68, 70, 72, 74, 76, 78, 80, 82, 84, 86, 88, 90, 92, 94, 96, 97, 99, 101, 103, 105, 108, 110, 112, 125
Outputs data of the AS-i slaves .....	32
Overview	
AS-i functions (FB_ASi) .....	60
CODESYS documentation of 3S .....	6
Project structure with AS-i Gateway AC14 .....	18
System functions (FB_System) .....	106
User documentation for AS-i Gateway AC14 .....	5

**P**

PI controller .....	4
Preliminary note .....	4
Process data of the AS-i slaves .....	29
Programming .....	24
Purpose of the document .....	4

**Q**

QuickSetupASI_Master .....	109
----------------------------	-----

**R**

Read configuration data of the slaves .....	38
Read network settings .....	37
Read parameter images .....	37
read slave lists .....	37
Read status of the voltage supply .....	38
Required background knowledge .....	7
Reset .....	54
Reset the application (cold) .....	55
Reset the application (origin) .....	55
Reset the application (warm) .....	55

**S**

Safety instructions .....	7
Send commands to the system and the AS-i master .....	39
Set communication path to PLC .....	20
Set parameters for visualisation task .....	45
Set the programming interface .....	20
Set_AddressMode .....	87
Set_ASi_Config .....	89
Set_LPS .....	91
Set_Mode .....	93
Set_PCD .....	95
Set_ProjectAll .....	97
Set_SlaveAddress .....	98
Set_SlaveExtendedID1 .....	100
Set_SlaveParameter .....	102
Set_TimeDate .....	111
Software .....	9
Start PLC application .....	53
States of the PLC application .....	52
Stop PLC application .....	53
Supported programming languages .....	26

Supported reset variants .....	54
Supported visualisation types .....	40
Switch operating states .....	53
Symbols and styles used .....	5
System configuration .....	21
System requirements .....	9

**T**

## Table

AS-i master commands .....	123
System commands .....	122
Testing the PLC application .....	46
Transfer CODESYS project to device .....	48

**U**

Uninstall the ifm package .....	14
Update ifm package .....	13
Use CODESYS online help .....	19
Use complex variables .....	36
Use functions of the ifm package .....	33
Use remanent variables .....	25
Use visualisations .....	40

**V**

Validity of the interface data .....	28
--------------------------------------	----

**W**

Warnings used .....	8
---------------------	---

# 11 ifm weltweit • ifm worldwide • ifm à l'échelle internationale

Version: 2017-12-18

8310

ifm electronic gmbh • Friedrichstraße 1 • 45128 Essen

[www.ifm.com](http://www.ifm.com) • Email: [info@ifm.com](mailto:info@ifm.com)

Service hotline: 0800 / 16 16 16 (only Germany, Mo-Fr 07.00...18.00 h)

## ifm Niederlassungen • Sales offices • Agences

D	Niederlassung Nord • 31135 Hildesheim • Tel. 05121 7667-0 Niederlassung West • 45128 Essen • Tel. 0201 36475 -0 Niederlassung Mitte-West • 58511 Lüdenscheid • Tel. 02351 4301-0 Niederlassung Süd-West • 64646 Heppenheim • Tel. 06252 7905-0 Niederlassung Baden-Württemberg • 73230 Kirchheim • Tel. 07021 8086-0 Niederlassung Bayern • 82178 Puchheim • Tel. 089 80091-0 Niederlassung Ost • 07639 Tautenhain • Tel. 036601 771-0
AE	ifm electronic FZC • Saif Zone, Sharjah • phone +971- 6-5573601
AR	ifm electronic s.r.l. • 1107 Buenos Aires • phone +54 11 5353-3436
AT	ifm electronic gmbh • 1120 Wien • phone +43 / 1 / 617 45 00
AU	ifm efector pty ltd. • Mulgrave Vic 3170 • phone +61 1300 365 088
BE	ifm electronic n.v./s.a. • 1731 Zellik • phone +32 2 481 0220
BG	ifm electronic eood • 1202 Sofia • phone +359 2 807 59 69
BR	ifm electronic Ltda. • 03337-000 São Paulo / SP • phone +55-11-2672-1730
CA	ifm efector Canada inc. • Mississauga, ON L5N 2X7 • phone +1 855-436-2262
CH	ifm electronic ag • 4624 Härringen • phone +41 / 800 88 80 33
CL	ifm electronic SpA • Oficina 5041 Comuna de Conchalí • phone +56-2-32239282
CN	ifm electronic (Shanghai) Co. Ltd. • 201203 Shanghai • phone +86 21 3813 4800
CZ	ifm electronic, spol. s.r.o. • 140 00 Praha 4 • phone +420 267 990 211
DK	ifm electronic a/s • 2605 Brøndby • phone +45 70 20 11 08
ES	ifm electronic s.a. • 08820 El Prat de Llobregat • phone +34 93 479 30 80
FI	ifm electronic oy • 00440 Helsinki • phone +358 75 329 5000
FR	ifm electronic s.a. • 93192 Noisy-le-Grand Cedex • phone +33 0820 22 30 01
GB	ifm electronic Ltd. • Hampton, Middlesex TW12 2HD • phone +44 / 20 / 8213 0000
GR	ifm electronic monoprosopi E.P.E. • 15125 Amaroussio • phone +30 210 61 800 90
HU	ifm electronic kft. • 9028 Györ • phone +36-96 / 518-397
IN	ifm electronic India Private Limited • Kolhapur, 416234 • phone +91 / 231 / 267 27 70
IE	ifm electronic (Ireland) Ltd. • Dublin 22 • phone +353 / 1 / 461 32 00
IT	ifm electronic s.r.l. • 20864 Agrate Brianza (MB) • phone +39 39-6899982
JP	efector co., ltd. • Chiba-shi, Chiba 261-7118 • phone +81 043-299-2070
KR	ifm electronic Ltd. • 04420 Seoul • phone +82 2-790-5610
MX	ifm efector S. de R.L. de C.V. • San Pedro Garza Garcia, N.L. 66269 • phone +52-81-8040-3535
MY	ifm electronic Pte. Ltd. • 47100 Puchong, Selangor • phone +603 8066 9853
NA	ifm electronic (pty) Ltd. • 25 Dr. W. Kulz Street Windhoek • phone +264 61 300984
NL	ifm electronic b.v. • 3843 GA Harderwijk • phone +31 341-438 438
NZ	ifm efector pty ltd. • 930 Great South Road Penrose, Auckland • phone +64 / 95 79 69 91
PL	ifm electronic sp. z o.o. • 40-106 Katowice • phone +48 32 70 56 400
PT	ifm electronic s.a. • 4410-137 São Félix da Marinha • phone +351 223 71 71 08
RO	ifm electronic s.r.l. • Sibiu 557260 • phone +40 269 224 550
RU	ifm electronic • 105318 Moscow • phone +7 495 921-44-14
SG	ifm electronic Pte Ltd • 609 916 Singapore • phone +65 6562 8661
SK	ifm electronic s.r.o. • 831 06 Bratislava • phone +421 244 872 329
SE	ifm electronic ab • 412 50 Göteborg • phone +46 31-750 23 00
TR	ifm electronic Ltd. Sti. • 34381 Sisli, İstanbul • phone +90 212 210 50 80
TW	ifm electronic • Kaohsiung City, 806, Taiwan R.O.C. • phone +886 7 3357778
UA	TOV ifm electronic • 02660 Kiev • phone +380 44 501-85-43
US	ifm efector inc. • Malvern, PA 19355 • phone +1 800-441-8246
VN	ifm electronic Vietnam Co., Ltd. • 700000 Ho Chi Minh City • phone +84-28-2253.6715
ZA	ifm electronic (Pty) Ltd. • 0157 Pretoria • phone +27 12 450 0412

Technische Änderungen behalten wir uns ohne vorherige Ankündigung vor.

We reserve the right to make technical alterations without prior notice.

Nous nous réservons le droit de modifier les données techniques sans préavis.