

CE




Original Programming Manual  
ClassicController

**ecomat100**  
CR0020

Runtime system v06  
CODESYS® v2.3

English

7391027\_03\_UK 2015-07-17



# Contents

<b>1</b>	<b>About this manual</b>	<b>5</b>
1.1	Copyright.....	5
1.2	Overview: documentation modules for ecomatmobile devices.....	6
1.3	CODESYS programming manual .....	6
1.4	What do the symbols and formats mean? .....	7
1.5	How is this documentation structured?.....	8
1.6	History of the instructions (CR0020,CR0505) .....	9
<b>2</b>	<b>Safety instructions</b>	<b>10</b>
2.1	Please note! .....	10
2.2	What previous knowledge is required? .....	11
2.3	Start-up behaviour of the controller.....	11
<b>3</b>	<b>System description</b>	<b>12</b>
3.1	Information concerning the device .....	12
3.2	Hardware description .....	12
3.2.1	Hardware structure .....	13
3.2.2	Operating principle of the delayed switch-off.....	16
3.2.3	Relays: important notes!.....	17
3.2.4	Monitoring concept .....	18
3.2.5	Inputs (technology) .....	21
3.2.6	Outputs (technology) .....	27
3.2.7	Note on wiring .....	34
3.2.8	Safety instructions about Reed relays .....	34
3.2.9	Feedback on bidirectional inputs/outputs .....	35
3.2.10	Feedback in case of externally supplied outputs .....	36
3.2.11	Status LED .....	38
3.3	Interface description.....	39
3.3.1	Serial interface .....	39
3.3.2	CAN interfaces .....	40
3.4	Software description .....	41
3.4.1	Software modules for the device .....	41
3.4.2	Programming notes for CODESYS projects .....	44
3.4.3	Operating states .....	48
3.4.4	Operating modes.....	52
3.4.5	Performance limits of the device .....	53
<b>4</b>	<b>Configurations</b>	<b>54</b>
4.1	Set up the runtime system .....	54
4.1.1	Reinstall the runtime system .....	55
4.1.2	Update the runtime system.....	56
4.1.3	Verify the installation .....	56
4.2	Set up the programming system .....	57
4.2.1	Set up the programming system manually .....	57
4.2.2	Set up the programming system via templates.....	60
4.3	Function configuration in general.....	61
4.3.1	Configuration of the inputs and outputs (default setting) .....	61
4.3.2	System variables .....	61
4.4	Function configuration of the inputs and outputs .....	62
4.4.1	Configure inputs .....	63
4.4.2	Configure outputs .....	67
4.5	Variables .....	73
4.5.1	Retain variables.....	73
4.5.2	Network variables.....	73

<b>5</b>	<b>ifm function elements</b>	<b>74</b>
5.1	ifm libraries for the device CR0020 .....	74
5.1.1	Library ifm_CR0020_V06yyzz.LIB .....	75
5.1.2	Library ifm_CR0020_CANopenMaster_V04yynn.LIB .....	77
5.1.3	Library ifm_CR0020_CANopenSlave_V04yynn.LIB .....	77
5.1.4	Library ifm_CAN1_EXT_Vxxyyzz.LIB .....	78
5.1.5	Library ifm_J1939_x_Vxxyyzz.LIB .....	78
5.1.6	Library ifm_hydraulic_16bitOS05_Vxxyyzz.LIB .....	79
5.2	ifm function elements for the device CR0020 .....	80
5.2.1	Function elements: CAN layer 2 .....	80
5.2.2	Function elements: CANopen master .....	96
5.2.3	Function elements: CANopen slave .....	106
5.2.4	Function elements: CANopen SDOs .....	114
5.2.5	Function elements: SAE J1939 .....	119
5.2.6	Function elements: serial interface .....	131
5.2.7	Function elements: Optimising the PLC cycle .....	136
5.2.8	Function elements: processing input values .....	142
5.2.9	Function elements: adapting analogue values .....	147
5.2.10	Function elements: counter functions for frequency and period measurement .....	150
5.2.11	Function elements: PWM functions .....	161
5.2.12	Function elements: hydraulic control .....	175
5.2.13	Function elements: controllers .....	191
5.2.14	Function elements: software reset .....	200
5.2.15	Function elements: measuring / setting of time .....	202
5.2.16	Function elements: saving, reading and converting data in the memory .....	205
5.2.17	Function elements: data access and data check .....	214
<b>6</b>	<b>Diagnosis and error handling</b>	<b>221</b>
6.1	Diagnosis .....	221
6.2	Fault .....	221
6.3	Reaction in case of an error .....	222
6.4	Relay: important notes! .....	222
6.5	Response to system errors .....	223
6.6	CAN / CANopen: errors and error handling .....	223
<b>7</b>	<b>Annex</b>	<b>224</b>
7.1	System flags .....	224
7.1.1	System flags: CAN .....	225
7.1.2	System flags: SAE J1939 .....	225
7.1.3	System flags: error flags (standard side) .....	226
7.1.4	System flags: LED (standard side) .....	227
7.1.5	System flags: voltages (standard side) .....	228
7.1.6	System flags: 16...40 inputs and 24...0 outputs (standard side) .....	229
7.2	Address assignment and I/O operating modes .....	230
7.2.1	Address assignment inputs / outputs .....	230
7.2.2	Possible operating modes inputs/outputs .....	234
7.2.3	Addresses / variables of the I/Os .....	238
7.3	Error tables .....	240
7.3.1	Error flags .....	240
7.3.2	Errors: CAN / CANopen .....	240

Contents

8	Glossary of Terms	241
9	Index	254
10	Notizen • Notes • Notes	258
11	ifm weltweit • ifm worldwide • ifm à l'échelle internationale	262



© ifm electronic gmbh

www.ifm.com

# 1 About this manual

## Inhalt

Copyright .....	5
Overview: documentation modules for ecomatmobile devices .....	6
CODESYS programming manual .....	6
What do the symbols and formats mean? .....	7
How is this documentation structured? .....	8
History of the instructions (CR0020,CR0505) .....	9

202

## 1.1 Copyright

6088

© All rights reserved by **ifm electronic gmbh**. No part of this manual may be reproduced and used without the consent of **ifm electronic gmbh**.

All product names, pictures, companies or other brands used on our pages are the property of the respective rights owners:

- AS-i is the property of the AS-International Association, (→ [www.as-interface.net](http://www.as-interface.net))
- CAN is the property of the CiA (CAN in Automation e.V.), Germany (→ [www.can-cia.org](http://www.can-cia.org))
- CODESYS™ is the property of the 3S – Smart Software Solutions GmbH, Germany (→ [www.codesys.com](http://www.codesys.com))
- DeviceNet™ is the property of the ODVA™ (Open DeviceNet Vendor Association), USA (→ [www.odva.org](http://www.odva.org))
- EtherNet/IP® is the property of the →ODVA™
- IO-Link® (→ [www.io-link.com](http://www.io-link.com)) is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- Microsoft® is the property of the Microsoft Corporation, USA (→ [www.microsoft.com](http://www.microsoft.com))
- PROFIBUS® is the property of the PROFIBUS Nutzerorganisation e.V., Germany (→ [www.profibus.com](http://www.profibus.com))
- PROFINET® is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- Windows® is the property of the →Microsoft Corporation, USA

## 1.2 Overview: documentation modules for ecomatmobile devices

17405

The documentation for **ecomatmobile** devices consists of the following modules:

1. Data sheet	
Contents	Technical data in a table
Source	→ <a href="http://www.ifm.com">www.ifm.com</a> > select your country > [Data sheet search] > CR0020 > [Technical data in PDF format]
2. Installation instructions / operating instructions	
Contents	Instructions for installation, electrical installation, (commissioning*), technical data
Source	The instructions are supplied with the device They are also found on ifm's homepage: → <a href="http://www.ifm.com">www.ifm.com</a> > select your country > [Data sheet search] > CR0020 > [Operating instructions]
3. Programming manual + online help	
Contents	Description of the configuration and the functions of the device software
Source	→ <a href="http://www.ifm.com">www.ifm.com</a> > select your country > [Data sheet search] > CR0020 > [Operating instructions]
4. System manual "Know-how ecomatmobile"	
Contents	Know-how about the following topics: <ul style="list-style-type: none"> <li>• Overview Templates and demo programs</li> <li>• CAN, CANopen</li> <li>• Control outputs</li> <li>• User flash memory</li> <li>• Visualisations</li> <li>• Overview of the files and libraries used</li> </ul>
Source	→ <a href="http://www.ifm.com">www.ifm.com</a> > select your country > [Data sheet search] > CR0020 > [Operating instructions]

\*) The descriptions in brackets are only included in the instructions of certain devices.

## 1.3 CODESYS programming manual

17542

In the additional "Programming Manual for CODESYS V2.3" you obtain more details about the use of the programming system.

This manual can be downloaded free of charge from **ifm's** website:

→ [www.ifm.com](http://www.ifm.com) > Select your country > [Service] > [Download] > [Systems for mobile machines]





You also find manuals and online help for **ecomatmobile** at:

→ **ecomatmobile** DVD "Software, tools and documentation"

## 1.4 What do the symbols and formats mean?

203

The following symbols or pictograms illustrate the notes in our instructions:

 <b>WARNING</b>	
Death or serious irreversible injuries may result.	
 <b>CAUTION</b>	
Slight reversible injuries may result.	
<b>NOTICE</b>	
Property damage is to be expected or may result.	
	Important notes concerning malfunctions or disturbances
	Other remarks
► ...	Request for action
> ...	Reaction, result
→ ...	"see"
<a href="#">abc</a>	Cross-reference
123	Decimal number
0x123	Hexadecimal number
0b010	Binary number
[...]	Designation of pushbuttons, buttons or indications

## 1.5 How is this documentation structured?

204  
1508

This documentation is a combination of different types of manuals. It is for beginners and also a reference for advanced users. This document is addressed to the programmers of the applications.

How to use this manual:

- Refer to the table of contents to select a specific subject.
- Using the index you can also quickly find a term you are looking for.
- At the beginning of a chapter we will give you a brief overview of its contents.
- Abbreviations and technical terms → Annex.

In case of malfunctions or uncertainties please contact the manufacturer at:

→ [www.ifm.com](http://www.ifm.com) > Select your country > [Contact].

We want to become even better! Each separate section has an identification number in the top right corner. If you want to inform us about any inconsistencies, indicate this number with the title and the language of this documentation. Thank you very much for your support!

We reserve the right to make alterations which can result in a change of contents of the documentation. You can find the current version on **ifm's** website at:

→ [www.ifm.com](http://www.ifm.com) > Select country > [Data sheet search] > (Article no.) > [Operating instructions]



## 1.6 History of the instructions (CR0020,CR0505)

9185

What has been changed in this manual? An overview:

Date	Theme	Change
2010-09-09	PID2 (FB)	parameters of the inputs corrected
2010-11-10	Terminating resistors	correction in topic 1244
2011-02-14	TIMER_READ_US (FB)	conversion of max. counter value corrected
2011-04-05	Memory POU's FRAMREAD, FRAMWRITE, FLASHREAD, FLASHWRITE	permitted values of the parameters SRC, LEN, DST
2011-04-13	CANopen overview	new: CANopen tables in the annex
2012-01-09	Memory modules FRAMREAD, FRAMWRITE	Swapped parameters SRC, DST in the table "Permissible values"
2012-07-16	Runtime system	upgrade to v06
2012-10-04	diverse	corrections
2013-06-24	various	new document structure
2014-04-28	Various function blocks	More precise description of the function block input CHANNEL
2014-06-30	Name of the documentation	"System manual" renamed as "Programming manual"
2014-07-31	FB PHASE	Description of parameters of outputs C, ET corrected
2014-08-26	Description of inputs, outputs	highside / lowside replaced by positive / negative switching
2015-01-13	Structure of documentation for error codes, system flags	<ul style="list-style-type: none"> <li>error flags: now only in the annex, chapter <i>System flags</i></li> <li>CAN / CANopen errors and error handling: now only in the system manual "Know-How"</li> <li>error codes, EMCY codes: now in the annex, chapter <i>Error tables</i></li> </ul>
2015-03-10	Available memory	Description improved
2015-05-22	FBs INPUT_ANALOG, INPUT_CURRENT, INPUT_VOLTAGE	permissible input channels
2015-05-26	FB J1939_x_GLOBAL_REQUEST	More precise description
2015-06-10	Various function blocks	Description of the FB input CHANNEL corrected

## 2 Safety instructions

### Inhalt

Please note!.....	10
What previous knowledge is required? .....	11
Start-up behaviour of the controller .....	11

213

### 2.1 Please note!

214  
11212

No characteristics are warranted with the information, notes and examples provided in this manual. With the drawings, representations and examples given no responsibility for the system is assumed and no application-specific particularities are taken into account.

- ▶ The manufacturer of the machine/equipment is responsible for ensuring the safety of the machine/equipment.
- ▶ Follow the national and international regulations of the country in which the machine/installation is to be placed on the market!



### WARNING

Non-observance of these instructions can lead to property damage or bodily injury!

**ifm electronic gmbh** does not assume any liability in this regard.

- ▶ The acting person must have read and understood the safety instructions and the corresponding chapters in this manual before working on and with this device.
- ▶ The acting person must be authorised to work on the machine/equipment.
- ▶ The acting person must have the qualifications and training required to perform this work.
- ▶ Adhere to the technical data of the devices!  
You can find the current data sheet on **ifm's** homepage at:  
→ [www.ifm.com](http://www.ifm.com) > Select your country > [Data sheet search] > (article number.) > [Technical data in PDF format]
- ▶ Note the installation and wiring information as well as the functions and features of the devices!  
→ supplied installation instructions or on **ifm's** homepage:  
→ [www.ifm.com](http://www.ifm.com) > Select your country > [Data sheet search] > (article number.) > [Operating instructions]
- ▶ Please note the corrections and notes in the release notes for the existing documentation, available on the **ifm** website:  
→ [www.ifm.com](http://www.ifm.com) > Select your country > [Data sheet search] > (article number.) > [Operating instructions]

5020

### NOTICE

The driver module of the serial interface can be damaged!

Disconnecting or connecting the serial interface while live can cause undefined states which damage the driver module.

- ▶ Do not disconnect or connect the serial interface while live.

## 2.2 What previous knowledge is required?

215

This document is intended for people with knowledge of control technology and PLC programming with IEC 61131-3.

To program the PLC, the people should also be familiar with the CODESYS software.

The document is intended for specialists. These specialists are people who are qualified by their training and their experience to see risks and to avoid possible hazards that may be caused during operation or maintenance of a product. The document contains information about the correct handling of the product.

Read this document before use to familiarise yourself with operating conditions, installation and operation. Keep the document during the entire duration of use of the device.

Adhere to the safety instructions.

## 2.3 Start-up behaviour of the controller

6827  
15233  
11575



### WARNING

Danger due to unintentional and dangerous start of machine or plant sections!

- ▶ When creating the program, the programmer must ensure that no unintentional and dangerous start of machines or plant sections after a fault (e.g. e-stop) and the following fault elimination can occur!  
⇒ Realise restart inhibit!
- ▶ In case of an error, set the outputs concerned to FALSE in the program!

A restart can, for example, be caused by:

- voltage restoration after power failure
- reset after watchdog response because of too long a cycle time
- error elimination after an E-stop

To ensure a safe behaviour of the controller:

- ▶ monitor the voltage supply in the application program.
- ▶ In case of an error switch off all relevant outputs in the application program.
- ▶ Additionally monitor relay contacts which can cause hazardous movements in the application program (feedback).
- ▶ If necessary, ensure that welded relay contacts in the application project cannot trigger or continue hazardous movements.
- ▶ Additionally monitor relay contacts which can cause hazardous movements in the application program (feedback).
- ▶ If necessary, ensure that welded relay contacts in the application project cannot trigger or continue hazardous movements.

## 3 System description

### Inhalt

Information concerning the device .....	12
Hardware description.....	12
Interface description .....	39
Software description .....	41

975

### 3.1 Information concerning the device

11568

This manual describes of the *ecomatmobile* family for mobile machines of **ifm electronic gmbh**:

- ClassicController: CR0020, CR0505 from hardware revision A1  
Runtime system (target) v06b

### 3.2 Hardware description

### Inhalt

Hardware structure .....	13
Operating principle of the delayed switch-off .....	16
Relays: important notes!.....	17
Monitoring concept .....	18
Inputs (technology) .....	21
Outputs (technology) .....	27
Note on wiring.....	34
Safety instructions about Reed relays.....	34
Feedback on bidirectional inputs/outputs.....	35
Feedback in case of externally supplied outputs .....	36
Status LED .....	38

14081

### 3.2.1 Hardware structure

15332

#### Conditions

19658

The device does not start until sufficient voltage is applied to the supply connection VBBS (e.g. supply of the relays on the standard side) and to clamp 15.

In vehicles clamp 15 is the plus cable switched by the ignition lock.

#### Relays

19659

The Controller has 2 internal output relays which can each separate 12 outputs from the terminal voltage VBBx (x = O / R).

The output relay (monitoring relay) is triggered by the microcontroller via two channels. To do so, one channel is triggered by an AND function of the watchdog signal (internal microcontroller monitoring) and the system flag bit RELAIS via a solid-state switch. The other channel is only triggered by the system flag bit ERROR via a solid-state switch. When actuated, the terminal voltage VBBx is applied to the outputs via the relay contact (not positively guided).

The clamp relay is activated via one channel via the system flag RELAIS\_CLAMP\_15 (→ graphics). RELAIS\_CLAMP\_15 is active after the start of the controller.

The clamp relay switches the VBBO voltage on the second output group.

The clamp relay ensures the internal supply of the device as long as VBBO continues to be applied even if VBBS is interrupted intentionally or unintentionally.

The clamp relay is submitted to the full control in the application program and can be switched via a set/reset command of the system flag RELAIS\_CLAMP\_15

## Prinziple block diagram

19660

The following block diagram shows the dependence of the relays on the applied signals and the logic states of the system flags.




Figure: principle block diagram of supply and relays

## Available memory

13736

## FLASH-Speicher

15366

FLASH memory (non-volatile, slow memory) overall existing in the device	2 MByte
--	---------

Thereof the following memory areas are reserved for ...

maximum size of the application program	704 kByte
data other than the application program user can write data such as files, bitmaps, fonts	1 MByte
data other than the application program read data with <b>FLASHREAD</b> (→ page <a href="#">209</a> ) or write data with <b>FLASHWRITE</b> (→ page <a href="#">210</a> ) (files: 128 bytes less for header)	64 kByte

The remaining rest of the memory is reserved for system internal purposes.

## SRAM

15906

SRAM (volatile, fast memory) overall existing in the device SRAM indicates here all kinds of volatile and fast memories.	512 kByte
--	-----------

Thereof the following memory areas are reserved for ...

data reserved by the application program	160 kByte
--	-----------

The remaining rest of the memory is reserved for system internal purposes.

## FRAM

8002

FRAM (non-volatile, fast memory) overall existing in the device FRAM indicates here all kinds of non-volatile and fast memories.	32 kByte
--	----------

Thereof the following memory areas are reserved for ...

variables in the application program, declared as VAR_RETAIN	1 kByte
as remanent defined flags (from %MB0...) ► Set the end of the memory area by FB <b>MEMORY_RETAIN_PARAM</b> (→ page <a href="#">207</a> )!	256 Byte
remanent memory freely available to the user Access is made via <b>FRAMREAD</b> (→ page <a href="#">211</a> ) and <b>FRAMWRITE</b> (→ page <a href="#">212</a> )	16 kByte

The remaining rest of the memory is reserved for system internal purposes.

### 3.2.2 Operating principle of the delayed switch-off

993

If the *ecomatmobile* controllers are disconnected from the supply voltage (ignition off), all outputs are normally switched off at once, input signals are no longer read and processing of the controller software (runtime system and application program) is interrupted. This happens irrespective of the current program step of the controller.

If this is not requested, the controller must be switched off via the program. After switch-off of the ignition this enables, for example, saving of memory states.

The ClassicControllers can be switched off via the program by means of a corresponding connection of the supply voltage inputs and the evaluation of the related system flags. The block diagram in the chapter *Hardware structure* (→ page [13](#)) shows the context of the individual current paths.

#### Connect terminal VBBS (23) to the ignition switch

994

Via terminal 23 the controller is supplied and can be switched off by an ignition switch.

In automotive engineering the potential is called "clamp 15".

This terminal is monitored internally. If no supply voltage is applied, the system flag CLAMP\_15 is set to FALSE. The reset of the flag CLAMP\_15 can be monitored by the application program.

#### Connect terminal VBBO (5) to battery (not switched)

995

Up to 12 outputs of the output group VBBO can be supplied via terminal 5. At the same time latching of the control electronics is supplied via this terminal.

#### Latching

996

Latching is active if voltage is applied to VBBO **and** the system flag RELAY\_CLAMP\_15 (and so the relay [Clamp]) is set.

If the system flag RELAY\_CLAMP\_15 is reset, the relay [Clamp] is de-energised. If at this moment no voltage is applied to terminal 23, latching is removed and the controller switches off completely.



### 3.2.3 Relays: important notes!

19480

Assignment relays – potentials: → data sheet

Max. total current per relay contact (= per output group): → data sheet

#### NOTICE

Risk of destruction of the relay contacts!

In an emergency situation, "sticking" relay contacts can no longer separate the outputs from the power supply!

Falls VBBS (clamp 15) and VBBO are separated from the power supply at the same time, but the potentials VBBx stay connected to it, then the relays can drop even before the outputs are deactivated by the system.

In this case the relays separate the outputs from the power supply **under load**. This significantly reduces the life cycle of the relays.

- ▶ If VBBx is permanently connected to the power supply:
  - also connect VBBO permanently and
  - switch off the outputs via the program with the help of VBBS (clamp 15).

### 3.2.4 Monitoring concept

#### Inhalt

Operating principle of the monitoring concept.....	18
--	----

991

The controller monitors the supply voltages and the system error flags. Depending on the status...

- the controller switches off the internal relays
  - > the outputs are de-energised, but retain their logic state

or:

- the runtime system deactivates the controller
  - > the program stops
  - > the outputs change to logic "0"

#### Operating principle of the monitoring concept

997

During program processing the output relay is completely controlled via the software by the user. So a parallel contact of the safety chain, for example, can be evaluated as an input signal and the output relay can be switched off accordingly. To be on the safe side, the corresponding applicable national regulations must be complied with.

If an error occurs during program processing, the relay can be switched off using the system flag bit ERROR to disconnect critical plant sections.

By resetting the system flag bit RELAIS (via the system flag bit ERROR or directly) all outputs are switched off. The outputs in the current path VBBR are disconnected directly by means of the output relay. So the outputs in the current path VBBO are only disconnected via the software.

11575



#### WARNING

Danger due to unintentional and dangerous start of machine or plant sections!

- ▶ When creating the program, the programmer must ensure that no unintentional and dangerous start of machines or plant sections after a fault (e.g. e-stop) and the following fault elimination can occur!
  - ⇒ Realise restart inhibit!
- ▶ In case of an error, set the outputs concerned to FALSE in the program!



If a watchdog error occurs, the program processing is interrupted automatically and the controller is reset. The controller then starts again as after power on.

#### Monitoring of the supply voltage VBBR

20109

Via the potential VBBR up to 12 outputs of the output group can be supplied. The terminal voltage is monitored:

ERROR_VBBR = TRUE	supply voltage is missed or too low
ERROR_VBBR = FALSE	supply voltage is in order

- ▶ This information is to be processed in the application program!

## Monitoring and securing mechanisms

### Inhalt

After application of the supply voltage.....	19
If runtime system / application is running .....	19
If the TEST pin is not active .....	20
One-time mechanisms .....	20

3926

For these devices the following monitoring activities are automatically carried out:

### After application of the supply voltage

3927

After application of the supply voltage (controller is in the boot loader) the following tests are carried out in the device:

- > RAM test (one-time)
- > supply voltage
- > system data consistency
- > CRC of the boot loader
- > if exists and is started: CRC of the runtime system
- > if exists and is started: CRC of the application program
- > memory error:
  - If the test is running: flag ERROR\_MEMORY = TRUE (can be evaluated as from the first cycle).
  - If the test is not running: red LED is lit.

### If runtime system / application is running

3928

then the following tests are cyclically carried out:

- > Triggering of the watchdog (100 ms)  
Then continuous program check watchdog
- > Continuous temperature check  
In case of a fault: system flag ERROR\_TEMPERATURE = TRUE
- > Continuous voltage monitoring  
In case of a fault: system flag ERROR\_POWER = TRUE or ERROR\_VBBR = TRUE
- > Continuous CAN bus monitoring
- > Continuous system data monitoring:
  - program loaded
  - operating mode RUN / STOP,
  - runtime system loaded,
  - node ID,
  - baud rate of CAN and RS232.
- > In the operating mode RUN:  
Cyclical I/O diagnosis:
  - short circuit,
  - wire break,
  - overload (current) of the inputs and outputs,
  - cross fault (only for SafetyController).

### If the TEST pin is not active

3929

- > Write protection for system data in FRAM <sup>1)</sup>, e.g.:
  - runtime system loaded,
  - calibration data.
 Implemented via hardware and software.
- > Write protection for application program (in the flash memory)
- > DEBUG mode

<sup>1)</sup> FRAM indicates here all kinds of non-volatile and fast memories.

### One-time mechanisms

3930

- > CRC monitoring during download or upload.
- > It must be checked that the runtime system and the application are assigned to the same device.



### 3.2.5 Inputs (technology)

#### Inhalt

Analogue inputs.....	21
Digital inputs.....	22
Input group I0 (I00...07 / ANALOG0...7).....	23
Input group I1 (I10...17 / FRQ0...3).....	24
Input group I2 (I20...27).....	25
Input group I3 (I30...I37).....	26
Input group I4 (I40...I47).....	26

14090

#### Analogue inputs

2426

The analogue inputs can be configured via the application program. The measuring range can be set as follows:

- current input 0...20 mA
- voltage input 0...10 V
- voltage input 0...32 V

The voltage measurement can also be carried out ratiometrically (0...1000 ‰, adjustable via function blocks). This means potentiometers or joysticks can be evaluated without additional reference voltage. A fluctuation of the supply voltage has no influence on this measured value.

As an alternative, an analogue channel can also be evaluated binarily.

**!** In case of ratiometric measurement the connected sensors should be supplied with VBBS of the device. So, faulty measurements caused by offset voltage are avoided.

8971




Figure: principle block diagram multifunction input

## Digital inputs

1015  
7345

The binary input can be operated in following modes:

- binary input plus switching (BL) for positive sensor signal
- binary input minus switching (BH) for negative sensor signal

Depending on the device the binary inputs can configured differently. In addition to the protective mechanisms against interference, the binary inputs are internally evaluated via an analogue stage. This enables diagnosis of the input signals. But in the application software the switching signal is directly available as bit information






Figure: basic circuit of binary input minus switching / plus switching for negative and positive sensor signals



Basic circuit of binary input plus switching (BL)  
for positive sensor signal:  
Input = open  $\Rightarrow$  signal = low (GND)



Basic circuit of binary input minus switching (BH)  
for negative sensor signal:  
Input = open  $\Rightarrow$  signal = high (supply)

For some of these inputs ( $\rightarrow$  data sheet) the potential can be selected to which it will be switched.

## Input group I0 (I00...07 / ANALOG0...7)

20389

These inputs are a group of multifunction channels.

These inputs can be used as follows (each input separately configurable):

- analogue input 0...20 mA
- analogue input 0...10 V
- analogue input 0...32 V
- voltage measurement ratiometric 0...1000 ‰
- binary input plus switching (BL) for positive sensor signal (with/without diagnosis)

→ chapter *Possible operating modes inputs/outputs* (→ page 234)

Sensors with diagnostic capabilities to NAMUR can be evaluated.

All inputs show the same behaviour concerning function and diagnosis.

 Detailed description → chapter *Address assignment inputs / outputs* (→ page 230)

In the application program, the system variables ANALOG00...ANALOGxx can be used for customer-specific diagnostics.

If the analogue inputs are configured for current measurement, the operating mode of the input switches to the safe voltage measurement range (0...30V DC) and the corresponding error bit in the flag byte ERROR\_IO is set when the final value (> 21 mA) is exceeded. If the value is again below the limit value, the input automatically switches back to the current measuring range.


- Configuration of each input is made via the application program:
  - FB *INPUT\_ANALOG* (→ page 144) > input MODE
  - Configuration byte Ixx\_MODE

15380

**Example with configuration byte Ixx\_MODE:**

The assignment sets the selected input to the operating mode IN\_DIGITAL\_H with diagnosis:

0001



13956

> The result of the diagnostics is for example shown by the following system flags:

System flags (symbol name)	Type	Description
ERROR_BREAK_Ix (0...x, value depends on the device, → data sheet)	DWORD	input group x: wire break error or (resistance input): short to supply [Bit 0 for input 0] ... [bit z for input z] of this group Bit = TRUE: error Bit = FALSE: no error
ERROR_SHORT_Ix (0...x, value depends on the device, → data sheet)	DWORD	input group x: short circuit error [Bit 0 for input 0] ... [bit z for input z] of this group Bit = TRUE: error Bit = FALSE: no error

NAMUR diagnosis for binary signals of non-electronic switches:

- Equip the switch with an additional resistor connection!




Figure: non-electronic switch S at input Inn

## Input group I1 (I10...17 / FRQ0...3)

19487

### Inputs I10...13

19490

These inputs are a group of multifunction channels.

These inputs can be used as follows (each input separately configurable):

- binary input plus switching (BL) for positive sensor signal
  - Output (→ chapter *Outputs (technology)* (→ page 27))
- chapter *Possible operating modes inputs/outputs* (→ page 234)

These inputs cannot be configured.

### Inputs I14...17 / FRQ0...3

19497

These inputs are a group of multifunction channels.

These inputs can be used as follows (each input separately configurable):

- binary input plus switching (BL) for positive sensor signal
  - fast input for e.g. incremental encoders and frequency or interval measurement
- chapter *Possible operating modes inputs/outputs* (→ page 234)

Sensors with diagnostic capabilities to NAMUR can be evaluated.

- Configuration of each input is made via the application program:
  - Configuration byte Ixx\_MODE
  - Fast inputs with the following FBs:

<i>FAST_COUNT</i> (→ page 151)	Counter block for fast input pulses
<i>FREQUENCY</i> (→ page 152)	Measures the frequency of the signal arriving at the selected channel
<i>INC_ENCODER</i> (→ page 153)	Up/down counter function for the evaluation of encoders
<i>PERIOD</i> (→ page 156)	Measures the frequency and the cycle period (cycle time) in [μs] at the indicated channel
<i>PERIOD_RATIO</i> (→ page 158)	Measures the frequency and the cycle period (cycle time) in [μs] during the indicated periods at the indicated channel. In addition, the mark-to-space ratio is indicated in [%].
<i>PHASE</i> (→ page 160)	Reads a pair of channels with fast inputs and compares the phase position of the signals



## Input group I2 (I20...27)

19489

### Inputs I20...23

19499

These inputs are a group of multifunction channels.

These inputs can be used as follows (each input separately configurable):

- binary input plus switching (BL) for positive sensor signal
- Output (→ chapter *Outputs (technology)* (→ page 27))
- chapter *Possible operating modes inputs/outputs* (→ page 234)

These inputs cannot be configured.

### Inputs I24...27 / CYL0...3

19500

These inputs are a group of multifunction channels.

These inputs can be used as follows (each input separately configurable):

- binary input plus switching (BL) for positive sensor signal
- fast input for e.g. incremental encoders and frequency or interval measurement
- chapter *Possible operating modes inputs/outputs* (→ page 234)

Sensors with diagnostic capabilities to NAMUR can be evaluated.

- Configuration of each input is made via the application program:
  - Configuration byte Ixx\_MODE
  - Fast inputs with the following FBs:

<i>FAST_COUNT</i> (→ page 151)	Counter block for fast input pulses
<i>FREQUENCY</i> (→ page 152)	Measures the frequency of the signal arriving at the selected channel
<i>INC_ENCODER</i> (→ page 153)	Up/down counter function for the evaluation of encoders
<i>PERIOD</i> (→ page 156)	Measures the frequency and the cycle period (cycle time) in [μs] at the indicated channel
<i>PERIOD_RATIO</i> (→ page 158)	Measures the frequency and the cycle period (cycle time) in [μs] during the indicated periods at the indicated channel. In addition, the mark-to-space ratio is indicated in [%].
<i>PHASE</i> (→ page 160)	Reads a pair of channels with fast inputs and compares the phase position of the signals

## Input group I3 (I30...I37)

19501

These inputs are a group of multifunction channels.

These inputs can be used as follows (each input separately configurable):

- binary input plus switching (BL) for positive sensor signal (with/without diagnosis)
- binary input minus switching (BH) for negative sensor signal
- Output (→ chapter *Outputs (technology)* (→ page [27](#)))

→ chapter *Possible operating modes inputs/outputs* (→ page [234](#))

Sensors with diagnostic capabilities to NAMUR can be evaluated.

All inputs show the same behaviour concerning function and diagnosis.

 Detailed description → chapter *Address assignment inputs / outputs* (→ page [230](#))

- ▶ Configuration of each input is made via the application program:
  - Configuration byte Ixx\_MODE

## Input group I4 (I40...I47)

19502

These inputs are a group of multifunction channels.

These inputs can be used as follows (each input separately configurable):

- binary input plus switching (BL) for positive sensor signal (with/without diagnosis)
- Output (→ chapter *Outputs (technology)* (→ page [27](#)))

→ chapter *Possible operating modes inputs/outputs* (→ page [234](#))

Sensors with diagnostic capabilities to NAMUR can be evaluated.

All inputs show the same behaviour concerning function and diagnosis.

 Detailed description → chapter *Address assignment inputs / outputs* (→ page [230](#))

- ▶ Configuration of each input is made via the application program:
  - Configuration byte Ixx\_MODE

### 3.2.6 Outputs (technology)


Inhalt	
Binary outputs.....	27
PWM outputs.....	27
Output group Q1Q2 (Q10...13 / Q20...23).....	28
Output group Q3 (Q30...37) .....	30
Output group Q4 (Q40...47) .....	32

14093


#### Binary outputs

The following operating modes are possible for the device outputs (→ data sheet):

- binary output, plus switching (BH) with/without diagnostic function
- binary output minus switched (BL) without diagnostic function



Basic circuit of output plus switching (BH)  
for positive output signal




Basic circuit of output minus switching (BL)  
for negative output signal

#### PWM outputs

The following operating modes are possible for the device outputs (→ data sheet):

- PWM output, plus switching (BH) without diagnostic function



Basic circuit of output plus switching (BH)  
for positive output signal

## Output group Q1Q2 (Q10...13 / Q20...23)

19507

These outputs are a group of multifunction channels.

These outputs provide several function options (each output separately configurable):

- binary output, plus switching (BH) with diagnostic function and protection
- analogue current-controlled output (PWMi)
- analogue output with Pulse Width Modulation (PWM)
- binary input (→ chapter *Inputs (technology)* (→ page 21))

→ chapter *Possible operating modes inputs/outputs* (→ page 234)

If the outputs are not used as PWM outputs, the diagnostics is carried out via the integrated current measurement channels which are also used for the current-controlled output functions.

- Configuration of each output is made via the application program:  
indicate the load currents → FB *OUTPUT\_CURRENT* (→ page 164)  
PWM output: → FB *PWM1000* (→ page 173)  
Configuration byte Qxx\_MODE

13975



### WARNING

Dangerous restart possible!

Risk of personal injury! Risk of material damage to the machine/plant!

If in case of a fault an output is switched off via the hardware, the logic state generated by the application program is not changed.

- Remedy:
  - Reset the output logic in the application program!
  - Remove the fault!
  - Reset the outputs depending on the situation.




The outputs in the PWM mode support no diagnostic functions.

When used as binary output, configuration is carried out using the system variables Q1x\_MODE...Q2x\_MODE. If the diagnostics is to be used, it must be activated in addition.

Wire break and short circuit of the output signal are indicated separately via the system variables ERROR\_BREAK\_Q1Q2 or ERROR\_SHORT\_Q1Q2. The individual output error bits can be masked in the application program, if necessary.

#### Example:

The assignment sets the selected output to the operating mode OUT\_DIGITAL\_H with diagnostics. Overload protection is activated (preset).



### NOTE

To protect the internal measuring resistors, OUT\_OVERLOAD\_PROTECTION should always be active (max. measurement current 4.1 A).

For the limit values please make sure to adhere to the data sheet!

The function OUT\_OVERLOAD\_PROTECTION is not supported in the pure PWM mode.

13976

⚠ Depending on the ambient temperature a short circuit cannot be reliably detected from a certain short circuit current since the output drivers temporarily deactivate themselves for protection against destruction.

### Diagnosis: binary outputs (via current measurement)

19398  
19396

The diagnostics of these outputs is made via internal current measurement in the output:




Figure: principle block diagram

- (1) Output channel
- (2) Read back channel for diagnostics
- (3) Pin output n
- (4) Load

### Diagnosis: overload (via current measurement)

19437  
15249

Overload can only be detected on an output with current measurement.

Overload is defined as ...

"a nominal maximum current of 12.5 %".

### Diagnosis: wire break (via current measurement)

19400

Wire-break detection is done via the read back channel. When the output is switched ( $Q_n = \text{TRUE}$ ) wire break is detected when no current flows on the resistor  $R_i$  (no voltage drops). Without wire break the load current flows through the series resistor  $R_i$  generating a voltage drop which is evaluated via the read back channel.

### Diagnosis: short circuit (via voltage measurement)

19401

Short-circuit detection is done via the read back channel. When the output is switched ( $Q_n = \text{TRUE}$ ) a short circuit against GND is detected when the supply voltage drops over the series resistor  $R_i$ .

## Output group Q3 (Q30...37)

19511

These outputs are a group of multifunction channels.

These outputs provide several function options (each output separately configurable):

- binary output, plus switching (BH) with diagnostic function and protection
- binary input (→ chapter *Inputs (technology)* (→ page 21))

→ chapter *Possible operating modes inputs/outputs* (→ page 234)

13975

### **WARNING**

Dangerous restart possible!

Risk of personal injury! Risk of material damage to the machine/plant!

If in case of a fault an output is switched off via the hardware, the logic state generated by the application program is not changed.


► Remedy:

- Reset the output logic in the application program!
- Remove the fault!
- Reset the outputs depending on the situation.

When used as binary output, configuration of each output is carried out using the system variables Qxx\_MODE. If the diagnostics is to be used, it must be activated in addition.

### **NOTE**

To protect the internal measuring resistors, OUT\_OVERLOAD\_PROTECTION should always be active (default setting). Depending on the selected current measuring range protection is given from 2.25 A or 4.5 A. The function is **not** supported in the PWM mode and can be deactivated, if necessary.

 For the limit values please make sure to adhere to the data sheet!

Depending on the ambient temperature a short circuit cannot be reliably detected from a certain short circuit current since the output drivers temporarily deactivate themselves for protection against destruction.

Wire break and short circuit detection are active when the output is switched **on**.

## Diagnosis: binary outputs (via voltage measurement)

19403  
19397

The diagnostics of these outputs is made via internal voltage measurement in the output:




Figure: principle block diagram

- (1) Output channel
- (2) Read back channel for diagnosis
- (3) Pin output n
- (4) Load

## Diagnosis: overload

19448

The outputs have no current measuring, no overload detection.

## Diagnosis: wire break (via voltage measurement)

19404

Wire-break detection is done via the read back channel. When the output is blocked ( $Q_n = \text{FALSE}$ ) wire break is detected when the resistor  $R_u$  pulls the read back channel to HIGH potential ( $V_{BB}$ ). Without the wire break the low-resistance load ( $R_L < 10 \text{ k}\Omega$ ) would force a LOW (logical 0).

## Diagnosis: short circuit (via voltage measurement)

19405

Short-circuit detection is done via the read back channel. When the output is switched ( $Q_n = \text{TRUE}$ ) short circuit against GND is detected when the read back channel is pulled to LOW potential (GND).

## Output group Q4 (Q40...47)

19513

These outputs are a group of multifunction channels.

These outputs provide several function options (each output separately configurable):

- binary output, plus switching (BH), partly also minus switching (BL)
- analogue output with pulse-width modulation (partly as H-bridge)
- binary input (→ chapter *Inputs (technology)* (→ page 21))

→ chapter *Possible operating modes inputs/outputs* (→ page 234)

- Configuration of each output is made via the application program:  
indicate the load currents → FB *OUTPUT\_CURRENT* (→ page 164)  
PWM output: → FB *PWM1000* (→ page 173)  
Configuration byte Qxx\_MODE

13975


### **WARNING**

Dangerous restart possible!

Risk of personal injury! Risk of material damage to the machine/plant!

If in case of a fault an output is switched off via the hardware, the logic state generated by the application program is not changed.

- Remedy:
  - Reset the output logic in the application program!
  - Remove the fault!
  - Reset the outputs depending on the situation.

 The outputs in the PWM mode support no diagnostic functions.

When used as binary output, configuration of each output is carried out using the system variables Qxx\_MODE. If the diagnostics is to be used, it must be activated in addition.

Wire break and short circuit of the output signal are indicated separately (combined per output group) via the system variables ERROR\_BREAK\_Qx or ERROR\_SHORT\_Qx. The individual output error bits can be masked in the application program, if necessary.

### **NOTE**

To protect the internal measuring resistors, OUT\_OVERLOAD\_PROTECTION should always be active (default setting). Depending on the selected current measuring range protection is given from 2.25 A or 4.5 A. The function is **not** supported in the PWM mode and can be deactivated, if necessary.

 For the limit values please make sure to adhere to the data sheet!

Depending on the ambient temperature a short circuit cannot be reliably detected from a certain short circuit current since the output drivers temporarily deactivate themselves for protection against destruction.

Wire break and short circuit detection are active when the output is switched **on**.



## Diagnosis: binary outputs (via voltage measurement)

19403  
19397

The diagnostics of these outputs is made via internal voltage measurement in the output:




Figure: principle block diagram

- (1) Output channel
- (2) Read back channel for diagnosis
- (3) Pin output n
- (4) Load

## Diagnosis: overload

19448

The outputs have no current measuring, no overload detection.

## Diagnosis: wire break (via voltage measurement)

19404

Wire-break detection is done via the read back channel. When the output is blocked ( $Q_n=FALSE$ ) wire break is detected when the resistor  $R_u$  pulls the read back channel to HIGH potential ( $V_{BB}$ ). Without the wire break the low-resistance load ( $R_L < 10\text{ k}\Omega$ ) would force a LOW (logical 0).

## Diagnosis: short circuit (via voltage measurement)

19405

Short-circuit detection is done via the read back channel. When the output is switched ( $Q_n=TRUE$ ) short circuit against GND is detected when the read back channel is pulled to LOW potential (GND).

### 3.2.7 Note on wiring

1426

The wiring diagrams (→ installation instructions of the devices, chapter "Wiring") describe the standard device configurations. The wiring diagram helps allocate the input and output channels to the IEC addresses and the device terminals.

The individual abbreviations have the following meaning:

A	Analogue input
BH	Binary high side input: minus switching for negative sensor signal Binary high side output: plus switching for positive output signal
BL	Binary low side input: plus switching for positive sensor signal Binary low side output: minus switching for negative output signal
CYL	Input period measurement
ENC	Input encoder signals
FRQ	Frequency input
H bridge	Output with H-bridge function
PWM	Pulse-width modulated signal
PWMI	PWM output with current measurement
IH	Pulse/counter input, high side: minus switching for negative sensor signal
IL	Pulse/counter input, low side: plus switching for positive sensor signal
R	Read back channel for one output

Allocation of the input/output channels: → Catalogue, mounting instructions or data sheet

### 3.2.8 Safety instructions about Reed relays

7348

For use of non-electronic switches please note the following:

**!** Contacts of Reed relays may be clogged (reversibly) if connected to the device inputs without series resistor.

- **Remedy:** Install a series resistor for the Reed relay:  
Series resistor = max. input voltage / permissible current in the Reed relay  
**Example:** 32 V / 500 mA = 64 Ohm
- The series resistor must not exceed 5 % of the input resistance RE of the device input (→ data sheet). Otherwise, the signal will not be detected as TRUE.  
**Example:**  
RE = 3 000 Ohm  
⇒ max. series resistor = 150 Ohm

### 3.2.9 Feedback on bidirectional inputs/outputs

999

Some terminals of the controller can be configured as input or output (→ data sheet).

## NOTICE

Destruction of outputs if there is inadmissible feedback!

If a group of bidirectional inputs/outputs is operated at the same time with inputs and outputs, the potential VBB of this output group **must not** become potential-free.

The output group is potential free if e.g. ...

- RELAIS = FALSE or
- RELAIS CLAMP 15 = FALSE.

This potential-free status has the consequence that the voltage is fed back via the protective diode of the output transistor if within an input/output group:

- an input (e.g. I1) = TRUE and
- an output of the same group (e.g. Q2) = TRUE.

> **Consequence:**


The load on the output (Q2) receives voltage via the protective diode of the input (I1). The protective diode and thus the output (Q1) via which the feedback current flows at that moment, can be destroyed.

► **Remedy:**

Operate an input/output group only as inputs OR only as outputs.

or:

Follow the note below.



Graphic: examples of inadmissible connection: danger of feedback!

**NOTE**

Help for mixed operated bidirectional inputs/outputs:

- Set the flag RELAIS and/or RELAIS\_CLAMP\_15 in the application program permanently to TRUE:
  - TRUE ---- RELAIS
  - TRUE ---- RELAIS\_CLAMP\_15

### 3.2.10 Feedback in case of externally supplied outputs

2422

In some applications actuators are not only controlled by outputs of the PLC but additionally by external switches. In such cases the externally supplied outputs must be protected with blocking diodes (→ see graphics below).


#### NOTICE

Destruction of outputs if there is inadmissible feedback!

If actuators are externally controlled, the corresponding potential bar of the same output group must not become potential-free (e.g. for RELAIS = FALSE).

Otherwise the terminal voltage VBBx is fed back to the potential bar of the output group via the protective diode integrated in the output driver of the external connected output. A possibly other set output of this group thus triggers its connected load. The load current destroys the output which feeds back.

► Protect externally supplied outputs by means of blocking diodes!



**! NOTE****Help for externally supplied outputs**

- The externally supplied outputs must be decoupled via diodes so that no external voltage is applied to the output terminal.



### 3.2.11 Status LED

1430

The operating states are indicated by the integrated status LED (default setting).

LED colour	Flashing frequency	Description
off	permanently out	no operating voltage
yellow	briefly on	initialisation or reset checks
green / black	5 Hz	no runtime system loaded
green / black	2 Hz	application RUN
green	permanently on	application STOP
red / black	2 Hz	application RUN with error
red	briefly on	fatal error
red	permanently on	fatal error (if input TEST = active) ERROR STOP / STYSTEM STOP

The operating states STOP and RUN can be changed by the programming system.

#### Control the LED in the application program

9989

For this device the status LED can also be set by the application program. To do so, the following system variables are used (→ **System flags** (→ page 224)):

LED	LED color for "active" (for "on")
LED_X	LED color for "Pause" (for "Off" or different colour)
---	Color constant from the data structure "LED_COLOR". Permissible entries: LED_GREEN LED_BLUE LED_RED LED_WHITE LED_MAGENTA LED_CYAN LED_YELLOW LED_ORANGE LED_BLACK (= LED off)
LED_MODE	Flashing frequency from the data structure "LED_MODES". Permissible entries: LED_2HZ LED_1HZ LED_05HZ (= 0.5 Hz) LED_0HZ (= constant)

#### ! NOTE

- Do NOT use the LED color RED in the application program.
- > In case of an error the LED color RED is set by the runtime system.  
BUT: If the colors and/or flashing modes are changed in the application program, the above table with the default setting is no longer valid.

## 3.3 Interface description

Inhalt	
Serial interface.....	39
CAN interfaces .....	40
	14098

### 3.3.1 Serial interface

14099

This device features a serial interface.

The serial interface can generally be used in combination with the following functions:

- program download
- debugging
- free use of the application

#### **NOTE**

The serial interface is not available to the user by default, because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit `SERIAL_MODE=TRUE`. Debugging of the application program is then only possible via one of the 4 CAN interfaces or via USB.

Connections and data → data sheet

### 3.3.2 CAN interfaces

#### Inhalt

CAN: interfaces and protocols.....	40
------------------------------------	----

14101

Connections and data → data sheet

#### CAN: interfaces and protocols

19523  
14587

The devices are equipped with several CAN interfaces depending on the hardware design. Basically, all interfaces can be used with the following functions independently of each other:

- Layer 2: CAN at level 2 (→ chapter *Function elements: CAN layer 2* (→ page 80))
- CANopen master (→ chapter *Function elements: CANopen master* (→ page 96))
- CANopen slave (→ chapter *Function elements: CANopen slave* (→ page 106))
- CANopen network variables (via CODESYS)
- SAE J1939 (for drive management, → chapter *Function elements: SAE J1939* (→ page 119))
- bus load detection
- error frame counter
- download interface
- 100 % bus load without package loss

11796

The following CAN interfaces and CAN protocols are available in this *ecomatmobile* device:

CAN interface	CAN 1	CAN 2	CAN 3	CAN 4
Default download ID	ID 127	ID 126	ID 125	ID 124
CAN protocols	CAN Layer 2	CAN Layer 2	Interface do not exist	Interface do not exist
	CANopen	---		
	SAE J1939	SAE J1939		

Standard baud rate = 125 kBit/s



## 3.4 Software description

### Inhalt

Software modules for the device .....	41
Programming notes for CODESYS projects .....	44
Operating states .....	48
Operating modes .....	52
Performance limits of the device .....	53

14107

### 3.4.1 Software modules for the device

#### Inhalt

Bootloader .....	42
Runtime system .....	42
Application program .....	42
Libraries .....	43

14110

The software in this device communicates with the hardware as below:

software module	Can user change the module?	By means of what tool?
Application program with libraries	Yes	CODESYS, MaintenanceTool
Runtime system *)	Upgrade yes Downgrade no	MaintenanceTool
Bootloader	No	---
(Hardware)	No	---

\*) The runtime system version number must correspond to the target version number in the CODESYS target system setting.  
→ chapter *Set up the target* (→ page [58](#))

Below we describe this software module:

## Bootloader

14111

On delivery *ecomatmobile* controllers only contain the boot loader.

The boot loader is a start program that allows to reload the runtime system and the application program on the device.

The boot loader contains basic routines...

- for communication between hardware modules,
- for reloading the operating system.

The boot loader is the first software module to be saved on the device.

## Runtime system

14112

Basic program in the device, establishes the connection between the hardware of the device and the application program.

On delivery, there is normally no runtime system loaded in the controller (LED flashes green at 5 Hz). Only the bootloader is active in this operating mode. It provides the minimum functions for loading the runtime system, among others support of the interfaces (e.g. CAN).

Normally it is necessary to download the runtime system only once. Then, the application program can be loaded into the controller (also repeatedly) without affecting the runtime system.

The runtime system is provided with this documentation on a separate data carrier. In addition, the current version can be downloaded from the website of **ifm electronic gmbh**:

→ [www.ifm.com](http://www.ifm.com) > Select your country > [Service] > [Download]

## Application program

14118

Software specific to the application, implemented by the machine manufacturer, generally containing logic sequences, limits and expressions that control the appropriate inputs, outputs, calculations and decisions.

8340

### **WARNING**

The user is responsible for the reliable function of the application programs he designed. If necessary, he must additionally carry out an approval test by corresponding supervisory and test organisations according to the national regulations.

## Libraries

19527

**ifm electronic** offers a series of libraries (\*.LIB) suitable for each device, containing the program modules for the application program. Examples:

Library	Usage
ifm_CR0020_Vxxyzz.LIB	Device-specific library Must always be contained in the application program!
ifm_CAN1_EXT_Vxxyzz.LIB	(optional) if CAN interface 1 of the device is to operate on 29 bits
ifm_CR0020_CANopenMaster_Vxxyzz.LIB	(optional) if CAN interface 1 of the device is to be operated as a CANopen master
ifm_CR0020_CANopenSlave_Vxxyzz.LIB	(optional) if CAN interface1 of the device is to be operated as a CANopen slave
ifm_CR0020_J1939_x_Vxxyzz.LIB x = 1...2 = number of the CAN interface	(optional) if a CAN interface of the device is to communicate with a motor control

→ chapter *ifm libraries for the device CR0020* (→ page [74](#))

### 3.4.2 Programming notes for CODESYS projects

#### Inhalt

FB, FUN, PRG in CODESYS .....	45
Note the cycle time! .....	45
Creating application program .....	46
Save boot project.....	47
Using ifm downloader .....	47
Using ifm maintenance tool .....	47

7426

Here you receive tips how to program the device.

- See the notes in the CODESYS programming manual
  - [www.ifm.com](http://www.ifm.com) > select your country > [Data sheet search] > CR0020 > [Operating instructions]
  - *ecomatmobile* DVD "Software, tools and documentation".

## FB, FUN, PRG in CODESYS

8473

In CODESYS we differentiate between the following types of function elements:

### FB = function block

- An FB can have several inputs and several outputs.
- An FB may be called several times in a project.
- An instance must be declared for each call.
- Permitted: Call FB and FUN in FB.

### FUN = function

- A function can have several inputs but only one output.
- The output is of the same data type as the function itself.

### PRG = program

- A PRG can have several inputs and several outputs.
- A PRG may only be called once in a project.
- Permitted: Call PRG, FB and FUN in PRG.

### NOTE

Function blocks must NOT be called in functions!  
Otherwise: During execution the application program will crash.  
All function elements must NOT be called recursively, nor indirectly!  
An IEC application must contain max. 8,000 function elements!

### Background:

All variables of functions...

- are initialised when called and
- become invalid after return to the caller.

Function blocks have 2 calls:

- an initialisation call and
- the actual call to do something.

Consequently that means for the FB call in a function:

- every time there is an additional initialisation call and
- the data of the last call gets lost.

### Note the cycle time!

8006

For the programmable devices from the controller family **ecomatmobile** numerous functions are available which enable use of the devices in a wide range of applications.

As these units use more or fewer system resources depending on their complexity it is not always possible to use all units at the same time and several times.

### NOTICE

Risk that the device acts too slowly!  
Cycle time must not become too long!

- ▶ When designing the application program the above-mentioned recommendations must be complied with and tested.
- ▶ If necessary, the cycle time must be optimised by restructuring the software and the system set-up.


## Creating application program

8007

The application program is generated by the CODESYS programming system and loaded in the controller several times during the program development for testing:

In CODESYS: [Online] > [Login] > load the new program.

For each such download via CODESYS the source code is translated again. The result is that each time a new checksum is formed in the controller memory. This process is also permissible for safety controllers until the release of the software.



Graphics: Creation and distribution of the software

## Save boot project

7430

**!** Always save the related boot project together with your application project in the device. Only then will the application program be available after a power failure in the device.

### **! NOTE**

Note: The boot project is slightly larger than the actual program.

However: Saving the boot project in the device will fail if the boot project is larger than the available IEC code memory range. After power-on the boot project is deleted or invalid.

- ▶ CODESYS menu [Online] > [Create boot project]  
This is necessary after each change!
- > After a reboot, the device starts with the boot project last saved.
- > If NO boot project was saved:
  - The device remains in the STOP operation after reboot.
  - The application program is not (no longer) available.
  - The LED lights green.

## Using ifm downloader

8008

The **ifm** downloader serves for easy transfer of the program code from the programming station to the controller. As a matter of principle each application software can be copied to the controllers using the **ifm** downloader. Advantage: A programming system with CODESYS licence is not required.

Here you will find the current **ifm** downloader (min. V06.18.26):

**ecomatmobile** DVD "Software, tools and documentation" under the tab 'R360 tools [D/E]'

## Using ifm maintenance tool

8492

The **ifm** Maintenance Tool serves for easy transfer of the program code from the programming station to the controller. As a matter of principle each application software can be copied to the controllers using the **ifm** Maintenance Tool. Advantage: A programming system with CODESYS licence is not required.

Here you will find the current **ifm** Maintenance Tool:

→ [www.ifm.com](http://www.ifm.com) > Select your country > [Service] > [Download] > [Systems for mobile machines]

→ **ecomatmobile** DVD "Software, tools and documentation" under the tab 'R360 tools [D/E]'

### 3.4.3 Operating states

<b>Inhalt</b>	
Operating states: runtime system is not available.....	48
Operating states: application program is not available .....	49
Operating states: application program is available .....	50
Bootloader state .....	51
INIT state (Reset) .....	51
STOP state .....	51
RUN state .....	51
SYSTEM STOP state .....	51

14120

After power on the *ecomatmobile* device can be in one of five possible operating states:

- BOOTLOADER
- INIT
- STOP
- RUN
- SYSTEM STOP (after ERROR STOP)

Operating states: runtime system is not available

19217




Figure: operating states (here: runtime system is not available)



Operating states: application program is not available

19218




Figure: operating states (here: application program is not available)

Operating states: application program is available

19219




Figure: operating states (here: application program is available)

## Bootloader state

1080

No runtime system was loaded. The *ecomatmobile* controller is in the boot loading state. Before loading the application software the runtime system must be downloaded.

- > The LED flashes green (5 Hz).

## INIT state (Reset)

1076

Premise: a valid runtime system is installed.

This state is passed through after every power on reset:

- > The runtime system is initialised.
- > Various checks are carried out, e.g. waiting for correctly power supply voltage.
- > This temporary state is replaced by the RUN or STOP state.
- > The LED lights yellow.

Change out of this state possible into one of the following states:

- RUN
- STOP

## STOP state

1078

This state is reached in the following cases:

- From the RESET state if:
  - no program is loaded or
  - the last state before the RESET state was the STOP state
- From the RUN state by the STOP command
  - only for the operating mode = Test (→ chapter *TEST mode* (→ page [52](#)))
- > The LED lights green.

## RUN state

1077

This state is reached in the following cases:

- From the RESET state if:
  - the last state before the RESET state was the RUN state
- From the STOP state by the RUN command
  - only for the operating mode = Test (→ chapter *TEST mode* (→ page [52](#)))
- > The LED flashes green (2 Hz).

## SYSTEM STOP state

19222

The *ecomatmobile* controller goes to this state if a non tolerable error (ERROR STOP) was found. This state can only be left by a power-off-on reset.

- > The LED lights red.

### 3.4.4 Operating modes

1083

Independent of the operating states the *ecomatmobile* controller can be operated in different modes.

#### TEST mode

1084

#### NOTICE

Loss of the stored software possible!  
In the test mode there is no protection of the stored runtime system and application software.

#### NOTE

- ▶ Connect the TEST connection to the supply voltage only AFTER you have connected the OPC client!
- > Otherwise a fatal error will occur.

This operating mode is reached by applying supply voltage to the test input (→ installation instructions > chapter "Technical data" > chapter "Wiring").

The *ecomatmobile* controller can now receive commands via one of the interfaces in the RUN or STOP mode and, for example, communicate with the programming system.

Only in the TEST mode the software can be downloaded to the controller.

The state of the application program can be queried via the flag TEST.

 Summary Test input is active:

- Programming mode is enabled
- Software download is possible
- Status of the application program can be queried
- Protection of stored software is not possible

#### SERIAL\_MODE

1085

The serial interface is available for the exchange of data in the application. Debugging the application software is then only possible via the CAN interface.

This function is switched off as standard (FALSE). Via the flag SERIAL\_MODE the state can be controlled and queried via the application program or the programming system.

→ chapter *Function elements: serial interface* (→ page [131](#))

#### DEBUG mode

1086

If the input DEBUG of *SET\_DEBUG* (→ page [218](#)) is set to TRUE, the programming system or the downloader, for example, can communicate with the controller and execute system commands (e.g. for service functions via the GSM modem CANremote).

In this operating mode a software download is not possible because the test input (→ chapter *TEST mode* (→ page [52](#))) is not connected to supply voltage.

### 3.4.5 Performance limits of the device

7358



Note the limits of the device! → Data sheet

#### Above-average stress

1488  
5023

The following FBs, for example, utilise the system resources above average:

Function block	Above average load
CYCLE, PERIOD, PERIOD_RATIO, PHASE	Use of several measuring channels with a high input frequency
OUTPUT_CURRENT_CONTROL, OCC_TASK	Simultaneous use of several current controllers
CAN interface	High baud rate (> 250 kbits) with a high bus load
PWM, PWM1000	Many PWM channels at the same time. In particular the channels as from 4 are much more time critical
INC_ENCODER	Many encoder channels at the same time

The FBs listed above as examples trigger system interrupts. This means: Each activation prolongs the cycle time of the application program.

The following indications should be seen as reference values:

#### Restrictions for the use of FBs

1489

Current controller	max. 8	If possible, do not use any other performance-affecting functions!
CYCLE, PERIOD, PERIOD_RATIO, PHASE	1 channel	Input frequency $\leq 10$ kHz
	4 channels	Input frequency $\leq 2$ kHz
INC_ENCODER	max. 4	If possible, do not use any other performance-affecting functions!

1509

#### NOTICE

Risk that the controller works too slowly! Cycle time must not become too long!

- When the application program is designed the above-mentioned recommendations must be complied with and tested. If necessary, the cycle time must be optimised by restructuring the software and the system set-up.

#### Watchdog behaviour

11786

In this device, a watchdog monitors the program runtime of the CODESYS application.

If the maximum watchdog time (approx. 100 ms) is exceeded:

> the device performs a reset and reboots.

This you can read in the flag LAST\_RESET.

## 4 Configurations

### Inhalt

Set up the runtime system.....	54
Set up the programming system .....	57
Function configuration in general .....	61
Function configuration of the inputs and outputs .....	62
Variables.....	73

1016

The device configurations described in the corresponding installation instructions or in the *Annex* (→ page [224](#)) to this documentation are used for standard devices (stock items). They fulfil the requested specifications of most applications.

Depending on the customer requirements for series use it is, however, also possible to use other device configurations, e.g. with respect to the inputs/outputs and analogue channels.

### 4.1 Set up the runtime system

#### Inhalt

Reinstall the runtime system .....	55
Update the runtime system .....	56
Verify the installation .....	56

14091

## 4.1.1 Reinstall the runtime system

14092  
2733

On delivery of the *ecomatmobile* device no runtime system is normally loaded (LED flashes green at 5 Hz). Only the bootloader is active in this operating mode. It provides the minimum functions for loading the runtime system (e.g. RS232, CAN).

Normally it is necessary to download the runtime system only once. The application program can then be loaded to the device (also several times) without influencing the runtime system.

The runtime system is provided with this documentation on a separate data carrier. In addition, the current version can be downloaded from the website of **ifm electronic gmbh** at:

→ [www.ifm.com](http://www.ifm.com) > Select your country > [Service] > [Download]

2689

### ! NOTE

The software versions suitable for the selected target must always be used:

- runtime system (ifm\_CR0020\_Vxxyzz.H86),
- PLC configuration (ifm\_CR0020\_Vxx.CFG),
- device library (ifm\_CR0020\_Vxxyzz.LIB) and
- the further files.

V	version
xx: 00...99	target version number
yy: 00...99	release number
zz: 00...99	patch number

The basic file name (e.g. "CR0020") and the software version number "xx" (e.g. "02") must always have the same value! Otherwise the device goes to the STOP mode.

The values for "yy" (release number) and "zz" (patch number) do **not** have to match.

4368

! The following files must also be loaded:

- the internal libraries (created in IEC 1131) required for the project,
- the configuration files (\*.CFG) and
- the target files (\*.TRG).

i It may happen that the target system cannot or only partly be programmed with your currently installed version of CODESYS. In such a case, please contact the technical support department of **ifm electronic gmbh**.

The runtime system is transferred to the device using the separate program "**ifm** downloader". (The downloader is on the *ecomatmobile* DVD "Software, tools and documentation" or can be downloaded from **ifm's** website, if necessary): → [www.ifm.com](http://www.ifm.com) > Select your country > [Service] > [Download].

Normally the application program is loaded to the device via the programming system. But it can also be loaded using the **ifm** downloader if it was first read from the device (→ upload).

## 4.1.2 Update the runtime system

13269

An older runtime system is already installed on the device. Now, you would like to update the runtime system on the device?

14158

### NOTICE

Risk of data loss!

When deleting or updating the runtime system all data and programs on the device are deleted.

- ▶ Save all required data and programs before deleting or updating the runtime system!

3084

When the operating system software or the CODESYS runtime system is considerably improved, ifm releases a new version. The versions are numbered consecutively (V01, V02, V03, ...).

Please see the respective documentation for the new functions of the new software version. Note whether special requirements for the hardware version are specified in the documentation.

If you have a device with an older version and if the conditions for the hardware and your project are OK, you can update your device to the new software version.

For this operation, the same instructions apply as in the previous chapter 'Reinstall the runtime system'.

## 4.1.3 Verify the installation

14512

- ▶ After loading of the runtime system into the controller:
  - check whether the runtime system was transmitted correctly!
  - check whether the right runtime system is on the controller!
- ▶ 1st check:
 

use the ifm downloader or the maintenance tool to verify whether the correct version of the runtime system was loaded:

  - read out the name, version and CRC of the runtime system in the device!
  - Manually compare this information with the target data!
- ▶ 2nd check (optional):
 

verify in the application program whether the correct version of the runtime system was loaded:

  - read out the name and version of the runtime system in the device!
  - Compare this data with the specified values!

The following FB serves for reading the data:

**GET\_IDENTITY** (→ page 217)

Reads the specific identifications stored in the device:

- hardware name and hardware version of the device
- name of the runtime system in the device
- version and revision no. of the runtime system in the device
- name of the application (has previously been saved by means of **SET\_IDENTITY** (→ page 219))



## 4.2 Set up the programming system

### Inhalt

Set up the programming system manually.....	57
Set up the programming system via templates .....	60

3968

### 4.2.1 Set up the programming system manually

#### Inhalt

Set up the target .....	58
Activate the PLC configuration (e.g. CR0033) .....	59

3963

## Set up the target

2687  
11379

When creating a new project in CODESYS the target file corresponding to the device must be loaded.

- ▶ Select the requested target file in the dialogue window [Target Settings] in the menu [Configuration].
- > The target file constitutes the interface to the hardware for the programming system.
- > At the same time, several important libraries and the PLC configuration are loaded when selecting the target.
- ▶ If necessary, in the window [Target settings] > tab [Network functionality] > activate [Support parameter manager] and / or activate [Support network variables].
- ▶ If necessary, remove the loaded (3S) libraries or complement them by further (ifm) libraries.
- ▶ Always complement the appropriate device library ifm\_CR0020\_Vxxyzz.LIB manually!

2689

### **NOTE**

The software versions suitable for the selected target must always be used:

- runtime system (ifm\_CR0020\_Vxxyzz.H86),
- PLC configuration (ifm\_CR0020\_Vxx.CFG),
- device library (ifm\_CR0020\_Vxxyzz.LIB) and
- the further files.

V	version
xx: 00...99	target version number
yy: 00...99	release number
zz: 00...99	patch number

The basic file name (e.g. "CR0020") and the software version number "xx" (e.g. "02") must always have the same value! Otherwise the device goes to the STOP mode.

The values for "yy" (release number) and "zz" (patch number) do **not** have to match.

4368

**!** The following files must also be loaded:

- the internal libraries (created in IEC 1131) required for the project,
- the configuration files (\*.CFG) and
- the target files (\*.TRG).

**i** It may happen that the target system cannot or only partly be programmed with your currently installed version of CODESYS. In such a case, please contact the technical support department of **ifm electronic gmbh**.

## Activate the PLC configuration (e.g. CR0033)


15824

During the configuration of the programming system (→ previous section) the PLC configuration was also carried out automatically.

- ▶ The menu item [PLC Configuration] is reached via the tab [Resources].  
Double-click on [PLC Configuration] to open the corresponding window.
- ▶ Click on the tab [Resources] in CODESYS:




- ▶ In the left column double-click on [PLC Configuration].
- > Display of the current PLC configuration (example → following figure):



Based on the configuration the user can find the following in the program environment:

- all important system and error flags  
Depending on the application and the application program, these flags must be processed and evaluated. Access is made via their symbolic names.
- The structure of the inputs and outputs  
These can directly be designated symbolically (highly recommended!) in the window [PLC Configuration] (→ figure below) and are available in the whole project as [Global Variables].




## 4.2.2 Set up the programming system via templates

13745

**ifm** offers ready-to-use templates (program templates), by means of which the programming system can be set up quickly, easily and completely.

970

-  When installing the **ecomatmobile** DVD "Software, tools and documentation", projects with templates have been stored in the program directory of your PC:  
...\\ifm\_electronic\\CoDeSys V...\\Projects\\Template\_DVD\_V...
- ▶ Open the requested template in CODESYS via:  
[File] > [New from template...]
  - > CODESYS creates a new project which shows the basic program structure. It is strongly recommended to follow the shown procedure.

## 4.3 Function configuration in general

3971

### 4.3.1 Configuration of the inputs and outputs (default setting)

2249

- All inputs and outputs are in the binary mode (plus switching!) when delivered.
- The diagnostic function is not active.
- The overload protection is active.

### 4.3.2 System variables

2252  
13519  
15576

All system variables (→ chapter *System flags* (→ page [224](#))) have defined addresses which cannot be shifted.

- > To indicate and process a watchdog error or causes of a new start the system variable LAST\_RESET is set.
- > Indication of the selected I/O configuration via mode bytes

## 4.4 Function configuration of the inputs and outputs

### Inhalt

Configure inputs .....	63
Configure outputs .....	67

1375  
1394

For some devices of the **ecomatmobile** controller family, additional diagnostic functions can be activated for the inputs and outputs. So, the corresponding input and output signal can be monitored and the application program can react in case of a fault.

Depending on the input and output, certain marginal conditions must be taken into account when using the diagnosis:

- ▶ It must be checked by means of the data sheet if the device used has the described input and output groups (→ data sheet).
- Constants are predefined (e.g. IN\_DIGITAL\_H) in the device libraries (e.g. ifm\_CR0020\_Vx.LIB) for the configuration of the inputs and outputs.  
For details → *Possible operating modes inputs/outputs* (→ page [234](#)).
- You find program blocks in the templates for each controller that are called during the 1st cycle after a restart of the controller. The networks programmed there are only used to assign a defined configuration to the input and outputs.

## 4.4.1 Configure inputs

### Inhalt

Safety instructions about Reed relays.....	63
Digital inputs.....	64
Fast inputs.....	65
Analogue inputs.....	66

19567  
3973

Valid operating modes → chapter *Possible operating modes inputs/outputs* (→ page [234](#))

- Configuration of each input is made via the application program:
  - FB *INPUT\_ANALOG* (→ page [144](#)) > input MODE
  - Configuration byte lxx\_MODE

### Safety instructions about Reed relays

7348

For use of non-electronic switches please note the following:

**!** Contacts of Reed relays may be clogged (reversibly) if connected to the device inputs without series resistor.

- **Remedy:** Install a series resistor for the Reed relay:  
 Series resistor = max. input voltage / permissible current in the Reed relay  
**Example:** 32 V / 500 mA = 64 Ohm
- The series resistor must not exceed 5 % of the input resistance RE of the device input (→ data sheet). Otherwise, the signal will not be detected as TRUE.  
**Example:**  
 RE = 3 000 Ohm  
 ⇒ max. series resistor = 150 Ohm

## Digital inputs

1015  
7345

The binary input can be operated in following modes:

- binary input plus switching (BL) for positive sensor signal
- binary input minus switching (BH) for negative sensor signal

Depending on the device the binary inputs can configured differently. In addition to the protective mechanisms against interference, the binary inputs are internally evaluated via an analogue stage. This enables diagnosis of the input signals. But in the application software the switching signal is directly available as bit information






Figure: basic circuit of binary input minus switching / plus switching for negative and positive sensor signals



Basic circuit of binary input plus switching (BL)  
for positive sensor signal:  
Input = open  $\Rightarrow$  signal = low (GND)



Basic circuit of binary input minus switching (BH)  
for negative sensor signal:  
Input = open  $\Rightarrow$  signal = high (supply)

For some of these inputs ( $\rightarrow$  data sheet) the potential can be selected to which it will be switched.



## Fast inputs

1018

In addition, the *ecomatmobile* controllers have up to 16 fast counter/pulse inputs for an input frequency up to 50 kHz (→ data sheet). If, for example, mechanical switches are connected to these inputs, there may be faulty signals in the controller due to contact bouncing. Using the application software, these "faulty signals" must be filtered if necessary.

Furthermore it has to be noted whether the pulse inputs are designed for frequency measurement (FRQx) and/or period measurement (CYLx) (→ data sheet).


Appropriate function blocks are e.g.:

### On FRQx inputs:

<b>FAST_COUNT</b> (→ page <a href="#">151</a> )	Counter block for fast input pulses
<b>FREQUENCY</b> (→ page <a href="#">152</a> )	Measures the frequency of the signal arriving at the selected channel

### On CYLx inputs:

<b>PERIOD</b> (→ page <a href="#">156</a> )	Measures the frequency and the cycle period (cycle time) in [μs] at the indicated channel
<b>PERIOD_RATIO</b> (→ page <a href="#">158</a> )	Measures the frequency and the cycle period (cycle time) in [μs] during the indicated periods at the indicated channel. In addition, the mark-to-space ratio is indicated in [%].
<b>PHASE</b> (→ page <a href="#">160</a> )	Reads a pair of channels with fast inputs and compares the phase position of the signals

 When using these units, the parameterised inputs and outputs are automatically configured, so the programmer of the application does not have to do this.

## Analogue inputs

1369

The analogue inputs can be configured via the application program. The measuring range can be set as follows:

- current input 0...20 mA
- voltage input 0...10 V
- voltage input 0...32 V

If in the operating mode "0...32 V" the supply voltage is read back, the measurement can also be performed ratiometrically. This means potentiometers or joysticks can be evaluated without additional reference voltage. A fluctuation of the supply voltage then has no influence on this measured value.

As an alternative, an analogue channel can also be evaluated binarily.

### NOTE

In case of ratiometric measurement the connected sensors should be supplied with VBBS of the device. So, faulty measurements caused by offset voltage are avoided.

► Note the higher input resistances for binary evaluation.

8971




Figure: principle block diagram multifunction input

## 4.4.2 Configure outputs

### Inhalt

Binary and PWM outputs.....	68
Output group Q1Q2 (Q10...13 / Q20...23).....	70
Output group Q3 (Q30...37) .....	71
Output group Q4 (Q40...47) .....	72

19568  
3976

Valid operating modes → chapter *Possible operating modes inputs/outputs* (→ page [234](#))

- Configuration of each output is made via the application program:  
 indicate the load currents → FB *OUTPUT\_CURRENT* (→ page [164](#))  
 PWM output: → FB *PWM1000* (→ page [173](#))  
 Configuration byte Qxx\_MODE


## Binary and PWM outputs

1346

The following operating modes are possible for the device outputs (→ data sheet):

- binary output, plus switching (BH) with diagnostic function and protection
- analogue output with Pulse Width Modulation (PWM)
- PWM output pair H-bridge without diagnostic function

PWM outputs can be operated with and without current control function.

 Current-controlled PWM outputs are mainly used for triggering proportional hydraulic functions.

14713


### WARNING

Property damage or bodily injury possible due to malfunctions!


The following applies for outputs in PWM mode:

- there is no diagnostic function
- no ERROR flags are set
- the overload protection OUT\_OVERLOAD\_PROTECTION is NOT active

15450



Basic circuit of output plus switching (BH) for positive output signal



Basic circuit of output minus switching (BL) for negative output signal

13975

### WARNING

Dangerous restart possible!

Risk of personal injury! Risk of material damage to the machine/plant!

If in case of a fault an output is switched off via the hardware, the logic state generated by the application program is not changed.

- Remedy:
- Reset the output logic in the application program!
  - Remove the fault!
  - Reset the outputs depending on the situation.

**Behaviour in case of short circuit, permanent overload or wire break:**

(applies as from the hardware version AH, however **not** in the safety mode)

- > System flag **ERROR\_SHORT\_Qx** (in case of short circuit or overload) or **ERROR\_BREAK\_Qx** (in case of wire break) becomes active.
- > Only in case of short circuit/overload: the runtime system deactivates the affected output driver. The logic of the affected output remains TRUE.  
After a waiting time the output is activated again, which can lead to periodic switching to short circuit.  
The waiting time increases with the (over)load of the output.  
Switch-on time in case of short circuit typically 50 µs, considerably longer in case of overload.
- ▶ Evaluate the error flag in the application program!  
Reset the output logic, stop the machine if necessary.  
If required, switch off the output group VBB<sub>r</sub> via RELAY=FALSE (e.g. via ERROR=TRUE).

After fault elimination:

- ▶ Reset the error flag **ERROR\_...\_Qx**.
- > The output relay re-enables the output group VBB<sub>r</sub>.
- ▶ New setting of the output or restart of the machine.

## Output group Q1Q2 (Q10...13 / Q20...23)

1378

These outputs have two functions. When used as PWM outputs, the diagnosis is implemented via the integrated current measurement channels, which are also used for the current-controlled output functions.


Using **OUTPUT\_CURRENT** (→ page 164) load currents  $\geq 100$  mA can be indicated.

When used as digital output, configuration is carried out using the system variables Q1x\_MODE...Q2x\_MODE. If the diagnosis is to be used, it must be activated in addition.

Wire break and short circuit of the output signal are indicated separately via the system variables ERROR\_BREAK\_Q1Q2 and ERROR\_SHORT\_Q1Q2. The individual output error bits can be masked in the application program, if necessary.

### Example:

The assignment sets the selected output to the operating mode OUT\_DIGITAL\_H with diagnosis. The overload protection is activated (default state).



### NOTE

To protect the internal measuring resistors, OUT\_OVERLOAD\_PROTECTION should always be active (max. measurement current 4.1 A).

For the limit values please make sure to adhere to the data sheet!

OUT\_OVERLOAD\_PROTECTION is not supported in the pure PWM mode.


Wire break and short circuit detection are active when ...

- the output is configured as "binary plus switching" (BH) AND
- the output is switched ON.

## Output group Q3 (Q30...37)

1379

The configuration of these outputs is carried out via the system variables Q3x\_MODE. If the diagnosis is to be used, it must be activated in addition. At the same time, the corresponding input must be deactivated by setting the system flag I3x\_MODE to IN\_NOMODE.



Example: The assignments on the right deactivate the input and set the selected output to the operating mode "OUT\_DIGITAL\_H with diagnosis".

Wire break and short circuit of the output signal are indicated separately via the system variables ERROR\_BREAK\_Q3 and ERROR\_SHORT\_Q3. The individual output error bits can be masked in the application program, if necessary.

**!** For the limit values please make sure to adhere to the data sheet!

The wire break detection is active when the output is switched **off**.

The short circuit detection is active when the output is switched **on**.

## Output group Q4 (Q40...47)

1380

On delivery, this output group is deactivated to enable diagnosis via the inputs. The outputs must be activated in order to be used.

The configuration of these outputs is carried out via the system variables Q4x\_MODE. If the diagnosis is to be used, it must be activated in addition. At the same time, the corresponding input must be deactivated by setting the system flag I4x\_MODE to IN\_NOMODE.

Wire break and short circuit of the output signal are indicated separately via the system variables ERROR\_BREAK\_Q4 and ERROR\_SHORT\_Q4. The individual output error bits can be masked in the application program, if necessary.

To implement an H-bridge function, the outputs Q41, Q42, Q45, Q46 can be switched to the mode OUT\_DIGITAL\_L in addition.

**!** For the limit values please make sure to adhere to the data sheet!

The wire break detection is active when the output is switched **off**.

The short circuit detection is active when the output is switched **on**.



## 4.5 Variables

Inhalt	
Retain variables.....	73
Network variables .....	73

3130

In this chapter you will learn more about how to handle variables.

### 4.5.1 Retain variables

3131

Variables declared as RETAIN generate remanent data. Retain variables keep the values saved in them when the device is switched on/off or when an online reset is made.

14166


Typical applications for retain variables are for example:

- operating hours which are counted up and retained while the machine is in operation,
- position values of incremental encoders,
- preset values entered in the monitor,
- machine parameters,

i.e. all variables whose values must not get lost when the device is switched off.

All variable types, also complex structures (e.g. timers), can be declared as retain.

► To do so, activate the control field [RETAIN] in the variable declaration (→ window).



### 4.5.2 Network variables

9856

Global network variables are used for data exchange between controllers in the network. The values of global network variables are available to all CODESYS projects in the whole network if the variables are contained in their declaration lists.

- Integrate the following library/libraries into the CODESYS project:
- 3S\_CANopenNetVar.lib

## 5 ifm function elements

### Inhalt

ifm libraries for the device CR0020 .....	74
ifm function elements for the device CR0020 .....	80

13586

All CODESYS function elements (FBs, PRGs, FUNs) are stored in libraries. Below you will find a list of all the **ifm** libraries you can use with this device.

This is followed by a description of the function elements, sorted by topic.

### 5.1 ifm libraries for the device CR0020

#### Inhalt

Library ifm_CR0020_V06yyzz.LIB .....	75
Library ifm_CR0020_CANopenMaster_V04yynn.LIB .....	77
Library ifm_CR0020_CANopenSlave_V04yynn.LIB .....	77
Library ifm_CAN1_EXT_Vxxyyzz.LIB .....	78
Library ifm_J1939_x_Vxxyyzz.LIB .....	78
Library ifm_hydraulic_16bitOS05_Vxxyyzz.LIB .....	79

14235

Legend for ...\_Vxxyyzz.LIB:

V	version
xx: 00...99	target version number
yy: 00...99	release number
zz: 00...99	patch number

Here you will find a list of the **ifm** function elements matching this device, sorted according to the CODESYS libraries.

## 5.1.1 Library ifm\_CR0020\_V06yyzz.LIB

19531

This is the device library. This **ifm** library contains the following function blocks:

Function element	Short description
<b>ANALOG_RAW</b> (→ page 143)	supplies non-standardised values of the analogue/digital converter for each individual input port
<b>CAN2</b> (→ page 88)	Initialises CAN interface x x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CAN1_BAUDRATE</b> (→ page 81)	Sets the transmission rate for the bus participant on CAN interface 1
<b>CAN1_DOWNLOADID</b> (→ page 82)	Sets the download identifier for CAN interface 1
<b>CANx_ERRORHANDLER</b> (→ page 89)	Executes a "manual" bus recovery on CAN interface x x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CANx_EXT_RECEIVE_ALL</b> (→ page 90)	CAN interface x: Configures all data receive objects and reads out the receive buffer of the data objects x = 2 = number of the CAN interface
<b>CANx_RECEIVE</b> (→ page 91)	CAN interface x: Configures a data receive object and reads out the receive buffer of the data object x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CANx_RECEIVE_RANGE</b> (→ page 93)	CAN interface x: Configures a sequence of data receive objects and reads out the receive buffer of the data objects x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CANx_SDO_READ</b> (→ page 115)	CAN interface x: Reads the SDO with the indicated indices from the node x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CANx_SDO_WRITE</b> (→ page 117)	CAN interface x: writes the SDO with the indicated indices to the node x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CANx_TRANSMIT</b> (→ page 95)	Transfers a CAN data object (message) to the CAN interface x for transmission at each call x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CHECK_DATA</b> (→ page 215)	Generates a checksum (CRC) for a configurable memory area and checks the data of the memory area for undesired changes
<b>DELAY</b> (→ page 192)	Delays the output of the input value by the time T (dead-time element)
<b>FAST_COUNT</b> (→ page 151)	Counter block for fast input pulses
<b>FLASHREAD</b> (→ page 209)	Transfers different data types directly from the flash memory to the RAM
<b>FLASHWRITE</b> (→ page 210)	Writes different data types directly into the flash memory
<b>FRAMREAD</b> (→ page 211)	Transfers different data types directly from the FRAM memory to the RAM FRAM indicates here all kinds of non-volatile and fast memories.
<b>FRAMWRITE</b> (→ page 212)	Writes different data types directly into the FRAM memory FRAM indicates here all kinds of non-volatile and fast memories.
<b>FREQUENCY</b> (→ page 152)	Measures the frequency of the signal arriving at the selected channel
<b>GET_IDENTITY</b> (→ page 217)	Reads the specific identifications stored in the device: <ul style="list-style-type: none"> <li>• hardware name and hardware version of the device</li> <li>• name of the runtime system in the device</li> <li>• version and revision no. of the runtime system in the device</li> <li>• name of the application (has previously been saved by means of <b>SET_IDENTITY</b> (→ page 219))</li> </ul>
<b>GLR</b> (→ page 193)	The synchro controller is a controller with PID characteristics
<b>INC_ENCODER</b> (→ page 153)	Up/down counter function for the evaluation of encoders
<b>INPUT_ANALOG</b> (→ page 144)	Current and voltage measurement on the analogue input channel
<b>INPUT_CURRENT</b> (→ page 145)	Current measurement on the analogue input channel
<b>INPUT_VOLTAGE</b> (→ page 146)	Voltage measurement on the analogue input channel
<b>MEMCPY</b> (→ page 213)	Writes and reads different data types directly in the memory
<b>MEMORY_RETAIN_PARAM</b> (→ page 207)	Determines the remanent data behaviour for various events

Function element	Short description
<b><i>NORM</i></b> (→ page <a href="#">148</a> )	Normalises a value [WORD] within defined limits to a value with new limits
<b><i>OCC_TASK</i></b> (→ page <a href="#">162</a> )	OCC = Output Current Control Current controller for a PWMi output channel Each instance of the function is called up in a cycle of 5 ms.
<b><i>OUTPUT_CURRENT</i></b> (→ page <a href="#">164</a> )	Measures the current (average via dither period) on an output channel
<b><i>OUTPUT_CURRENT_CONTROL</i></b> (→ page <a href="#">165</a> )	Current controller for a PWMi output channel
<b><i>PERIOD</i></b> (→ page <a href="#">156</a> )	Measures the frequency and the cycle period (cycle time) in [µs] at the indicated channel
<b><i>PERIOD_RATIO</i></b> (→ page <a href="#">158</a> )	Measures the frequency and the cycle period (cycle time) in [µs] during the indicated periods at the indicated channel. In addition, the mark-to-space ratio is indicated in [%].
<b><i>PHASE</i></b> (→ page <a href="#">160</a> )	Reads a pair of channels with fast inputs and compares the phase position of the signals
<b><i>PID1</i></b> (→ page <a href="#">195</a> )	PID controller
<b><i>PID2</i></b> (→ page <a href="#">197</a> )	PID controller
<b><i>PT1</i></b> (→ page <a href="#">199</a> )	Controlled system with first-order delay
<b><i>PWM</i></b> (→ page <a href="#">167</a> )	Initialises and configures a PWM-capable output channel Definition of the PWM frequency via RELOAD
<b><i>PWM100</i></b> (→ page <a href="#">171</a> )	Initialises and configures a PWM-capable output channel Indicate PWM frequency in [Hz] Indicate mark-to-space ratio in steps of 1 %
<b><i>PWM1000</i></b> (→ page <a href="#">173</a> )	Initialises and configures a PWM-capable output channel the mark-to-space ratio can be indicated in steps of 1 %
<b><i>SERIAL_PENDING</i></b> (→ page <a href="#">132</a> )	Determines the number of data bytes stored in the serial receive buffer
<b><i>SERIAL_RX</i></b> (→ page <a href="#">133</a> )	Reads a received data byte from the serial receive buffer at each call
<b><i>SERIAL_SETUP</i></b> (→ page <a href="#">134</a> )	Initialises the serial RS232 interface
<b><i>SERIAL_TX</i></b> (→ page <a href="#">135</a> )	Transmits one data byte via the serial RS232 interface
<b><i>SET_DEBUG</i></b> (→ page <a href="#">218</a> )	organises the DEBUG mode or the monitoring mode (depending on the TEST input)
<b><i>SET_IDENTITY</i></b> (→ page <a href="#">219</a> )	Sets an application-specific program identification
<b><i>SET_INTERRUPT_I</i></b> (→ page <a href="#">137</a> )	Conditional execution of a program part after an interrupt request via a defined input channel
<b><i>SET_INTERRUPT_XMS</i></b> (→ page <a href="#">140</a> )	Conditional execution of a program part at an interval of x milliseconds
<b><i>SET_PASSWORD</i></b> (→ page <a href="#">220</a> )	Sets a user password for access control to program and memory upload
<b><i>SOFTRESET</i></b> (→ page <a href="#">201</a> )	leads to a complete reboot of the device
<b><i>TIMER_READ</i></b> (→ page <a href="#">203</a> )	Reads out the current system time in [ms] Max. value = 49d 17h 2min 47s 295ms
<b><i>TIMER_READ_US</i></b> (→ page <a href="#">204</a> )	Reads out the current system time in [µs] Max. value = 1h 11min 34s 967ms 295µs

## 5.1.2 Library ifm\_CR0020\_CANOpenMaster\_V04yynn.LIB

18714

This library contains the function blocks for operation of the device as a CANopen master. The library is only permissible for the 1st CAN interface.

x = 1 = number of the CAN interface

This **ifm** library contains the following function blocks:

Function element	Short description
<b>CANx_MASTER_EMCY_HANDLER</b> (→ page 97)	Handles the device-specific error status of the CANopen master on CAN interface x x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CANx_MASTER_SEND_EMERGENCY</b> (→ page 98)	Sends application-specific error status of the CANopen master on CAN interface x x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CANx_MASTER_STATUS</b> (→ page 100)	Status indication on CAN interface x of the device used as CANopen master x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

## 5.1.3 Library ifm\_CR0020\_CANOpenSlave\_V04yynn.LIB

18719

This library contains the function blocks for operation of the device as a CANopen slave. The library is only permissible for the 1st CAN interface.

x = 1 = number of the CAN interface

This **ifm** library contains the following function blocks:

Function element	Short description
<b>CANx_SLAVE_EMCY_HANDLER</b> (→ page 107)	Handles the device-specific error status of the CANopen slave on CAN interface x: • error register (index 0x1001) and • error field (index 0x1003) of the CANopen object directory x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CANx_SLAVE_NODEID</b> (→ page 108)	Enables setting of the node ID of a CANopen slave on CAN interface x at runtime of the application program x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CANx_SLAVE_SEND_EMERGENCY</b> (→ page 109)	Sends application-specific error status of the CANopen slave on CAN interface x x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>CANx_SLAVE_STATUS</b> (→ page 111)	Shows the status of the device used as CANopen slave on CAN interface x x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

## 5.1.4 Library ifm\_CAN1\_EXT\_Vxxyzz.LIB

18732

This library contains the complementary POU's for engine control on the 1st CAN interface. The library is only permissible for the 1st CAN interface.

This **ifm** library contains the following function blocks:

Function element	Short description
<b>CAN1_EXT</b> (→ page 83)	Initialises CAN interface 1 also for the extended mode Set the mode and baud rate
<b>CAN1_EXT_ERRORHANDLER</b> (→ page 84)	Executes a "manual" bus recovery on CAN interface 1
<b>CAN1_EXT_RECEIVE</b> (→ page 85)	CAN interface 1: Configures a data receive object and reads out the receive buffer of the data object
<b>CANx_EXT_RECEIVE_ALL</b> (→ page 90)	CAN interface x: Configures all data receive objects and reads out the receive buffer of the data objects x = 1 = number of the CAN interface
<b>CAN1_EXT_TRANSMIT</b> (→ page 87)	Transfers a CAN data object (message) to CAN interface 1 for transmission at each call

## 5.1.5 Library ifm\_J1939\_x\_Vxxyzz.LIB

18722

This library contains the function blocks for engine control.  
x = 1...2 = number of the CAN interface

This **ifm** library contains the following function blocks:

Function element	Short description
<b>J1939_x</b> (→ page 120)	CAN interface x: protocol handler for the communication profile SAE J1939 x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>J1939_x_GLOBAL_REQUEST</b> (→ page 121)	CAN interface x: handles global requesting and receipt of data from the J1939 network participants x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>J1939_x_RECEIVE</b> (→ page 123)	CAN interface x: Receives a single message or a message block x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>J1939_x_RESPONSE</b> (→ page 125)	CAN interface x: handles the automatic response to a request message x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>J1939_x_SPECIFIC_REQUEST</b> (→ page 127)	CAN interface x: automatic requesting of individual messages from a specific J1939 network participant x = 1...n = number of the CAN interface (depending on the device, → Data sheet)
<b>J1939_x_TRANSMIT</b> (→ page 129)	CAN interface x: sends individual messages or message blocks x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

### 5.1.6 Library ifm\_hydraulic\_16bitOS05\_Vxxyzz.LIB

19535

This library contains function blocks for hydraulic controls.

This **ifm** library contains the following function blocks:

Function element	Short description
<b>CONTROL_OCC</b> (→ page <a href="#">176</a> )	OCC = Output Current Control Scales the input value [WORD] to an indicated current range
<b>JOYSTICK_0</b> (→ page <a href="#">179</a> )	Scales signals [INT] from a joystick to clearly defined characteristic curves, standardised to 0... 1000
<b>JOYSTICK_1</b> (→ page <a href="#">182</a> )	Scales signals [INT] from a joystick D standardised to 0... 1000
<b>JOYSTICK_2</b> (→ page <a href="#">186</a> )	Scales signals [INT] from a joystick to a configurable characteristic curve; free selection of the standardisation
<b>NORM_HYDRAULIC</b> (→ page <a href="#">189</a> )	Normalises a value [DINT] within defined limits to a value with new limits



## 5.2 ifm function elements for the device CR0020

### Inhalt

Function elements: CAN layer 2.....	80
Function elements: CANopen master .....	96
Function elements: CANopen slave .....	106
Function elements: CANopen SDOs.....	114
Function elements: SAE J1939.....	119
Function elements: serial interface.....	131
Function elements: Optimising the PLC cycle.....	136
Function elements: processing input values .....	142
Function elements: adapting analogue values .....	147
Function elements: counter functions for frequency and period measurement .....	150
Function elements: PWM functions.....	161
Function elements: hydraulic control.....	175
Function elements: controllers .....	191
Function elements: software reset .....	200
Function elements: measuring / setting of time.....	202
Function elements: saving, reading and converting data in the memory .....	205
Function elements: data access and data check .....	214

13988  
3826

Here you will find the description of the **ifm** function elements suitable for this device, sorted by topic.

### 5.2.1 Function elements: CAN layer 2

#### Inhalt

CAN1_BAUDRATE .....	81
CAN1_DOWNLOADID .....	82
CAN1_EXT .....	83
CAN1_EXT_ERRORHANDLER.....	84
CAN1_EXT_RECEIVE .....	85
CAN1_EXT_TRANSMIT .....	87
CAN2 .....	88
CANx_ERRORHANDLER.....	89
CANx_EXT_RECEIVE_ALL.....	90
CANx_RECEIVE .....	91
CANx_RECEIVE_RANGE .....	93
CANx_TRANSMIT .....	95

13754

Here, the CAN function blocks (layer 2) for use in the application program are described.



## CAN1\_BAUDRATE

651

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

Symbol in CODESYS:



### Description

654

CAN1\_BAUDRATE sets the transmission rate for the bus participant.

- To do so, the corresponding value in kbits/s is entered at the input BAUDRATE.

### NOTICE

Please note for CR250n, CR0301, CR0302 and CS0015:

The EEPROM memory module may be destroyed by the permanent use of this unit!

- Only carry out the unit **once** during initialisation in the first program cycle!
- Afterwards block the unit again with ENABLE = FALSE!

**!** The new baud rate will become effective on RESET (voltage OFF/ON or soft reset).

**ExtendedController:** In the slave module, the new baud rate will become effective after voltage OFF/ON.

### Parameters of the inputs

655

Parameter	Data type	Description
ENABLE	BOOL	TRUE (in the 1st cycle): Adopt and activate parameters else: this function is not executed
BAUDRATE	WORD := 125	Baud rate [kbits/s] valid = 20, 50, 100, 125, 250, 500, 1000

## CAN1\_DOWNLOADID

645

= CAN1 download ID

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

648

CAN1\_DOWNLOADID sets the download identifier for the first CAN interface.

Using the FB the communication identifier for the program download and for debugging can be set. The new value is entered when the input ENABLE is set to TRUE. The new download ID will become effective after voltage OFF/ON or after a soft reset.

**!** The new value will become effective on RESET (voltage OFF/ON or soft reset).

## NOTICE

Please note for CR250n, CR0301, CR0302 and CS0015:

The EEPROM memory module may be destroyed by the permanent use of this unit!

- ▶ Only carry out the unit **once** during initialisation in the first program cycle!
- ▶ Afterwards block the unit again with ENABLE = FALSE!

### Parameters of the inputs

649

Parameter	Data type	Description
ENABLE	BOOL	TRUE (in the 1st cycle): Adopt and activate parameters else: this function is not executed
ID	BYTE	Set download ID of CAN interface x x = 1...n = number of the CAN interface (depending on the device, → Data sheet) allowed = 1...127 preset = 127 - (x-1)


## CAN1\_EXT

4192

Unit type = function block (FB)

Unit is contained in the library ifm\_CAN1\_EXT\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

4333

CAN1\_EXT initialises the first CAN interface for the extended identifier (29 bits).

The FB has to be retrieved if the first CAN interface e.g. with the function libraries for **SAE J1939** is to be used.

A change of the baud rate will become effective after voltage OFF/ON.

The baud rates of CAN 1 and CAN 2 can be set differently.

The input START is only set for one cycle during reboot or restart of the interface.

**!** The FB must be executed **before** CAN1\_EXT\_... .

### Parameters of the inputs

4334

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
START	BOOL	TRUE (in the 1st cycle): Start CAN protocol at CAN interface x FALSE: during further processing of the program
EXTENDED_MODE	BOOL := FALSE	TRUE: identifier of the CAN interface operates with 29 bits FALSE: identifier of the CAN interface operates with 11 bits
BAUDRATE	WORD := 125	Baud rate [Kbits/s] Permissible = 50, 100, 125, 250, 500, 800, 1000

## CAN1\_EXT\_ERRORHANDLER

4195

Unit type = function block (FB)

Unit is contained in the library ifm\_CAN1\_EXT\_Vxxxyzz.LIB

Symbol in CODESYS:



### Description

4335

CAN1\_EXT\_ERRORHANDLER monitors the first CAN interface and evaluates the CAN errors. If a certain number of transmission errors occurs, the CAN participant becomes error passive. If the error frequency decreases, the participant becomes error active again (= normal condition).

If a participant already is error passive and still transmission errors occur, it is disconnected from the bus (= bus off) and the error bit CANx\_BUSOFF is set. Returning to the bus is only possible if the "bus off" condition has been removed (signal BUSOFF\_RECOVER).

Afterwards, the error bit CANx\_BUSOFF must be reset in the application program.

**!** If the automatic bus recover function is to be used (default setting) CAN1\_EXT\_ERRORHANDLER must **not** be integrated and instanced in the program!

### Parameters of the inputs

2177

Parameter	Data type	Description
BUSOFF_RECOVER	BOOL	<p>TRUE (only 1 cycle):</p> <ul style="list-style-type: none"> <li>&gt; remedy 'bus off' status</li> <li>&gt; reboot of the CAN interfaced</li> </ul> <p>FALSE: function element is not executed</p>


## CAN1\_EXT\_RECEIVE

4302

Unit type = function block (FB)

Unit is contained in the library ifm\_CAN1\_EXT\_Vxxyzzz.LIB

### Symbol in CODESYS:



### Description

4336

CAN1\_EXT\_RECEIVE configures a data receive object and reads the receive buffer of the data object.

The FB must be called once for each data object during initialisation to inform the CAN controller about the identifiers of the data objects.

In the further program cycle CAN1\_EXT\_RECEIVE is called for reading the corresponding receive buffer, this is done several times in case of long program cycles. The programmer must ensure by evaluating the byte AVAILABLE that newly received data objects are retrieved from the buffer and further processed.

Each call of the FB decrements the byte AVAILABLE by 1. If the value of AVAILABLE is 0, there is no data in the buffer.

By evaluating the output OVERFLOW, an overflow of the data buffer can be detected. If OVERFLOW = TRUE at least 1 data object has been lost.

**!** If this unit is to be used, the 1st CAN interface must first be initialised for the extended ID with **CAN1\_EXT** (→ page 83).

### Parameters of the inputs

2172

Parameter	Data type	Description
CONFIG	BOOL	TRUE (in the 1st cycle): configure data object FALSE: during further processing of the program
CLEAR	BOOL	TRUE: delete receive buffer FALSE: function element is not executed
ID	DWORD	Number of the data object identifier: normal frame (2 <sup>11</sup> IDs): 0...2 047 = 0x0000 0000...0x0000 07FF extended Frame (2 <sup>29</sup> IDs): 0...536 870 911 = 0x0000 0000...0x1FFF FFFF

## Parameters of the outputs

19810

Parameter	Data type	Description
DATA	ARRAY [0..7] OF BYTE	received data, (1...8 bytes)
DLC	BYTE	Number of bytes received in the DATA array with RDO allowed: 0...8
RTR	BOOL = FALSE	Received message was a Remote Transmission Request (wird hier nicht unterstützt)
AVAILABLE	BYTE	Number of remaining data bytes allowed = 0...16 0 = no valid data available
OVERFLOW	BOOL	TRUE: Overflow of the data buffer ⇒ loss of data! FALSE: Data buffer is without data loss

## CAN1\_EXT\_TRANSMIT

4307

Unit type = function block (FB)

Unit is contained in the library ifm\_CAN1\_EXT\_Vxxyzz.LIB

**Symbol in CODESYS:**


### Description

4337

CAN1\_EXT\_TRANSMIT transfers a CAN data object (message) to the CAN controller for transmission.

The FB is called for each data object in the program cycle; this is done several times in case of long program cycles. The programmer must ensure by evaluating the output RESULT that his transmit order was accepted. To put it simply, at 125 kbits/s one transmit order can be executed per 1 ms.

The execution of the FB can be temporarily blocked via the input ENABLE = FALSE. This can, for example, prevent a bus overload.

Several data objects can be transmitted virtually at the same time if a flag is assigned to each data object and controls the execution of the FB via the ENABLE input.

**!** If this unit is to be used, the 1st CAN interface must first be initialised for the extended ID with **CAN1\_EXT** (→ page 83).

### Parameters of the inputs

4380

Parameter	Data type	Description
ID	DWORD	Number of the data object identifier: normal frame (2 <sup>11</sup> IDs): 0...2 047 = 0x0000 0000...0x0000 07FF extended Frame (2 <sup>29</sup> IDs): 0...536 870 911 = 0x0000 0000...0x1FFF FFFF
DLC	BYTE	Number of bytes to be transmitted from the DATA array with RDO allowed: 0...8
DATA	ARRAY [0..7] OF BYTE	data to be sent (1...8 bytes)
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified

### Parameters of the outputs

614

Parameter	Data type	Description
RESULT	BOOL	TRUE (only for 1 cycle): Function block accepted transmit order FALSE: Transmit order was not accepted


## CAN2

639

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

Symbol in CODESYS:



### Description

642

CAN2 initialises the 2nd CAN interface.

The FB must be called if the 2nd CAN interface is to be used.

A change of the baud rate will become effective after voltage OFF/ON.

The baud rates of CAN 1 and CAN 2 can be set differently.

The input START is only set for one cycle during reboot or restart of the interface.

For the 2nd CAN interface the libraries for *SAE J1939* and *Use of the CAN interface to ISO 11992*, among others, are available. The FBs to ISO 11992 are only available in the CR2501 on the 2nd CAN interface.

**!** The FB must be executed **before** CAN2... .

### Parameters of the inputs

643

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
START	BOOL	TRUE (in the 1st cycle): Start CAN protocol at CAN interface x FALSE: during further processing of the program
EXTENDED_MODE	BOOL := FALSE	TRUE: identifier of the CAN interface operates with 29 bits FALSE: identifier of the CAN interface operates with 11 bits
BAUDRATE	WORD := 125	Baud rate [Kbits/s] Permissible = 50, 100, 125, 250, 500, 800, 1000



## CANx\_ERRORHANDLER


633

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

636

Error routine for monitoring the CAN interfaces

CANx\_ERRORHANDLER monitors the CAN interfaces and evaluates the CAN errors. If a certain number of transmission errors occurs, the CAN participant becomes error passive. If the error frequency decreases, the participant becomes error active again (= normal condition).

If a participant already is error passive and still transmission errors occur, it is disconnected from the bus (= bus off) and the error bit CANx\_BUSOFF is set. Returning to the bus is only possible if the "bus off" condition has been removed (signal BUSOFF\_RECOVER).

The input CAN\_RESTART is used for rectifying other CAN errors. The CAN interface is reinitialised.

Afterwards, the error bit must be reset in the application program.

The procedures for the restart of the interfaces are different:

- For CAN interface 1 or devices with only one CAN interface:  
set the input CAN\_RESTART = TRUE (only 1 cycle)
- For CAN interface 2:  
set the input START = TRUE (only 1 cycle) in **CAN2** (→ page 88)

### NOTE

In principle, CAN2 must be executed to initialise the second CAN interface, before FBs can be used for it.

If the automatic bus recover function is to be used (default setting) CANx\_ERRORHANDLER must **not** be integrated and instanced in the program!

### Parameters of the inputs

637

Parameter	Data type	Description
BUSOFF_RECOVER	BOOL	TRUE (only 1 cycle): > remedy 'bus off' status > reboot of the CAN interface FALSE: function element is not executed
CAN_RESTART	BOOL	TRUE (only 1 cycle): completely reinitialise CAN interface FALSE: function element is not executed

## CANx\_EXT\_RECEIVE\_ALL

4183

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CANx\_EXT\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

4326

CANx\_EXT\_RECEIVE\_ALL configures all data receive objects and reads the receive buffer of the data objects.

The FB must be called once during initialisation to inform the CAN controller about the identifiers of the data objects.

In the further program cycle CANx\_EXT\_RECEIVE\_ALL is called for reading the corresponding receive buffer, also repeatedly in case of long program cycles. The programmer must ensure by evaluating the byte AVAILABLE that newly received data objects are retrieved from the buffer and further processed.

Each call of the FB decrements the byte AVAILABLE by 1. If the value of AVAILABLE is 0, there is no data in the buffer.

By evaluating the output OVERFLOW, an overflow of the data buffer can be detected. If OVERFLOW = TRUE at least 1 data object has been lost.

Receive buffer: max. 16 software buffers per identifier.

### Parameters of the inputs

4329

Parameter	Data type	Description
CONFIG	BOOL	TRUE (in the 1st cycle): configure data object FALSE: during further processing of the program
CLEAR	BOOL	TRUE: delete receive buffer FALSE: function element is not executed

### Parameters of the outputs

2292

Parameter	Data type	Description
ID	DWORD	Number of the data object identifier
DATA	ARRAY [0..7] OF BYTE	received data, (1...8 bytes)
DLC	BYTE	Number of bytes received in the DATA array with SRDO allowed: 0...8
AVAILABLE	BYTE	Number of remaining data bytes allowed = 0...16 0 = no valid data available
OVERFLOW	BOOL	TRUE: Overflow of the data buffer ⇒ loss of data! FALSE: Data buffer is without data loss

## CANx\_RECEIVE


627

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

### Symbol in CODESYS:



### Description

630

CANx\_RECEIVE configures a data receive object and reads the receive buffer of the data object.

The FB must be called once for each data object during initialisation, in order to inform the CAN controller about the identifiers of the data objects.

In the further program cycle CANx\_RECEIVE is called for reading the corresponding receive buffer, also repeatedly in case of long program cycles. The programmer must ensure by evaluating the byte AVAILABLE that newly received data objects are retrieved from the buffer and further processed.

Each call of the FB decrements the byte AVAILABLE by 1. If the value of AVAILABLE is 0, there is no data in the buffer.

By evaluating the output OVERFLOW, an overflow of the data buffer can be detected. If OVERFLOW = TRUE at least 1 data object has been lost.

**!** If CAN2\_RECEIVE is to be used, the second CAN interface must be initialised first using **CAN2** (→ page [88](#)).

### Parameters of the inputs

631

Parameter	Data type	Description
CONFIG	BOOL	TRUE (in the 1st cycle): configure data object FALSE: during further processing of the program
CLEAR	BOOL	TRUE: delete receive buffer FALSE: function element is not executed
ID	WORD	number of the data object identifier permissible values = 0...2 047

## Parameters of the outputs

19810

Parameter	Data type	Description
DATA	ARRAY [0..7] OF BYTE	received data, (1...8 bytes)
DLC	BYTE	Number of bytes received in the DATA array with RDO allowed: 0...8
RTR	BOOL = FALSE	Received message was a Remote Transmission Request (wird hier nicht unterstützt)
AVAILABLE	BYTE	Number of remaining data bytes allowed = 0...16 0 = no valid data available
OVERFLOW	BOOL	TRUE: Overflow of the data buffer ⇒ loss of data! FALSE: Data buffer is without data loss

## CANx\_RECEIVE\_RANGE

4179

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyyzz.LIB (xx ≥ 05)

### Symbol in CODESYS:



### Description

2295

CANx\_RECEIVE\_RANGE configures a sequence of data receive objects and reads the receive buffer of the data objects.

For the first CAN interface max. 2048 IDs per bit are possible.

For the second CAN interface max. 256 IDs per 11 OR 29 bits are possible.

The second CAN interface requires a long initialisation time. To ensure that the watchdog does not react, the process should be distributed to several cycles in the case of bigger ranges. → **Example: Initialisation of CANx\_RECEIVE\_RANGE in 4 cycles** (→ page 94).

The FB must be called once for each sequence of data objects during initialisation to inform the CAN controller about the identifiers of the data objects.

The FB must NOT be mixed with **CANx\_RECEIVE** (→ page 91) or CANx\_RECEIVE\_RANGE for the same IDs at the same CAN interfaces.

In the further program cycle CANx\_RECEIVE\_RANGE is called for reading the corresponding receive buffer, also repeatedly in case of long program cycles. The programmer has to ensure by evaluating the byte AVAILABLE that newly received data objects are retrieved from buffer SOFORT and are further processed as the data are only available for one cycle.

Each call of the FB decrements the byte AVAILABLE by 1. If the value of AVAILABLE is 0, there is no data in the buffer.

By evaluating the output OVERFLOW, an overflow of the data buffer can be detected. If OVERFLOW = TRUE, at least 1 data object has been lost.

Receive buffer: max. 16 software buffers per identifier.

### Parameters of the inputs

2290

Parameter	Data type	Description
CONFIG	BOOL	TRUE (in the 1st cycle): configure data object FALSE: during further processing of the program
CLEAR	BOOL	TRUE: delete receive buffer FALSE: function element is not executed
FIRST_ID	CAN1: WORD CAN2: DWORD	number of the first data object identifier of the sequence permissible values normal frame = 0...2 047 (2 <sup>11</sup> ) permissible values extended frame = 0...536 870 911 (2 <sup>29</sup> )
LAST_ID	CAN1: WORD CAN2: DWORD	number of the last data object identifier of the sequence permissible values normal frame = 0...2 047 (2 <sup>11</sup> ) permissible values extended frame = 0...536 870 911 (2 <sup>29</sup> ) LAST_ID has to be bigger than FIRST_ID!

## Parameters of the outputs

4381

Parameter	Data type	Description
ID	CAN1: WORD CAN2: DWORD	ID of the transmitted data object
DATA	ARRAY [0..7] OF BYTE	received data, (1...8 bytes)
DLC	BYTE	Number of bytes received in the DATA array with RDO allowed: 0...8
AVAILABLE	BYTE	Number of remaining data bytes allowed = 0...16 0 = no valid data available
OVERFLOW	BOOL	TRUE: Overflow of the data buffer ⇒ loss of data! FALSE: Data buffer is without data loss

## Example: Initialisation of CANx\_RECEIVE\_RANGE in 4 cycles

2294

```

PLC_PRG (PRG-ST) (-1/181/-1/88)
0001 PROGRAM PLC_PRG
0002 VAR
0003   init : BOOL := FALSE;
0004   initstep : WORD := 1;
0005   can20 : CAN2;
0006   cr2 : CAN2_RECEIVE_RANGE;
0007   cnt : WORD;
0008 END_VAR
0009
0010 (* CAN2 init *)
0011 can20(ENABLE:= TRUE, START:= init, EXTENDED_MODE:= FALSE, BAUDRATE:= 125);
0012
0013 (* CAN2_RECEIVE_RANGE in mehreren Steps initialisieren *)
0014 CASE initstep OF
0015   1:
0016     cr2(CONFIG:= TRUE, CLEAR:= FALSE, FIRST_ID:= 16#100, LAST_ID:= 16#10F, ID:= , DATA:= , DLC:= , AVAILABLE:= , OVERFLOW:= );
0017     initstep := initstep + 1;
0018   2:
0019     cr2(CONFIG:= TRUE, CLEAR:= FALSE, FIRST_ID:= 16#110, LAST_ID:= 16#11F, ID:= , DATA:= , DLC:= , AVAILABLE:= , OVERFLOW:= );
0020     initstep := initstep + 1;
0021   3:
0022     cr2(CONFIG:= TRUE, CLEAR:= FALSE, FIRST_ID:= 16#120, LAST_ID:= 16#12F, ID:= , DATA:= , DLC:= , AVAILABLE:= , OVERFLOW:= );
0023     initstep := initstep + 1;
0024   4:
0025     cr2(CONFIG:= TRUE, CLEAR:= FALSE, FIRST_ID:= 16#130, LAST_ID:= 16#13F, ID:= , DATA:= , DLC:= , AVAILABLE:= , OVERFLOW:= );
0026     initstep := initstep + 1;
0027   ELSE
0028     cr2(CONFIG:= FALSE, CLEAR:= FALSE, FIRST_ID:= 16#100, LAST_ID:= 16#100, ID:= , DATA:= , DLC:= , AVAILABLE:= , OVERFLOW:= );
0029   END_CASE
0030
0031 init := FALSE;
0032
0033 (* Test *)
0034 IF cr2.available > 0 THEN
0035   cnt := cnt + 1;
0036 END_IF

```

## CANx\_TRANSMIT


609

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

612

CANx\_TRANSMIT transmits a CAN data object (message) to the CAN controller for transmission.

The FB is called for each data object in the program cycle, also repeatedly in case of long program cycles. The programmer must ensure by evaluating the FB output RESULT that his transmit order was accepted. Simplified it can be said that at 125 kbits/s one transmit order can be executed per ms.

The execution of the FB can be temporarily blocked (ENABLE = FALSE) via the input ENABLE. So, for example a bus overload can be prevented.

Several data objects can be transmitted virtually at the same time if a flag is assigned to each data object and controls the execution of the FB via the ENABLE input.

**!** If CAN2\_TRANSMIT is to be used, the second CAN interface must be initialised first using **CAN2** (→ page [88](#)).

### Parameters of the inputs

613

Parameter	Data type	Description
ID	WORD	number of the data object identifier permissible values = 0...2 047
DLC	BYTE	Number of bytes to be transmitted from the DATA array with RDO allowed: 0...8
DATA	ARRAY [0..7] OF BYTE	data to be sent (1...8 bytes)
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified

### Parameters of the outputs

614

Parameter	Data type	Description
RESULT	BOOL	TRUE (only for 1 cycle): Function block accepted transmit order FALSE: Transmit order was not accepted

## 5.2.2 Function elements: CANopen master

### Inhalt

CANx_MASTER_EMCY_HANDLER .....	97
CANx_MASTER_SEND_EMERGENCY .....	98
CANx_MASTER_STATUS .....	100

1870

**ifm electronic** provides a number of FBs for the CANopen master which will be explained below.



## CANx\_MASTER\_EMCY\_HANDLER

13192

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_CANopenMaster\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

2009

CANx\_MASTER\_EMCY\_HANDLER manages the device-specific error status of the master. The FB must be called in the following cases:

- the error status is to be transmitted to the network and
- the error messages of the application are to be stored in the object directory.

The current values from the error register (index 0x1001/01) and error field (index 0x1003/0-5) of the CANopen object directory can be read via the FB.

**!** If application-specific error messages are to be stored in the object directory, CANx\_MASTER\_EMCY\_HANDLER must be called **after** (repeatedly) calling **CANx\_MASTER\_SEND\_EMERGENCY** (→ page 98).

### Parameters of the inputs

2010

Parameter	Data type	Description
CLEAR_ERROR_FIELD	BOOL	FALSE ⇒ TRUE (edge): • transmit content of ERROR_FIELD to function block output • delete content of ERROR_FIELD in object directory else: this function is not executed

### Parameters of the outputs

2011

Parameter	Data type	Description
ERROR_REGISTER	BYTE	Shows content of OBV index 0x1001 (error register)
ERROR_FIELD	ARRAY [0..5] OF WORD	Shows the content of the OBV index 0x1003 (error field) ERROR_FIELD[0]: number of stored errors ERROR_FIELD[1...5]: Stored errors, the most recent error is shown on index [1]

## CANx\_MASTER\_SEND\_EMERGENCY


13195

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_CANopenMaster\_Vxxyzzz.LIB

### Symbol in CODESYS:



### Description

2015

CANx\_MASTER\_SEND\_EMERGENCY transmits application-specific error states. The FB is called if the error status is to be transmitted to other devices in the network.

**!** If application-specific error messages are to be stored in the object directory, **CANx\_MASTER\_EMCY\_HANDLER** (→ page 97) must be called **after** (repeatedly) calling CANx\_MASTER\_SEND\_EMERGENCY.


### Parameters of the inputs

2016

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
ERROR	BOOL	Using this input, the information whether the error associated to the configured error code is currently present is transmitted. FALSE ⇒ TRUE (edge): sends the next error code if input was not TRUE in the last second TRUE ⇒ FALSE (edge) AND the fault is no longer indicated: after a delay of approx. 1 s: > zero error message is sent else: this function is not executed
ERROR_CODE	WORD	The error code provides detailed information about the detected error. The values should be entered according to the CANopen specification.
ERROR_REGISTER	BYTE	ERROR_REGISTER indicates the error type. The value indicated here is linked by a bit-by-bit OR operation with all the other error messages that are currently active. The resulting value is written into the error register (index 1001 <sub>h</sub> /00) and transmitted with the EMCY message. The values should be entered according to the CANopen specification.
MANUFACTURER_ERROR_FIELD	ARRAY [0..4] OF BYTE	Here, up to 5 bytes of application-specific error information can be entered. The format can be freely selected.

## Example: CANx\_MASTER\_SEND\_EMERGENCY

2018



In this example 3 error messages will be generated subsequently:

1. ApplError1, Code = 0xFF00 in the error register 0x81
2. ApplError2, Code = 0xFF01 in the error register 0x81
3. ApplError3, Code = 0xFF02 in the error register 0x81

CAN1\_MASTER\_EMCY\_HANDLER sends the error messages to the error register "Object 0x1001" in the error array "Object 0x1003".

## CANx\_MASTER\_STATUS


2021

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_CANopenMaster\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

2024

Status indication of the device used with CANopen.


CANx\_MASTER\_STATUS shows the status of the device used as CANopen master. Further possibilities:

- monitoring the network status
- monitoring the status of the connected slaves
- resetting or starting the slaves in the network.

The FB simplifies the use of the CODESYS CANopen master libraries. We urgently recommend to carry out the evaluation of the network status and of the error messages via this FB.


## Parameters of the inputs

2025

Parameter	Data type	Description
CANOPEN_LED_STATUS	BOOL	(input not available for PDM devices) TRUE: the status LED of the controller is switched to the mode "CANopen": flashing frequency 0.5 Hz = PRE-OPERATIONAL flashing frequency 2.0 Hz = OPERATIONAL The other diagnostic LED signals are not changed by this operating mode.
GLOBAL_START	BOOL	TRUE: All connected network participants (slaves) are started simultaneously during network initialisation (⇒ state OPERATIONAL). FALSE: The connected network participants are started one after the other.
CLEAR_RX_OVERFLOW_FLAG	BOOL	FALSE ⇒ TRUE (edge): Clear error flag RX_OVERFLOW else: this function is not executed
CLEAR_RX_BUFFER	BOOL	FALSE ⇒ TRUE (edge): Delete data in the receive buffer else: this function is not executed
CLEAR_TX_OVERFLOW_FLAG	BOOL	FALSE ⇒ TRUE (edge): Clear error flag TX_OVERFLOW else: this function is not executed
CLEAR_TX_BUFFER	BOOL	FALSE ⇒ TRUE (edge): Delete data in the transmit buffer else: this function is not executed
CLEAR_OD_CHANGED_FLAG	BOOL	FALSE ⇒ TRUE (edge): Delete flag OD_CHANGED else: this function is not executed
CLEAR_ERROR_CONTROL	BOOL	FALSE ⇒ TRUE (edge): Delete the guard error list (ERROR_CONTROL) else: this function is not executed
RESET_ALL_NODES	BOOL	FALSE ⇒ TRUE (edge): All connected network participants (slaves) are reset via NMT command else: this function is not executed
START_ALL_NODES	BOOL	FALSE ⇒ TRUE (edge): All connected network participants (slaves) are started via NMT command else: this function is not executed
NODE_STATE_SLAVES	DWORD	Shows states of all network nodes. Example code → chapter <i>Example: CANx_MASTER_STATUS</i> (→ page 104)
EMERGENCY_OBJECT_SLAVES	DWORD	Shows the last error messages of all network nodes.  → chapter <i>Access to the structures at runtime of the application</i> (→ page 105)

## Parameters of the outputs

2029

Parameter	Data type	Description
NODE_ID	BYTE	current node ID of the CANopen master
BAUDRATE	WORD	current baudrate of the CANopen master in [kBaud]
NODE_STATE	INT	Current status of CANopen master
SYNC	BOOL	SYNC signal of the CANopen master TRUE: In the last cycle a SYNC signal was sent FALSE: In the last cycle no SYNC signal was sent
RX_OVERFLOW	BOOL	TRUE: Error: receive buffer overflow FALSE: no overflow
TX_OVERFLOW	BOOL	TRUE: Error: transmission buffer overflow FALSE: no overflow
OD_CHANGED	BOOL	TRUE: Data in the object directory of the CANopen master have been changed FALSE: no data change
ERROR_CONTROL	ARRAY [0..7] OF BYTE	The array contains the list (max. 8) of missing network nodes (guard or heartbeat error)  → chapter <i>Access to the structures at runtime of the application</i> (→ page 105)
GET_EMERGENCY	STRUCT CANx_EMERGENCY_MESSAGE	At the output the data for the structure CANx_EMERGENCY_MESSAGE are available. The last received EMCY message in the CANopen network is always displayed. To obtain a list of all occurred errors, the array "EMERGENCY_OBJECT_SLAVES" must be evaluated.
NODE_ID	BYTE	node ID of the master
BAUDRATE	WORD	baud rate of the master
NODE_STATE	INT	current status of the master
SYNC	BOOL	SYNC signal of the master This is set in the <i>tab [CAN parameters]</i> of the master depending on the set time [Com. Cycle Period].
RX_OVERFLOW	BOOL	error flag "receive buffer overflow"

## Parameters of internal structures

2030

Below are the structures of the arrays used in this FB.

Parameter	Data type	Description
CANx_EMERGENCY_MESSAGE	STRUCT	<p>NODE_ID: BYTE  ERROR_CODE: WORD  ERROR_REGISTER: BYTE  MANUFACTURER_ERROR_FIELD: ARRAY[0...4] OF BYTE</p> <p>The structure is defined by the global variables of the library ifm_CR0020_CANopenMaster_Vxxyzz.LIB.</p>
CANx_NODE_STATE	STRUCT	<p>NODE_ID: BYTE  NODE_STATE: BYTE  LAST_STATE: BYTE  RESET_NODE: BOOL  START_NODE: BOOL  PREOP_NODE: BOOL  SET_TIMEOUT_STATE: BOOL  SET_NODE_STATE: BOOL</p> <p>The structure is defined by the global variables of the library ifm_CR0020_CANopenMaster_Vxxyzz.LIB.</p>

Using the controller CR0020 as an example the following code fragments show the use of the FB CANx\_MASTER\_STATUS.

## Example: CANx\_MASTER\_STATUS

2031

### Slave information

2033

To be able to access the information of the individual CANopen nodes, an array for the corresponding structure must be generated. The structures are contained in the library. You can see them under "Data types" in the library manager.

The number of the array elements is determined by the global variable MAX\_NODEINDEX which is automatically generated by the CANopen stack. It contains the number of the slaves minus 1 indicated in the network configurator.

**!** The numbers of the array elements do **not** correspond to the node ID. The identifier can be read from the corresponding structure under NODE\_ID.

```

0001 PROGRAM MasterStatus
0002 VAR
0003   Status: CR0020_MASTER_STATUS;
0004   LedStatus: BOOL := TRUE;
0005   GlobalStartNodes: BOOL := TRUE;
0006   ClearRxOverflowFlag: BOOL;
0007   ClearRxBuffer: BOOL;
0008   ClearTxOverflowFlag: BOOL;
0009   ClearTxBuffer: BOOL;
0010   ClearOdChanged: BOOL;
0011   ClearErrorControl: BOOL;
0012   ResetAllNodes: BOOL;
0013   StartAllNodes: BOOL;
0014   NodeId: BYTE;
0015   Baudrate: WORD;
0016   NodeState: INT;
0017   Sync: BOOL;
0018   RxOverflow: BOOL;
0019   TxOverflow: BOOL;
0020   OdChanged: BOOL;
0021   GuardHeartbeatErrorArray: ARRAY[0..7] OF BYTE;
0022   GetEmergency: EMERGENCY_MESSAGE;
0023 END_VAR

```

### Structure node status

2034

```

TYPE CAN1_NODE_STATE :
STRUCT
  NODE_ID: BYTE;
  NODE_STATE: BYTE;
  LAST_STATE: BYTE;
  RESET_NODE: BOOL;
  START_NODE: BOOL;
  PREOP_NODE: BOOL;
  SET_TIMEOUT_STATE: BOOL;
  SET_NODE_STATE: BOOL;
END_STRUCT
END_TYPE

```

### Structure Emergency\_Message

2035

```

TYPE CAN1_EMERGENCY_MESSAGE :
STRUCT
  NODE_ID: BYTE;
  ERROR_CODE: WORD;
  ERROR_REGISTER: BYTE;
  MANUFACTURER_ERROR_FIELD: ARRAY[0..4] OF BYTE;
END_STRUCT
END_TYPE

```



## Access to the structures at runtime of the application

2036

At runtime you can access the corresponding array element via the global variables of the library and therefore read the status or EMCY messages or reset the node.

0001	NodeStateList
0002	NodeStateList[0]
0003	Node_ID = 16#02
0004	Node_State = 16#04
0005	Last_State = 16#00
0006	Reset_Node = FALSE <= TRUE>
0007	Start_Node = FALSE
0008	Preop_Node = FALSE
0009	Set_Timeout_State = FALSE
0010	Set_Node_State = FALSE
0011	NodeStateList[1]
0012	Node_ID = 16#03
0013	Node_State = 16#03
0014	Last_State = 16#00
0015	Reset_Node = FALSE
0016	Start_Node = FALSE
0017	Preop_Node = FALSE
0018	Set_Timeout_State = FALSE
0019	Set_Node_State = FALSE
0020	NodeEmergencyList
0021	NodeEmergencyList[0]
0022	Node_ID = 16#02
0023	Error_Code = 16#0000
0024	Error_Register = 16#00
0025	Manufacturer_Error_Field
0026	Manufacturer_Error_Field[0] = 16#00
0027	Manufacturer_Error_Field[1] = 16#00
0028	Manufacturer_Error_Field[2] = 16#00
0029	Manufacturer_Error_Field[3] = 16#00
0030	Manufacturer_Error_Field[4] = 16#00
0031	NodeEmergencyList[1]
0032	Node_ID = 16#03
0033	Error_Code = 16#0000
0034	Error_Register = 16#00
0035	Manufacturer_Error_Field
0036	Manufacturer_Error_Field[0] = 16#00
0037	Manufacturer_Error_Field[1] = 16#00
0038	Manufacturer_Error_Field[2] = 16#00
0039	Manufacturer_Error_Field[3] = 16#00
0040	Manufacturer_Error_Field[4] = 16#00

If ResetSingleNodeArray[0].RESET\_NODE is set to TRUE for a short time in the example given above, the first node is reset in the configuration tree.

ⓘ concerning the possible error codes → system manual "Know-How *ecomatmobile*"  
→ chapter *CAN / CANopen: errors and error handling*.

### 5.2.3 Function elements: CANopen slave

#### Inhalt

CANx_SLAVE_EMCY_HANDLER .....	107
CANx_SLAVE_NODEID .....	108
CANx_SLAVE_SEND_EMERGENCY .....	109
CANx_SLAVE_STATUS .....	111

1874

**ifm electronic** provides a number of FBs for the CANopen slave which will be explained below.

## CANx\_SLAVE\_EMCY\_HANDLER

13199

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_CANopenSlave\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

2053

CANx\_SLAVE\_EMCY\_HANDLER handles the device-specific error status of the CANopen slave:

- error register (index 0x1001) and
  - error field (index 0x1003) of the CANopen object directory.
- Call the function block in the following cases:
- the error status is to be transmitted to the CAN network and
  - the error messages of the application program are to be stored in the object directory.

**!** Do you want to store the error messages in the object directory?

- **After** (repeated) handling of **CANx\_SLAVE\_SEND\_EMERGENCY** (→ page 109) call CANx\_SLAVE\_EMCY\_HANDLER once!

### Parameters of the inputs

2054

Parameter	Data type	Description
CLEAR_ERROR_FIELD	BOOL	FALSE ⇒ TRUE (edge): • transmit content of ERROR_FIELD to function block output • delete content of ERROR_FIELD in object directory else: this function is not executed

### Parameters of the outputs

2055

Parameter	Data type	Description
ERROR_REGISTER	BYTE	Shows content of OBV index 0x1001 (error register)
ERROR_FIELD	ARRAY [0..5] OF WORD	Shows the content of the OBV index 0x1003 (error field) ERROR_FIELD[0]: number of stored errors ERROR_FIELD[1...5]: Stored errors, the most recent error is shown on index [1]

## CANx\_SLAVE\_NODEID

13202

= CANx Slave Node-ID

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library `ifm_CR0020_CANopenSlave_Vxxyzz.LIB`

### Symbol in CODESYS:



### Description

2049

CANx\_SLAVE\_NODEID enables the setting of the node ID of a CANopen slave at runtime of the application program.

Normally, the FB is called once during initialisation of the controller, in the first cycle. Afterwards, the input ENABLE is set to FALSE again.

### Parameters of the inputs

2047

Parameter	Data type	Description
ENABLE	BOOL	FALSE ⇒ TRUE (edge): Adopt and activate parameters else: this function is not executed
NODEID	BYTE	node ID = ID of the node permissible values = 0...127

## CANx\_SLAVE\_SEND\_EMERGENCY


13205

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_CANopenSlave\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

2059

CANx\_SLAVE\_SEND\_EMERGENCY transmits application-specific error states. These are error messages which are to be sent in addition to the device-internal error messages (e.g. short circuit on the output).

- Call the FB if the error status is to be transmitted to other devices in the network.


### Parameters of the inputs

2060

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
ERROR	BOOL	Using this input, the information whether the error associated to the configured error code is currently present is transmitted. FALSE ⇒ TRUE (edge): sends the next error code if input was not TRUE in the last second TRUE ⇒ FALSE (edge) AND the fault is no longer indicated: after a delay of approx. 1 s: > zero error message is sent else: this function is not executed
ERROR_CODE	WORD	The error code provides detailed information about the detected error. The values should be entered according to the CANopen specification.
ERROR_REGISTER	BYTE	ERROR_REGISTER indicates the error type. The value indicated here is linked by a bit-by-bit OR operation with all the other error messages that are currently active. The resulting value is written into the error register (index 1001 <sub>h</sub> /00) and transmitted with the EMCY message. The values should be entered according to the CANopen specification.
MANUFACTURER_ERROR_FIELD	ARRAY [0..4] OF BYTE	Here, up to 5 bytes of application-specific error information can be entered. The format can be freely selected.

## Example: CANx\_SLAVE\_SEND\_EMERGENCY

2062



In this example 3 error messages will be generated subsequently:

1. ApplError1, Code = 0xFF00 in the error register 0x81
2. ApplError2, Code = 0xFF01 in the error register 0x81
3. ApplError3, Code = 0xFF02 in the error register 0x81

CAN1\_SLAVE\_EMCY\_HANDLER sends the error messages to the error register "Object 0x1001" in the error array "Object 0x1003".

## CANx\_SLAVE\_STATUS


2063

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_CANopenSlave\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

2066

CANx\_SLAVE\_STATUS shows the status of the device used as CANopen slave. The FB simplifies the use of the CoDeSys CANopen slave libraries. We urgently recommend to carry out the evaluation of the network status via this FB.

At runtime you can then access the individual outputs of the block to obtain a status overview.

### Example:

```

0001 PROGRAM SlaveStatus
0002 VAR
0003   SlaveStatus: CR0505_SLAVE_STATUS;
0004   LedStatus: BOOL := TRUE;
0005   ClearRxOverflowFlag: BOOL;
0006   ClearRxBuffer: BOOL;
0007   ClearTxOverflowFlag: BOOL;
0008   ClearTxBuffer: BOOL;
0009   ClearResetFlags: BOOL;
0010   ClearOdChanged: BOOL;
0011   NodeId: BYTE;
0012   Baudrate: WORD;
0013   NodeState: BYTE;
0014   Sync: BOOL;
0015   SyncError: BOOL;
0016   GuardHeartbeatError: BOOL;
0017   RxOverflow: BOOL;
0018   TxOverflow: BOOL;
0019   ResetNode: BOOL;
0020   ResetCom: BOOL;
0021   OdChanged: BOOL;
0022   OdChangedIndex: INT;
0023 END_VAR
    
```

## Parameters of the inputs

2067

Parameter	Data type	Description
CANOPEN_LED_STATUS	BOOL	(input not available for PDM devices) TRUE: the status LED of the controller is switched to the mode "CANopen": flashing frequency 0.5 Hz = PRE-OPERATIONAL flashing frequency 2.0 Hz = OPERATIONAL The other diagnostic LED signals are not changed by this operating mode.
GLOBAL_START	BOOL	TRUE: All connected network participants (slaves) are started simultaneously during network initialisation (⇒ state OPERATIONAL). FALSE: The connected network participants are started one after the other.
CLEAR_RX_OVERFLOW_FLAG	BOOL	FALSE ⇒ TRUE (edge): Clear error flag RX_OVERFLOW else: this function is not executed
CLEAR_RX_BUFFER	BOOL	FALSE ⇒ TRUE (edge): Delete data in the receive buffer else: this function is not executed
CLEAR_TX_OVERFLOW_FLAG	BOOL	FALSE ⇒ TRUE (edge): Clear error flag TX_OVERFLOW else: this function is not executed
CLEAR_TX_BUFFER	BOOL	FALSE ⇒ TRUE (edge): Delete data in the transmit buffer else: this function is not executed
CLEAR_RESET_FLAGS	BOOL	FALSE ⇒ TRUE (edge): Clear flag RESET_NODE Clear flag RESET_COM else: this function is not executed
CLEAR_OD_CHANGED_FLAGS	BOOL	FALSE ⇒ TRUE (edge): Clear flag OD_CHANGED Clear flag OD_CHANGED_INDEX else: this function is not executed



## Parameters of the outputs

2068

Parameter	Data type	Description
NODE_ID	BYTE	current node ID of the CANopen slave
BAUDRATE	WORD	current baudrate of the CANopen node in [kBaud]
NODE_STATE	BYTE	Current status of CANopen slave 0 = Bootup message sent 4 = CANopen slave in PRE-OPERATIONAL state and is configured via SDO access 5 = CANopen slave in OPERATIONAL state 127 = CANopen slave in PRE-OPERATIONAL state
SYNC	BOOL	SYNC signal of the CANopen master TRUE: In the last cycle a SYNC signal was received FALSE: In the last cycle no SYNC signal was received
SYNC_ERROR	BOOL	TRUE: Error: the SYNC signal of the master was not received or received too late (after expiration of ComCyclePeriod) FALSE: no SYNC error
GUARD_HEARTBEAT_ERROR	BOOL	TRUE: Error: the guarding or heartbeat signal of the master was not received or received too late FALSE: no guarding or heartbeat error
RX_OVERFLOW	BOOL	TRUE: Error: receive buffer overflow FALSE: no overflow
TX_OVERFLOW	BOOL	TRUE: Error: transmission buffer overflow FALSE: no overflow
RESET_NODE	BOOL	TRUE: the CANopen stack of the slave was reset by the master FALSE: the CANopen stack of the slave was not reset
RESET_COM	BOOL	TRUE: the communication interface of the CAN stack was reset by the master FALSE: the communication interface was not reset
OD_CHANGED	BOOL	TRUE: Data in the object directory of the CANopen master have been changed FALSE: no data change
OD_CHANGED_INDEX	INT	Index of the object directory entry changed last

## 5.2.4 Function elements: CANopen SDOs

### Inhalt

CANx_SDO_READ .....	115
CANx_SDO_WRITE.....	117

2071

Here you will find **ifm** function elements for CANopen handling of Service Data Objects (SDOs).

## CANx\_SDO\_READ


621

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

### Symbol in CODESYS:



### Description


624

CANx\_SDO\_READ reads the → *SDO* (→ page 252) with the indicated indexes from the node.

Prerequisite: Node must be in the mode "PRE-OPERATIONAL" or "OPERATIONAL".

By means of these, the entries in the object directory can be read. So it is possible to selectively read the node parameters.

### Example:



### Parameters of the inputs

625

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
NODE	BYTE	ID of the node permissible values = 1...127 = 0x01...0x7F
IDX	WORD	index in object directory
SUBIDX	BYTE	sub-index referred to the index in the object directory
DATA	DWORD	Addresse of the receive data array valid length = 0...255 <b>!</b> Determine the address by means of the operator ADR and assigne it to the FB!

## Parameters of the outputs

626

Parameter	Data type	Description
RESULT	BYTE	feedback of the function block (possible messages → following table)
LEN	WORD	Length of the entry in "number of bytes" The value for LEN must not be greater than the size of the receive array. Otherwise any data is overwritten in the application.

### Possible results for RESULT:

Value dec   hex		Description
0	00	FB is inactive
1	01	FB execution completed without error – data is valid
2	02	function block is active (action not yet completed)
3	03	Error, no data received during monitoring time

## CANx\_SDO\_WRITE


615

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

618


CANx\_SDO\_WRITE writes the → *SDO* (→ page 252) with the specified indexes to the node.

Prerequisite: the node must be in the state "PRE-OPERATIONAL" or "OPERATIONAL".

Using this FB, the entries can be written to the object directory. So it is possible to selectively set the node parameters.

**!** The value for LEN must be lower than the length of the transmit array. Otherwise, random data will be sent.

### Example:



## Parameters of the inputs

619

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
NODE	BYTE	ID of the node permissible values = 1...127 = 0x01...0x7F
IDX	WORD	index in object directory
SUBIDX	BYTE	sub-index referred to the index in the object directory
LEN	WORD	Length of the entry in "number of bytes" The value for LEN must not be greater than the size of the transmit array. Otherwise any data is sent.
DATA	DWORD	Address of the transmit data array permissible length = 0...255 <b>!</b> Determine the address by means of the operator ADR and assigne it to the FB!

## Parameters of the outputs

620

Parameter	Data type	Description
RESULT	BYTE	feedback of the function block (possible messages → following table)

### Possible results for RESULT:

Value dec   hex	Description
0   00	FB is inactive
1   01	FB execution completed without error – data is valid
2   02	function block is active (action not yet completed)
3   03	Error, data cannot be transmitted

## 5.2.5 Function elements: SAE J1939

Inhalt	
J1939_x .....	120
J1939_x_GLOBAL_REQUEST .....	121
J1939_x_RECEIVE .....	123
J1939_x_RESPONSE .....	125
J1939_x_SPECIFIC_REQUEST .....	127
J1939_x_TRANSMIT .....	129

2273

For SAE J1939, **ifm electronic** provides a number of function elements which will be explained in the following.

## J1939\_x


9375

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_J1939\_x\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

4325

J1939\_x serves as protocol handler for the communication profile SAE J1939.

4313

### NOTE

(for RTS to v05 only)

J1939 communication via the 1st CAN interface:

- First initialise the interface via **CAN1\_EXT** (→ page [83](#))!

J1939 communication via the 2nd CAN interface:

- First initialise the interface via **CAN2** (→ page [88](#))!

To handle the communication, the protocol handler must be called in each program cycle. To do so, the input ENABLE is set to TRUE.

The protocol handler is started if the input START is set to TRUE for one cycle.

Using MY\_ADDRESS, a device address is assigned to the controller. It must differ from the addresses of the other J1939 bus participants. It can then be read by other bus participants.

### Parameters of the inputs

469

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
START	BOOL	TRUE (only for 1 cycle): Start J1939 protocol at CAN interface x FALSE: during further processing of the program
MY_ADDRESS	BYTE	J1939 address of the device



## J1939\_x\_GLOBAL\_REQUEST


4315

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_J1939\_x\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

2301

J1939\_x\_GLOBAL\_REQUEST is responsible for the automatic requesting of individual messages from all (global) active J1939 network participants. To do so, the parameters PG, PF, PS and the address of the array DST in which the received data is stored are assigned to the FB.



### Info

PGN = [Page] + [PF] + [PS]

PDU = [PRIO] + [PGN] + [J1939 address] + [data]

13790


## NOTICE

Risk of inadmissible overwriting of data!

- ▶ Create a receiver array with a size of 1 785 bytes.  
This is the maximum size of a J1939 message.
- ▶ Check the amount of received data:  
the value must not exceed the size of the array created to receive data!
- ▶ For every requested message use an own instance of the FB!
- ▶ To the destination address DST applies:
  - ❗ Determine the address by means of the operator ADR and assigne it to the FB!
- ▶ In addition, the priority (typically 3, 6 or 7) must be assigned.
- ▶ Given that the request of data can be handled via several control cycles, this process must be evaluated via the RESULT byte.
- RESULT = 2: the POU is waiting for data of the participants.
- RESULT = 1: data was received by a participant.  
The output LEN indicates how many data bytes have been received.  
Store / evaluate this new data immediately!  
When a new message is received, the data in the memory address DST is overwritten.
- RESULT = 0: no participant on the bus sends a reply within 1.25 seconds.  
The FB returns to the non-active state.  
Only now may ENABLE be set again to FALSE!
- ▶ For the reception of data from several participants at short intervals:  
call the POU several times in the same PLC cycle and evaluate it at once!

## Parameters of the inputs

463

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
PRI0	BYTE	message priority (0...7)
PG	BYTE	Data page Value of defined PGN (Parameter Group Number) allowed = 0...1 (normally = 0)
PF	BYTE	PDU format byte Value of defined PGN (Parameter Group Number) PDU2 (global) = 240...255
PS	BYTE	PDU specific byte Value of defined PGN (Parameter Group Number) GE (Group Extension) = 0...255
DST	DWORD	destination address  Determine the address by means of the operator ADR and assigne it to the FB!

### Info

PGN = [Page] + [PF] + [PS]

PDU = [PRI0] + [PGN] + [J1939 address] + [data]

## Parameters of the outputs

464

Parameter	Data type	Description
RESULT	BYTE	feedback of the function block (possible messages → following table)
SA	BYTE	J1939 address of the answering device
LEN	WORD	Number of received bytes

### Possible results for RESULT:

Value dec   hex	Description
0   00	FB is inactive
1   01	FB execution completed without error – data is valid
2   02	function block is active (action not yet completed)
3   03	Error

## J1939\_x\_RECEIVE


9393

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_J1939\_x\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

2288

J1939\_x\_RECEIVE serves for receiving one individual message or a block of messages.

To do so, the FB must be initialised for one cycle via the input CONFIG. During initialisation, the parameters PG, PF, PS, RPT, LIFE and the memory address of the data array DST are assigned.

**!** Once the following parameters have been configured they can no longer be modified in the running application program: PG, PF, PS, RPT, LIFE, DST.

13790

### NOTICE

Risk of inadmissible overwriting of data!

- ▶ Create a receiver array with a size of 1 785 bytes.  
This is the maximum size of a J1939 message.
- ▶ Check the amount of received data:  
the value must not exceed the size of the array created to receive data!

- ▶ To the destination address DST applies:

**!** Determine the address by means of the operator ADR and assigne it to the FB!

**!** Once RPT has been set it can no longer be modified!

- ▶ The receipt of data must be evaluated via the RESULT byte. If RESULT = 1 the data can be read from the memory address assigned via DST and can be further processed.

- > When a new message is received, the data in the memory address DST is overwritten.
- > The number of received message bytes is indicated via the output LEN.
- > If RESULT = 3, no valid messages have been received in the indicated time window (LIFE • RPT).

**!** This block must also be used if the messages are requested using the FBs J1939\_...\_REQUEST.

## Parameters of the inputs

457

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
CONFIG	BOOL	TRUE (in the 1st cycle): configure data object FALSE: during further processing of the program
PG	BYTE	Data page Value of defined PGN (Parameter Group Number) allowed = 0...1 (normally = 0)
PF	BYTE	PDU format byte Value of defined PGN (Parameter Group Number) PDU1 (specific) = 0...239 PDU2 (global) = 240...255
PS	BYTE	PDU specific byte Value of defined PGN (Parameter Group Number) If PF = PDU1 ⇒ PS = DA (Destination Address) (DA = J1939 address of external device) If PF = PDU2 ⇒ PS = GE (Group Extension)
DST	DWORD	destination address <b>!</b> Determine the address by means of the operator ADR and assigne it to the FB!
RPT	TIME	Monitoring time Within this time window the messages must be received cyclically. > Otherwise, there will be an error message. RPT = T#0s ⇒ no monitoring <b>!</b> Once RPT has been set it can no longer be modified!
LIFE	BYTE	tolerated number of J1939 messages not received

## Parameters of the outputs

458

Parameter	Data type	Description
RESULT	BYTE	feedback of the function block (possible messages → following table)
DEVICE	BYTE	J1939 address of the sender
LEN	WORD	Number of received bytes

### Possible results for RESULT:

Value dec   hex	Description
0   00	FB is inactive
1   01	FB execution completed without error – data is valid
3   03	Error, no data received during monitoring time

## J1939\_x\_RESPONSE


9399

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_J1939\_x\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

2299

J1939\_x\_RESPONSE handles the automatic response to a request message.

This FB is responsible for the automatic sending of messages to "Global Requests" and "Specific Requests". To do so, the FB must be initialised for one cycle via the input CONFIG.

The parameters PG, PF, PS, RPT and the address of the data array SRC are assigned to the FB.

- ▶ To the source address SRC applies:
  - ❗ Determine the address by means of the operator ADR and assigne it to the FB!
- ▶ In addition, the number of data bytes to be transmitted is assigned.

### Parameters of the inputs

451

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
CONFIG	BOOL	TRUE (in the 1st cycle): configure data object FALSE: during further processing of the program
PG	BYTE	Data page Value of defined PGN (Parameter Group Number) allowed = 0...1 (normally = 0)
PF	BYTE	PDU format byte Value of defined PGN (Parameter Group Number) PDU1 (specific) = 0...239 PDU2 (global) = 240...255
PS	BYTE	PDU specific byte Value of defined PGN (Parameter Group Number) If PF = PDU1 ⇨ PS = DA (Destination Address) (DA = J1939 address of external device) If PF = PDU2 ⇨ PS = GE (Group Extension)
SRC	DWORD	Start address in source memory ❗ Determine the address by means of the operator ADR and assigne it to the FB!
LEN	WORD	number (≥ 1) of the data bytes to be transmitted

## Parameters of the outputs

13993

Parameter	Data type	Description
RESULT	BYTE	feedback of the function block (possible messages → following table)

### Possible results for RESULT:

Value dec   hex		Description
0	00	FB is inactive
1	01	Data transfer completed without errors
2	02	function block is active (action not yet completed)
3	03	Error, data cannot be transmitted

## J1939\_x\_SPECIFIC\_REQUEST


8884

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_J1939\_x\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

2300

J1939\_x\_SPECIFIC\_REQUEST is responsible for the automatic requesting of individual messages from a specific J1939 network participant. To do so, the logical device address DA, the parameters PG, PF, PS and the address of the array DST in which the received data is stored are assigned to the FB.



#### Info

PGN = [Page] + [PF] + [PS]

PDU = [PRIO] + [PGN] + [J1939 address] + [data]

13790

### NOTICE


Risk of inadmissible overwriting of data!

- ▶ Create a receiver array with a size of 1 785 bytes.  
This is the maximum size of a J1939 message.
- ▶ Check the amount of received data:  
the value must not exceed the size of the array created to receive data!

- ▶ To the destination address DST applies:
  - ❗ Determine the address by means of the operator ADR and assigne it to the FB!
- ▶ In addition, the priority (typically 3, 6 or 7) must be assigned.
- ▶ Given that the request of data can be handled via several control cycles, this process must be evaluated via the RESULT byte. All data has been received if RESULT = 1.
- > The output LEN indicates how many data bytes have been received.

## Parameters of the inputs

445

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
PRI0	BYTE	message priority (0...7)
DA	BYTE	J1939 address of the requested device
PG	BYTE	Data page Value of defined PGN (Parameter Group Number) allowed = 0...1 (normally = 0)
PF	BYTE	PDU format byte Value of defined PGN (Parameter Group Number) PDU1 (specific) = 0...239 PDU2 (global) = 240...255
PS	BYTE	PDU specific byte Value of defined PGN (Parameter Group Number) If PF = PDU1 ⇒ PS = DA (Destination Address) (DA = J1939 address of external device) If PF = PDU2 ⇒ PS = GE (Group Extension)
DST	DWORD	destination address  Determine the address by means of the operator ADR and assigne it to the FB!



### Info

 $PGN = [Page] + [PF] + [PS]$ 
 $PDU = [PRI0] + [PGN] + [J1939\ address] + [data]$ 

## Parameters of the outputs

446

Parameter	Data type	Description
RESULT	BYTE	feedback of the function block (possible messages → following table)
LEN	WORD	Number of received bytes

### Possible results for RESULT:

Value dec   hex	Description
0   00	FB is inactive
1   01	FB execution completed without error – data is valid
2   02	function block is active (action not yet completed)
3   03	Error



## J1939\_x\_TRANSMIT


4322

x = 1...n = number of the CAN interface (depending on the device, → Data sheet)

Unit type = function block (FB)

Unit is contained in the library ifm\_J1939\_x\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description



2298

J1939\_x\_TRANSMIT is responsible for transmitting individual messages or blocks of messages. To do so, the parameters PG, PF, PS, RPT and the address of the data array SRC are assigned to the FB.

#### Info


PGN = [Page] + [PF] + [PS]

PDU = [PRIO] + [PGN] + [J1939 address] + [data]

- ▶ To the source address SRC applies:
  -  Determine the address by means of the operator ADR and assigne it to the FB!
- ▶ In addition, the number of data bytes to be transmitted and the priority (typically 3, 6 or 7) must be assigned.
- ▶ Given that the transmission of data is processed via several control cycles, the process must be evaluated via the RESULT byte. All data has been transmitted if RESULT = 1.
-  If more than 8 bytes are to be sent, a "multi package transfer" is carried out.

## Parameters of the inputs

439

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
PRI0	BYTE	message priority (0...7)
PG	BYTE	Data page Value of defined PGN (Parameter Group Number) allowed = 0...1 (normally = 0)
PF	BYTE	PDU format byte Value of defined PGN (Parameter Group Number) PDU1 (specific) = 0...239 PDU2 (global) = 240...255
PS	BYTE	PDU specific byte Value of defined PGN (Parameter Group Number) If PF = PDU1 ⇒ PS = DA (Destination Address) (DA = J1939 address of external device) If PF = PDU2 ⇒ PS = GE (Group Extension)
SRC	DWORD	Start address in source memory  Determine the address by means of the operator ADR and assigne it to the FB!
LEN	WORD	Number of data bytes to be transmitted allowed = 1...1 785 = 0x0001...0x06F9
RPT	TIME	Repeat time during which the data messages are to be transmitted cyclically RPT = T#0s ⇒ sent only once

### Info

PGN = [Page] + [PF] + [PS]

PDU = [PRI0] + [PGN] + [J1939 address] + [data]

## Parameters of the outputs

440

Parameter	Data type	Description
RESULT	BYTE	feedback of the function block (possible messages → following table)

### Possible results for RESULT:

Value dec   hex	Description
0   00	FB is inactive
1   01	FB execution completed without error – data is valid
2   02	function block is active (action not yet completed)
3   03	Error, data cannot be transmitted

## 5.2.6 Function elements: serial interface

### Inhalt

SERIAL_PENDING .....	132
SERIAL_RX .....	133
SERIAL_SETUP .....	134
SERIAL_TX .....	135

1600

### ! NOTE

In principle, the serial interface is not available for the user, because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit SERIAL\_MODE to TRUE. Then however, program download and debugging are only possible via the CAN interface.

The serial interface can be used in the application program by means of the following FBs.

## SERIAL\_PENDING

314

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

Symbol in CODESYS:



### Description

317

SERIAL\_PENDING determines the number of data bytes stored in the serial receive buffer.

In contrast to **SERIAL\_RX** (→ page [133](#)) the contents of the buffer remain unchanged after calling this FB.

The SERIAL FBs form the basis for the creation of an application-specific protocol for the serial interface.

To do so, set the system flag bit SERIAL\_MODE=TRUE!

### ! NOTE

In principle, the serial interface is not available for the user, because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit SERIAL\_MODE to TRUE. Then however, program download and debugging are only possible via the CAN interface.

### Parameters of the outputs

319

Parameter	Data type	Description
NUMBER	WORD	Number of data bytes received


## SERIAL\_RX

308

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

### Symbol in CODESYS:



### Description

311

SERIAL\_RX reads a received data byte from the serial receive buffer at each call.

Then, the value of AVAILABLE is decremented by 1.

If more than 1000 data bytes are received, the buffer overflows and data is lost. This is indicated by the bit OVERFLOW.

If 7-bit data transmission is used, the 8th bit contains the parity and must be suppressed by the user if necessary.

The SERIAL FBs form the basis for the creation of an application-specific protocol for the serial interface.

To do so, set the system flag bit SERIAL\_MODE=TRUE!

### ! NOTE

In principle, the serial interface is not available for the user, because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit SERIAL\_MODE to TRUE. Then however, program download and debugging are only possible via the CAN interface.

### Parameters of the inputs

312

Parameter	Data type	Description
CLEAR	BOOL	TRUE: delete receive buffer FALSE: function element is not executed

### Parameters of the outputs

313

Parameter	Data type	Description
Rx	BYTE	Byte data received from the receive buffer
AVAILABLE	WORD	Number of remaining data bytes 0 = no valid data available
OVERFLOW	BOOL	TRUE: Overflow of the data buffer ⇒ loss of data! FALSE: Data buffer is without data loss


## SERIAL\_SETUP

302

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

Symbol in CODESYS:



### Description

305

SERIAL\_SETUP initialises the serial RS232 interface.

The function block does not necessarily need to be executed in order to be able to use the serial interface. Without function block call the default settings below apply.

Using ENABLE=TRUE for one cycle, the function block sets the serial interface to the indicated parameters. The changes made with the help of the function block are saved non-volatily.

#### NOTE

In principle, the serial interface is not available for the user, because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit SERIAL\_MODE to TRUE. Then however, program download and debugging are only possible via the CAN interface.

5020

#### NOTICE

The driver module of the serial interface can be damaged!

Disconnecting or connecting the serial interface while live can cause undefined states which damage the driver module.

► Do not disconnect or connect the serial interface while live.

### Parameters of the inputs

306

Parameter	Data type	Description
ENABLE	BOOL	TRUE (only for 1 cycle): Initialise interface FALSE: during further processing of the program
BAUD RATE	WORD	Baud rate Permissible values → data sheet Preset value → data sheet
DATABITS	BYTE := 8	Number of data bits allowed = 7 or 8
PARITY	BYTE := 0	Parity allowed: 0=none, 1=even, 2=odd
STOPBITS	BYTE := 1	Number of stop bits allowed = 1 or 2


## SERIAL\_TX

296

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

Symbol in CODESYS:



### Description

299

SERIAL\_TX transmits one data byte via the serial RS232 interface.

Using the input ENABLE the transmission can be enabled or blocked.

The SERIAL FBs form the basis for the creation of an application-specific protocol for the serial interface.

To do so, set the system flag bit SERIAL\_MODE=TRUE!

### NOTE

In principle, the serial interface is not available for the user, because it is used for program download and debugging.

The interface can be freely used if the user sets the system flag bit SERIAL\_MODE to TRUE. Then however, program download and debugging are only possible via the CAN interface.

### Parameters of the inputs

300

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
DATA	BYTE	value to be transmitted

## 5.2.7 Function elements: Optimising the PLC cycle

### Inhalt

Function elements: processing interrupts .....	136
--	-----

8609

Here we show you functions to optimise the PLC cycle.

### Function elements: processing interrupts

#### Inhalt

SET_INTERRUPT_I .....	137
SET_INTERRUPT_XMS .....	140

1599

The PLC cyclically processes the stored application program in its full length. The cycle time can vary due to program branchings which depend e.g. on external events (= conditional jumps). This can have negative effects on certain functions.

By means of systematic interrupts of the cyclic program it is possible to call time-critical processes independently of the cycle in fixed time periods or in case of certain events.

Since interrupt functions are principally not permitted for SafetyControllers, they are thus not available.




## SET\_INTERRUPT\_I

2381

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

281  
11573

SET\_INTERRUPT\_I handles the execution of a program part by an interrupt request via an input channel.

In the conventional PLC the cycle time is decisive for real-time monitoring. So the PLC is at a disadvantage as compared to customer-specific controllers. Even a "real-time operating system" does not change this fact when the whole application program runs in one single block which cannot be changed.

A possible solution would be to keep the cycle time as short as possible. This often leads to splitting the application up to several control cycles. This, however, makes programming complex and difficult.

Another possibility is to call a certain program part only upon request by an input pulse independently of the control cycle:

The time-critical part of the application is integrated by the user in a block of the type PROGRAM (PRG). This block is declared as the interrupt routine by calling SET\_INTERRUPT\_I once (during initialisation). As a consequence, this program block will always be executed if an edge is detected on the input CHANNEL. If inputs and outputs are used in this program part, these are also read and written in the interrupt routine, triggered by the input edge. Reading and writing can be stopped via the FB inputs READ\_INPUTS, WRITE\_OUTPUTS and ANALOG\_INPUTS.

So in the program block all time-critical events can be processed by linking inputs or global variables and writing outputs. So FBs can only be executed if actually called by an input signal.

### ! NOTE

The program block should be skipped in the cycle (except for the initialisation call) so that it is not cyclically called, too.

The input (CHANNEL) monitored for triggering the interrupt cannot be initialised and further processed in the interrupt routine.

The runtime of the main cycle plus the sum of the duration of all program parts called via interrupt must always be within the max. permissible cycle time!

The user is responsible for data consistency between the main program and the program parts running in the interrupt mode!

### Interrupt priorities:

- All program parts called via interrupt have the same priority of execution. Several simultaneous interrupts are processed sequentially in the order of their occurrence.
- If a further edge is detected on the same input during execution of the program part called via interrupt, the interrupt is listed for processing and the program is directly called again after completion. As an option, interfering multiple pulses can be filtered out by setting the glitch filter.
- The program running in the interrupt mode can be disrupted by interrupts with a higher priority (e.g. CAN).
- If several interrupts are present on the same channel, the last initialised FB (or the PRG) will be assigned the channel. The previously defined FB (or the PRG) is then no longer called and no longer provides data.

### **!** NOTE

The uniqueness of the inputs and outputs in the cycle is affected by the interrupt routine. Therefore only part of the inputs and outputs is serviced. If initialised in the interrupt program, the following inputs and outputs will be read or written.

#### **Inputs, digital:**

%IX0.0...%IX0.7 (Controller: CR0n3n, CR7n3n)

%IX0.12...%IX0.15, %IX1.4...%IX1.8 (all other ClassicController, ExtendedController, SafetyController)

%IX0.0, %IX0.8 (SmartController: CR250n)

IN08...IN11 (CabinetController: CR030n)

IN0...IN3 (PCB controller: CS0015)

#### **Inputs, analogue:**

%IX0.0...%IX0.7 (Controller: CR0n3n, CR7n3n)

All channels (selection bit-coded) (all other controller)

#### **Outputs, digital:**

%QX0.0...%QX0.7 (ClassicController, ExtendedController, SafetyController)

%QX0.0, %QX0.8 (SafetyController: CR7nnn)

OUT00...OUT03 (CabinetController: CR030n)

OUT0...OUT7 (PCB controller: CS0015)

Global variants, too, are no longer unique if they are accessed simultaneously in the cycle and by the interrupt routine. This problem applies in particular to larger data types (e.g. DINT).

All other inputs and outputs are processed once in the cycle, as usual.

## Parameters of the inputs

2383  
282

Parameter	Data type	Description	
ENABLE	BOOL	TRUE (only for 1 cycle): initialisation of the function block FALSE: unit is not executed	
CHANNEL	BYTE	Number of interrupt input	
		• CabinetController: CR030n	0 = IN08 ... 3 = IN11
		• ClassicController: CR0020, CR0505 • ExtendedController: CR0200	0 = %IX1.4 ... 3 = %IX1.7
		• ClassicController: CR0032, CR0033 • ExtendedController: CR0232, CR0233	0 = IN00 ... 7 = IN07
		• SmartController: CR250n	0 = %IX0.0 1 = %IX0.8
		• PCB controller: CS0015 • PDM360smart: CR1071	0 = IN0 ... 3 = IN3
MODE	BYTE	Type of edge at the input CHANNEL which triggers the interrupt 1 = rising edge (standard value) 2 = falling edge 3 = rising and falling edge > 3 = standard value	
READ_INPUTS	BOOL	TRUE: read the inputs 0...7 before calling the program and write into the input flags I00...I07 FALSE: only read the channel indicated under CHANNEL and write to the corresponding input flag Ixx	
WRITE_OUTPUTS	BOOL	TRUE: write the current values of the output flags Q00...Q07 to the outputs after completion of the program sequence FALSE: do not write outputs	
ANALOG_INPUTS	BOOL	TRUE: read inputs 0...7 and write the unfiltered, uncalibrated analogue values to the flags ANALOG_IQ00...07 FALSE: do not write flags ANALOG_IQ00...07	


## SET\_INTERRUPT\_XMS

272

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

275

SET\_INTERRUPT\_XMS handles the execution of a program part at an interval of x ms.

In the conventional PLC the cycle time is decisive for real-time monitoring. So, the PLC is at a disadvantage as compared to customer-specific controllers. Even a "real-time operating system" does not change this fact when the whole application program runs in one single block which cannot be changed.

A possible solution would be to keep the cycle time as short as possible. This often leads to splitting the application up to several control cycles. This, however, makes programming complex and difficult.

Another possibility is to call a certain program part at fixed intervals (every x ms) independently of the control cycle.

The time-critical part of the application is integrated by the user in a block of the type PROGRAM (PRG). This block is declared as the interrupt routine by calling SET\_INTERRUPT\_XMS once (during initialisation). As a consequence, this program block is always processed after the REPEATTIME has elapsed (every x ms). If inputs and outputs are used in this program part, they are also read and written in the defined cycle. Reading and writing can be stopped via the FB inputs READ\_INPUTS, WRITE\_OUTPUTS and ANALOG\_INPUTS.

So, in the program block all time-critical events can be processed by linking inputs or global variables and writing outputs. So, timers can be monitored more precisely than in a "normal cycle".

### NOTE

To avoid that the program block called by interrupt is additionally called cyclically, it should be skipped in the cycle (with the exception of the initialisation call).

Several timer interrupt blocks can be active. The time requirement of the interrupt functions must be calculated so that all called functions can be executed. This in particular applies to calculations, floating point arithmetic or controller functions.

The user is responsible for data consistency between the main program and the program parts running in the interrupt!

**Please note:** In case of a high CAN bus activity the set REPEATTIME may fluctuate.

## NOTE

The uniqueness of the inputs and outputs in the cycle is affected by the interrupt routine. Therefore only part of the inputs and outputs is serviced. If initialised in the interrupt program, the following inputs and outputs will be read or written.

### Inputs, digital:

%IX0.0...%IX0.7 (Controller: CR0n3n, CR7n3n)

%IX0.12...%IX0.15, %IX1.4...%IX1.8 (all other ClassicController, ExtendedController, SafetyController)

%IX0.0, %IX0.8 (SmartController: CR250n)

IN08...IN11 (CabinetController: CR030n)

IN0...IN3 (PCB controller: CS0015)

### Inputs, analogue:

%IX0.0...%IX0.7 (Controller: CR0n3n, CR7n3n)

All channels (selection bit-coded) (all other controller)

### Outputs, digital:

%QX0.0...%QX0.7 (ClassicController, ExtendedController, SafetyController)

%QX0.0, %QX0.8 (SafetyController: CR7nnn)

OUT00...OUT03 (CabinetController: CR030n)

OUT0...OUT7 (PCB controller: CS0015)

Global variants, too, are no longer unique if they are accessed simultaneously in the cycle and by the interrupt routine. This problem applies in particular to larger data types (e.g. DINT).

All other inputs and outputs are processed once in the cycle, as usual.

## Parameters of the inputs

2382

Parameter	Data type	Description
ENABLE	BOOL	TRUE (only for 1 cycle): initialisation of the function block FALSE: unit is not executed
REPEATTIME	TIME	Duration in [ms] between end of program and reboot The duration between two calls is determined as the sum of REPEATTIME and runtime of the program called via interrupt.
READ_INPUTS	BOOL	TRUE: read the inputs 0...7 before calling the program and write into the input flags I00...I07 FALSE: no update of the inputs
WRITE_OUTPUTS	BOOL	TRUE: write the current values of the output flags Q00...Q07 to the outputs after completion of the program sequence FALSE: do not write outputs
ANALOG_INPUTS	BOOL	TRUE: read inputs 0...7 and write the unfiltered, uncalibrated analogue values to the flags ANALOG_IRQ00...07 FALSE: do not write flags ANALOG_IRQ00...07

## 5.2.8 Function elements: processing input values

### Inhalt

ANALOG_RAW .....	143
INPUT_ANALOG .....	144
INPUT_CURRENT .....	145
INPUT_VOLTAGE .....	146

1602  
1302

In this chapter we show you **ifm** FBs which allow you to read and process the analogue or digital signals at the device input.

### ! NOTE

The analogue raw values shown in the PLC configuration of CODESYS directly come from the ADC. They are not yet corrected!

Therefore different raw values can appear in the PLC configuration for identical devices.

Error correction and normalisation are only carried out by ifm function blocks. The function blocks provide the corrected value.


## ANALOG\_RAW

19589

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

**Symbol in CODESYS:**



### Description

9918

ANALOG\_RAW provides the raw analogue signal of the inputs, without any filtering.

### Parameters of the outputs

13148

Parameter	Data type	Description
P0	ARRAY [0..7] OF WORD	Raw input values of the analogue inputs, port 0: P0.0 for I00 ... P0.7 for I07
P12	ARRAY [0..7] OF WORD	Raw input values of the analogue inputs, ports 1+2: P12.0 for I14 ... P12.3 for I17 P12.4 for I24 ... P12.7 for I27
P3	ARRAY [0..7] OF WORD	Raw input values of the analogue inputs, port 3: P3.0 for I30 ... P3.7 for I37
P4	ARRAY [0..7] OF WORD	Raw input values of the analogue inputs, port 4: P4.0 for I40 ... P4.7 for I47


## INPUT\_ANALOG

519

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyyzz.LIB

Symbol in CODESYS:



### Description

522

INPUT\_ANALOG enables current and voltage measurements at the analogue channels.

The FB provides the current analogue value at the selected analogue channel. The measurement and the output value result from the operating mode specified via MODE.

MODE	Input operating mode	Output OUT	Unit
IN_DIGITAL_H	digital input	0 / 1	---
IN_CURRENT	current input	0...20 000	µA
IN_VOLTAGE10	voltage input	0...10 000	mV
IN_VOLTAGE30	voltage input	0...30 000	mV
IN_RATIO	voltage input ratiometric	0...1 000	‰

For parameter setting of the operating mode, the indicated global system variables should be used. The analogue values are provided as standardised values.

**!** When using this FB you must set the system variable RELAIS \*). Otherwise the internal reference voltages are missed for the current measurement.

\*) Relay exists only in the following devices: CR0020, CRnn32, CRnn33, CR0200, CR0505, CR7nnn

### Parameters of the inputs

523

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
MODE	BYTE	IN_DIGITAL_H Digital input IN_CURRENT Current input 0/20... 000 IN_VOLTAGE10 Voltage input 0...10 000 mV IN_VOLTAGE30 Voltage input 0...30 000 mV IN_RATIO ratiometric analogue input
INPUT_CHANNEL	BYTE	Number of input channel allowed = 0...7

### Parameters of the outputs

524

Parameter	Data type	Description
OUT	WORD	Output value according to MODE in case of an invalid setting: OUT = "0"



## INPUT\_CURRENT

513

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

Symbol in CODESYS:



### Description

516

INPUT\_CURRENT returns the actual input current in [μA] at the analogue current inputs.

#### Info

INPUT\_CURRENT is a compatibility FB for older programs. In new programs, the more powerful **INPUT\_ANALOG** (→ page [144](#)) should be used.

### Parameters of the inputs

517

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
INPUT_CHANNEL	BYTE	Number of input channel allowed = 0...7

### Parameters of the outputs

518

Parameter	Data type	Description
ACTUAL_CURRENT	WORD	input current in [μA]


## INPUT\_VOLTAGE

507

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

Symbol in CODESYS:



### Description

510

INPUT\_VOLTAGE processes analogue voltages measured on the analogue channels.

- > The FB returns the current input voltage in [mV] on the selected analogue channel. The measurement refers to the voltage range defined via MODE\_10V\_32V (10 000 mV or 32 000 mV).



### Info

INPUT\_VOLTAGE is a compatibility FB for older programs. In new programs, the more powerful **INPUT\_ANALOG** (→ page [144](#)) should be used.

### Parameters of the inputs

511

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
MODE_10V_32V	BOOL	TRUE: voltage range 0...32 V FALSE: voltage range 0...10 V
INPUT_CHANNEL	BYTE	Number of input channel allowed = 0...7

### Parameters of the outputs

512

Parameter	Data type	Description
ACTUAL_VOLTAGE	WORD	input voltage in [mV]

## 5.2.9 Function elements: adapting analogue values

### Inhalt

NORM.....	148
-----------	-----

1603

If the values of analogue inputs or the results of analogue functions must be adapted, the following FBs will help you.


## NORM

401

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

Symbol in CODESYS:



## Description

404

NORM normalises a value within defined limits to a value with new limits.

The FB normalises a value of type WORD within the limits of XH and XL to an output value within the limits of YH and YL. This FB is for example used for generating PWM values from analogue input values.

### NOTE

- The value for X must be in the defined input range between XL and XH! There is no internal plausibility check of the value X.
- > Due to rounding errors the normalised value can deviate by 1.
- > If the limits (XH/XL or YH/YL) are defined in an inverted manner, normalisation is also done in an inverted manner.

## Parameters of the inputs

405

Parameter	Data type	Description
X	WORD	input value
XH	WORD	Upper limit of input value range [increments]
XL	WORD	Lower limit of input value range [increments]
YH	WORD	Upper limit of output value range
YL	WORD	Lower limit of output value range

## Parameters of the outputs

406

Parameter	Data type	Description
Y	WORD	output value

### Example: NORM (1)

407

lower limit value input	0	XL
upper limit value input	100	XH
lower limit value output	0	YL
upper limit value output	2000	YH

then the FB converts the input signal for example as follows:

<b>from X =</b>	50	0	100	75
	↓	↓	↓	↓
<b>to Y =</b>	1000	0	2000	1500

### Example: NORM (2)

408

lower limit value input	2000	XL
upper limit value input	0	XH
lower limit value output	0	YL
upper limit value output	100	YH

then the FB converts the input signal for example as follows:

<b>from X =</b>	1000	0	2000	1500
	↓	↓	↓	↓
<b>to Y =</b>	50	100	0	25

## 5.2.10 Function elements: counter functions for frequency and period measurement

### Inhalt

FAST_COUNT.....	151
FREQUENCY.....	152
INC_ENCODER.....	153
PERIOD.....	156
PERIOD_RATIO.....	158
PHASE.....	160

18818

The controllers support up to 4 fast inputs which can process input frequencies of up to 30 kHz. In addition to frequency measurement, the FRQ inputs can also be used for the evaluation of incremental encoders (counter function).

Due to the different measuring methods errors can occur when the frequency is determined.

The following FBs are available for easy evaluation:

Function element	Permissible values	Explanation
FREQUENCY	0...50 000 Hz	Measurement of the frequency on the indicated channel. Measurement error is reduced in case of high frequencies
PERIOD	0.1...30 000 Hz	Measurement of frequency and period duration (cycle time) on the indicated channel
PERIOD_RATIO	0...30 000 Hz	Measurement of frequency and period duration (cycle time) as well as mark-to-space ratio [%] on the indicated channel
FREQUENCY_PERIOD	0...30 000 Hz	The FB combines the two FBs FREQUENCY and PERIOD or PERIOD_RATIO. Automatic selection of the measuring method at 5 kHz
PHASE	0...5 000 Hz	Reading of a channel pair and comparison of the phase position of the signals
INC_ENCODER	0...5 000 Hz	Up/down counter function for the evaluation of encoders
FAST_COUNT	0...5 000 Hz	Counting of fast pulses

**!** Important when using the fast inputs as "normal" digital inputs:


- The increased sensitivity to noise pulses must be taken into account (e.g. contact bouncing for mechanical contacts).
- The standard digital input can evaluate signals up to 50 Hz.

## FAST\_COUNT

20430

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

**Symbol in CODESYS:**


### Description

570

FAST\_COUNT operates as counter block for fast input pulses.

This FB detects fast pulses at the FRQ input channels 0...3. With the FRQ input channel 0 FAST\_COUNT operates like the block CTU. Maximum input frequency → data sheet.

**!** Due to the technical design, for the *ecomatmobile* controllers channel 0 can only be used as up counter. The channels 1...3 can be used as up and down counters.

### Parameters of the inputs

20433

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > counter stopped
INIT	BOOL	FALSE ⇒ TRUE (edge): unit is initialised FALSE: during further processing of the program
CHANNEL	BYTE	Number of the fast input channel (0...3) 0...3 for the inputs I14...I17
MODE_UP_DOWN	BOOL	TRUE: counter counts downwards FALSE: counter counts upwards
LOAD	BOOL	TRUE: start value PV is loaded in CV FALSE: function element is not executed
PV	DWORD	Start value (preset value) for the counter

### Parameters of the outputs

572

Parameter	Data type	Description
CV	DWORD	current counter value Behaviour in case of overflow: • the counter stops at 0 when counting downwards • there is an overflow when counting upwards


## FREQUENCY

20604

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

**Symbol in CODESYS:**



### Description

540

FREQUENCY measures the signal frequency at the indicated channel. Maximum input frequency → data sheet.

This FB measures the frequency of the signal at the selected CHANNEL. To do so, the positive edge is evaluated. Depending on the TIMEBASE, frequency measurements can be carried out in a wide value range. High frequencies require a short time base, low frequencies a correspondingly longer time base. The frequency is provided directly in [Hz].

**!** For FREQUENCY only the inputs FRQ0...FRQ3 can be used.

### Parameters of the inputs

20610

Parameter	Data type	Description
INIT	BOOL	FALSE ⇒ TRUE (edge): unit is initialised FALSE: during further processing of the program
CHANNEL	BYTE	Number of the fast input channel (0...3) 0...3 for the inputs I14...I17
TIMEBASE	TIME	Time basis for frequency measurement (max. 57 s)

8406

**!** The FB may provide wrong values before initialisation.  
▶ Do not evaluate the output before the FB has been initialised.  
We urgently recommend to program an own instance of this FB for each channel to be evaluated.  
Otherwise, wrong values may be provided.

### Parameters of the outputs

542

Parameter	Data type	Description
F	REAL	frequency of the input signal in [Hz]



## INC\_ENCODER


20432

= Incremental Encoder

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

4330

INC\_ENCODER offers up/down counter functions for the evaluation of encoders.

Each input pair to be evaluated by means of the function block is formed by two frequency inputs.

Limit frequency = 30 kHz

max. number of units to be connected: 4 encoders (ExtendedController: max. 8 encoders)

Set preset value:

1. Enter value in PRESET\_VALUE
2. Set PRESET to TRUE for one cycle
3. Reset PRESET to FALSE

The function block counts the pulses at the inputs as long as INIT=FALSE and PRESET=FALSE.

The current counter value is available at the output COUNTER.

The outputs UP and DOWN indicate the current counting direction of the counter. The outputs are TRUE if the counter has counted in the corresponding direction in the preceding program cycle. If the counter stops, the direction output in the following program cycle is also reset.




**!** Do **not** use this function block on one input together with one of the following function blocks!

- **FAST\_COUNT** (→ page [151](#))
- **FREQUENCY** (→ page [152](#))
- **PERIOD** (→ page [156](#))
- **PERIOD\_RATIO** (→ page [158](#))
- **PHASE** (→ page [160](#))

On input RESOLUTION the resolution of the encoder can be evaluated in multiples:

- 1 = normal resolution (identical with the resolution of the encoder),
- 2 = double evaluation of the resolution,
- 4 = 4-fold evaluation of the resolution.

All other values on this input mean normal resolution.

	<p><b>RESOLUTION = 1</b></p> <p>In the case of normal resolution only the falling edge of the B-signal is evaluated.</p>
	<p><b>RESOLUTION = 2</b></p> <p>In the case of double resolution the falling and the rising edges of the B-signal are evaluated.</p>
	<p><b>RESOLUTION = 4</b></p> <p>In the case of 4-fold resolution the falling and the rising edges of the A-signal and the B-signal are evaluated.</p>

## Parameters of the inputs

20438

Parameter	Data type	Description
INIT	BOOL	TRUE (only for 1 cycle): Function block is initialised FALSE: during further processing of the program
CHANNEL	BYTE	Number of the input channel pair (0...3) 0 = channel pair 0 = inputs I14 + I15 1 = channel pair 1 = inputs I16 + I17 2 = channel pair 2 = inputs I24 + I25 3 = channel pair 3 = inputs I26 + I27
PRESET_VALUE	DINT	counter start value
PRESET	BOOL	FALSE ⇒ TRUE (edge): PRESET_VALUE is loaded to COUNTER TRUE: Counter ignores the input pulses FALSE: Counter counts the input pulses
RESOLUTION	BYTE	evaluation of the encoder resolution: 01 = counts for every fourth edge (= resolution of the encoder) 02 = counts for every second edge 04 = counts for every rising and falling edge All other values count as "01".

## Parameters of the outputs

530

Parameter	Data type	Description
COUNTER	DINT	Current counter value
UP	BOOL	TRUE: counter counts upwards in the last cycle FALSE: counter counts not upwards in the last cycle
DOWN	BOOL	TRUE: counter counts downwards in the last cycle FALSE: counter counts not downwards in the last cycle




## PERIOD

20606

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

373

PERIOD measures the frequency and the cycle period (cycle time) in [μs] at the indicated channel. Maximum input frequency → data sheet.

This FB measures the frequency and the cycle time of the signal at the selected CHANNEL. To calculate, all positive edges are evaluated and the average value is determined by means of the number of indicated PERIODS.

In case of low frequencies there will be inaccuracies when using FREQUENCY. To avoid this, PERIOD can be used. The cycle time is directly indicated in [μs].

The maximum measuring range is approx. 71 min.

### NOTE

For PERIOD only the inputs CYL0...CYL3 can be used.

For PDM360smart: CR1071: all inputs.

Frequencies < 0.5 Hz are no longer clearly indicated!

### Parameters of the inputs

20608

Parameter	Data type	Description
INIT	BOOL	FALSE ⇒ TRUE (edge): unit is initialised FALSE: during further processing of the program
CHANNEL	BYTE	Number of the fast input channel (0...3) 0...3 for the inputs I24...I27
PERIODS	BYTE	Number of periods to be compared

8406

! The FB may provide wrong values before initialisation.

► Do not evaluate the output before the FB has been initialised.

We urgently recommend to program an own instance of this FB for each channel to be evaluated. Otherwise, wrong values may be provided.

## Parameters of the outputs

375

Parameter	Data type	Description
C	DWORD	Cycle time of the detected periods in [μs] allowed = 200...10 000 000 = 0xC8...0x989680 (= 10 seconds)
F	REAL	frequency of the input signal in [Hz]
ET	TIME	time elapsed since the last rising edge on the input (can be used for very slow signals)




## PERIOD\_RATIO

20441

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyyzz.LIB

### Symbol in CODESYS:



### Description

367

PERIOD\_RATIO measures the frequency and the cycle period (cycle time) in [μs] during the indicated periods at the indicated channel. In addition, the mark-to-period ratio is indicated in [%]. Maximum input frequency → data sheet.

This FB measures the frequency and the cycle time of the signal at the selected CHANNEL. To calculate, all positive edges are evaluated and the average value is determined by means of the number of indicated PERIODS. In addition, the mark-to-period ratio is indicated in [%].

**For example:** In case of a signal ratio of 25 ms high level and 75 ms low level the value RATIO1000 is provided as 250 %.

In case of low frequencies there will be inaccuracies when using FREQUENCY. To avoid this, PERIOD\_RATIO can be used. The cycle time is directly indicated in [μs].

The maximum measuring range is approx. 71 min.

### NOTE

For PERIOD\_RATIO only the inputs CYL0...CYL3 can be used.

For PDM360smart: CR1071: all inputs.

The output RATIO1000 provides the value 0 for a mark-to-period ratio of 100 % (input signal permanently at supply voltage).

Frequencies < 0.05 Hz are no longer clearly indicated!

### Parameters of the inputs

20446

Parameter	Data type	Description
INIT	BOOL	FALSE ⇒ TRUE (edge): unit is initialised FALSE: during further processing of the program
CHANNEL	BYTE	Number of the fast input channel (0...3) 0...3 for the inputs I24...I27
PERIODS	BYTE	Number of periods to be compared

8406

⚠ The FB may provide wrong values before initialisation.

► Do not evaluate the output before the FB has been initialised.

We urgently recommend to program an own instance of this FB for each channel to be evaluated. Otherwise, wrong values may be provided.

## Parameters of the outputs

369

Parameter	Data type	Description
C	DWORD	Cycle time of the detected periods in [μs] allowed = 200...10 000 000 = 0xC8...0x989680 (= 10 seconds)
F	REAL	frequency of the input signal in [Hz]
ET	TIME	Time passed since the last change of state on the input (can be used in case of very slow signals)
RATIO1000	WORD	for measuring the interval: Mark-to-space ratio in [%] Preconditions: • pulse duration ≥ 100 μs • frequency < 5 kHz for other measurements: RATIO1000 = 0


## PHASE

20443

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

### Symbol in CODESYS:



### Description

361

PHASE reads a pair of channels with fast inputs and compares the phase position of the signals.  
Maximum input frequency → data sheet.

This FB compares a pair of channels with fast inputs so that the phase position of two signals towards each other can be evaluated. An evaluation of the cycle period is possible even in the range of seconds.

**!** For frequencies lower than 15 Hz a cycle period or phase shift of 0 is indicated.

### Parameters of the inputs

20444

Parameter	Data type	Description
INIT	BOOL	FALSE ⇒ TRUE (edge): unit is initialised FALSE: during further processing of the program
CHANNEL	BYTE	Number of the input channel pair (0/1) 0 = channel pair 0 = inputs I14 + I15 1 = channel pair 1 = inputs I16 + I17

8406

**!** The FB may provide wrong values before initialisation.  
▶ Do not evaluate the output before the FB has been initialised.  
We urgently recommend to program an own instance of this FB for each channel to be evaluated.  
Otherwise, wrong values may be provided.

### Parameters of the outputs

363

Parameter	Data type	Description
C	DWORD	period duration of the first input's signal of the channel pair in [μs]
P	INT	angle of the phase shaft valid measurement: 1...358 °
ET	TIME	Time elapsed since the last positive edge at the second pulse input of the channel pair



## 5.2.11 Function elements: PWM functions

Inhalt	
OCC_TASK .....	162
OUTPUT_CURRENT .....	164
OUTPUT_CURRENT_CONTROL .....	165
PWM .....	167
PWM100 .....	171
PWM1000 .....	173

13758

Here, you will find **ifm** function blocks that allow you to operate the outputs with Pulse-Width Modulation (PWM).


## OCC\_TASK

20619

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

Symbol in CODESYS:



### Description

391

OCC\_TASK operates as current controller for the PWM outputs.

The controller is designed as an adaptive controller so that it is self-optimising. If the self-optimising performance is not desired, a value > 0 can be transmitted via the input MANUAL (the self-optimising performance is deactivated). The numerical value represents a compensation value, which has an influence on the integral and differential components of the controller. To determine the best settings of the controller in the MANUAL mode, the value 50 is suitable. Depending on the requested controller characteristics the value can then be incremented step-by-step (controller becomes more sensitive / faster) or decremented (controller becomes less sensitive / slower).

If the input MANUAL is set to 0, the controller is always self-optimising. The performance of the controlled system is permanently monitored and the updated compensation values are automatically and permanently stored in each cycle. Changes in the controlled system are immediately recognised and corrected.

### NOTE

OCC\_TASK operates with a fixed cycle time of 5 ms. No actual values need to be entered because these are detected internally by the FB.

OCC\_TASK is based on *PWM* (→ page 167).

If OUTPUT\_CURRENT\_CONTROL is used for the outputs 4...7, only the PWM FB may be used there if the PWM outputs 8...11 are used simultaneously.

- ▶ When defining the parameter DITHER\_VALUE make sure that the resulting PWM ratio in the operating range of the loop control remains between 0...100 %:

- PWM ratio + DITHER\_VALUE < 100 % and
- PWM ratio - DITHER\_VALUE > 0 %.

Outside of this permissible range the current specified in the parameter DESIRED\_CURRENT cannot be reached.

## Parameters of the inputs

20620

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
INIT	BOOL	FALSE ⇒ TRUE (edge): unit is initialised FALSE: during further processing of the program
OUTPUT_CHANNEL	BYTE	Number of the current-controlled output channel (0...7) 0...3 for the outputs Q10...Q13 4...7 for the outputs Q20...Q23
DESIRED_CURRENT	WORD	desired current value of the output in [mA]
PWM_FREQUENCY	WORD	PWM frequency [Hz] for load on input
DITHER_FREQUENCY	WORD	dither frequency in [Hz] value range = 0...FREQUENCY / 2 FREQUENCY / DITHER_FREQUENCY must be even-numbered! The FB increases all other values to the next matching value.
DITHER_VALUE	BYTE	peak-to-peak value of the dither in [%] permissible values = 0...100 = 0x00...0x64
MODE	BYTE	Controller characteristics: 0 = very slow increase, no overshoot 1 = slow increase, no overshoot 2 = minimum overshoot 3 = moderate overshoot permissible
MANUAL	BYTE	Value = 0: the controller operates in a self-optimising way Value > 0: the self-optimising performance of the closed-loop controller is overwritten (typical: 50)

## Parameters of the outputs

393

Parameter	Data type	Description
PWM_RATIO	BYTE	for monitoring purposes: display PWM pulse ratio 0...100%


## OUTPUT\_CURRENT

20449

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

Symbol in CODESYS:



### Description

385

OUTPUT\_CURRENT handles the current measurement in conjunction with an active PWM channel.

The FB provides the current output current if the outputs are used as PWM outputs or as plus switching. The current measurement is carried out in the device, i.e. no external measuring resistors are required.

### Parameters of the inputs

20451

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
OUTPUT_CHANNEL	BYTE	Number of the current-controlled output channel (0...7) 0...3 for the outputs Q10...Q13 4...7 for the outputs Q20...Q23
DITHER_RELATED	BOOL	Current is determined as an average value via... TRUE: one dither period FALSE: one PWM period

### Parameters of the outputs

387

Parameter	Data type	Description
ACTUAL_CURRENT	WORD	Output current in [mA]


## OUTPUT\_CURRENT\_CONTROL

20453

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

### Symbol in CODESYS:



### Description

20454

OUTPUT\_CURRENT\_CONTROL operates as current controller for the PWM outputs.

The controller is designed as an adaptive controller so that it is self-optimising. If this self-optimising performance is not desired, a value > 0 can be transmitted via the input MANUAL; the self-optimising performance is then deactivated. The numerical value represents a compensation value, which has an influence on the integral and differential components of the controller. To determine the best settings of the controller in the MANUAL mode, the value 50 is suitable. Depending on the requested controller characteristics the value can then be incremented step-by-step (controller becomes more sensitive / faster) or decremented (controller becomes less sensitive / slower).

If the input MANUAL is set to 0, the controller is always self-optimising. The performance of the controlled system is permanently monitored and the updated compensation values are automatically and permanently stored in each cycle. Changes in the controlled system are immediately recognised and corrected.

### NOTE

To obtain a stable output value OUTPUT\_CURRENT\_CONTROL should be called cyclically at regular intervals.

OUTPUT\_CURRENT\_CONTROL is based on *PWM* (→ page [167](#)).

If OUTPUT\_CURRENT\_CONTROL is used for the outputs 4...7, only the PWM FB may be used there if the PWM outputs 8...11 are used simultaneously.

- When defining the parameter DITHER\_VALUE make sure that the resulting PWM ratio in the operating range of the loop control remains between 0...100 %:

- PWM ratio + DITHER\_VALUE < 100 % and
- PWM ratio - DITHER\_VALUE > 0 %.

Outside of this permissible range the current specified in the parameter DESIRED\_CURRENT cannot be reached.

## Parameters of the inputs

20455

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
INIT	BOOL	FALSE ⇒ TRUE (edge): unit is initialised FALSE: during further processing of the program
OUTPUT_CHANNEL	BYTE	Number of the current-controlled output channel (0...7) 0...3 for the outputs Q10...Q13 4...7 for the outputs Q20...Q23
ACTUAL_CURRENT	WORD	Actual current on the PWM output in [mA] ► Transfer the output value of <b>OUTPUT_CURRENT</b> (→ page 164) to the input ACTUAL_CURRENT.
DESIRED_CURRENT	WORD	desired current value of the output in [mA]
PWM_FREQUENCY	WORD	PWM frequency [Hz] for load on input
DITHER_FREQUENCY	WORD	dither frequency in [Hz] value range = 0...FREQUENCY / 2 FREQUENCY / DITHER_FREQUENCY must be even-numbered! The FB increases all other values to the next matching value.
DITHER_VALUE	BYTE	peak-to-peak value of the dither in [%] permissible values = 0...100 = 0x00...0x64
MODE	BYTE	Controller characteristics: 0 = very slow increase, no overshoot 1 = slow increase, no overshoot 2 = minimum overshoot 3 = moderate overshoot permissible
MANUAL	BYTE	Value = 0: the controller operates in a self-optimising way Value > 0: the self-optimising performance of the closed-loop controller is overwritten (typical: 50)

## Parameters of the outputs

381

Parameter	Data type	Description
PWM_RATIO	BYTE	for monitoring purposes: display PWM pulse ratio 0...100%


## PWM

20467

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyzz.LIB

### Symbol in CODESYS:



### Description

20467

PWM is used for initialisation and parameter setting of the PWM outputs.

PWM has a more technical background. Due to their structure, PWM values can be very finely graded. So, this FB is suitable for use in controllers.

PWM is called once for each channel during initialisation of the application program. When doing so, input INIT must be set to TRUE. During initialisation, the parameter RELOAD is also assigned.

#### **NOTE**

The value RELOAD must be identical for the channels 4...11.

For these channels, PWM and *PWM1000* (→ page [173](#)) must not be mixed.

The PWM frequency (and so the RELOAD value) is internally limited to 5 kHz.

Depending on whether a high or a low PWM frequency is required, the input DIV64 must be set to FALSE (0) or TRUE (1).

During cyclical processing of the program INIT is set to FALSE. The FB is called and the new PWM value is assigned. The value is adopted if the input CHANGE = TRUE.

A current measurement for the initialised PWM channel can be implemented:

- via *OUTPUT\_CURRENT* (→ page [164](#))
- or for example using the ifm unit EC2049 (series element for current measurement).

PWM\_Dither is called once for each channel during initialisation of the application program. When doing so, input INIT must be set to TRUE. During initialisation, the DIVIDER for the determination of the dither frequency and the VALUE are assigned.

**NOTE** The parameters DITHER\_FREQUENCY and DITHER\_VALUE can be individually set for each channel.

## Parameters of the inputs

20458

Parameter	Data type	Description
INIT	BOOL	FALSE $\Rightarrow$ TRUE (edge): unit is initialised FALSE: during further processing of the program
RELOAD	WORD	Value for the determination of the PWM frequency ( $\rightarrow$ chapter <i>Calculation of the RELOAD value</i> ( $\rightarrow$ page 169))
DIV64	BOOL	CPU cycle / 64
CHANNEL	BYTE	Number of the PWM output channel (0...15) 0...3 for the outputs Q10...Q13 4...7 for the outputs Q20...Q23 8...15 for the outputs Q40...Q47
VALUE	WORD	Current PWM value permissible = 0...RELOAD 0 = switch-on time 100 % RELOAD = switch-on time 0 %
CHANGE	BOOL	TRUE: Adopting new value from ... • VALUE: after the current PMW period • DITHER_VALUE: after the current Dither period FALSE: the changed PWM value has no influence on the output
DITHER_VALUE	WORD	peak-to-peak value of the dither in [%] permissible values = 0...1 000 = 0000...03E8
DITHER_DIVIDER	WORD	Dither frequency = PWM frequency / DIVIDER * 2

## PWM frequency

1529

Depending on the valve type, a corresponding PWM frequency is required. For the PWM function the PWM frequency is transmitted via the reload value (PWM) or directly as a numerical value in [Hz] (PWM1000). Depending on the controller, the PWM outputs differ in their operating principle but the effect is the same.

The PWM frequency is implemented by means of an internally running counter, derived from the CPU pulse. This counter is started with the initialisation of the PWM. Depending on the PWM output group (0...3 and / or 4...7 or 4...11), it counts from 0xFFFF backwards or from 0x0000 forwards. If a transmitted comparison value (VALUE) is reached, the output is set. In case of an overflow of the counter (change of the counter reading from 0x0000 to 0xFFFF or from 0xFFFF to 0x0000), the output is reset and the operation restarts.

If this internal counter shall not operate between 0x0000 and 0xFFFF, another preset value (RELOAD) can be transmitted for the internal counter. In doing so, the PWM frequency increases. The comparison value must be within the now specified range.



## Calculation of the RELOAD value

1531




Figure: RELOAD value for the PWM channels 0...3

The RELOAD value of the internal PWM counter is calculated on the basis of the parameter DIV64 and the CPU frequency as follows:

	<ul style="list-style-type: none"> <li>CabinetController: CR0303</li> <li>ClassicController: CR0020, CR0505</li> <li>ExtendedController: CR0200</li> <li>SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506</li> </ul>	<ul style="list-style-type: none"> <li>CabinetController: CR0301, CR0302</li> <li>SmartController: CR250n</li> <li>PCB controller: CS0015</li> <li>PDM360smart: CR1071</li> </ul>
DIV64 = 0	RELOAD = 20 MHz / $f_{PWM}$	RELOAD = 10 MHz / $f_{PWM}$
DIV64 = 1	RELOAD = 312.5 kHz / $f_{PWM}$	RELOAD = 156.25 kHz / $f_{PWM}$

Depending on whether a high or a low PWM frequency is required, the input DIV64 must be set to FALSE (0) or TRUE (1). In case of frequencies below 305 Hz respectively 152 Hz (according to the controller), DIV64 must be set to "1" to ensure that the RELOAD value is not greater than 0xFFFF.

## Calculation examples RELOAD value

1532

<ul style="list-style-type: none"> <li>CabinetController: CR0303</li> <li>ClassicController: CR0020, CR0505</li> <li>ExtendedController: CR0200</li> <li>SafetyController: CR7020, CR7021, CR7200, CR7201, CR7505, CR7506</li> </ul>	<ul style="list-style-type: none"> <li>CabinetController: CR0301, CR0302</li> <li>SmartController: CR250n</li> <li>PCB controller: CS0015</li> <li>PDM360smart: CR1071</li> </ul>
The PWM frequency shall be 400 Hz.  $\frac{20 \text{ MHz}}{400 \text{ Hz}} = 50\,000 = 0xC350 = \text{RELOAD}$	The PWM frequency shall be 200 Hz.  $\frac{10 \text{ MHz}}{200 \text{ Hz}} = 50\,000 = 0xC350 = \text{RELOAD}$
Thus the permissible range of the PWM value is the range from 0x0000...0xC350. The comparison value at which the output switches must then be between 0x0000 and 0xC350.	

This results in the following mark-to-space ratios:

Mark-to-space ratio	Switch-on time	Value for mark-to-space ratio
Minimum	0 %	50 000 = 0xC350
Maximum	100 %	0 = 0x0000

Between minimum and maximum triggering 50 000 intermediate values (PWM values) are possible.

## PWM dither

1534

For certain hydraulic valve types a so-called dither frequency must additionally be superimposed on the PWM frequency. If valves were triggered over a longer period by a constant PWM value, they could block due to the high system temperatures.

To prevent this, the PWM value is increased or reduced on the basis of the dither frequency by a defined value (DITHER\_VALUE). As a consequence a vibration with the dither frequency and the amplitude DITHER\_VALUE is superimposed on the constant PWM value. The dither frequency is indicated as the ratio (divider,  $\text{DITHER\_DIVIDER} \cdot 2$ ) of the PWM frequency.

## Ramp function

1535

In order to prevent abrupt changes from one PWM value to the next, e.g. from 15 % ON to 70 % ON, it is possible to delay the increase by using *PT1* (→ page 199). The ramp function used for PWM is based on the CODESYS library UTIL.LIB. This allows a smooth start e.g. for hydraulic systems.

964


### NOTE

When installing the *ecomatmobile* DVD "Software, tools and documentation", projects with examples have been stored in the program directory of your PC:

...\ifm\_electronic\CoDeSys V...\Projects\DEMO\_PLC\_DVD\_V... (for controllers) or

...\ifm\_electronic\CoDeSys V...\Projects\DEMO\_PDM\_DVD\_V... (for PDMs).


There you also find projects with examples regarding this subject. It is strongly recommended to follow the shown procedure.

 The PWM function of the controller is a hardware function provided by the processor. The PWM function remains set until a hardware reset (power off and on) has been carried out on the controller.

## PWM100


20461

Unit type = function block (FB)

 New *ecomatmobile* controllers only support *PWM1000* (→ page [173](#)).

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

20462

PWM100 handles the initialisation and parameter setting of the PWM outputs.

The FB enables a simple application of the PWM FB in the *ecomatmobile* controller. The PWM frequency can be directly indicated in [Hz] and the mark-to-space ratio in steps of 1 %. This FB is **not** suited for use in controllers, due to the relatively coarse grading.

The FB is called once for each channel in the initialisation of the application program. For this, the input INIT must be set to TRUE. During initialisation, the parameter FREQUENCY is also assigned.

### NOTE

The value FREQUENCY must be identical for the channels 4...11.

For these channels, *PWM* (→ page [167](#)) and PWM100 must not be mixed.


The PWM frequency is limited to 5 kHz internally.

During cyclical processing of the program INIT is set to FALSE. The FB is called and the new PWM value is assigned. The value is adopted if the input CHANGE = TRUE.

A current measurement for the initialised PWM channel can be implemented:

- via *OUTPUT\_CURRENT* (→ page [164](#))
- or for example using the ifm unit EC2049 (series element for current measurement).

DITHER is called once for each channel during initialisation of the application program. When doing so, input INIT must be set to TRUE. During initialisation, the value FREQUENCY for determining the dither frequency and the dither value (VALUE) are transmitted.

 The parameters DITHER\_FREQUENCY and DITHER\_VALUE can be individually set for each channel.

## Parameters of the inputs

20463

Parameter	Data type	Description
INIT	BOOL	FALSE $\Rightarrow$ TRUE (edge): unit is initialised FALSE: during further processing of the program
FREQUENCY	WORD	PWM frequency in [Hz] allowed = 20...250 = 0x0014...0x00FA
CHANNEL	BYTE	Number of the PWM output channel (0...15) 0...3 for the outputs Q10...Q13 4...7 for the outputs Q20...Q23 8...15 for the outputs Q40...Q47
VALUE	BYTE	current PWM value
CHANGE	BOOL	TRUE: Adopting new value from ... • VALUE: after the current PMW period • DITHER_VALUE: after the current Dither period FALSE: the changed PWM value has no influence on the output
DITHER_VALUE	BYTE	peak-to-peak value of the dither in [%] permissible values = 0...100 = 0x00...0x64
DITHER_FREQUENCY	WORD	dither frequency in [Hz] value range = 0...FREQUENCY / 2 FREQUENCY / DITHER_FREQUENCY must be even-numbered! The FB increases all other values to the next matching value.


## PWM1000

20465

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

### Symbol in CODESYS:



### Description

20466

PWM1000 handles the initialisation and parameter setting of the PWM outputs.

The FB enables a simple use of the PWM FB in the *ecomatmobile* device. The PWM frequency can be directly indicated in [Hz] and the mark-to-space ratio in steps of 1 %.

The FB is called once for each channel during initialisation of the application program. When doing so, input INIT must be set to TRUE. During initialisation, the parameter FREQUENCY is also assigned.

### NOTE

The value FREQUENCY must be identical for the channels 4...11.

For these channels, *PWM* (→ page [167](#)) and PWM1000 must not be mixed.

The PWM frequency is limited to 5 kHz internally.

During cyclical processing of the program INIT is set to FALSE. The FB is called and the new PWM value is assigned. The value is adopted if the input CHANGE = TRUE.

A current measurement for the initialised PWM channel can be implemented:

- via *OUTPUT\_CURRENT* (→ page [164](#))
- or for example using the ifm unit EC2049 (series element for current measurement).

DITHER is called once for each channel during initialisation of the application program. When doing so, input INIT must be set to TRUE. During initialisation, the value FREQUENCY for determining the dither frequency and the dither value (VALUE) are transmitted.

! The parameters DITHER\_FREQUENCY and DITHER\_VALUE can be individually set for each channel.

## Parameters of the inputs

20471

Parameter	Data type	Description
INIT	BOOL	FALSE $\Rightarrow$ TRUE (edge): unit is initialised FALSE: during further processing of the program
FREQUENCY	WORD	PWM frequency in [Hz] allowed = 20...250 = 0x0014...0x00FA
CHANNEL	BYTE	Number of the PWM output channel (0...15) 0...3 for the outputs Q10...Q13 4...7 for the outputs Q20...Q23 8...15 for the outputs Q40...Q47
VALUE	WORD	PWM value (mark-to-space ratio) in [%] allowed = 0...1 000 = 0x0000...0x03E8 Values > 1 000 are regarded as = 1 000
CHANGE	BOOL	TRUE: adoption of the new value of ... • FREQUENCY: after the current PWM period • VALUE: after the current PWM period • DITHER_VALUE: after the current dither period • DITHER_FREQUENCY: after the current dither period FALSE: the changed PWM value has no influence on the output
DITHER_VALUE	WORD	peak-to-peak value of the dither in [%] permissible values = 0...1 000 = 0000...03E8
DITHER_FREQUENCY	WORD	dither frequency in [Hz] value range = 0...FREQUENCY / 2 FREQUENCY / DITHER_FREQUENCY must be even-numbered! The FB increases all other values to the next matching value.

## 5.2.12 Function elements: hydraulic control

Inhalt	
CONTROL_OCC .....	176
JOYSTICK_0 .....	179
JOYSTICK_1 .....	182
JOYSTICK_2 .....	186
NORM_HYDRAULIC .....	189

19540

The library `ifm_hydraulic_16bitS05_Vxxyzz.LIB` contains the following function blocks:

<b>CONTROL_OCC</b> (→ page <a href="#">176</a> )	OCC = Output Current Control Scales the input value [WORD] to an indicated current range
<b>JOYSTICK_0</b> (→ page <a href="#">179</a> )	Scales signals [INT] from a joystick to clearly defined characteristic curves, standardised to 0... 1000
<b>JOYSTICK_1</b> (→ page <a href="#">182</a> )	Scales signals [INT] from a joystick D standardised to 0... 1000
<b>JOYSTICK_2</b> (→ page <a href="#">186</a> )	Scales signals [INT] from a joystick to a configurable characteristic curve; free selection of the standardisation
<b>NORM_HYDRAULIC</b> (→ page <a href="#">189</a> )	Normalises a value [DINT] within defined limits to a value with new limits

The following function blocks are needed from the library `UTIL.Lib` (in the CODESYS package):

- RAMP\_INT
- CHARCURVE

These function blocks are automatically called and configured by the function blocks of the hydraulics library.

The following function blocks are needed from the library: `ifm_CR0020_Vxxyzz.LIB`

<b>OUTPUT_CURRENT</b> (→ page <a href="#">164</a> )	Measures the current (average via dither period) on an output channel
<b>OUTPUT_CURRENT_CONTROL</b> (→ page <a href="#">165</a> )	Current controller for a PWMi output channel

These function blocks are automatically called and configured by the function blocks of the hydraulics library.


## CONTROL\_OCC

6245

Unit type = function block (FB)

Unit is contained in the library ifm\_HYDRAULIC\_16bit0505\_Vxxyzz.Lib

Symbol in CODESYS:



### Description

600

CONTROL\_OCC scales the input value X to a specified current range.

Each instance of the FB is called once in each PLC cycle. The FB uses **OUTPUT\_CURRENT\_CONTROL** (→ page 165) and **OUTPUT\_CURRENT** (→ page 164) from the library ifm\_CR0020\_Vxxyzz.LIB. The controller is designed as an adaptive controller so that it is self-optimising.


If this self-optimising performance is not desired, a value > 0 can be transferred via the input MANUAL: → the self-optimising performance is deactivated.

The numerical value in MANUAL represents a compensation value, which has an influence on the integral and differential components of the controller. To determine the best settings of the controller in the MANUAL mode, the value 50 is suitable.

Increase the value MANUAL: → controller becomes more sensitive / faster

Decrease the value MANUAL: → controller becomes less sensitive / slower


If the input MANUAL is set to "0", the controller is always self-optimising. The performance of the controlled system is permanently monitored and the updated compensation values are automatically and permanently stored in each cycle. Changes in the controlled system are immediately recognised and corrected.

 The input X of CONTROL\_OCC should be supplied by the output of the JOYSTICK FBs.



## Parameters of the inputs

6247

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
INIT	BOOL	FALSE ⇒ TRUE (edge): unit is initialised FALSE: during further processing of the program
R_RAMP	INT	Rising edge of the ramp in [increments/PLC cycle] or [increments/TIMEBASE] 0 = without ramp
F_RAMP	INT	Falling edge of the ramp in [increments/PLC cycle] or [increments/TIMEBASE] 0 = without ramp
TIMEBASE	TIME	Reference for rising and falling edge of the ramp: t#0s = rising/falling edge in [increments/PLC cycle]  Fast controllers have very short cycle times! otherwise = rising/falling edge in [increments/TIMEBASE]
X	WORD	input value
XH	WORD	Upper limit of input value range [increments]
XL	WORD	Lower limit of input value range [increments]
MAX_CURRENT	WORD	Max. valve current in [mA]
MIN_CURRENT	WORD	Min. valve current in [mA]
TOLERANCE	BYTE	Tolerance for min. valve current in [increments] When the tolerance is exceeded, jump to MIN_CURRENT is effected
CHANNEL	BYTE	Number of the current-controlled output channel (0...7) 0...3 for the outputs Q10...Q13 4...7 for the outputs Q20...Q23
PWM_FREQUENCY	WORD	PWM frequency [Hz] for load on input
DITHER_FREQUENCY	WORD	dither frequency in [Hz] value range = 0...FREQUENCY / 2 FREQUENCY / DITHER_FREQUENCY must be even-numbered! The FB increases all other values to the next matching value.
DITHER_VALUE	BYTE	peak-to-peak value of the dither in [%] permissible values = 0...100 = 0x00...0x64
MODE	BYTE	Controller characteristics: 0 = very slow increase, no overshoot 1 = slow increase, no overshoot 2 = minimum overshoot 3 = moderate overshoot permissible
MANUAL	BYTE	Value = 0: the controller operates in a self-optimising way Value > 0: the self-optimising performance of the closed-loop controller is overwritten (typical: 50)

## Parameters of the outputs

602

Parameter	Data type	Description
DESIRED_CURRENT	WORD	Desired current value in [mA] for OCC (for monitoring purposes)
ACTUAL_CURRENT	WORD	Output current in [mA]
BREAK	BOOL	Error: cable interrupted at output
SHORT	BOOL	Error: short circuit in cable at output


## JOYSTICK\_0

13224

Unit type = function block (FB)

Unit is contained in the library `ifm_hydraulic_16bit0S05_Vxxyyzz.Lib`

**Symbol in CODESYS:**



### Description


432

JOYSTICK\_0 scales signals from a joystick to clearly defined characteristic curves, standardised to 0...1000.


For this FB the characteristic curve values are specified (→ figures):




- Rising edge of the ramp = 5 increments/PLC cycle  
! Fast Controllers have a very short cycle time!
- Falling edge of the ramp = no ramp

The parameters XL\_POS (XL+), XH\_POS (XH+), XL\_NEG (XL-) and XH\_NEG (XH-) are used to evaluate the joystick movements only in the requested area.  
 The values for the positive and negative area may be different.  
 The values for XL\_NEG and XH\_NEG are negative here.



Mode 0:  
 characteristic curve linear for the range XL to XH



<p>Mode 1: Characteristic curve linear with dead band Values fixed to: Dead band: 0...10% of 1000 increments</p>	
<p>Mode 2: 2-step linear characteristic curve with dead band Values fixed to: Dead band: 0...10% of 1000 increments Step: X = 50 % of 1000 increments Y = 20 % of 1000 increments</p>	
<p>Characteristic curve mode 3: Curve rising (line is fixed)</p>	

## Parameters of the inputs

433

Parameter	Data type	Description
X	INT	Input value [increments]
XH_POS	INT	Max. preset value positive direction [increments] (negative values also permissible)
XL_POS	INT	Min. preset value positive direction [increments] (negative values also permissible)
XH_NEG	INT	Max. preset value negative direction [increments] (negative values also permissible)
XL_NEG	INT	Min. preset value negative direction [increments] (negative values also permissible)
MODE	BYTE	Mode selection characteristic curve: 0 = linear $(X OUT = 0 0 \dots 1000 1000)$ 1 = linear with dead band $(X OUT = 0 0 \dots 100 0 \dots 1000 1000)$ 2 = 2-step linear with dead band $(X OUT = 0 0 \dots 100 0 \dots 500 200 \dots 1000 1000)$ 3 = curve rising (line is fixed)

## Parameters of the outputs

6252

Parameter	Data type	Description
OUT1	WORD	Standardised output value: 0...1000 increments e.g. for valve left
OUT2	WORD	Standardised output value: 0...1000 increments e.g. for valve right
OUT3	INT	Standardised output value: -1000...0...1000 increments e.g. for valve on output module (e.g. CR2011 or CR2031)
WRONG_MODE	BOOL	Error: invalid mode
ERR1	BYTE	Error code for rising edge (referred to the internally used function blocks CHARCURVE and RAMP_INT from <code>util.lib</code> ) (possible messages → following table)
ERR2	BYTE	Error code for falling edge (referred to the internally used function blocks CHARCURVE and RAMP_INT from <code>util.lib</code> ) (possible messages → following table)

### Possible results for ERR1 and ERR2:

Value dec   hex	Description
0   00	no error
1   01	Error in array: wrong sequence
2   02	Error: Input value IN is not contained in value range of array
4   04	Error: invalid number N for array


## JOYSTICK\_1

13227

Unit type = function block (FB)

Unit is contained in the library ifm\_hydraulic\_16bit0S05\_Vxxyzz.Lib

Symbol in CODESYS:






### Description

425

JOYSTICK\_1 scales signals from a joystick to configurable characteristic curves, standardised to 0...1000.


For this FB the characteristic curve values can be configured (→ figures):



<p>Mode 2: 2-step linear characteristic curve with dead band</p> <p>Values can be configured to:</p> <p>Dead band: 0...DB in % of 1000 increments</p> <p>Step: X = CPX in % of 1000 increments Y = CPY in % of 1000 increments</p> <p>100 % = 1000 increments DB = Dead_Band CPX = Change_Point_X CPY = Change_Point_Y</p>	 <p>The graph shows the output (OUT) versus input (X) for Mode 2. The y-axis is labeled 'OUT' and has a mark at 100%. The x-axis is labeled 'X' and has marks at DB, CPX, and 100%. The curve starts at the origin (0,0), remains at zero until the dead band (DB) is reached, then rises linearly through the point (CPX, CPY) to the point (100%, 100%).</p>
<p>Characteristic curve mode 3: Curve rising (line is fixed)</p>	 <p>The graph shows the output (OUT) versus input (X) for Mode 3. The y-axis is labeled 'OUT' and has a mark at 100%. The x-axis is labeled 'X' and has a mark at 100%. The curve starts at the origin (0,0) and rises in a non-linear, concave-up fashion to the point (100%, 100%).</p>

## Parameters of the inputs

6256

Parameter	Data type	Description
X	INT	Input value [increments]
XH_POS	INT	Max. preset value positive direction [increments] (negative values also permissible)
XL_POS	INT	Min. preset value positive direction [increments] (negative values also permissible)
XH_NEG	INT	Max. preset value negative direction [increments] (negative values also permissible)
XL_NEG	INT	Min. preset value negative direction [increments] (negative values also permissible)
R_RAMP	INT	Rising edge of the ramp in [increments/PLC cycle] 0 = no ramp
F_RAMP	INT	Falling edge of the ramp in [increments/PLC cycle] 0 = no ramp
TIMEBASE	TIME	Reference for rising and falling edge of the ramp: t#0s = rising/falling edge in [increments/PLC cycle]  Fast controllers have very short cycle times! otherwise = rising/falling edge in [increments/TIMEBASE]
MODE	BYTE	Mode selection characteristic curve: 0 = linear (X OUT = 0 0 ... 1000 1000) 1 = linear with dead band (X OUT = 0 0 ... DB 0 ... 1000 1000) 2 = 2-step linear with dead band (X OUT = 0 0 ... DB 0 ... CPX CPY ... 1000 1000) 3 = curve rising (line is fixed)
DEAD_BAND	BYTE	Adjustable dead band in [% of 1000 increments]
CHANGE_POINT_X	BYTE	For mode 2: ramp step, value for X in [% of 1000 increments]
CHANGE_POINT_Y	BYTE	For mode 2: ramp step, value for Y in [% of 1000 increments]



## Parameters of the outputs

6252

Parameter	Data type	Description
OUT1	WORD	Standardised output value: 0...1000 increments e.g. for valve left
OUT2	WORD	Standardised output value: 0...1000 increments e.g. for valve right
OUT3	INT	Standardised output value -1000...0...1000 increments e.g. for valve on output module (e.g. CR2011 or CR2031)
WRONG_MODE	BOOL	Error: invalid mode
ERR1	BYTE	Error code for rising edge (referred to the internally used function blocks CHARCURVE and RAMP_INT from <b>util.lib</b> ) (possible messages → following table)
ERR2	BYTE	Error code for falling edge (referred to the internally used function blocks CHARCURVE and RAMP_INT from <b>util.lib</b> ) (possible messages → following table)

Possible results for ERR1 and ERR2:

Value dec   hex		Description
0	00	no error
1	01	Error in array: wrong sequence
2	02	Error: Input value IN is not contained in value range of array
4	04	Error: invalid number N for array


## JOYSTICK\_2

13228

Unit type = function block (FB)

Unit is contained in the library ifm\_hydraulic\_16bit0S05\_Vxxyyzz.Lib

Symbol in CODESYS:




### Description

418

JOYSTICK\_2 scales the signals from a joystick to a configurable characteristic curve. Free selection of the standardisation.

For this FB, the characteristic curve is freely configurable (→ figure):



## Parameters of the inputs

6261

Parameter	Data type	Description
X	INT	Input value [increments]
XH_POS	INT	Max. preset value positive direction [increments] (negative values also permissible)
XL_POS	INT	Min. preset value positive direction [increments] (negative values also permissible)
XH_NEG	INT	Max. preset value negative direction [increments] (negative values also permissible)
XL_NEG	INT	Min. preset value negative direction [increments] (negative values also permissible)
R_RAMP	INT	Rising edge of the ramp in [increments/PLC cycle] 0 = no ramp
F_RAMP	INT	Falling edge of the ramp in [increments/PLC cycle] 0 = no ramp
TIMEBASE	TIME	Reference for rising and falling edge of the ramp: t#0s = rising/falling edge in [increments/PLC cycle] <b>!</b> Fast controllers have very short cycle times! otherwise = rising/falling edge in [increments/TIMEBASE]
VARIABLE_GAIN	ARRAY [0..10] OF POINT	Pairs of values describing the curve The first pairs of values indicated in N_POINT are used. n = 2...11 <b>Example:</b> 9 pairs of values declared as variable VALUES: VALUES : ARRAY [0..10] OF POINT := (X:=0,Y:=0), (X:=200,Y:=0), (X:=300,Y:=50), (X:=400,Y:=100), (X:=700,Y:=500), (X:=1000,Y:=900), (X:=1100,Y:=950), (X:=1200,Y:=1000), (X:=1400,Y:=1050); There may be blanks between the values.
N_POINT	BYTE	Number of points (pairs of values in VARIABLE_GAIN) by which the curve characteristic is defined: n = 2...11

## Parameters of the outputs

420

Parameter	Data type	Description
OUT1	WORD	Standardised output value: 0...1000 increments e.g. for valve left
OUT2	WORD	Standardised output value: 0...1000 increments e.g. for valve right
OUT3	INT	Standardised output value -1000...0...1000 increments e.g. for valve on output module (e.g. CR2011 or CR2031)
ERR1	BYTE	Error code for rising edge (referred to the internally used function blocks CHARCURVE and RAMP_INT from <code>util.lib</code> ) (possible messages → following table)
ERR2	BYTE	Error code for falling edge (referred to the internally used function blocks CHARCURVE and RAMP_INT from <code>util.lib</code> ) (possible messages → following table)

Possible results for ERR1 and ERR2:

Value dec   hex		Description
0	00	no error
1	01	Error in array: wrong sequence
2	02	Error: Input value IN is not contained in value range of array
4	04	Error: invalid number N for array


## NORM\_HYDRAULIC

13232

Unit type = function block (FB)

Unit is contained in the library ifm\_hydraulic\_16bit0S05\_Vxxyyzz.Lib

Symbol in CODESYS:



### Description

397


NORM\_HYDRAULIC standardises input values with fixed limits to values with new limits.

 This function block corresponds to NORM\_DINT from the CODESYS library UTIL.Lib.

The function block standardises a value of type DINT, which is within the limits of XH and XL, to an output value within the limits of YH and YL.

Due to rounding errors deviations from the standardised value of 1 may occur. If the limits (XH/XL or YH/YL) are indicated in inversed form, standardisation is also inversed.

If X is outside the limits of XL...XH, the error message will be X\_OUT\_OF\_RANGE = TRUE.



## Parameters of the inputs

398

Parameter	Data type	Description
X	DINT	current input value
XH	DINT	Max. input value [increments]
XL	DINT	Min. input value [increments]
YH	DINT	Max. output value [increments], e.g.: valve current [mA] / flow [l/min]
YL	DINT	Min. output value [increments], e.g.: valve current [mA], flow [l/min]

## Parameters of the outputs

399

Parameter	Data type	Description
Y	DINT	output value
X_OUT_OF_RANGE	BOOL	Error: X is beyond the limits of XH and XL

## Example: NORM\_HYDRAULIC

400

Parameter	Case 1	Case 2	Case 3
Upper limit value input XH	100	100	2000
Lower limit value input XL	0	0	0
Upper limit value output YH	2000	0	100
Lower limit value output YL	0	2000	0
Non standardised value X	20	20	20
Standardised value Y	400	1600	1

- Case 1:  
Input with relatively coarse resolution.  
Output with high resolution.  
1 X increment results in 20 Y increments.
- Case 2:  
Input with relatively coarse resolution.  
Output with high resolution.  
1 X increment results in 20 Y increments.  
Output signal is inverted as compared to the input signal.
- Case 3:  
Input with high resolution.  
Output with relatively coarse resolution.  
20 X increments result in 1 Y increment.

## 5.2.13 Function elements: controllers

### Inhalt

Setting rule for a controller .....	191
DELAY .....	192
GLR .....	193
PID1 .....	195
PID2 .....	197
PT1 .....	199

1634

The section below describes in detail the units that are provided for set-up by software controllers in the *ecomatmobile* device. The units can also be used as basis for the development of your own control functions.

### Setting rule for a controller

1627

For controlled systems, whose time constants are unknown the setting procedure to Ziegler and Nickols in a closed control loop is of advantage.

### Setting control

1628

At the beginning the controlling system is operated as a purely P-controlling system. In this respect the derivative time  $T_V$  is set to 0 and the reset time  $T_N$  to a very high value (ideally to  $\infty$ ) for a slow system. For a fast controlled system a small  $T_N$  should be selected.

Afterwards the gain  $K_P$  is increased until the control deviation and the adjustment deviation perform steady oscillation at a constant amplitude at  $K_P = K_{P_{critical}}$ . Then the stability limit has been reached.

Then the time period  $T_{critical}$  of the steady oscillation has to be determined.

Add a differential component only if necessary.

$T_V$  should be approx. 2...10 times smaller than  $T_N$ .

$K_P$  should be equal to  $K_D$ .

Idealised setting of the controlled system:

Control unit	$K_P = K_D$	$T_N$	$T_V$
P	$2.0 \cdot K_{P_{critical}}$	—	—
PI	$2.2 \cdot K_{P_{critical}}$	$0.83 \cdot T_{critical}$	—
PID	$1.7 \cdot K_{P_{critical}}$	$0.50 \cdot T_{critical}$	$0.125 \cdot T_{critical}$

**!** For this setting process it has to be noted that the controlled system is not harmed by the oscillation generated. For sensitive controlled systems  $K_P$  must only be increased to a value at which no oscillation occurs.

### Damping of overshoot

1629

To dampen overshoot *PT1* (→ page 199) (low pass) can be used. In this respect the preset value  $X_S$  is damped by the PT1 link before it is supplied to the controller function.

The setting variable  $T_1$  should be approx. 4...5 times greater than  $T_N$  of the controller.

DELAY

585

Unit type = function block (FB)  
Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

Symbol in CODESYS:



Description

588

DELAY delays the output of the input value by the time T (dead-time element).




Figure: Time characteristics of DELAY

The dead time is influenced by the duration of the PLC cycle.  
The dead time may not exceed 100 • PLC cycle time (memory limit!).  
In case a longer delay is set, the resolution of the values at the output of the FB will be poorer, which may cause that short value changes will be lost.

**!** To ensure that the FB works correctly: FB must be called in each cycle.

Parameters of the inputs

589

Parameter	Data type	Description
X	WORD	input value
T	TIME	Delay time (dead time) allowed: 0...100 • cycle time

Parameters of the outputs

590

Parameter	Data type	Description
Y	WORD	input value, delayed by the time T




## GLR

531

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyyzz.LIB

### Symbol in CODESYS:



### Description

534

GLR handles a synchro controller.

The synchro controller is a controller with PID characteristics.

The values entered at the inputs KP and KD are internally divided by 10. So, a finer grading can be obtained (e.g.: KP = 17, which corresponds to 1.7).

The manipulated variable referred to the greater actual value is increased accordingly.

The manipulated variable referred to the smaller actual value corresponds to the reference variable.

Reference variable =  $65\,536 - (XS / XMAX * 65\,536)$ .

### NOTE

The manipulated variables Y1 and Y2 are already standardised to the PWM FB (RELOAD value = 65 535). Note the reverse logic:

65 535 = minimum value

0 = maximum value.

Note that the input value KD depends on the cycle time. To obtain stable, repeatable control characteristics, the FB should be called in a time-controlled manner.

## Parameters of the inputs

535

Parameter	Data type	Description
X1	WORD	actual value channel 1
X2	WORD	actual value channel 2
XS	WORD	preset value
XMAX	WORD	maximum preset value
KP	Byte	constant of the proportional component (/10) (positive values only!)
TN	TIME	integral action time (integral component)
KD	BYTE	differential component (/10) (positive values only!)
TV	TIME	derivative action time (differential component)
RESET	BOOL	TRUE: reset the function element FALSE: function element is not executed

## Parameters of the outputs

536

Parameter	Data type	Description
Y1	WORD	manipulated variable channel 1
Y2	WORD	manipulated variable channel 2


## PID1

351

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

### Symbol in CODESYS:



### Description

354

PID1 handles a PID controller.

The change of the manipulated variable of a PID controller has a proportional, integral and differential component. The manipulated variable changes first by an amount which depends on the rate of change of the input value (D component). After the end of the derivative action time the manipulated variable returns to the value corresponding to the proportional range and changes in accordance with the reset time.

### NOTE

The manipulated variable Y is already standardised to the PWM FB (RELOAD value = 65,535). Note the reverse logic:

65,535 = minimum value

0 = maximum value.

Note that the input values KI and KD depend on the cycle time. To obtain stable, repeatable control characteristics, the FB should be called in a time-controlled manner.

If  $X > X_S$ , the manipulated variable is increased.

If  $X < X_S$ , the manipulated variable is reduced.

The manipulated variable Y has the following time characteristics:




Figure: Typical step response of a PID controller

## Parameters of the inputs

355

Parameter	Data type	Description
X	WORD	input value
XS	WORD	preset value
XMAX	WORD	maximum preset value
KP	BYTE	proportional component of the output signal
KI	BYTE	integral component of the output signal
KD	BYTE	differential component of the output signal

## Parameters of the outputs

356

Parameter	Data type	Description
Y	WORD	Manipulated variable (0...1000 ‰)

## Recommended settings

357

KP = 50

KI = 30

KD = 5

With the values indicated above the controller operates very quickly and in a stable way. The controller does not fluctuate with this setting.

- To optimise the controller, the values can be gradually changed afterwards.


## PID2

9167

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

### Symbol in CODESYS:



### Description

347

PID2 handles a PID controller with self optimisation.

The change of the manipulated variable of a PID controller has a proportional, integral and differential component. The manipulated variable changes first by an amount which depends on the rate of change of the input value (D component). After the end of the derivative action time TV the manipulated variable returns to the value corresponding to the proportional component and changes in accordance with the reset time TN.

The values entered at the inputs KP and KD are internally divided by 10. So, a finer grading can be obtained (e.g.: KP = 17, which corresponds to 1.7).

### NOTE

The manipulated variable Y is already standardised to the PWM FB (RELOAD value = 65,535). Note the reverse logic:

65,535 = minimum value

0 = maximum value.

Note that the input value KD depends on the cycle time. To obtain stable, repeatable control characteristics, the FB should be called in a time-controlled manner.

If  $X > X_S$ , the manipulated variable is increased.

If  $X < X_S$ , the manipulated variable is reduced.

A reference variable is internally added to the manipulated variable.

$$Y = Y + 65,536 - (X_S / X_{MAX} * 65,536).$$

The manipulated variable Y has the following time characteristics.




Figure: Typical step response of a PID controller

## Parameters of the inputs

348

Parameter	Data type	Description
X	WORD	input value
XS	WORD	preset value
XMAX	WORD	maximum preset value
KP	Byte	constant of the proportional component (/10) (positive values only!)
TN	TIME	integral action time (integral component)
KD	BYTE	differential component (/10) (positive values only!)
TV	TIME	derivative action time (differential component)
SO	BOOL	TRUE: self-optimisation active FALSE: self-optimisation not active
RESET	BOOL	TRUE: reset the function element FALSE: function element is not executed

## Parameters of the outputs

349

Parameter	Data type	Description
Y	WORD	Manipulated variable (0...1000 ‰)

## Recommended setting

9127  
350

- Select TN according to the time characteristics of the system:  
fast system = small TN  
slow system = large TN
- Slowly increment KP gradually, up to a value at which still definitely no fluctuation will occur.
- Readjust TN if necessary.
- Add differential component only if necessary:  
Select a TV value approx. 2...10 times smaller than TN.  
Select a KD value more or less similar to KP.

Note that the maximum control deviation is + 127. For good control characteristics this range should not be exceeded, but it should be exploited to the best possible extent.

Function input SO (self-optimisation) clearly improves the control performance. A precondition for achieving the desired characteristics:

- The controller is operated with I component ( $TN \geq 50 \text{ ms}$ )
- Parameters KP and especially TN are already well adjusted to the actual controlled system.
- The control range ( $X - XS$ ) of  $\pm 127$  is utilised (if necessary, increase the control range by multiplying X, XS and XMAX).
- When you have finished setting the parameters, you can set SO = TRUE.
- > This will significantly improve the control performance, especially reducing overshoot.

PT1

338

Unit type = function block (FB)  
Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB


Symbol in CODESYS:



Description

341

PT1 handles a controlled system with a first-order time delay.  
This FB is a proportional controlled system with a time delay. It is for example used for generating ramps when using the PWM FBs.

 The output of the FB can become instable if T1 is shorter than the SPS cycle time.

The output variable Y of the low-pass filter has the following time characteristics (unit step):




Figure: Time characteristics of PT1

Parameters of the inputs

342

Parameter	Data type	Description
X	INT	Input value [increments]
T1	TIME	Delay time (time constant)

Parameters of the outputs

343

Parameter	Data type	Description
Y	INT	output value

## 5.2.14 Function elements: software reset

### Inhalt

SOFTRESET .....	201
-----------------	-----

1594

Using this FB the control can be restarted via an order in the application program.



## SOFTRESET

260

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

**Symbol in CODESYS:**



### Description

263

SOFTRESET leads to a complete reboot of the device.

The FB can for example be used in conjunction with CANopen if a node reset is to be carried out. FB SOFTRESET executes an immediate reboot of the controller. The current cycle is not completed.

Before reboot, the retain variables are stored.

The reboot is logged in the error memory.

**!** In case of active communication: the long reset period must be taken into account because otherwise guarding errors will be signalled.

### Parameters of the inputs

264

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified

## 5.2.15 Function elements: measuring / setting of time

### Inhalt

TIMER_READ .....	203
TIMER_READ_US .....	204

1601

Using the following function blocks of **ifm electronic** you can...

- measure time and evaluate it in the application program,
- change time values, if required.

## TIMER\_READ

236

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

**Symbol in CODESYS:**



### Description

239

TIMER\_READ reads the current system time.

When the supply voltage is applied, the device generates a clock pulse which is counted upwards in a register. This register can be read using the FB call and can for example be used for time measurement.

**!** The system timer goes up to 0xFFFF FFFF at the maximum (corresponds to 49d 17h 2min 47s 295ms) and then starts again from 0.

### Parameters of the outputs

241

Parameter	Data type	Description
T	TIME	Current system time [ms]

## TIMER\_READ\_US

657

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

### Symbol in CODESYS:



### Description

660

TIMER\_READ\_US reads the current system time in [µs].

When the supply voltage is applied, the device generates a clock pulse which is counted upwards in a register. This register can be read by means of the FB call and can for example be used for time measurement.



### Info

The system timer runs up to the counter value 4 294 967 295 µs at the maximum and then starts again from 0.

4 294 967 295 µs = 1h 11min 34s 967ms 295µs

### Parameters of the outputs

662

Parameter	Data type	Description
TIME_US	DWORD	current system time [µs]

## 5.2.16 Function elements: saving, reading and converting data in the memory

### Inhalt

Storage types for data backup .....	205
Automatic saving of data .....	206
Manual data storage.....	208

13795

### Storage types for data backup

13805

The device provides the following memory types:

#### Flash memory

13803

Properties:

- non-volatile memory
- writing is relatively slow and only block by block
- before re-writing, memory content must be deleted
- fast reading
- limited writing and reading frequency
- really useful only for storing large data quantities
- secure data with FLASHWRITE
- read data with FLASHREAD

#### FRAM memory

13802

FRAM indicates here all kinds of non-volatile and fast memories.

Properties:

- fast writing and reading
- unlimited writing and reading frequency
- any memory area can be selected
- secure data with FRAMWRITE
- read data with FRAMREAD

## Automatic saving of data

### Inhalt

MEMORY_RETAIN_PARAM .....	207
---------------------------	-----

2347

The *ecomatmobile* controllers allow to save data (BOOL, BYTE, WORD, DWORD) non-volatilely (= saved in case of voltage failure) in the memory. If the supply voltage drops, the backup operation is automatically started. Therefore it is necessary that the data is defined as RETAIN variables (→ CODESYS).

A distinction is made between variables declared as RETAIN and variables in the flag area which can be configured as a remanent block with *MEMORY\_RETAIN\_PARAM* (→ page [207](#)).


Details → chapter *Variables* (→ page [73](#))

The advantage of the automatic backup is that also in case of a sudden voltage drop or an interruption of the supply voltage, the storage operation is triggered and thus the current values of the data are saved (e.g. counter values).

**MEMORY\_RETAIN\_PARAM**

2372

Unit type = function block (FB)

Unit is contained in the library `ifm_CR0020_Vxxyzz.LIB`**Symbol in CODESYS:****Description**

2374

MEMORY\_RETAIN\_PARAM determines the remanent data behaviour for various events. Variables declared as VAR\_RETAIN in CODESYS have a remanent behaviour from the outset.

Remanent data keep their value (as the variables declared as VAR\_RETAIN) after an uncontrolled termination as well as after normal switch off and on of the controller. After a restart the program continues to work with the stored values.

For groups of events that can be selected (with MODE), this function block determines how many (LEN) data bytes (from flag byte %MB0) shall have retain behaviour even if they have not been explicitly declared as VAR\_RETAIN.

Event	MODE = 0	MODE = 1	MODE = 2	MODE = 3
Power OFF ⇒ ON	Data is newly initialised	Data is remanent	Data is remanent	Data is remanent
Soft reset	Data is newly initialised	Data is remanent	Data is remanent	Data is remanent
Cold reset	Data is newly initialised	Data is newly initialised	Data is remanent	Data is remanent
Reset default	Data is newly initialised	Data is newly initialised	Data is remanent	Data is remanent
Load application program	Data is newly initialised	Data is newly initialised	Data is remanent	Data is remanent
Load runtime system	Data is newly initialised	Data is newly initialised	Data is newly initialised	Data is remanent

If MODE = 0, only those data have retain behaviour as with MODE=1 which have been explicitly declared as VAR\_RETAIN.

If the FB is never called, the flag bytes act according to MODE = 0. The flag bytes which are above the configured area act according to MODE = 0, too.

Once a configuration has been made, it remains on the device even if the application or the runtime system is reloaded.

**Parameters of the inputs**

2375

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
LEN	WORD	Number of data bytes from flag address %MB0 onwards to show remanent behaviour allowed = 0...4 096 = 0x0...0x1000 LEN > 4 096 will be corrected automatically to LEN = 4 096
MODE	BYTE	Events for which these variables shall have retain behaviour (0...3; → table above) For MODE > 3 the last valid setting will remain


## Manual data storage

### Inhalt

FLASHREAD .....	209
FLASHWRITE .....	210
FRAMREAD .....	211
FRAMWRITE .....	212
MEMCPY .....	213

13801

Besides the possibility to store data automatically, user data can be stored manually, via function block calls, in integrated memories from where they can also be read.

 By means of the storage partitioning (→ chapter *Available memory* (→ page [15](#))) the programmer can find out which memory area is available.




## FLASHREAD

561

Unit type = function block (FB)

Unit is contained in the library `ifm_CR0020_Vxxyzz.LIB`

Symbol in CODESYS:



### Description

564

FLASHREAD enables reading of different types of data directly from the flash memory.

- > The FB reads the contents as from the address of SRC from the flash memory. In doing so, as many bytes as indicated under LEN are transmitted.
- > The contents are read completely during the cycle in which the FB is called up.
- ▶ Please make sure that the target memory area in the RAM is sufficient.
- ▶ To the destination address DST applies:
  - ❗ Determine the address by means of the operator ADR and assigne it to the FB!

### Parameters of the inputs

565

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
SRC	WORD	relative source start address in the memory permissible = 0...65 535 = 0x0000...0xFFFF
LEN	WORD	number of data bytes permissible = 0...65 535 = 0x0000...0xFFFF
DST	DWORD	start address of the destination variable ❗ Determine the address by means of the operator ADR and assigne it to the FB!

## FLASHWRITE

555

Unit type = function block (FB)

Unit is contained in the library `ifm_CR0020_Vxxyzz.LIB`

### Symbol in CODESYS:



### Description

558



### WARNING

Danger due to uncontrollable process operations!

The status of the inputs/outputs is "frozen" during execution of FLASHWRITE.

- ▶ Do not execute this FB when the machine is running!

FLASHWRITE enables writing of different data types directly into the flash memory.

Using this FB, large data volumes are to be stored during set-up, to which there is only read access in the process.

- ▶ If a page has already been written (even if only partly), the entire flash memory area needs to be deleted before new write access to this page. This is done by write access to the address 0.
- ▶ Never write to a page several times! Always delete everything first! Otherwise, traps or watchdog errors occur.
- ▶ ⓘ Do not delete the flash memory area more often than 100 times. Otherwise, the data consistency in other flash memory areas is no longer guaranteed.
- ▶ During each SPS cycle, FLASHWRITE may only be started once!
- ▶ To the destination address DST applies:
  - ⓘ Determine the address by means of the operator ADR and assigne it to the FB!
- > The FB writes the contents of the address SRC into the flash memory. In doing so, as many bytes as indicated under LEN are transmitted.

ⓘ If start address SRC is outside the permissible range: no data transfer!

### Parameters of the inputs

559

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
DST	WORD	relative destination start address in the memory permissible = 0...65 535 = 0x0000...0xFFFF
LEN	WORD	number of data bytes permissible = 0...65 535 = 0x0000...0xFFFF
SRC	DWORD	start address of the source variables ⓘ Determine the address by means of the operator ADR and assigne it to the FB!


## FRAMREAD

549

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

Symbol in CODESYS:



### Description

552

FRAMREAD enables quick reading of different data types directly from the FRAM memory <sup>1)</sup>.

The FB reads the contents as from the address of SRC from the FRAM memory. In doing so, as many bytes as indicated under LEN are transmitted.

If the FRAM memory area were to be exceeded by the indicated number of bytes, only the data up to the end of the FRAM memory area will be read.

► To the destination address DST applies:

**!** Determine the address by means of the operator ADR and assigne it to the FB!

<sup>1)</sup> FRAM indicates here all kinds of non-volatile and fast memories.

### Parameters of the inputs

553

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
SRC	WORD	relative source start address in the memory zulässig = 0...1 023 = 0x0000...0x03FF
LEN	WORD	number of data bytes
DST	DWORD	start address of the destination variable <b>!</b> Determine the address by means of the operator ADR and assigne it to the FB!

## FRAMWRITE

543

Unit type = function block (FB)

Unit is contained in the library `ifm_CR0020_Vxxyzz.LIB`

### Symbol in CODESYS:



### Description

546

FRAMWRITE enables the quick writing of different data types directly into the FRAM memory <sup>1)</sup>.

The FB writes the contents of the address SRC to the non-volatile FRAM memory. In doing so, as many bytes as indicated under LEN are transmitted.

If the FRAM memory area were to be exceeded by the indicated number of bytes, only the data up to the end of the FRAM memory area will be written.

► To the source address SRC applies:

❗ Determine the address by means of the operator ADR and assigne it to the FB!

❗ If the target address DST is outside the permissible range: no data transfer!

<sup>1)</sup> FRAM indicates here all kinds of non-volatile and fast memories.

### Parameters of the inputs

547

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
DST	WORD	relative destination start address in the memory permissible = 0...1 023 = 0x0000...0x03FF
LEN	WORD	number of data bytes
SRC	DWORD	start address of the source variables ❗ Determine the address by means of the operator ADR and assigne it to the FB!

## MEMCPY


409

= memory copy

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

### Symbol in CODESYS:



### Description

412

MEMCPY enables writing and reading different types of data directly in the memory.

The FB writes the contents of the address of SRC to the address DST.

- To the addresses SRC and DST apply:
  - ❗ Determine the address by means of the operator ADR and assigne it to the FB!
- > In doing so, as many bytes as indicated under LEN are transmitted. So it is also possible to transmit exactly one byte of a word variable.

### Parameters of the inputs

413

Parameter	Data type	Description
DST	DWORD	destination address ❗ Determine the address by means of the operator ADR and assigne it to the FB!
SRC	DWORD	Start address in source memory ❗ Determine the address by means of the operator ADR and assigne it to the FB!
LEN	WORD	number ( $\geq 1$ ) of the data bytes to be transmitted

## 5.2.17 Function elements: data access and data check

### Inhalt

CHECK_DATA .....	215
GET_IDENTITY .....	217
SET_DEBUG .....	218
SET_IDENTITY .....	219
SET_PASSWORD .....	220

1598

The FBs described in this chapter control the data access and enable a data check.


## CHECK\_DATA

603

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB


### Symbol in CODESYS:



### Description

606

CHECK\_DATA generates a checksum (CRC) for a configurable memory area and checks the data of the memory area for undesired changes.

- ▶ Create a separate instance of the function block for each memory area to be monitored.
- ▶  Determine the address by means of the operator ADR and assigne it to the FB!
- ▶ In addition, indicate the number of data bytes LENGTH (length from the STARTADR).

Undesired change: Error!


If input UPDATE = FALSE and data in the memory is changed inadvertently, then RESULT = FALSE. The result can then be used for further actions (e.g. deactivation of the outputs).

Desired change:

Data changes in the memory (e.g. of the application program or *ecomatmobile* device) are only permitted if the output UPDATE is set to TRUE. The value of the checksum is then recalculated. The output RESULT is permanently TRUE again.

### Parameters of the inputs

607

Parameter	Data type	Description
STARTADR	DINT	start address of the monitored data memory (WORD address as from %MW0)  Determine the address by means of the operator ADR and assigne it to the FB!
LENGTH	WORD	length of the monitored data memory in [byte]
UPDATE	BOOL	TRUE: changes to data permissible FALSE: changes to data not permitted

### Parameters of the outputs


608

Parameter	Data type	Description
RESULT	BOOL	TRUE: CRC checksum ok FALSE: CRC checksum faulty (data modified)
CHECKSUM	DWORD	current CRC checksum

## Example: CHECK\_DATA

4168

In the following example the program determines the checksum and stores it in the RAM via pointer pt:



**!** The method shown here is not suited for the flash memory.



## GET\_IDENTITY

2212

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

**Symbol in CODESYS:**



### Description

2344

GET\_IDENTITY reads the specific identifications stored in the device:

- hardware name and hardware version of the device
- name of the runtime system in the device
- version and revision no. of the runtime system in the device
- name of the application (has previously been saved by means of *SET\_IDENTITY* (→ page 219))

### Parameters of the inputs

2609

Parameter	Data type	Description
ENABLE	BOOL	<p>TRUE: execute this function element</p> <p>FALSE: unit is not executed</p> <ul style="list-style-type: none"> <li>&gt; Function block inputs are not active</li> <li>&gt; Function block outputs are not specified</li> </ul>

### Parameters of the outputs

2610

Parameter	Data type	Description
DEVICENAME	STRING(31)	hardware name as a string of max. 31 characters, e.g.: "CR0403"
FIRMWARE	STRING(31)	Name of the runtime system in the device as character string of max. 31 characters e.g.: "CR0403"
RELEASE	STRING(31)	software version as a character string of max. 31 characters
APPLICATION	STRING(79)	Name of the application as a string of max. 79 characters e.g.: "Crane1704"

## SET\_DEBUG

290

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxxyzz.LIB

**Symbol in CODESYS:**



### Description

293

SET\_DEBUG handles the DEBUG mode without active test input (→ chapter *TEST mode* (→ page 52)).

If the input DEBUG of the FB is set to TRUE, the programming system or the downloader, for example, can communicate with the device and execute system commands (e.g. for service functions via the GSM modem CANremote).

**!** In this operating mode a software download is not possible because the test input is not connected to supply voltage. Only read access is possible.

### Parameters of the inputs

294

Parameter	Data type	Description
ENABLE	BOOL	TRUE: execute this function element FALSE: unit is not executed > Function block inputs are not active > Function block outputs are not specified
DEBUG	BOOL	TRUE: debugging via the interfaces possible FALSE: debugging via the interfaces not possible

## SET\_IDENTITY

284

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

Symbol in CODESYS:




## Description

287

SET\_IDENTITY sets an application-specific program identification.

Using this FB, a program identification can be created by the application program. This identification (i.e. the software version) can be read via the software tool DOWNLOADER.EXE in order to identify the loaded program.

The following figure shows the correlations of the different identifications as indicated by the different software tools. (Example: ClassicController CR0020):



\*) 'Nozzle in front' is substitutionally here for a customised text.

## Parameters of the inputs

288

Parameter	Data type	Description
ID	STRING(80)	Any text with a maximum length of 80 characters

## SET\_PASSWORD

266

Unit type = function block (FB)

Unit is contained in the library ifm\_CR0020\_Vxyxyz.LIB

**Symbol in CODESYS:**



### Description

269

SET\_PASSWORD sets a user password for the program and memory upload with the DOWNLOADER.

If the password is activated, reading of the application program or the data memory with the software tool DOWNLOADER is only possible if the correct password has been entered.

If an empty string (default condition) is assigned to the input PASSWORD, an upload of the application software or of the data memory is possible at any time.

A new password can be set only after resetting the previous password.

**!** The password is reset when loading a new application program.

### Parameters of the inputs

270

Parameter	Data type	Description
ENABLE	BOOL	TRUE (nur 1 Zyklus lang): use new Parameter FALSE: unit is not executed
PASSWORD	STRING(16)	password If PASSWORD = "", then access is possible without enter of a password

## 6 Diagnosis and error handling

### Inhalt

Diagnosis.....	221
Fault.....	221
Reaction in case of an error .....	222
Relay: important notes! .....	222
Response to system errors .....	223
CAN / CANopen: errors and error handling .....	223

19598

The runtime-system (RTS) checks the device by internal error checks:

- during the boot phase (reset phase)
- during executing the application program

→ chapter **Operating states** (→ page [48](#))

In so doing a high operating reliability is provided, as much as possible.

### 6.1 Diagnosis

19601

During the diagnosis, the "state of health" of the device is checked. It is to be found out if and what → faults are given in the device.

Depending on the device, the inputs and outputs can also be monitored for their correct function.

- wire break,
- short circuit,
- value outside range.

For diagnosis, configuration and log data can be used, created during the "normal" operation of the device.

The correct start of the system components is monitored during the initialisation and start phase.

Errors are recorded in the log file.

For further diagnosis, self-tests can also be carried out.

### 6.2 Fault

19602

A fault is the state of an item characterized by the inability to perform the requested function, excluding the inability during preventive maintenance or other planned actions, or due to lack of external resources.

A fault is often the result of a failure of the item itself, but may exist without prior failure.

In →ISO 13849-1 "fault" means "random fault".

## 6.3 Reaction in case of an error

19603  
12217


When errors are detected the system flag ERROR can also be set in the application program. Thus, in case of a fault, the controller reacts as follows:

- > the operation LED lights red,
- > the output relays switch off,
- > the outputs protected by the relays are disconnected from power,
- > the logic signal states of the outputs remain unchanged.

### **NOTE**

If the outputs are switched off by the relays, the logic signal states remain unchanged.

- ▶ The programmer must evaluate the ERROR bit and thus also reset the output logic in case of a fault.

 Complete list of the device-specific error codes and diagnostic messages  
→ chapter *System flags* (→ page [224](#)).

## 6.4 Relay: important notes!

1446

Using the logic function via the system flag RELAIS or RELAY\_CLAMP\_15 (→ chapter *Latching* (→ page [16](#))) all other outputs are also switched off.

Depending on the application it must now be decided whether by resetting the system flag bit ERROR the relay – and so also the outputs – may be switched on again.

In addition it is also possible to set the system flag bit ERROR as "defined error" by the application program.

### **NOTICE**

Premature wear of the relay contacts possible.

- ▶ Only use this function for a general switch-off of the outputs in case of an "emergency".
- ▶ In normal operation switch off the relays only without load!  
To do so, first switch off the outputs via the application program!

## 6.5 Response to system errors

2258

**!** The programmer has the sole responsibility for the safe processing of data in the application software.

- ▶ Process the specific error flags in the application program!  
An error description is provided via the error flag.  
These error flags can be further processed if necessary.

In case of serious errors the system flag bit ERROR can additionally be set.

At the same time, ERROR = TRUE leads to the following:

- set all relevant outputs to FALSE via the application program,
- the operation LED lights red,
- the ERROR output is set to FALSE and
- the output relays switch off.
- So the outputs protected via these relays are switched off.

After analysis and elimination of the error cause:

- ▶ as a general rule, reset all error flags via the application program.  
Without explicit reset of the error flags the flags remain set with the corresponding effect on the application program.

## 6.6 CAN / CANopen: errors and error handling

19604

- System manual "Know-How *ecomatmobile*"  
→ chapter *CAN / CANopen: errors and error handling*

## 7 Annex

### Inhalt

System flags .....	224
Address assignment and I/O operating modes .....	230
Error tables .....	240

1664

Additionally to the indications in the data sheets you find summary tables in the annex.

## 7.1 System flags

### Inhalt

System flags: CAN .....	225
System flags: SAE J1939 .....	225
System flags: error flags (standard side) .....	226
System flags: LED (standard side) .....	227
System flags: voltages (standard side) .....	228
System flags: 16...40 inputs and 24...0 outputs (standard side) .....	229

12167



The addresses of the system flags can change if the PLC configuration is extended.

- While programming only use the symbol names of the system flags!



→ System manual "Know-How *ecomatmobile*"

→ chapter *Error codes and diagnostic information*



## 7.1.1 System flags: CAN

19555

System flags (symbol name)	Type	Description														
CANx_BAUDRATE	WORD	CAN interface x: set baud rate in [kBaud]														
CANx_BUSOFF	BOOL	CAN interface x: Error "CAN-Bus off"  Reset of the error code also resets the flag														
CANx_LASTERROR	BYTE	CAN interface x: Error number of the last CAN transmission: <table><tr><td>0 = no error</td><td>Initial value</td></tr><tr><td>1 = stuff error</td><td>more than 5 identical bits in series on the bus</td></tr><tr><td>2 = form error</td><td>received message had wrong format</td></tr><tr><td>3 = ack error</td><td>sent message was not confirmed</td></tr><tr><td>4 = bit1 error</td><td>a recessive bit was sent outside the arbitration area, but a dominant bit was read on the bus</td></tr><tr><td>5 = bit0 error</td><td>it was tried to send a dominant bit, but a recessive level was read OR: a sequence of 11 recessive bits was read during bus-off recovery</td></tr><tr><td>6 = CRC error</td><td>checksum of the received message was wrong</td></tr></table>	0 = no error	Initial value	1 = stuff error	more than 5 identical bits in series on the bus	2 = form error	received message had wrong format	3 = ack error	sent message was not confirmed	4 = bit1 error	a recessive bit was sent outside the arbitration area, but a dominant bit was read on the bus	5 = bit0 error	it was tried to send a dominant bit, but a recessive level was read OR: a sequence of 11 recessive bits was read during bus-off recovery	6 = CRC error	checksum of the received message was wrong
0 = no error	Initial value															
1 = stuff error	more than 5 identical bits in series on the bus															
2 = form error	received message had wrong format															
3 = ack error	sent message was not confirmed															
4 = bit1 error	a recessive bit was sent outside the arbitration area, but a dominant bit was read on the bus															
5 = bit0 error	it was tried to send a dominant bit, but a recessive level was read OR: a sequence of 11 recessive bits was read during bus-off recovery															
6 = CRC error	checksum of the received message was wrong															
CANx_WARNING	BOOL	CAN interface x: warning threshold reached ( $\geq 96$ )  A reset of the flag is possible via write access														
DOWNLOADID	WORD	CAN interface x: set download identifier														

x = 1...2 = number of the CAN interface

## 7.1.2 System flags: SAE J1939

19556

System flags (symbol name)	Type	Description
J1939_TASK	BOOL	Using J1939_TASK, the time requirement for sending J1939 messages is met. If J1939 messages are to be sent with a repetition time $\leq 50$ ms, the runtime system automatically sets J1939_TASK=TRUE. For applications for which the time requirement is $\geq$ PLC cycle time: ▶ Reduce system load with J1939_TASK=FALSE! TRUE: J1939 task is active (= initial value) The task is called every 2 ms. The J1939 stack sends its messages in the required time frame FALSE: J1939 task is not active

### 7.1.3 System flags: error flags (standard side)

19557

System flags (symbol name)	Type	Description
ERROR	BOOL	TRUE = set group error message, switch off relay
ERROR_BREAK_Qx (0...x, value depends on the device, → data sheet)	WORD	output group x: wire break error [Bit 0 for output 0] ... [bit z for output z] of this group Bit = TRUE: error Bit = FALSE: no error
ERROR_Ix (0...x, value depends on the device, → data sheet)	BYTE	input group x: periphery fault [Bit 0 for input 0] ... [bit z for input z] of this group Bit = TRUE: error Bit = FALSE: no error
ERROR_MEMORY	BOOL	memory error
ERROR_POWER	BOOL	Voltage error for VBBS / clamp 15: TRUE: Value out of range or: difference (VBB15 - VBBS) too great > general error FALSE: Value OK
ERROR_SHORT_Qx (0...x, value depends on the device, → data sheet)	WORD	output group x: short circuit error [Bit 0 for output 0] ... [bit z for output z] of this group Bit = TRUE: error Bit = FALSE: no error
ERROR_TEMPERATURE	BOOL	Temperature error TRUE: Value out of range > general error FALSE: Value OK
ERROR_VBBx	BOOL	Supply voltage error on VBBx (x = O   R): TRUE: Value out of range > general error FALSE: Value OK

## 7.1.4 System flags: LED (standard side)

12817

System flags (symbol name)	Type	Description
LED	WORD	LED color for "LED switched on": 0x0000 = LED_GREEN (preset) 0x0001 = LED_BLUE 0x0002 = LED_RED 0x0003 = LED_WHITE 0x0004 = LED_BLACK 0x0005 = LED_MAGENTA 0x0006 = LED_CYAN 0x0007 = LED_YELLOW
LED_X	WORD	LED color for "LED switched off": 0x0000 = LED_GREEN 0x0001 = LED_BLUE 0x0002 = LED_RED 0x0003 = LED_WHITE 0x0004 = LED_BLACK (preset) 0x0005 = LED_MAGENTA 0x0006 = LED_CYAN 0x0007 = LED_YELLOW
LED_MODE	WORD	LED flashing frequency: 0x0000 = LED_2HZ (flashes at 2 Hz; preset) 0x0001 = LED_1HZ (flashes at 1 Hz) 0x0002 = LED_05HZ (flashes at 0.5 Hz) 0x0003 = LED_0HZ (lights permanently with value in LED) 0x0004 = LED_5HZ (flashes at 5 Hz)

## 7.1.5 System flags: voltages (standard side)

19558

System flags (symbol name)	Type	Description
CLAMP_15	BOOL	Voltage monitoring on clamp 15
RELAIS	BOOL	<p>TRUE: relay energised outputs are supplied with voltage</p> <p>FALSE: relay de-energised outputs are voltage-free</p>
RELAIS_CLAMP_15	BOOL	Relay clamp 15 (pin 5)
SERIAL_BAUDRATE	WORD	Baud rate of the RS232 interface
SERIAL_MODE	BOOL	<p>Activate serial interface (RS232) for use in the application</p> <p>TRUE: The RS232 interface can be used in the application, but no longer for programming, debugging or monitoring of the device.</p> <p>FALSE: The RS232 interface cannot be used in the application. Programming, debugging or monitoring of the device is possible.</p>
SUPPLY_VOLTAGE	WORD	supply voltage at VBBS in [mV]
TEST	BOOL	<p>TRUE: Test input is active:</p> <ul style="list-style-type: none"> <li>• Programming mode is enabled</li> <li>• Software download is possible</li> <li>• Status of the application program can be queried</li> <li>• Protection of stored software is not possible</li> </ul> <p>FALSE: application is in operation</p>

## 7.1.6 System flags: 16...40 inputs and 24...0 outputs (standard side)

19560

System flags (symbol name)	Type	Description
ANALOGx x = 0...7	WORD	Analogue input xx: filtered A/D converter raw value (12 bits) without calibration or standardisation
Ixx xx = 00...07 / 10...17 / 20...27 / 30...37 / 40...47	BOOL	Status on binary input xx Requirement: input is configured as binary input (MODE = IN_DIGITAL_H or IN_DIGITAL_L) TRUE: Voltage on binary input > 70 % of VBBs FALSE: Voltage on binary input < 30 % of VBBs or: not configured as binary input or: wrong configuration
Ixx_MODE xx = 00...07 / 14...17 / 24...27 / 30...37 / 40...47	BYTE	Operating mode of the input Ixx → chapter <i>Possible operating modes inputs/outputs</i> (→ page <a href="#">234</a> )
Qxx xx = 10...13 / 20...23 / 30...37 / 40...47	BOOL	Status on binary output xx: Requirement: output is configured as binary output TRUE: output activated FALSE: output deactivated (= initial value) or: not configured as binary output
Qxx_MODE xx = 10...13 / 20...23 / 30...37 / 40...47	BYTE	Operating mode of the output Qxx → chapter <i>Possible operating modes inputs/outputs</i> (→ page <a href="#">234</a> )

## 7.2 Address assignment and I/O operating modes

### Inhalt

Address assignment inputs / outputs .....	230
Possible operating modes inputs/outputs .....	234
Addresses / variables of the I/Os .....	238

1656

→ also data sheet

### 7.2.1 Address assignment inputs / outputs

#### Inhalt

Inputs: Address assignment (standard side) (16...40 inputs).....	231
Outputs: address assignment (standard side) (0...24 outputs) .....	233

2371

## Inputs: Address assignment (standard side) (16...40 inputs)

19572

Abbreviations →chapter *Note on wiring* (→ page [34](#))Operating modes of the inputs/outputs →chapter *Possible operating modes inputs/outputs* (→ page [234](#))

IEC address	Symbolic address
%IX0.00 %IW03	I00 ANALOG0
%IX0.01 %IW3	I01 ANALOG1
%IX0.02 %IW4	I02 ANALOG2
%IX0.03 %IW5	I03 ANALOG3
%IX0.04 %IW6	I04 ANALOG4
%IX0.05 %IW7	I05 ANALOG5
%IX0.06 %IW8	I06 ANALOG6
%IX0.07 %IW9	I07 ANALOG7
%IX0.08	I10
%IX0.09	I11
%IX0.10	I12
%IX0.11	I13
%IX0.12	I14
%IX0.13	I15
%IX0.14	I16
%IX0.15	I17
%IX1.00	I20
%IX1.01	I21
%IX1.02	I22
%IX1.03	I23
%IX1.04	I24
%IX1.05	I25
%IX1.06	I26
%IX1.07	I27
%IX1.08	I30
%IX1.09	I31
%IX1.10	I32
%IX1.11	I33
%IX1.12	I34
%IX1.13	I35
%IX1.14	I36
%IX1.15	I37

IEC address	Symbolic address
%IX2.00	I40
%IX2.01	I41
%IX2.02	I42
%IX2.03	I43
%IX2.04	I44
%IX2.05	I45
%IX2.06	I46
%IX2.07	I47



## Outputs: address assignment (standard side) (0...24 outputs)

19573

Abbreviations →chapter *Note on wiring* (→ page [34](#))

Operating modes of the inputs/outputs →chapter *Possible operating modes inputs/outputs* (→ page [234](#))

IEC address	Symbolic address
%QX0.00	Q10
%QX0.01	Q11
%QX0.02	Q12
%QX0.03	Q13
%QX0.04	Q20
%QX0.05	Q21
%QX0.06	Q22
%QX0.07	Q23
%QX0.08	Q30
%QX0.09	Q31
%QX0.10	Q32
%QX0.11	Q33
%QX0.12	Q34
%QX0.13	Q35
%QX0.14	Q36
%QX0.15	Q37
%QX1.00	Q40
%QX1.01	Q41
%QX1.02	Q42
%QX1.03	Q43
%QX1.04	Q44
%QX1.05	Q45
%QX1.06	Q46
%QX1.07	Q47

## 7.2.2 Possible operating modes inputs/outputs

### Inhalt

Inputs: operating modes (standard side) (16...40 inputs) .....	234
Outputs: operating modes (standard side) (0...24 outputs) .....	236

2386

### Inputs: operating modes (standard side) (16...40 inputs)

19575

Possible configuration combinations (where permissible) are created by adding the configuration values.

  = this configuration value is default

Inputs	Possible operating mode	Set with function block	FB input	Value	
				dec	hex
I00...I07	IN_NOMODE Off	INPUT_ANALOG	MODE	0	00
	IN_DIGITAL_H plus	INPUT_ANALOG	MODE	<span style="background-color: #90EE90;">1</span>	<span style="background-color: #90EE90;">01</span>
	IN_CURRENT 0...20 000 µA	INPUT_ANALOG	MODE	4	04
	IN_VOLTAGE10 0...10 000 mV	INPUT_ANALOG	MODE	8	08
	IN_VOLTAGE30 0...30 000 mV	INPUT_ANALOG	MODE	<span style="background-color: #90EE90;">16</span>	<span style="background-color: #90EE90;">10</span>
	IN_RATIO 0...1 000 ‰	INPUT_ANALOG	MODE	32	20
	IN_DIAGNOSTIC with IN_DIGITAL_H	INPUT_ANALOG	MODE	64	40
I10...I13	IN_NOMODE Off	INPUT_ANALOG	MODE	0	00
	IN_DIGITAL_H plus	INPUT_ANALOG	MODE	<span style="background-color: #90EE90;">1</span>	<span style="background-color: #90EE90;">01</span>
I14...I17	IN_NOMODE Off	INPUT_ANALOG	MODE	0	00
	IN_DIGITAL_H plus	INPUT_ANALOG	MODE	<span style="background-color: #90EE90;">1</span>	<span style="background-color: #90EE90;">01</span>
	IN_DIAGNOSTIC with IN_DIGITAL_H	INPUT_ANALOG	MODE	64	40
	IN_FAST with IN_DIGITAL_H	internal		128	80
	IN_FAST 0...30 000 Hz	FREQUENCY PHASE	Frequency measurement		
	0.1...5 000 Hz	PERIOD	Period duration measurement		
	0.1...5 000 Hz	PERIOD_RATIO	Period duration and ratio measurement		
	0...30 000 Hz	FAST_COUNT	Counters		
I20...I23	IN_NOMODE Off	INPUT_ANALOG	MODE	0	00
	IN_DIGITAL_H plus	INPUT_ANALOG	MODE	<span style="background-color: #90EE90;">1</span>	<span style="background-color: #90EE90;">01</span>
I24...I27	IN_NOMODE Off	INPUT_ANALOG	MODE	0	00
	IN_DIGITAL_H plus	INPUT_ANALOG	MODE	<span style="background-color: #90EE90;">1</span>	<span style="background-color: #90EE90;">01</span>
	IN_DIGITAL_L minus	INPUT_ANALOG	MODE	2	02
	IN_DIAGNOSTIC with IN_DIGITAL_H	INPUT_ANALOG	MODE	64	40
	IN_FAST with IN_DIGITAL_H	internal		128	80

Inputs	Possible operating mode		Set with function block	FB input	Value	
					dec	hex
	IN_FAST	0...1 000 Hz	FREQUENCY PHASE	Frequency measurement		
		0.1...1 000 Hz	PERIOD	Period duration measurement		
		0.1...1 000 Hz	PERIOD_RATIO	Period duration and ratio measurement		
		0...1 000 Hz	FAST_COUNT	Counters		
		0...1 000 Hz	INC_ENCODER	Detect encoder		
I30...I37	IN_NOMODE	Off	INPUT_ANALOG	MODE	0	00
	IN_DIGITAL_H	plus	INPUT_ANALOG	MODE	1	01
	IN_DIGITAL_L	minus	INPUT_ANALOG	MODE	2	02
	IN_DIAGNOSTIC	with IN_DIGITAL_H	INPUT_ANALOG	MODE	64	40
I40...I47	IN_NOMODE	Off	INPUT_ANALOG	MODE	0	00
	IN_DIGITAL_H	plus	INPUT_ANALOG	MODE	1	01
	IN_DIAGNOSTIC	with IN_DIGITAL_H	INPUT_ANALOG	MODE	64	40

Set operating modes with the following function block:

<b>FAST_COUNT</b> (→ page <a href="#">151</a> )	Counter block for fast input pulses
<b>FREQUENCY</b> (→ page <a href="#">152</a> )	Measures the frequency of the signal arriving at the selected channel
<b>INC_ENCODER</b> (→ page <a href="#">153</a> )	Up/down counter function for the evaluation of encoders
<b>INPUT_ANALOG</b> (→ page <a href="#">144</a> )	Current and voltage measurement on the analogue input channel
<b>PERIOD</b> (→ page <a href="#">156</a> )	Measures the frequency and the cycle period (cycle time) in [μs] at the indicated channel
<b>PERIOD_RATIO</b> (→ page <a href="#">158</a> )	Measures the frequency and the cycle period (cycle time) in [μs] during the indicated periods at the indicated channel. In addition, the mark-to-space ratio is indicated in [%].
<b>PHASE</b> (→ page <a href="#">160</a> )	Reads a pair of channels with fast inputs and compares the phase position of the signals

## Outputs: operating modes (standard side) (0...24 outputs)

19576

Possible configuration combinations (where permissible) are created by adding the configuration values.

= this configuration value is default

Outputs	Possible operating mode		set with	Value	
				dec	hex
Q10...Q13	OUT_NOMODE	Off	Qxx_MOD	0	00
	OUT_DIGITAL_H	plus	Qxx_MODE	1	01
	OUT_CURRENT		Qxx_MODE	4	04
	OUT_DIAGNOSTIC		Qxx_MODE	64	40
	OUT_OVERLOAD_PROTECTION		Qxx_MODE	128	80
Q20...Q23	OUT_NOMODE	Off	Qxx_MODE	0	00
	OUT_DIGITAL_H	plus	Qxx_MODE	1	01
	OUT_CURRENT		Qxx_MODE	4	04
	OUT_DIAGNOSTIC		Qxx_MODE	64	40
	OUT_OVERLOAD_PROTECTION		Qxx_MODE	128	80
Q30...Q37	OUT_NOMODE	Off	Qxx_MODE	0	00
	OUT_DIGITAL_H	plus	Qxx_MODE	1	01
	OUT_DIAGNOSTIC		Qxx_MODE	64	40
	OUT_OVERLOAD_PROTECTION		Qxx_MODE	128	80
Q40, Q43, Q44, Q47	OUT_NOMODE	Off	Qxx_MODE	0	00
	OUT_DIGITAL_H	plus	Qxx_MODE	1	01
	OUT_DIAGNOSTIC		Qxx_MODE	64	40
Q41, Q42, Q45, Q46	OUT_NOMODE	Off	Qxx_MODE	0	00
	OUT_DIGITAL_H	plus	Qxx_MODE	1	01
	OUT_DIGITAL_L	minus	Qxx_MODE	2	02
	OUT_DIAGNOSTIC		Qxx_MODE	64	40

## Outputs: permitted operating modes

19577

Operating mode		Q10	Q11	Q12	Q13	Q20	Q21	Q22	Q23
OUT_NOMODE	Off	X	X	X	X	X	X	X	X
OUT_DIGITAL_H	plus	X	X	X	X	X	X	X	X
OUT_CURRENT		X	X	X	X	X	X	X	X
OUT_DIAGNOSTIC		X	X	X	X	X	X	X	X
OUT_OVERLOAD_PROTECTION		X	X	X	X	X	X	X	X
PWM		X	X	X	X	X	X	X	X

Operating mode		Q30	Q31	Q32	Q33	Q34	Q35	Q36	Q37
OUT_NOMODE	Off	X	X	X	X	X	X	X	X
OUT_DIGITAL_H	plus	X	X	X	X	X	X	X	X
OUT_DIAGNOSTIC		X	X	X	X	X	X	X	X

Operating mode		Q40	Q41	Q42	Q43	Q44	Q45	Q46	Q47
OUT_NOMODE	Off	X	X	X	X	X	X	X	X
OUT_DIGITAL_H	plus	X	X	X	X	X	X	X	X
OUT_DIGITAL_L	minus	--	X	X	--	--	X	X	--
OUT_DIAGNOSTIC		X	X	X	X	X	X	X	X
OUT_OVERLOAD_PROTECTION		X	X	X	X	X	X	X	X
PWM		X	--	--	X	X	--	--	X
H bridge		--	X	X	--	--	X	X	--

## 7.2.3 Addresses / variables of the I/Os

### Inhalt

Inputs: Addresses and variables (standard side) (16...40 inputs).....	238
Outputs: Addresses and variables (standard side) (0...24 outputs).....	239

2376

### Inputs: Addresses and variables (standard side) (16...40 inputs)

19579

IEC address	I/O variable	Note
%QB8	I00_MODE	Configuration byte for %IX0.00 (I00)
%QB9	I01_MODE	Configuration byte for %IX0.01 (I01)
%QB10	I02_MODE	Configuration byte for %IX0.02 (I02)
%QB11	I03_MODE	Configuration byte for %IX0.03 (I03)
%QB12	I04_MODE	Configuration byte for %IX0.04 (I04)
%QB13	I05_MODE	Configuration byte for %IX0.05 (I05)
%QB14	I06_MODE	Configuration byte for %IX0.06 (I06)
%QB15	I07_MODE	Configuration byte for %IX0.07 (I07)
%QB16	I14_MODE	Configuration byte for %IX0.14 (I14)
%QB17	I15_MODE	Configuration byte for %IX0.15 (I15)
%QB18	I16_MODE	Configuration byte for %IX0.16 (I16)
%QB19	I17_MODE	Configuration byte for %IX0.17 (I17)
%QB20	I24_MODE	Configuration byte for %IX1.04 (I24)
%QB21	I25_MODE	Configuration byte for %IX1.05 (I25)
%QB22	I26_MODE	Configuration byte for %IX1.06 (I26)
%QB23	I27_MODE	Configuration byte for %IX1.07 (I27)
%QB24	I30_MODE	Configuration byte for %IX1.08 (I30)
%QB25	I31_MODE	Configuration byte for %IX1.09 (I31)
%QB26	I32_MODE	Configuration byte for %IX1.10 (I32)
%QB27	I33_MODE	Configuration byte for %IX1.11 (I33)
%QB28	I34_MODE	Configuration byte for %IX1.12 (I34)
%QB29	I35_MODE	Configuration byte for %IX1.13 (I35)
%QB30	I36_MODE	Configuration byte for %IX1.14 (I36)
%QB31	I37_MODE	Configuration byte for %IX1.15 (I37)
%QB32	I40_MODE	Configuration byte for %IX2.00 (I40)
%QB33	I41_MODE	Configuration byte for %IX2.01 (I41)
%QB34	I42_MODE	Configuration byte für %IX2.02 (I42)
%QB35	I43_MODE	Configuration byte for %IX2.03 (I43)
%QB36	I44_MODE	Configuration byte for %IX2.04 (I44)
%QB37	I45_MODE	Configuration byte for %IX2.05 (I45)
%QB38	I46_MODE	Configuration byte for %IX2.06 (I46)
%QB39	I47_MODE	Configuration byte for %IX2.07 (I47)

IEC address	I/O variable	Note
%IW3	ANALOG0	Analogue value at I00
%IW4	ANALOG1	Analogue value at I01
%IW5	ANALOG2	Analogue value at I02
%IW6	ANALOG3	Analogue value at I03
%IW7	ANALOG4	Analogue value at I04
%IW8	ANALOG5	Analogue value at I05
%IW9	ANALOG6	Analogue value at I06
%IW10	ANALOG7	Analogue value at I07

### Outputs: Addresses and variables (standard side) (0...24 outputs)

19580

IEC address	I/O variable	Note
%QB40	Q10_MODE	Configuration byte for %QX0.00 (Q10)
%QB41	Q11_MODE	Configuration byte for %QX0.01 (Q11)
%QB42	Q12_MODE	Configuration byte for %QX0.02 (Q12)
%QB43	Q13_MODE	Configuration byte for %QX0.03 (Q13)
%QB44	Q20_MODE	Configuration byte for %QX0.04 (Q20)
%QB45	Q21_MODE	Configuration byte for %QX0.05 (Q21)
%QB46	Q22_MODE	Configuration byte for %QX0.06 (Q22)
%QB47	Q23_MODE	Configuration byte for %QX0.07 (Q23)
%QB48	Q30_MODE	Configuration byte for %QX0.08 (Q30)
%QB49	Q31_MODE	Configuration byte for %QX0.09 (Q31)
%QB50	Q32_MODE	Configuration byte for %QX0.10 (Q32)
%QB51	Q33_MODE	Configuration byte for %QX0.11 (Q33)
%QB52	Q34_MODE	Configuration byte for %QX0.12 (Q34)
%QB53	Q35_MODE	Configuration byte for %QX0.13 (Q35)
%QB54	Q36_MODE	Configuration byte for %QX0.14 (Q36)
%QB55	Q37_MODE	Configuration byte for %QX0.15 (Q37)
%QB56	Q40_MODE	Configuration byte for %QX1.00 (Q40)
%QB57	Q41_MODE	Configuration byte for %QX1.01 (Q41)
%QB58	Q42_MODE	Configuration byte for %QX1.02 (Q42)
%QB59	Q43_MODE	Configuration byte for %QX1.03 (Q43)
%QB60	Q44_MODE	Configuration byte for %QX1.04 (Q44)
%QB61	Q45_MODE	Configuration byte for %QX1.05 (Q45)
%QB62	Q46_MODE	Configuration byte for %QX1.06 (Q46)
%QB63	Q47_MODE	Configuration byte for %QX1.07 (Q47)

## 7.3 Error tables

### Inhalt

Error flags .....	240
Errors: CAN / CANopen .....	240

19606

### 7.3.1 Error flags

19608

→ chapter *System flags* (→ page [224](#))


### 7.3.2 Errors: CAN / CANopen

19610  
19604

→ System manual "Know-How ecomatmobile"  
→ chapter *CAN / CANopen: errors and error handling*

### EMCY codes: CANx

13094

 The indications for CANx also apply to each of the CAN interfaces.

EMCY code object 0x1003		Object 0x1001	Manufacturer specific information					Description
Byte 0 [hex]	Byte 1 [hex]	Byte 2 [hex]	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	
00	80	11	--	--	--	--	--	CANx monitoring SYNC error (only slave)
00	81	11	--	--	--	--	--	CANx warning threshold (> 96)
10	81	11	--	--	--	--	--	CANx receive buffer overrun
11	81	11	--	--	--	--	--	CANx transmit buffer overrun
30	81	11	--	--	--	--	--	CANx guard/heartbeat error (only slave)

### EMCY codes: I/Os, system (standard side)

19552

The following EMCY messages are sent automatically, if the FB *CANx\_MASTER\_EMCY\_HANDLER* (→ page [97](#)) is called cyclically.

EMCY code object 0x1003		Object 0x1001	Manufacturer specific information					Description
Byte 0 [hex]	Byte 1 [hex]	Byte 2 [hex]	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	
00	21	03	I0	I1	I2	I3	I4	Input diagnostics
00	23	03	Q1Q2	Q3	Q4			Output diagnostics if interruption
02	23	03	Q1Q2	Q3	Q4			Output diagnostics if short circuit
00	31	05						Terminal voltage VBBO/VBBS
00	33	05						Output voltage VBBS
00	42	09						Excess temperature
00	61	11						Memory error



## 8 Glossary of Terms

### A

#### Address

This is the "name" of the bus participant. All participants need a unique address so that the signals can be exchanged without problem.

#### Application software

Software specific to the application, implemented by the machine manufacturer, generally containing logic sequences, limits and expressions that control the appropriate inputs, outputs, calculations and decisions.

#### Architecture

Specific configuration of hardware and/or software elements in a system.

### B

#### Baud

Baud, abbrev.: Bd = unit for the data transmission speed. Do not confuse baud with "bits per second" (bps, bits/s). Baud indicates the number of changes of state (steps, cycles) per second over a transmission length. But it is not defined how many bits per step are transmitted. The name baud can be traced back to the French inventor J. M. Baudot whose code was used for telex machines.  
1 MBd = 1024 x 1024 Bd = 1 048 576 Bd

#### Boot loader

On delivery *ecomatmobile* controllers only contain the boot loader.

The boot loader is a start program that allows to reload the runtime system and the application program on the device.

The boot loader contains basic routines...

- for communication between hardware modules,
- for reloading the operating system.

The boot loader is the first software module to be saved on the device.

#### Bus

Serial data transmission of several participants on the same cable.

### C

#### CAN

CAN = **C**ontroller **A**rea **N**etwork

CAN is a priority-controlled fieldbus system for large data volumes. There are several higher-level protocols that are based on CAN, e.g. 'CANopen' or 'J1939'.

#### CAN stack

CAN stack = software component that deals with processing CAN messages.

## CiA

CiA = CAN in Automation e.V.

User and manufacturer organisation in Germany / Erlangen. Definition and control body for CAN and CAN-based network protocols.

Homepage → [www.can-cia.org](http://www.can-cia.org)

## CiA DS 304

DS = **D**raft **S**tandard

CANopen device profile for safety communication

## CiA DS 401

DS = **D**raft **S**tandard

CANopen device profile for binary and analogue I/O modules

## CiA DS 402

DS = **D**raft **S**tandard

CANopen device profile for drives

## CiA DS 403

DS = **D**raft **S**tandard

CANopen device profile for HMI

## CiA DS 404

DS = **D**raft **S**tandard

CANopen device profile for measurement and control technology

## CiA DS 405

DS = **D**raft **S**tandard

CANopen specification of the interface to programmable controllers (IEC 61131-3)

## CiA DS 406

DS = **D**raft **S**tandard

CANopen device profile for encoders

## CiA DS 407

DS = **D**raft **S**tandard

CANopen application profile for local public transport

## Clamp 15

In vehicles clamp 15 is the plus cable switched by the ignition lock.

## COB ID

COB = **C**ommunication **O**bject

ID = **I**dentifier

ID of a CANopen communication object

Corresponds to the identifier of the CAN message with which the communication project is sent via the CAN bus.

## CODESYS

CODESYS® is a registered trademark of 3S – Smart Software Solutions GmbH, Germany. 'CODESYS for Automation Alliance' associates companies of the automation industry whose hardware devices are all programmed with the widely used IEC 61131-3 development tool CODESYS®.

Homepage → [www.codesys.com](http://www.codesys.com)

## CSV file

CSV = **C**omma **S**eparated **V**alues (also: **C**haracter **S**eparated **V**alues)

A CSV file is a text file for storing or exchanging simply structured data.

The file extension is .csv.

**Example:** Source table with numerical values:

value 1.0	value 1.1	value 1.2	value 1.3
value 2.0	value 2.1	value 2.2	value 2.3
value 3.0	value 3.1	value 3.2	value 3.3

This results in the following CSV file:

```
value 1.0;value 1.1;value 1.2;value 1.3
value 2.0;value 2.1;value 2.2;value 2.3
value 3.0;value 3.1;value 3.2;value 3.3
```

## Cycle time

This is the time for a cycle. The PLC program performs one complete run.

Depending on event-controlled branchings in the program this can take longer or shorter.

## D

### Data type

Depending on the data type, values of different sizes can be stored.

Data type	min. value	max. value	size in the memory
BOOL	FALSE	TRUE	8 bits = 1 byte
BYTE	0	255	8 bits = 1 byte
WORD	0	65 535	16 bits = 2 bytes
DWORD	0	4 294 967 295	32 bits = 4 bytes
SINT	-128	127	8 bits = 1 byte
USINT	0	255	8 bits = 1 byte
INT	-32 768	32 767	16 bits = 2 bytes
UINT	0	65 535	16 bits = 2 bytes
DINT	-2 147 483 648	2 147 483 647	32 bits = 4 bytes
UDINT	0	4 294 967 295	32 bits = 4 bytes
REAL	-3.402823466 · 10 <sup>38</sup>	3.402823466 · 10 <sup>38</sup>	32 bits = 4 bytes
ULINT	0	18 446 744 073 709 551 615	64 Bit = 8 Bytes
STRING			number of char. + 1

## DC

**Direct Current**

## Diagnosis

During the diagnosis, the "state of health" of the device is checked. It is to be found out if and what →faults are given in the device.

Depending on the device, the inputs and outputs can also be monitored for their correct function.

- wire break,
- short circuit,
- value outside range.

For diagnosis, configuration and log data can be used, created during the "normal" operation of the device.

The correct start of the system components is monitored during the initialisation and start phase.

Errors are recorded in the log file.

For further diagnosis, self-tests can also be carried out.

## Dither

Dither is a component of the →PWM signals to control hydraulic valves. It has shown for electromagnetic drives of hydraulic valves that it is much easier for controlling the valves if the control signal (PWM pulse) is superimposed by a certain frequency of the PWM frequency. This dither frequency must be an integer part of the PWM frequency.

## DLC

**Data Length Code** = in CANopen the number of the data bytes in a message.

For →SDO: DLC = 8

## DRAM

DRAM = **D**ynamic **R**andom **A**ccess **M**emory.

Technology for an electronic memory module with random access (Random Access Memory, RAM).

The memory element is a capacitor which is either charged or discharged. It becomes accessible via a switching transistor and is either read or overwritten with new contents. The memory contents are volatile: the stored information is lost in case of lacking operating voltage or too late restart.

## DTC

DTC = **D**iagnostic **T**rouble **C**ode = error code

In the protocol J1939 faults and errors will be managed and reported via assigned numbers – the DTCs.

## E

### ECU

(1) **E**lectronic **C**ontrol **U**nit = control unit or microcontroller

(2) **E**ngine **C**ontrol **U**nit = control device of an engine

### EDS-file

EDS = **E**lectronic **D**ata **S**heet, e.g. for:

- File for the object directory in the CANopen master,
- CANopen device descriptions.

Via EDS devices and programs can exchange their specifications and consider them in a simplified way.

## Embedded software

System software, basic program in the device, virtually the →runtime system.

The firmware establishes the connection between the hardware of the device and the application program. The firmware is provided by the manufacturer of the controller as a part of the system and cannot be changed by the user.

## EMC

EMC = **E**lectro **M**agnetic **C**ompatibility.

According to the EC directive (2004/108/EEC) concerning electromagnetic compatibility (in short EMC directive) requirements are made for electrical and electronic apparatus, equipment, systems or components to operate satisfactorily in the existing electromagnetic environment. The devices must not interfere with their environment and must not be adversely influenced by external electromagnetic interference.

## EMCY

abbreviation for emergency

Message in the CANopen protocol with which errors are signalled.

## Ethernet

Ethernet is a widely used, manufacturer-independent technology which enables data transmission in the network at a speed of 10...10 000 million bits per second (Mbps). Ethernet belongs to the family of so-called "optimum data transmission" on a non exclusive transmission medium. The concept was developed in 1972 and specified as IEEE 802.3 in 1985.

## EUC

EUC = **E**quipment **U**nder **C**ontrol.

EUC is equipment, machinery, apparatus or plant used for manufacturing, process, transportation, medical or other activities (→ IEC 61508-4, section 3.2.3). Therefore, the EUC is the set of all equipment, machinery, apparatus or plant that gives rise to hazards for which the safety-related system is required.

If any reasonably foreseeable action or inaction leads to →hazards with an intolerable risk arising from the EUC, then safety functions are necessary to achieve or maintain a safe state for the EUC. These safety functions are performed by one or more safety-related systems.

## F

### FiFo

FIFO (**F**irst **I**n, **F**irst **O**ut) = Operating principle of the stack memory: The data packet that was written into the stack memory first, will also be read first. Each identifier has such a buffer (queue).

## Flash memory

Flash ROM (or flash EPROM or flash memory) combines the advantages of semiconductor memory and hard disks. Similar to a hard disk, the data are however written and deleted blockwise in data blocks up to 64, 128, 256, 1024, ... bytes at the same time.

### Advantages of flash memories

- The stored data are maintained even if there is no supply voltage.
- Due to the absence of moving parts, flash is noiseless and insensitive to shocks and magnetic fields.

**Disadvantages of flash memories**

- A storage cell can tolerate a limited number of write and delete processes:
  - Multi-level cells: typ. 10 000 cycles
  - Single level cells: typ. 100 000 cycles
- Given that a write process writes memory blocks of between 16 and 128 Kbytes at the same time, memory cells which require no change are used as well.

**FRAM**

FRAM, or also FeRAM, means **F**erroelectric **R**andom **A**ccess **M**emory. The storage operation and erasing operation is carried out by a polarisation change in a ferroelectric layer.

Advantages of FRAM as compared to conventional read-only memories:

- non-volatile,
- compatible with common EEPROMs, but:
- access time approx. 100 ns,
- nearly unlimited access cycles possible.

**H****Heartbeat**

The participants regularly send short signals. In this way the other participants can verify if a participant has failed.

**HMI**

HMI = **H**uman **M**achine **I**nterface

**I****ID**

ID = **I**dentifier

Name to differentiate the devices / participants connected to a system or the message packets transmitted between the participants.

**IEC 61131**

Standard: Basics of programmable logic controllers

- Part 1: General information
- Part 2: Production equipment requirements and tests
- Part 3: Programming languages
- Part 5: Communication
- Part 7: Fuzzy Control Programming

**IEC user cycle**

IEC user cycle = PLC cycle in the CODESYS application program.

**Instructions**

Superordinate word for one of the following terms:

installation instructions, data sheet, user information, operating instructions, device manual, installation information, online help, system manual, programming manual, etc.

## Intended use

Use of a product in accordance with the information provided in the instructions for use.

## IP address

IP = Internet Protocol.

The IP address is a number which is necessary to clearly identify an internet participant. For the sake of clarity the number is written in 4 decimal values, e.g. 127.215.205.156.

## ISO 11898

Standard: Road vehicles – Controller area network

- Part 1: Data link layer and physical signalling
- Part 2: High-speed medium access unit
- Part 3: Low-speed, fault-tolerant, medium dependent interface
- Part 4: Time-triggered communication
- Part 5: High-speed medium access unit with low-power mode

## ISO 11992

Standard: Interchange of digital information on electrical connections between towing and towed vehicles

- Part 1: Physical and data-link layers
- Part 2: Application layer for brakes and running gear
- Part 3: Application layer for equipment other than brakes and running gear
- Part 4: Diagnostics

## ISO 16845

Standard: Road vehicles – Controller area network (CAN) – Conformance test plan

## J

### J1939

→ SAE J1939

## L

### LED

LED = **L**ight **E**mitting **D**iode.

Light emitting diode, also called luminescent diode, an electronic element of high coloured luminosity at small volume with negligible power loss.

## Link

A link is a cross-reference to another part in the document or to an external document.

## LSB

**L**east **S**ignificant **B**it/Byte

## M

### MAC-ID

MAC = **M**anufacturer's **A**ddress **C**ode  
= manufacturer's serial number.

→ID = **I**dentifier

Every network card has a MAC address, a clearly defined worldwide unique numerical code, more or less a kind of serial number. Such a MAC address is a sequence of 6 hexadecimal numbers, e.g. "00-0C-6E-D0-02-3F".

### Master

Handles the complete organisation on the bus. The master decides on the bus access time and polls the →slaves cyclically.

### Misuse

The use of a product in a way not intended by the designer.

The manufacturer of the product has to warn against readily predictable misuse in his user information.

### MMI

→ *HMI* (→ page [246](#))

### MRAM

MRAM = **M**agnetoresistive **R**andom **A**ccess **M**emory

The information is stored by means of magnetic storage elements. The property of certain materials is used to change their electrical resistance when exposed to magnetic fields.

Advantages of MRAM as compared to conventional RAM memories:

- non volatile (like FRAM), but:
- access time only approx. 35 ns,
- unlimited number of access cycles possible.

### MSB

**M**ost **S**ignificant **B**it/Byte

## N

### NMT

NMT = **N**etwork **M**anagement = (here: in the CANopen protocol).

The NMT master controls the operating states of the NMT slaves.

### Node

This means a participant in the network.

### Node Guarding

Node = here: network participant

Configurable cyclic monitoring of each →slave configured accordingly. The →master verifies if the slaves reply in time. The slaves verify if the master regularly sends requests. In this way failed network participants can be quickly identified and reported.



## O

### Obj / object

Term for data / messages which can be exchanged in the CANopen network.

### Object directory

Contains all CANopen communication parameters of a device as well as device-specific parameters and data.

### OBV

Contains all CANopen communication parameters of a device as well as device-specific parameters and data.

### OPC

OPC = **O**LE for **P**rocess **C**ontrol

Standardised software interface for manufacturer-independent communication in automation technology

OPC client (e.g. device for parameter setting or programming) automatically logs on to OPC server (e.g. automation device) when connected and communicates with it.

### Operational

Operating state of a CANopen participant. In this mode →SDOs, →NMT commands and →PDOs can be transferred.

## P

### PC card

→PCMCIA card

### PCMCIA card

PCMCIA = Personal Computer Memory Card International Association, a standard for expansion cards of mobile computers.

Since the introduction of the cardbus standard in 1995 PCMCIA cards have also been called PC card.

### PDM

PDM = **P**rocess and **D**ialogue **M**odule.

Device for communication of the operator with the machine / plant.

### PDO

PDO = **P**rocess **D**ata **O**bject.

The time-critical process data is transferred by means of the "process data objects" (PDOs). The PDOs can be freely exchanged between the individual nodes (PDO linking). In addition it is defined whether data exchange is to be event-controlled (asynchronous) or synchronised. Depending on the type of data to be transferred the correct selection of the type of transmission can lead to considerable relief for the →CAN bus.

According to the protocol, these services are unconfirmed data transmission: it is not checked whether the receiver receives the message. Exchange of network variables corresponds to a "1 to n connection" (1 transmitter to n receivers).

## PDU

PDU = **P**rotocol **D**ata **U**nit.

The PDU is an item of the →CAN protocol →SAE J1939. PDU indicates a part of the destination or source address.

## PES

**P**rogrammable **E**lectronic **S**ystem ...

- for control, protection or monitoring,
- dependent for its operation on one or more programmable electronic devices,
- including all elements of the system such as input and output devices.

## PGN

PGN = **P**arameter **G**roup **N**umber

PGN = PDU format (PF) + PDU source (PS)

The parameter group number is an item of the →CAN protocol →SAE J1939. PGN collects the address parts PF and PS.

## Pictogram

Pictograms are figurative symbols which convey information by a simplified graphic representation.

(→ chapter *What do the symbols and formats mean?* (→ page [7](#)))

## PID controller

The PID controller (proportional–integral–derivative controller) consists of the following parts:

- P = proportional part
- I = integral part
- D = differential part (but not for the controller CR04nn, CR253n).

## PLC configuration

Part of the CODESYS user interface.

- The programmer tells the programming system which hardware is to be programmed.
- > CODESYS loads the corresponding libraries.
- > Reading and writing the periphery states (inputs/outputs) is possible.

## Pre-Op

Pre-Op = PRE-OPERATIONAL mode.

Operating status of a CANopen participant. After application of the supply voltage each participant automatically passes into this state. In the CANopen network only →SDOs and →NMT commands can be transferred in this mode but no process data.

## Process image

Process image is the status of the inputs and outputs the PLC operates with within one →cycle.

- At the beginning of the cycle the PLC reads the conditions of all inputs into the process image. During the cycle the PLC cannot detect changes to the inputs.
- During the cycle the outputs are only changed virtually (in the process image).
- At the end of the cycle the PLC writes the virtual output states to the real outputs.

## PWM

PWM = pulse width modulation

The PWM output signal is a pulsed signal between GND and supply voltage.

Within a defined period (PWM frequency) the mark-to-space ratio is varied. Depending on the mark-to-space ratio, the connected load determines the corresponding RMS current.

## R

### ratiometric

Measurements can also be performed ratiometrically. If the output signal of a sensor is proportional to its supply voltage then via ratiometric measurement (= measurement proportional to the supply) the influence of the supply's fluctuation can be reduced, in ideal case it can be eliminated.

→ analogue input

### RAW-CAN

RAW-CAN means the pure CAN protocol which works without an additional communication protocol on the CAN bus (on ISO/OSI layer 2). The CAN protocol is international defined according to ISO 11898-1 and guarantees in ISO 16845 the interchangeability of CAN chips in addition.

### remanent

Remanent data is protected against data loss in case of power failure.

The →runtime system for example automatically copies the remanent data to a →flash memory as soon as the voltage supply falls below a critical value. If the voltage supply is available again, the runtime system loads the remanent data back to the RAM memory.

The data in the RAM memory of a controller, however, is volatile and normally lost in case of power failure.

### ro

RO = read only for reading only

Unidirectional data transmission: Data can only be read and not changed.

### RTC

RTC = **R**ea**T**ime **C**lock

Provides (batter-backed) the current date and time. Frequent use for the storage of error message protocols.

### Runtime system

Basic program in the device, establishes the connection between the hardware of the device and the application program.

### rw

RW = read/ write

Bidirectional data transmission: Data can be read and also changed.

## S

### SAE J1939

The network protocol SAE J1939 describes the communication on a →CAN bus in commercial vehicles for transmission of diagnosis data (e.g. engine speed, temperature) and control information. Standard: Recommended Practice for a Serial Control and Communications Vehicle Network

- Part 2: Agricultural and Forestry Off-Road Machinery Control and Communication Network
- Part 3: On Board Diagnostics Implementation Guide
- Part 5: Marine Stern Drive and Inboard Spark-Ignition Engine On-Board Diagnostics Implementation Guide
- Part 11: Physical Layer – 250 kBits/s, Shielded Twisted Pair
- Part 13: Off-Board Diagnostic Connector
- Part 15: Reduced Physical Layer, 250 kBits/s, Un-Shielded Twisted Pair (UTP)
- Part 21: Data Link Layer
- Part 31: Network Layer
- Part 71: Vehicle Application Layer
- Part 73: Application Layer – Diagnostics
- Part 81: Network Management Protocol

### SD card

An SD memory card (short for **Secure Digital Memory Card**) is a digital storage medium that operates to the principle of →flash storage.

### SDO

SDO = **S**ervice **D**ata **O**bject.

The SDO is used for access to objects in the CANopen object directory. 'Clients' ask for the requested data from 'servers'. The SDOs always consist of 8 bytes.

#### Examples:

- Automatic configuration of all slaves via →SDOs at the system start,
- reading error messages from the →object directory.

Every SDO is monitored for a response and repeated if the slave does not respond within the monitoring time.

### Self-test

Test program that actively tests components or devices. The program is started by the user and takes a certain time. The result is a test protocol (log file) which shows what was tested and if the result is positive or negative.

### Slave

Passive participant on the bus, only replies on request of the →master. Slaves have a clearly defined and unique →address in the bus.

### stopped

Operating status of a CANopen participant. In this mode only →NMT commands are transferred.

### Symbols

Pictograms are figurative symbols which convey information by a simplified graphic representation. (→ chapter *What do the symbols and formats mean?* (→ page [7](#)))

## System variable

Variable to which access can be made via IEC address or symbol name from the PLC.

## T

### Target

The target contains the hardware description of the target device for CODESYS, e.g.: inputs and outputs, memory, file locations.

Corresponds to an electronic data sheet.

### TCP

The **T**ransmission **C**ontrol **P**rotocol is part of the TCP/IP protocol family. Each TCP/IP data connection has a transmitter and a receiver. This principle is a connection-oriented data transmission. In the TCP/IP protocol family the TCP as the connection-oriented protocol assumes the task of data protection, data flow control and takes measures in the event of data loss. (compare: →UDP)

### Template

A template can be filled with content.

Here: A structure of pre-configured software elements as basis for an application program.

## U

### UDP

UDP (**U**ser **D**atagram **P**rotocol) is a minimal connectionless network protocol which belongs to the transport layer of the internet protocol family. The task of UDP is to ensure that data which is transmitted via the internet is passed to the right application.

At present network variables based on →CAN and UDP are implemented. The values of the variables are automatically exchanged on the basis of broadcast messages. In UDP they are implemented as broadcast messages, in CAN as →PDOs.

According to the protocol, these services are unconfirmed data transmission: it is not checked whether the receiver receives the message. Exchange of network variables corresponds to a "1 to n connection" (1 transmitter to n receivers).

### Use, intended

Use of a product in accordance with the information provided in the instructions for use.

## W

### Watchdog

In general the term watchdog is used for a component of a system which watches the function of other components. If a possible malfunction is detected, this is either signalled or suitable program branchings are activated. The signal or branchings serve as a trigger for other co-operating system components to solve the problem.

### WO

WO = write only

Unidirectional data transmission: Data can only be changed and not read.

# 9 Index

## A

About this manual.....	5
Above-average stress.....	53
Access to the structures at runtime of the application.....	105
Activate the PLC configuration (e.g. CR0033).....	59
Adapt process values.....	147
Address.....	241
Address assignment.....	230
Address assignment and I/O operating modes.....	230
Address assignment inputs / outputs.....	230
Address assignment of the inputs.....	231
Address assignment of the outputs.....	233
Addresses / variables of the I/Os.....	238
After application of the supply voltage.....	19
ANALOG_RAW.....	143
Analogue inputs.....	21, 66
Annex.....	224
Application program.....	42
Application software.....	241
Architecture.....	241
Automatic saving of data.....	206
Available memory.....	15

## B

Baud.....	241
Binary and PWM outputs.....	68
Binary outputs.....	27
Boot loader.....	241
Bootloader.....	42
Bootloader state.....	51
Bus.....	241

## C

Calculation examples RELOAD value.....	169
Calculation of the RELOAD value.....	169
CAN.....	241
interfaces and protocols.....	40
CAN / CANopen.....	223
errors and error handling.....	223
CAN interfaces.....	40
CAN stack.....	241
CAN1_BAUDRATE.....	81
CAN1_DOWNLOADID.....	82
CAN1_EXT.....	83
CAN1_EXT_ERRORHANDLER.....	84
CAN1_EXT_RECEIVE.....	85
CAN1_EXT_TRANSMIT.....	87
CAN2.....	88
CANx_ERRORHANDLER.....	89
CANx_EXT_RECEIVE_ALL.....	90
CANx_MASTER_EM CY_HANDLER.....	97
CANx_MASTER_SEND_EMERGENCY.....	98
CANx_MASTER_STATUS.....	100
CANx_RECEIVE.....	91
CANx_RECEIVE_RANGE.....	93
CANx_SDO_READ.....	115
CANx_SDO_WRITE.....	117

CANx_SLAVE_EM CY_HANDLER.....	107
CANx_SLAVE_NODEID.....	108
CANx_SLAVE_SEND_EMERGENCY.....	109
CANx_SLAVE_STATUS.....	111
CANx_TRANSMIT.....	95
CHECK_DATA.....	215
CIA.....	242
CIA DS 304.....	242
CIA DS 401.....	242
CIA DS 402.....	242
CIA DS 403.....	242
CIA DS 404.....	242
CIA DS 405.....	242
CIA DS 406.....	242
CIA DS 407.....	242
Clamp 15.....	242
COB ID.....	242
CODESYS.....	243
CODESYS programming manual.....	6
Conditions.....	13
Configuration of the inputs and outputs (default setting).....	61
Configurations.....	54
Configure inputs.....	63
Configure outputs.....	67
Connect terminal VBBO (5) to battery (not switched).....	16
Connect terminal VBBS (23) to the ignition switch.....	16
Control the LED in the application program.....	38
CONTROL_OCC.....	176
Copyright.....	5
Creating application program.....	46
CSV file.....	243
Cycle time.....	243

## D

Damping of overshoot.....	191
Data access and data check.....	214
Data type.....	243
DC.....	243
Debug.....	52
DEBUG mode.....	52
DELAY.....	192
Diagnosis.....	221, 244
binary outputs (via current measurement).....	29
binary outputs (via voltage measurement).....	31, 33
overload.....	31, 33
overload (via current measurement).....	29
short circuit (via voltage measurement).....	29, 31, 33
wire break (via current measurement).....	29
wire break (via voltage measurement).....	31, 33
Diagnosis and error handling.....	221
Digital inputs.....	22, 64
Digital outputs.....	68
Dither.....	170, 244
DLC.....	244
DRAM.....	244
DTC.....	244

## E

ECU.....	244
EDS-file.....	244
Embedded software.....	245

# Index

EMC .....	245
EMCY .....	245
EMCY codes .....	
CANx .....	240
I/Os, system (standard side) .....	240
Error flags .....	240
Error tables .....	240
Errors .....	
CAN / CANopen .....	240
Ethernet .....	245
EUC .....	245
Example .....	
CANx_MASTER_SEND_EMERGENCY .....	99
CANx_MASTER_STATUS .....	104
CANx_SLAVE_SEND_EMERGENCY .....	110
CHECK_DATA .....	216
Initialisation of CANx_RECEIVE_RANGE in 4 cycles .....	94
NORM (1) .....	149
NORM (2) .....	149
NORM_HYDRAULIC .....	190
<b>F</b> .....	
Fast inputs .....	65
FAST_COUNT .....	151
Fault .....	221
FB, FUN, PRG in CODESYS .....	45
Feedback in case of externally supplied outputs .....	36
Feedback on bidirectional inputs/outputs .....	35
Feedback on outputs .....	35
FiFo .....	245
Flash memory .....	205, 245
FLASHREAD .....	209
FLASH-Speicher .....	15
FLASHWRITE .....	210
FRAM .....	15, 246
FRAM memory .....	205
FRAMREAD .....	211
FRAMWRITE .....	212
FREQUENCY .....	152
Function configuration .....	61, 62
Function configuration in general .....	61
Function configuration of the inputs and outputs .....	62
Function elements .....	
adapting analogue values .....	147
CAN layer 2 .....	80
CANopen master .....	96
CANopen SDOs .....	114
CANopen slave .....	106
controllers .....	191
counter functions for frequency and period measurement .....	150
data access and data check .....	214
hydraulic control .....	175
measuring / setting of time .....	202
Optimising the PLC cycle .....	136
processing input values .....	142
processing interrupts .....	136
PWM functions .....	161
SAE J1939 .....	119
saving, reading and converting data in the memory .....	205
serial interface .....	131
software reset .....	200

## G

GET_IDENTITY .....	217
GLR .....	193

## H

Hardware description .....	12
Hardware structure .....	13
Heartbeat .....	246
History of the instructions (CR0020, CR0505) .....	9
HMI .....	246
How is this documentation structured? .....	8

## I

ID .....	246
IEC 61131 .....	246
IEC user cycle .....	246
If runtime system / application is running .....	19
If the TEST pin is not active .....	20
ifm function elements .....	74
ifm function elements for the device CR0020 .....	80
ifm libraries for the device CR0020 .....	74
ifm weltweit • ifm worldwide • ifm à l'échelle internationale .....	262
INC_ENCODER .....	153
Information concerning the device .....	12
INIT state (Reset) .....	51
Input group I0 (I00...07 / ANALOG0...7) .....	23
Input group I1 (I10...17 / FRQ0...3) .....	24
Input group I2 (I20...27) .....	25
Input group I3 (I30...I37) .....	26
Input group I4 (I40...I47) .....	26
INPUT_ANALOG .....	144
INPUT_CURRENT .....	145
INPUT_VOLTAGE .....	146
Inputs .....	
Address assignment (standard side) (16...40 inputs) .....	231
Addresses and variables (standard side) (16...40 inputs) .....	238
operating modes (standard side) (16...40 inputs) .....	234
Inputs (technology) .....	21
Inputs I10...13 .....	24
Inputs I14...17 / FRQ0...3 .....	24
Inputs I20...23 .....	25
Inputs I24...27 / CYL0...3 .....	25
Instructions .....	246
Intended use .....	247
Interface description .....	39
Interrupt .....	53
Interrupt processing .....	136
IP address .....	247
ISO 11898 .....	247
ISO 11992 .....	247
ISO 16845 .....	247
<b>J</b> .....	
J1939 .....	247
J1939_x .....	120
J1939_x_GLOBAL_REQUEST .....	121
J1939_x_RECEIVE .....	123
J1939_x_RESPONSE .....	125



# Index

J1939_x_SPECIFIC_REQUEST .....	127
J1939_x_TRANSMIT .....	129
JOYSTICK_0 .....	179
JOYSTICK_1 .....	182
JOYSTICK_2 .....	186

## L

Latching .....	16
LED .....	38, 247
Libraries .....	43
Library ifm_CAN1_EXT_Vxxyzz.LIB .....	78
Library ifm_CR0020_CANOpenMaster_V04yynn.LIB .....	77
Library ifm_CR0020_CANOpenSlave_V04yynn.LIB .....	77
Library ifm_CR0020_V06yzz.LIB .....	75
Library ifm_hydraulic_16bitOS05_Vxxyzz.LIB .....	79
Library ifm_J1939_x_Vxxyzz.LIB .....	78
Link .....	247
LSB .....	247

## M

MAC-ID .....	248
manual .....	208
Manual data storage .....	208
Master .....	248
MEMCPY .....	213
Memory, available .....	15
MEMORY_RETAIN_PARAM .....	207
Misuse .....	248
MMI .....	248
Monitoring and securing mechanisms .....	19
Monitoring concept .....	18
Monitoring of the supply voltage VBRR .....	18
MRAM .....	248
MSB .....	248

## N

Network variables .....	73
NMT .....	248
No runtime system .....	51
Node .....	248
Node Guarding .....	248
NORM .....	148
NORM_HYDRAULIC .....	189
Note on wiring .....	34
Note the cycle time! .....	45
Notizen • Notes • Notes .....	258

## O

Obj / object .....	249
Object directory .....	249
OBV .....	249
OCC_TASK .....	162
One-time mechanisms .....	20
OPC .....	249
Operating modes .....	52
Operating modes of the inputs / outputs .....	234
Operating principle .....	18
Operating principle of the delayed switch-off .....	16
Operating principle of the monitoring concept .....	18

Operating states .....	48
application program is available .....	50
application program is not available .....	49
runtime system is not available .....	48
Operational .....	249
Output group Q1Q2 (Q10...13 / Q20...23) .....	28, 70
Output group Q3 (Q30...37) .....	30, 71
Output group Q4 (Q40...47) .....	32, 72
OUTPUT_CURRENT .....	164
OUTPUT_CURRENT_CONTROL .....	165
Outputs .....	
address assignment (standard side) (0...24 outputs) .....	233
Addresses and variables (standard side) (0...24 outputs) .....	239
operating modes (standard side) (0...24 outputs) .....	236
permitted operating modes .....	237
Outputs (technology) .....	27
Overview .....	
documentation modules for ecomatmobile devices .....	6

## P

Parameters of internal structures .....	103
PC card .....	249
PCMCIA card .....	249
PDM .....	249
PDO .....	249
PDU .....	250
Performance limits of the device .....	53
PERIOD .....	156
PERIOD_RATIO .....	158
PES .....	250
PGN .....	250
PHASE .....	160
Pictogram .....	250
Pictograms .....	7
PID controller .....	195, 197, 250
PID1 .....	195
PID2 .....	197
PLC configuration .....	58, 250
Please note! .....	10
Possible operating modes inputs/outputs .....	234
Pre-Op .....	250
Previous knowledge .....	11
Prinziple block diagram .....	14
Process image .....	250
Process input values .....	142
Programming notes for CODESYS projects .....	44
PT1 .....	199
PWM .....	167, 251
PWM diather .....	170
PWM frequency .....	168
PWM outputs .....	68
PWM outputs .....	27
PWM100 .....	171
PWM1000 .....	173

## R

Ramp function .....	170
radiometric .....	251
RAW-CAN .....	251
Reaction in case of an error .....	222



# Index

Recommended setting .....	198
Recommended settings .....	196
Reinstall the runtime system .....	55
Relay .....	
important notes! .....	222
Relays .....	13
important notes! .....	17
remanent .....	251
Reset .....	51
Response to system errors .....	223
Restrictions for the use of FBs .....	53
Retain variables .....	73
ro .....	251
RTC .....	251
Run .....	51
RUN state .....	51
Runtime system .....	42, 251
rw .....	251

## S

SAE J1939 .....	119, 252
Safety instructions .....	10
Safety instructions about Reed relays .....	34, 63
Save boot project .....	47
Save, read and convert data .....	205
SD card .....	252
SDO .....	252
Self-test .....	252
Serial interface .....	39, 131
Serial mode .....	52
SERIAL_MODE .....	52
SERIAL_PENDING .....	132
SERIAL_RX .....	133
SERIAL_SETUP .....	134
SERIAL_TX .....	135
Set up the programming system .....	57
Set up the programming system manually .....	57
Set up the programming system via templates .....	60
Set up the runtime system .....	54
Set up the target .....	58
SET_DEBUG .....	218
SET_IDENTITY .....	219
SET_INTERRUPT_I .....	137
SET_INTERRUPT_XMS .....	140
SET_PASSWORD .....	220
Setting control .....	191
Setting rule .....	191
Setting rule for a controller .....	191
Slave .....	252
Slave information .....	104
SOFTRESET .....	201

Software controller configuration .....	58
Software description .....	41
Software modules for the device .....	41
Software reset .....	200
SRAM .....	15
Start-up behaviour of the controller .....	11
Status LED .....	38
STOP state .....	51
Stopp .....	51
stopped .....	252
Storage types for data backup .....	205
Structure Emergency_Message .....	104
Structure node status .....	104
Symbols .....	252
System description .....	12
System flags .....	224
16...40 inputs and 24...0 outputs (standard side) .....	229
CAN .....	225
error flags (standard side) .....	226
LED (standard side) .....	227
SAE J1939 .....	225
voltages (standard side) .....	228
SYSTEM STOP state .....	51
System time .....	202
System variable .....	253
System variables .....	61

## T

Target .....	253
TCP .....	253
Template .....	253
Test .....	52
TEST mode .....	52
TIMER_READ .....	203
TIMER_READ_US .....	204

## U

UDP .....	253
Update the runtime system .....	56
Use, intended .....	253
Using ifm downloader .....	47
Using ifm maintenance tool .....	47

## V

Variables .....	73
Verify the installation .....	56

## W

watchdog .....	53, 253
Watchdog .....	253
Watchdog behaviour .....	53
What do the symbols and formats mean? .....	7
What previous knowledge is required? .....	11
Wiring .....	34
wo .....	253

## 10 Notizen • Notes • Notes



© ifm electronic gmbh

www.ifm.com

© ifm electronic gmbh



www.ifm.com

© ifm electronic gmbh



www.ifm.com

© ifm electronic gmbh



www.ifm.com

# 11 ifm weltweit • ifm worldwide • ifm à l'échelle internationale

Version: 2015-03-06

8310

[www.ifm.com](http://www.ifm.com) • Email: [info@ifm.com](mailto:info@ifm.com)

Service hotline: 0800 / 16 16 16 (only Germany, Mo-Fr 07.00...18.00 h)

## ifm Niederlassungen • Sales offices • Agences

D	ifm electronic gmbh Vertrieb Deutschland Niederlassung Nord • 31135 Hildesheim • Tel. 0 51 21 / 76 67-0 Niederlassung West • 45128 Essen • Tel. 02 01 / 3 64 75 -0 Niederlassung Mitte-West • 58511 Lüdenscheid • Tel. 0 23 51 / 43 01-0 Niederlassung Süd-West • 64646 Heppenheim • Tel. 0 62 52 / 79 05-0 Niederlassung Baden-Württemberg • 73230 Kirchheim • Tel. 0 70 21 / 80 86-0 Niederlassung Bayern • 82178 Puchheim • Tel. 0 89 / 8 00 91-0 Niederlassung Ost • 07639 Tautenhain • Tel. 0 36 601 / 771-0 ifm electronic gmbh • Friedrichstraße 1 • 45128 Essen
A	ifm electronic gmbh • 1120 Wien • Tel. +43 16 17 45 00
OFF	ifm efector pty ltd. • Mulgrave Vic 3170 • Tel. +61 3 00 365 088
B, L	ifm electronic N.V. • 1731 Zellik • Tel. +32 2 / 4 81 02 20
BR	ifm electronic Ltda. • 03337-000, Sao Paulo SP • Tel. +55 11 / 2672-1730
CH	ifm electronic ag • 4 624 Härkingen • Tel. +41 62 / 388 80 30
CN	ifm electronic (Shanghai) Co. Ltd. • 201203 Shanghai • Tel. +86 21 / 3813 4800
CND	ifm efector Canada inc. • Oakville, Ontario L6K 3V3 • Tel. +1 800-441-8246
CZ	ifm electronic spol. s.r.o. • 25243 Průhonice • Tel. +420 267 990 211
DK	ifm electronic a/s • 2605 BROENDBY • Tel. +45 70 20 11 08
E	ifm electronic s.a. • 08820 El Prat de Llobregat • Tel. +34 93 479 30 80
F	ifm electronic s.a. • 93192 Noisy-le-Grand Cedex • Tél. +33 0820 22 30 01
FIN	ifm electronic oy • 00440 Helsinki • Tel. +358 75 329 5000
GB, IRL	ifm electronic Ltd. • Hampton, Middlesex TW12 2HD • Tel. +44 208 / 213-0000
GR	ifm electronic Monoprosopi E.P.E. • 15125 Amaroussio • Tel. +30 210 / 6180090
H	ifm electronic kft. • 9028 Győr • Tel. +36 96 / 518-397
I	ifm electronic s.a. • 20041 Agrate-Brianza (MI) • Tel. +39 039 / 68.99.982
IL	Astragal Ltd. • Azur 58001 • Tel. +972 3 -559 1660
IND	ifm electronic India Branch Office • Kolhapur, 416234 • Tel. +91 231-267 27 70
J	efector co., ltd. • Chiba-shi, Chiba 261-7118 • Tel. +81 043-299-2070
MAL	ifm electronic Pte. Ltd. • 47100 Puchong Selangor • Tel. +603 8063 9522
MEX	ifm efector S. de R. L. de C. V. • Monterrey, N. L. 64630 • Tel. +52 81 8040-3535
N	Sivilingeniør J. F. Knudtzen A/S • 1396 Billingstad • Tel. +47 66 / 98 33 50
NL	ifm electronic b.v. • 3843 GA Harderwijk • Tel. +31 341 / 438 438
P	ifm electronic s.a. • 4410-136 São Félix da Marinha • Tel. +351 223 / 71 71 08
PL	ifm electronic Sp. z o.o. • 40-106 Katowice • Tel. +48 32-608 74 54
RA, ROU	ifm electronic s.r.l. • 1107 Buenos Aires • Tel. +54 11 / 5353 3436
ROK	ifm electronic Ltd. • 140-884 Seoul • Tel. +82 2 / 790 5610
RP	Gram Industrial, Inc. • 1770 Mantilupa City • Tel. +63 2 / 850 22 18
RUS	ifm electronic • 105318 Moscow • Tel. +7 495 921-44-14
S	ifm electronic a b • 41250 Göteborg • Tel. +46 31 / 750 23 00
SGP	ifm electronic Pte. Ltd. • Singapore 609 916 • Tel. +65 6562 8661/2/3
SK	ifm electronic s.r.o. • 835 54 Bratislava • Tel. +421 2 / 44 87 23 29
THA	SCM Alliances Co., Ltd. • Bangkok 10 400 • Tel. +66 02 615 4888
TR	ifm electronic Ltd. Sti. • 34381 Sisli/Istanbul • Tel. +90 212 / 210 50 80
UA	TOV ifm electronic • 02660 Kiev • Tel. +380 44 501 8543
USA	ifm efector inc. • Exton, PA 19341 • Tel. +1 610 / 5 24-2000
ZA	ifm electronic (Pty) Ltd. • 0157 Pretoria • Tel. +27 12 345 44 49

Technische Änderungen behalten wir uns ohne vorherige Ankündigung vor.

We reserve the right to make technical alterations without prior notice.

Nous nous réservons le droit de modifier les données techniques sans préavis.