

ifm electronic



Operating instructions
Through-beam sensor


efector200

OGE08x

OGS08x

UK

704942 / 00 10 / 2010




1 Functions and features

The through-beam sensor detects objects and materials without contact and indicates their presence by a switching signal.


For the range see the type label.

2 Installation




- ▶ Install the receiver (OGE08x) and secure it to a bracket.
- ▶ Align the transmitter (OGS08x) to the receiver and secure it also to a bracket.
- > Maximum range only with accurate alignment.


3 Electrical connection

- ▶ Disconnect power.
 - ▶ Connect the unit as follows.
-  ▶ The device shall be protected by a Listed fuse rated 2A max
- ▶ Recommendation: check the unit for reliable function after a short circuit

3.1 Transmitter



3.2 Receiver



4 Operation

Check whether the sensor operates correctly.

- Receiver (OGE08x): The yellow LED is lit when the switching output is switched.
- Transmitter (OGS08x): The green LED is lit when the sensor is ready for operation.

5 Maintenance

- Keep the lens of the sensor free from soiling.
- For cleaning do not use any solvents or cleaning agents which could damage the plastic material.