



Device Manual  
SmartPLC DataLine  
with EtherCAT slave interface

**AC1433**  
**AC1434**

Master Profile: M4  
Firmware: 4.2.x

English

# Contents

|          |                                                                     |           |
|----------|---------------------------------------------------------------------|-----------|
| <b>1</b> | <b>Preliminary note</b>                                             | <b>5</b>  |
| 1.1      | Legal and copyright information .....                               | 5         |
| 1.2      | Purpose of the document .....                                       | 5         |
| 1.3      | Symbols and styles used .....                                       | 6         |
| 1.4      | Overview: User documentation for AC1433/34 .....                    | 6         |
| 1.5      | Modification history .....                                          | 7         |
| <b>2</b> | <b>Safety instructions</b>                                          | <b>8</b>  |
| 2.1      | General safety instructions .....                                   | 8         |
| 2.2      | Required background knowledge .....                                 | 8         |
| 2.3      | Tampering with the unit .....                                       | 9         |
| 2.4      | Warnings used .....                                                 | 9         |
| <b>3</b> | <b>System description</b>                                           | <b>10</b> |
| 3.1      | Intended use .....                                                  | 11        |
| 3.1.1    | Permitted use .....                                                 | 11        |
| 3.1.2    | Prohibited use .....                                                | 11        |
| 3.2      | Information concerning the device .....                             | 12        |
| 3.2.1    | Overview .....                                                      | 12        |
| 3.2.2    | Operating elements .....                                            | 13        |
| 3.2.3    | Display elements .....                                              | 13        |
| 3.2.4    | CODESYS PLC .....                                                   | 13        |
| 3.2.5    | Interfaces .....                                                    | 14        |
| 3.2.6    | Required accessories .....                                          | 15        |
| <b>4</b> | <b>Operation</b>                                                    | <b>16</b> |
| 4.1      | Control of the graphical user interface .....                       | 16        |
| 4.1.1    | Function keys .....                                                 | 17        |
| 4.1.2    | Arrow keys .....                                                    | 17        |
| 4.2      | Menu view .....                                                     | 18        |
| 4.2.1    | Menu navigation .....                                               | 19        |
| 4.2.2    | Navigation aids .....                                               | 19        |
| 4.3      | Page view .....                                                     | 21        |
| 4.3.1    | Navigate on a page .....                                            | 21        |
| 4.3.2    | Use navigation aids .....                                           | 21        |
| 4.3.3    | Description of the control elements .....                           | 22        |
| 4.4      | Remote access .....                                                 | 34        |
| 4.4.1    | General .....                                                       | 34        |
| 4.4.2    | Recommended browsers .....                                          | 34        |
| 4.4.3    | Operating instructions .....                                        | 35        |
| <b>5</b> | <b>Menu</b>                                                         | <b>38</b> |
| 5.1      | Start screen .....                                                  | 38        |
| 5.2      | Menu functions .....                                                | 39        |
| 5.2.1    | Additional functions .....                                          | 39        |
| 5.3      | Quick setup .....                                                   | 40        |
| 5.3.1    | Quick setup: Project AS-i networks .....                            | 41        |
| 5.3.2    | Quick setup: Configure the operating mode of the AS-i masters ..... | 42        |
| 5.3.3    | Quick setup: Configure the output access .....                      | 43        |
| 5.3.4    | Quick setup: Access the device via QR code .....                    | 43        |

## Content

|          |                                                                      |            |
|----------|----------------------------------------------------------------------|------------|
| 5.3.5    | Quick setup: Configure the EtherCAT interface.....                   | 44         |
| 5.3.6    | Quick setup: Set the Configuration interface 1.....                  | 45         |
| 5.3.7    | Quick setup: Set the configuration interface 2.....                  | 46         |
| 5.3.8    | Quick setup: Address the AS-i slaves connected to AS-i master 1..... | 47         |
| 5.3.9    | Quick setup: Address the AS-i slaves connected to AS-i master 2..... | 48         |
| 5.4      | AS-i 1 / AS-i 2.....                                                 | 49         |
| 5.4.1    | AS-i 1 / AS-i 2: Master setup.....                                   | 50         |
| 5.4.2    | AS-i 1 / AS-i 2: Diagnosis.....                                      | 52         |
| 5.4.3    | AS-i 1 / AS-i 2: AS-i slaves.....                                    | 54         |
| 5.5      | System.....                                                          | 61         |
| 5.5.1    | System: Programmable Logic Controller (PLC).....                     | 62         |
| 5.5.2    | System: Information.....                                             | 68         |
| 5.5.3    | System: Setup.....                                                   | 69         |
| 5.5.4    | System: Diagnosis.....                                               | 82         |
| 5.6      | Interfaces.....                                                      | 83         |
| 5.6.1    | Interfaces: Configuration interface 1.....                           | 84         |
| 5.6.2    | Interfaces: Configuration interface 2.....                           | 86         |
| 5.6.3    | Interfaces: EtherCAT interface.....                                  | 87         |
| 5.7      | ifm system solutions.....                                            | 92         |
| 5.7.1    | Notes on ifm system solutions.....                                   | 93         |
| 5.7.2    | Show information about installed ifm apps.....                       | 94         |
| 5.7.3    | Install single/basic app.....                                        | 95         |
| 5.7.4    | Install multi app.....                                               | 96         |
| 5.7.5    | Update ifm apps.....                                                 | 97         |
| 5.7.6    | Uninstall ifm apps.....                                              | 97         |
| <b>6</b> | <b>Setup</b>                                                         | <b>99</b>  |
| 6.1      | Connect the device to the periphery.....                             | 99         |
| 6.1.1    | EtherCAT interface.....                                              | 99         |
| 6.1.2    | Ethernet configuration interfaces.....                               | 99         |
| 6.2      | Start screen 'Basic settings'.....                                   | 100        |
| 6.2.1    | Change the basic settings of the device.....                         | 100        |
| 6.3      | Update the firmware of the device.....                               | 102        |
| 6.3.1    | Behaviour of the settings upon firmware update.....                  | 102        |
| 6.3.2    | Firmware update from SD card.....                                    | 103        |
| 6.3.3    | Firmware update via the web interface.....                           | 104        |
| 6.4      | Connect and address AS-i slaves.....                                 | 106        |
| 6.5      | Configure EtherCAT interface.....                                    | 106        |
| 6.6      | Set Ethernet configuration interfaces.....                           | 106        |
| 6.7      | Exchange AS-i slave.....                                             | 107        |
| <b>7</b> | <b>Troubleshooting</b>                                               | <b>108</b> |
| 7.1      | Status LED.....                                                      | 108        |
| 7.1.1    | Status LED: Basic device.....                                        | 108        |
| 7.1.2    | Status LED: Fieldbus EtherCAT.....                                   | 108        |
| 7.1.3    | Status LED: Configuration interface 2 (X8).....                      | 109        |
| 7.2      | Start screen: Status LEDs.....                                       | 110        |
| 7.2.1    | Status of the web interface.....                                     | 110        |
| 7.2.2    | Operating mode of the AS-i master.....                               | 110        |
| 7.2.3    | Control instance of the AS-i outputs.....                            | 110        |
| 7.2.4    | EtherCAT: fieldbus status.....                                       | 110        |
| 7.2.5    | EtherCAT: Error status.....                                          | 111        |
| 7.3      | Online diagnosis function.....                                       | 112        |
| 7.3.1    | Message types.....                                                   | 112        |
| 7.3.2    | Locate error sources.....                                            | 112        |
| 7.4      | Online Support Center (OSC).....                                     | 113        |
| 7.4.1    | OSC: View current error messages.....                                | 114        |
| 7.4.2    | OSC: Show message history.....                                       | 115        |

|           |                                                                      |            |
|-----------|----------------------------------------------------------------------|------------|
| <b>8</b>  | <b>Appendix</b>                                                      | <b>116</b> |
| 8.1       | Approval tests / certifications .....                                | 116        |
| 8.2       | Technical data.....                                                  | 117        |
| 8.2.1     | Housing .....                                                        | 117        |
| 8.2.2     | Display elements .....                                               | 117        |
| 8.2.3     | Operation.....                                                       | 117        |
| 8.2.4     | Power supply connections.....                                        | 118        |
| 8.2.5     | Interface .....                                                      | 118        |
| 8.2.6     | Programmable Logic Controller (PLC) .....                            | 118        |
| 8.3       | Address assignment in Ethernet networks .....                        | 119        |
| 8.4       | Configuration interfaces: Connection concepts .....                  | 120        |
| 8.4.1     | Direct connection.....                                               | 120        |
| 8.4.2     | Connection via Ethernet network.....                                 | 121        |
| 8.5       | AS-i master .....                                                    | 122        |
| 8.5.1     | Operating modes of the AS-i master .....                             | 123        |
| 8.5.2     | Master flags.....                                                    | 124        |
| 8.6       | AS-i slaves .....                                                    | 125        |
| 8.6.1     | Profiles of AS-i slaves.....                                         | 126        |
| 8.7       | Fieldbus EtherCAT.....                                               | 135        |
| 8.7.1     | Parameter data.....                                                  | 136        |
| 8.7.2     | Cyclic data.....                                                     | 139        |
| 8.7.3     | Acyclic data .....                                                   | 152        |
| 8.7.4     | EtherCAT projection software: Programmers' notes.....                | 157        |
| 8.8       | OSC messages .....                                                   | 166        |
| 8.8.1     | OSC messages: System .....                                           | 166        |
| 8.8.2     | OSC messages: AS-i 1 / AS-i 2.....                                   | 167        |
| <b>9</b>  | <b>Index</b>                                                         | <b>168</b> |
| <b>10</b> | <b>ifm weltweit • ifm worldwide • ifm à l'échelle internationale</b> | <b>171</b> |

# 1 Preliminary note

## Contents

|                                                  |   |
|--------------------------------------------------|---|
| Legal and copyright information .....            | 5 |
| Purpose of the document .....                    | 5 |
| Symbols and styles used.....                     | 6 |
| Overview: User documentation for AC1433/34 ..... | 6 |
| Modification history .....                       | 7 |

14801

## 1.1 Legal and copyright information

1631

© All rights reserved by **ifm electronic gmbh**. No part of this manual may be reproduced and used without the consent of **ifm electronic gmbh**.

- All product names, pictures, companies or other brands used on our pages are the property of the respective rights owners:
- AS-i is the property of the AS-International Association, (→ [www.as-interface.net](http://www.as-interface.net))
- CAN is the property of the CiA (CAN in Automation e.V.), Germany (→ [www.can-cia.org](http://www.can-cia.org))
- CODESYS™ is the property of the 3S – Smart Software Solutions GmbH, Germany (→ [www.codesys.com](http://www.codesys.com))
- DeviceNet™ is the property of the ODVA™ (Open DeviceNet Vendor Association), USA (→ [www.odva.org](http://www.odva.org))
- EtherNet/IP® is the property of the →ODVA™
- EtherCAT® is a registered trade mark and patented technology, licensed by Beckhoff Automation GmbH, Germany
- IO-Link® (→ [www.io-link.com](http://www.io-link.com)) is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- ISOBUS is the property of the AEF – Agricultural Industry Electronics Foundation e.V., Deutschland (→ [www.aef-online.org](http://www.aef-online.org))
- Microsoft® is the property of the Microsoft Corporation, USA (→ [www.microsoft.com](http://www.microsoft.com))
- PROFIBUS® is the property of the PROFIBUS Nutzerorganisation e.V., Germany (→ [www.profibus.com](http://www.profibus.com))
- PROFINET® is the property of the →PROFIBUS Nutzerorganisation e.V., Germany
- Windows® is the property of the →Microsoft Corporation, USA

## 1.2 Purpose of the document

7471

This document applies to devices of the type "SmartPLC DataLine with EtherNet/IP device interface (art. no.: AC1433/34)

It is part of the device and contains information about the correct handling of the product.

- Read this document before using the device.
- Keep this document during the service life of the device.

## 1.3 Symbols and styles used

13839

- ... Instructions
- > ... Reaction, result
- ... Cross-reference or internet link
- 123 Decimal number
- 0x123 Hexadecimal number
- 0b010 Binary number
- [...] Designation of pushbuttons, buttons or indications

## 1.4 Overview: User documentation for AC1433/34

6998

ifm electronic provides the following user documentation for the models of the device class "SmartPLC DataLine with EtherNet/IP device interface":

| Document                 | Content / Description                                                                                                                                                                                                                                                                 |
|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Data sheet               | Technical data of the device as a table                                                                                                                                                                                                                                               |
| Operating instructions * | <ul style="list-style-type: none"> <li>▪ Notes on mounting and electrical installation of the device</li> <li>▪ Set-up, description of the operating and display elements, maintenance information, scale drawing</li> </ul>                                                          |
| Device manual            | <ul style="list-style-type: none"> <li>▪ Notes on operation of the device via GUI and web interface</li> <li>▪ Error elimination</li> <li>▪ Description of the fieldbus data</li> </ul>                                                                                               |
| Supplement device manual | <ul style="list-style-type: none"> <li>▪ Description of the acyclic data sets and the command interface</li> </ul>                                                                                                                                                                    |
| Programming manual       | <ul style="list-style-type: none"> <li>▪ Creation of a project with the device using CODESYS</li> <li>▪ Configuration of the device using CODESYS</li> <li>▪ Programming of the PLC of the device</li> <li>▪ Description of the device-specific CODESYS function libraries</li> </ul> |

\*... The operating instructions are supplied with the device.



The user can download all documents from the ifm website.

## 1.5 Modification history

21676

| Version | Topic                                                                                                                                                                                                        | Date    |
|---------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| 00      | New creation of document                                                                                                                                                                                     | 07/2017 |
| 01      | Correction: <ul style="list-style-type: none"> <li>Chapter 3.2.1: Designation of EtherCAT interface X7 (IN) and X6 (OUT)</li> <li>Ch. 6.1: Designation of EtherCAT interface X7 (IN) and X6 (OUT)</li> </ul> | 05/2018 |

## 2 Safety instructions

### Contents

|                                     |   |
|-------------------------------------|---|
| General safety instructions .....   | 8 |
| Required background knowledge ..... | 8 |
| Tampering with the unit .....       | 9 |
| Warnings used .....                 | 9 |

213

### 2.1 General safety instructions

8516

Read this document before setting up the product and keep it during the entire service life.

Only use the product for its intended purpose.

If the operating instructions or the technical data are not adhered to, personal injury and/or damage to property may occur.

Improper or non-intended use may lead to malfunctions of the device, to unwanted effects in the application or to a loss of the warranty claims.

The manufacturer assumes no liability for any consequences caused by tampering with the device or incorrect use by the operator.

- ▶ Observe these operating instructions.
- ▶ Adhere to the warning notes on the product.

### 2.2 Required background knowledge

6919

This document is intended for specialists. Specialists are people who, based on their relevant training and experience, are capable of identifying risks and avoiding potential hazards that may be caused during operation or maintenance of the product.

For programming these people should also have knowledge of control technology experience in PLC programming to IEC 61131-3.

The document contains information about the correct handling of the product.



## 2.3 Tampering with the unit

11242

### **WARNING**

Tampering with the units can affect the safety of operators and machinery!

Tampering with the units is not allowed.

In case of non-compliance our liability and warranty expire.

- ▶ Do not open the devices!
- ▶ Do not insert any objects into the devices!
- ▶ Prevent metal foreign bodies from penetrating!

## 2.4 Warnings used

13685

### **WARNING**

Death or serious irreversible injuries may result.

### **CAUTION**

Slight reversible injuries may result.

### **NOTICE**

Property damage is to be expected or may result.



Important note  
Non-compliance may result in malfunction or interference.



Information  
Supplementary note.

### 3 System description

#### Contents

|                                         |    |
|-----------------------------------------|----|
| Intended use .....                      | 11 |
| Information concerning the device ..... | 12 |

975

## 3.1 Intended use

### Contents

|                     |    |
|---------------------|----|
| Permitted use ..... | 11 |
| Prohibited use..... | 11 |

5310

### 3.1.1 Permitted use

7103

The device is designed for operation in the control cabinet.

The device may only be used for the following purposes:

- as AS-i master in 1 or 2 AS-i networks to control the data exchange to the sensor/actuator level
- as gateway between the AS-i network and a higher-level controller (EtherCAT-Controller = Host; e.g. PLC) via the fieldbus interface
- as Programmable Logic Controller (PLC) for program-based parameter setting, control and regulation of the AS-i slaves connected to the device
- as EtherCAT master (software extension)
- as fieldbus slave (software extension)

### 3.1.2 Prohibited use

22053

The device may not be used beyond the limits of the technical data (→ **Technical data** (→ p. [117](#)))!

## 3.2 Information concerning the device


### Contents

|                            |    |
|----------------------------|----|
| Overview .....             | 12 |
| Operating elements .....   | 13 |
| Display elements .....     | 13 |
| CODESYS PLC .....          | 13 |
| Interfaces .....           | 14 |
| Required accessories ..... | 15 |

5330

### 3.2.1 Overview

7237



## 3.2.2 Operating elements

15840

The device provides the following operating elements.

### Arrow and function keys

15867

Below the display is the key panel with two function keys and four arrow keys. The operator controls the Graphical User Interface (GUI) of the device with the keys.

Operating notes: → **Operation** (→ p. [16](#))

## 3.2.3 Display elements

7062

The device provides the following display elements:

### Display

7083

The display is used to display the Graphical User Interface (GUI) of the device.

Operating notes: → **Operation** (→ p. [16](#))

Technical data: → **Technical data** (→ p. [117](#))

### Status LEDs

18985

The device features the following status LEDs which display the current status of system components.

Meaning of the LED colours and flashing frequencies: → **Status LED** (→ p. [108](#))

## 3.2.4 CODESYS PLC

7095

The device features a Programmable Logic Controller (PLC). The PLC can run the following application types:

- Applications that have been created with the IEC 61131-3 compliant programming software "CODESYS Development System" (from version 3.5 SP9 Patch 7 Hotfix 3)
- System solutions that have been provided by ifm electronic

Technical data: → **Programmable Logic Controller (PLC)** (→ p. [118](#))



For information about the programming of the device-internal PLC with CODESYS, please refer to the programming manual:

→ [www.ifm.com](http://www.ifm.com) > product page > [Downloads]

## 3.2.5 Interfaces

15839

The device provides the following interfaces:

### Ethernet configuration interfaces

7107

The configuration interface 1 (X3) is behind the front flap of the device.

The configuration interface 2 (X8) is underneath the EtherCAT interface (X6/X7).

The user can access the following functions via both interfaces:

- web interface for device configuration and diagnostics
- Programming of the device-internal PLC and the fail-safe PLC with CODESYS
- Operation as additional fieldbus interface

Possible network topologies: → **Configuration interfaces: Connection concepts** (→ p. [120](#))

Technical data: → **Technical data** (→ p. [117](#))

### EtherCAT fieldbus interface

12113

The device communicates with the higher-level control instance of the EtherCAT network via the EtherCAT interface (X6/X7).

- Notes regarding connection concepts: → **Configuration interfaces: Connection concepts** (→ p. [120](#))
- Technical data: → **Technical data** (→ p. [117](#))

### SD card slot

9135

The SD card slot (X5) is located behind the front flap of the device. The following actions can be performed with an SD card:

- update the firmware of the device
- save/restore the device configuration

Technical data: → **Technical data** (→ p. [117](#))

### 3.2.6 Required accessories

6926

To be able to operate the device in a sensible way you need the following accessories (not supplied with the device):

- Depending on the selected voltage supply (→ Operating instructions) you need:
  - a power supply for the 24 V power supply (e.g. art. no. DN3011)
  - for each AS-i master one AS-i power supply each (e.g. art. no. AC1236)
  - a data decoupling module AC1250 (accessory, optional)
- AS-i slaves.

## 4 Operation

### Contents


|                                               |    |
|-----------------------------------------------|----|
| Control of the graphical user interface ..... | 16 |
| Menu view.....                                | 18 |
| Page view .....                               | 21 |
| Remote access.....                            | 34 |

14805

### 4.1 Control of the graphical user interface

6930

Below the display is the key panel with six membrane keys. The operator controls the graphical user interface of the device with these keys. The key panel is closely linked to the navigation status bar.





## 4.1.1 Function keys


7090

The two **function keys** allow the operator to trigger specified actions (e.g. tick a checkbox). The function of the function keys changes depending on the context.

The two **text fields in the navigation status bar** are associated with the function keys located directly below the display. They indicate the action that will be triggered if the function key is pressed in the current work step. If the function key is not labelled, it means that it has no function in the present situation.

Example (→ figure):

- ▶ The left function key triggers the action [Select].
- ▶ The right function key triggers the action [Back].



## 4.1.2 Arrow keys

7091

The four **arrow keys** [▲], [▶], [▼] and [◀] can be used for navigation and selection.

The **navigation compass** shows which of the four arrow keys can be used in the respective work step.


Examples:



All arrow keys are active and will trigger a device response when pressed.




Only the arrow keys [▶] and [▼] are active and will trigger a device response when pressed.



## 4.2 Menu view

6996

The menu view allows the user to select the menu page with the required control or display function.



Long texts are displayed as scrolling text in the info bar.

## 4.2.1 Menu navigation

10967

The central operating elements in the menu view are the three **navigation bars**. They reflect the menu structure of the device software. Each navigation bar represents a menu level. The symbols in a navigation bar represent the submenus and menu items.

Rules for menu navigation:

- ▶ Use [◀] / [▶] to navigate within a menu level.
- > The selected symbol has the **focus** (= orange frame).
- > If the selected symbol has a submenu, the corresponding **subnavigation bar** will automatically appear.
- ▶ Use [▼] to go one menu level down.
- ▶ Use [▲] to go one menu level up.

At the lowest menu level:

- ▶ Press [Select] function key to go to the page of the selected menu item (→ **Page view** (→ p. [21](#))).

In the main navigation bar:


- ▶ Press [Back] function key to return to the start screen (→ **Start screen** (→ p. [38](#))).

## 4.2.2 Navigation aids

15830

The following screen elements help you navigate through the menu:

- > The **info bar** shows the navigation path of the selected menu symbol.
- > The **navigation compass** shows which navigation steps are possible from the current position.



### Legend:

- ① Info bar

Navigation path to the focused menu element:  
[System] > [PLC] > [Setup]

- ② Menu element with focus

Navigation path to the focused menu element:



## Example

11770

To access the menu page containing the setting options for the device-internal PLC:


1. > Initial position when accessing the menu screen
2. ► Use [▶] to select the [System] menu symbol.
  - > The focus is on the [System] menu symbol.
  - > The first subnavigation bar appears.
3. ► Use [▼] to change to the first subnavigation barh.
  - > The focus is on the [Diagnosis] menu symbol.
4. ► Use [◀] to select the [PLC] menu symbol.
  - > The focus is on the [PLC] menu symbol.
  - > The second subnavigation bar appears.
5. ► Use [▼] to change to the second subnavigation bar.
  - > The focus is on the [Information] menu symbol.
6. ► Use [▶] to select the [Settings] menu symbol.
  - > The focus is on the [Settings] menu symbol.
  - Press the [Select] function key to go to the page view of the [Settings] menu item.
  - > The page shows the setting options for the device-internal PLC.



## 4.3 Page view

7959

The page view allows the user to select and execute a requested function.



### 4.3.1 Navigate on a page

15831

The page contains elements, that allow the operator to control the device or access information.

For page navigation, the following basic rules apply:

- ▶ Use the arrow keys [▼] / [▲] to change between the different page elements.
- > The selected element is marked (= orange frame).
- ▶ Use the [Back] function key to return to the tab menu / menu view.



Rules for using the different control elements: → **Description of the control elements** (→ p. [22](#))

### 4.3.2 Use navigation aids

14838

The following aids offer navigation users additional orientation:

- > The **info bar** shows detailed information about the selected element (focus).



Long texts are displayed as scrolling text in the info bar.

- > The active menu symbol in the **main navigation bar** has a dark background.
- > A **scroll bar** appears on the right side of the screen if the elements do not fit on the page.
- > The **navigation compass** shows the navigation options in the active work step.
- > The **text fields in the navigation status bar** show the current assignment of the function keys.

### 4.3.3 Description of the control elements

| Contents                  |    |
|---------------------------|----|
| Tab menu/Tab .....        | 23 |
| Button .....              | 24 |
| Checkbox.....             | 24 |
| List .....                | 25 |
| Slave selector .....      | 26 |
| Confirmation message..... | 31 |
| Numerical field .....     | 32 |
| Binary field .....        | 33 |

7013


A page consists of different control elements.

## Tab menu/Tab

8737

A tab menu groups together the different functions of a menu page. A tab menu consists of at least two tabs. A tab combines related functions.

Example:



- > The focused tab has an orange background
- > The info bar displays the name of the active tab (in this example: Errors / slave).
- > The symbols ◀ and ▶ indicate that there are more tabs on the left and right sides of the visible tab.
- > The page shows the control elements that belong to the currently selected tab.

Tabs can have the following background colours:

**Version** = Tab has the focus

**Version** = Tab is active

**Version** = Tab is inactive

Use:

### 1 Select the menu item

- ▶ Go to the menu item with the tab menu.
- > The tab menu appears.
- > The focus is on the left-hand tab.

### 2 Select a tab

- ▶ Use [◀] / [▶] arrow key to select the desired tab.
- > The focus (orange background) moves to the selected tab:  
**Version**
- > The page shows the functions of the selected tab.

### 3 Activate the menu page

- ▶ Press [Select] arrow key to go to the page that belongs to the active tab.
- > When going to the page, the tab menu remains visible.
- > The background colour of the active tab turns grey.  
**Version**

### 4 Carry out the desired functions

- ▶ Use [▼] to select and execute the desired function.

### 5 Change to tab menu

- ▶ Press [Back] function key to change to the tab menu.
- > The focus (orange background) moves to the active tab.

## Button

14196

A button allows the operator to carry out a specified action once. The caption on the button describes the action.


Example:



Use:

### 1 Select a button

- ▶ Use the arrow keys [▲] / [▼] to select a button.
- > The selected button gets an orange frame:



### 2 Activate the button


- ▶ Use [Select] function key to activate the selected button.
- > The function is executed.

## Checkbox

7038

A checkbox permits the user to activate/deactivate a parameter. A checkbox control element consists of a checkbox and a caption.


Example:



Use:

### 1 Select a checkbox

- ▶ Use [▲] / [▼] arrow key to select the checkbox
- > The focus (orange frame) moves to the selected checkbox



OR:



### 2 Check/uncheck a checkbox

- ▶ Use [Select] function key to check/uncheck the selected checkbox.
- > The status change is indicated:
  - ☑ = checkbox is checked
  - OR:
  - ☐ = checkbox is unchecked



The setting or clearing of a checkbox is not always immediately effective. Often the change must be confirmed by clicking a button (e.g. [Accept selection])!



## List

7042

A list provides a set of defined values. The operator can select precisely one value from this set (= 1 of n selection).


Examples:



Use:

### 1 Select a list

- ▶ Use [▲] / [▼] arrow key to select the list.
- > The focus (orange frame) moves to the selected list.




- > The list shows the active value: (in this example Gateway).

### 2 Activate the list

- ▶ Use [Select] function key to open the list.
- > The opened list shows the selectable values.

### 3 Select a value

- ▶ Use [▲] / [▼] arrow key to select the desired value from the list.
- > The background colour of the selected value turns orange.



### 4 Apply the selected value

- ▶ Use [Select] function key to apply the selected value.
- OR:
- Use [Back] function key to quit and close the list.
- > The list shows the selected value.



The set value will not always become effective immediately. Often the change must be confirmed by clicking a button (e.g. [Accept selection])!


## Slave selector

### Contents

|                                        |    |
|----------------------------------------|----|
| Overview of slave states.....          | 27 |
| Overview of free slave addresses ..... | 29 |

7018

The slave selector is used to select an AS-i slave or an AS-i address.



#### Legend:

- ① Indicator of AS-i master operating mode
- ② AS-i address symbol
- ③ Highlighted AS-i address (focus)
- ④ Status message of highlighted AS-i address

- > The **status LED** indicates the active operating mode of the AS-i master:
  - = AS-i master in protected mode
  - = AS-i master in projection mode
- > Every field represents an **AS-i address**. An AS-i address can be occupied by:
  - a single slave symbol
  - an A/B slave pair symbol
- > The row and column headers help to locate the AS-i address.

Example: address of the field selected in the picture

- row header: 1x (= tens digit of the AS-i address)
- column header: 8 (= units digit of the AS-i address)
- type of slave: single slave (= symbol fully occupies the address field)
- resulting AS-i address: 18


- > The symbol of the A/B slave pair appears when an A or B slave is used on this address.

The slave selector is used in the following overviews:

- Overview of slave states (→ **Overview of slave states** (→ p. [27](#)))
- Overview of free slave addresses (→ **Overview of free slave addresses** (→ p. [29](#)))

## Overview of slave states

6992



- > The slave selector shows an overview of the slaves in the selected AS-i network.
- > The symbol colour signals the slave status. Meaning of symbols and colours:  
→ **Slave status: colour code + symbols** (→ p. 28)
- > The text field displays the status of the selected AS-i slave.  
Possible status messages:
  - Slave active
  - Not projected (= configuration error)
  - Double address (= double address error)
  - Periphery (= periphery fault)

Use:

### 1 Select an AS-i slave

- ▶ Use the arrow keys [▲], [▶], [▼] and [◀] to select the desired AS-i slave.
- > The focus (= orange frame) is on the selected AS-i slave.
- > The info bar shows the address of the selected AS-i slave.
- > The text field shows a status message about the selected AS-i slave.

### 2 Activate the selected AS-i slave

- ▶ Use [Select] function key to activate the selected AS-i slave and go to the next menu page.  
OR:  
Use [Back] function key to cancel and leave the slave selector.

## Slave status: colour code + symbols

11236

| Single slave                                                                      | A/B slave                                                                         | Colour   | Meaning                                                                                                                                                                                         |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  |  | grey     | No slave found:<br>slave address is neither in the LPS nor in the LDS                                                                                                                           |
|  |  | green    | Slave is activated ( in LAS)                                                                                                                                                                    |
|  |  | red      | Configuration error type 1:<br>slave is projected (in LPS) but was not found (in LDS)                                                                                                           |
|  |  | yellow   | Slave signals a peripheral fault                                                                                                                                                                |
|  |  | pink     | Several slaves have the same address (double address error)                                                                                                                                     |
|  |  | grey red | Configuration error type 2:<br><ul style="list-style-type: none"> <li>the found slave (in LDS) is not projected (in LPS)</li> <li>the found slave has another profile than projected</li> </ul> |

## Meaning of the colour combinations (example: configuration error type 2)

11237

| Symbol                                                                              | Colour           | Meaning                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | grey red<br>grey | Configuration error type 2:<br><ul style="list-style-type: none"> <li>Single slave is projected (in LPS) but was not found (in LDS).</li> <li>Instead, a new A slave with the same address was installed.</li> </ul>      |
|  | grey<br>grey red | Configuration error type 2:<br><ul style="list-style-type: none"> <li>Single slave is projected (in LPS) but was not found (in LDS).</li> <li>Instead, a new B slave with the same address was installed.</li> </ul>      |
|  | grey red         | Configuration error type 2:<br><ul style="list-style-type: none"> <li>A or B slave is projected (in LPS) but was not found (in LDS).</li> <li>Instead, a new single slave with the same address was installed.</li> </ul> |

## Overview of free slave addresses

6993

In this overview, the slave selector shows the free and occupied AS-i addresses.



- > The symbol colour indicates the state of the AS-i address.  
Meaning of symbols and colours:  
→ **Free slave addresses: colour code + symbols** (→ p. 30)
- > The text field displays the status of the selected AS-i slave.  
Possible status messages:
  - Free
  - Missing slave

Use:

### 1 Select the AS-i address

- ▶ Use the arrow keys [▲], [▶], [▼] and [◀] to select the desired AS-i address.
- > The focus (= orange frame) is on the selected AS-i address.
- > The info bar displays the selected AS-i address.
- > The text field shows a status message for the selected AS-i address.

### 2 Activate the selected AS-i address

- ▶ Press [Select] function key to activate the selected AS-i address and go to the next menu page.
- OR:
- Press [Back] function key to cancel and leave the slave selector.

## Free slave addresses: colour code + symbols

11239

| Single slave                                                                      | A/B slave                                                                         | Colour    | Meaning                                                                                                                               | Prio. |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------|---------------------------------------------------------------------------------------------------------------------------------------|-------|
|  |  | grey      | Slave address is already used.                                                                                                        | --    |
|  |  | turquoise | Address is free according to LDS (= no slave found), however: address already belongs to a stored projection (= application profile). | 1     |
|  |  | blue      | Address is free according to LDS (= no slave found). Address is not used in a stored projection (= application profile).              | 2     |

## Meaning of the colour combinations

11240

| Symbol                                                                              | Colour                 | Meaning                                                                                                                         |
|-------------------------------------------------------------------------------------|------------------------|---------------------------------------------------------------------------------------------------------------------------------|
|    | blue<br>blue           | Slave to be addressed is an A/B slave:<br>A and B addresses are free.                                                           |
|    | blue<br>grey           | Slave to be addressed is an A/B slave:<br>– A address is free.<br>– B address is used.                                          |
|  | grey<br>blue           | Slave to be addressed is an A/B slave:<br>– A address is used.<br>– B address is free.                                          |
|  | turquoise<br>turquoise | Slave to be addressed is an A/B slave:<br>A and B addresses are free, but already used in a stored projection.                  |
|  | turquoise<br>grey      | Slave to be addressed is an A/B slave:<br>– A address is free, but already used in a stored projection.<br>– B address is used. |
|  | grey<br>turquoise      | Slave to be addressed is an A/B slave:<br>– A address is used.<br>– B address is free, but already used in a stored projection. |
|  | turquoise<br>blue      | Slave to be addressed is an A/B slave:<br>– A address is free, but already used in a stored projection.<br>– B address is free. |
|  | blue<br>turquoise      | Slave to be addressed is an A/B slave:<br>– A address is free<br>– B address is free, but already used in a stored projection.  |

## Confirmation message

7033

The confirmation message is a security prompt. It appears when important changes are made to the system settings. The confirmation message shows the changes made. For the changes to become effective, they first need to be acknowledged by the operator.

Example:



- > Action: Change AS-i slave address from 1a to 1b
- > Confirmation message shows:
  - Action (= Change AS-i address)
  - Slave address prior to change
  - Slave address after change
- > The operator has the following input options:
  - [Select] function key
  - [Back] function key

Use:

### 1 Change the settings

- ▶ Change the system settings.
- > The confirmation message appears.

### 2 Confirm the message

- ▶ Press [Select] function key to confirm the changes and apply the new value.  
OR:  
Press [Back] function key to reject the changes and continue to use the old value.
- > The page displays the valid settings.

## Numerical field

7046

The numerical field allows the operator to enter integer values. The value range is context-specific. Numerical fields are part of the following GUI elements:

| Control element | Example | Meaning                                                                                                                                                                                                                                                                                  |
|-----------------|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| IP address      |         | Entry of an IP address (IPv4) in [w.x.y.z] format <ul style="list-style-type: none"> <li>▪ w   x   y   z = network segments (value range: 0... 255)</li> </ul>                                                                                                                           |
| Date            |         | Date entry in [yyyy-mm-ss] format <ul style="list-style-type: none"> <li>▪ yyyy = year (value range: 0000 ... 9999)</li> <li>▪ mm = month (value range: 01 ... 12)</li> <li>▪ dd = day (value range: 01 ... 31)</li> </ul>                                                               |
| Time            |         | Time entry in [hh:mm:ss] format <ul style="list-style-type: none"> <li>▪ hh = hours (value range: 00 ... 12)</li> <li>▪ mm = minutes (value range: 00 ... 59)</li> <li>▪ ss = seconds (value range: 00 ... 59)</li> </ul> <p> The numerical field for seconds (ss) cannot be edited!</p> |
| Analogue value  |         | Entry of an analogue output value<br>Value range (per numerical field): 0 ... 9                                                                                                                                                                                                          |

Use (using the example of the numerical date field):

### 1 Select a numerical field

- ▶ Use [▲] / [▼] arrow key to select the date control element.
- > The focus (= orange frame) is on the selected date control element.

- > The date control element displays the current date

### 2 Activate the editing mode

- ▶ Press [Select] function key to enter the editing mode.
- > The focus (orange frame) is on the right element

### 3 Set the desired value

- ▶ Use [▲] / [▼] arrow key to increment the desired value.
- > The segment displays the new value.



Press and hold the arrow key [▲] / [▼] to rapidly move through larger value ranges.

### 4 Select the next segment

- ▶ Use the arrow key [◀] / [▶] to mark the segment to be edited.
- > The focus (orange frame) moves to the marked segment

- ▶ Optional: Repeat steps 3 and 4 until all segments have the desired values.



## 5 Adopt the set values

- ▶ Use [Select] function key to confirm the set values and to leave the edit mode.  
OR:  
Use [Back] function key to reset the set values and to leave the edit mode.
- > The date control element displays the valid date



The set value will not always become effective immediately. Often the change must be confirmed by clicking a button (e.g. [Accept selection])!

## Binary field

7047

The binary field allows the operator to change a digital value bit-wise.


Example:



- > Display of the 4-bit digital value:
  - Binary representation  
 = bit is on (= 1).  
 = bit is off (= 0).
  - Hexadecimal representation:  
 0xf = 1111

Use:

### 1 Select the binary field

- ▶ Use [▲] / [▼] arrow key to select the binary field.
  - > The focus (orange frame) is on the selected binary field.
- 
- > The control element shows the current value (digital and hexadecimal).

### 2 Activate the editing mode

- ▶ Press [Select] function key to enter the editing mode.
- > The focus (orange frame) is on the right element.



### 3 Set the desired value

- ▶ Use [▲] / [▼] arrow key to set the desired value.
- > The control element shows the new value in digital and hexadecimal format.

### 4 Select the next segment

- ▶ Use [◀] / [▶] arrow key to mark the segment to be edited.
- > The focus (orange frame) is on the selected segment.



- ▶ Optional: Repeat steps 3 and 4 until all segments have the desired values.

### 5 Apply the set values

- ▶ Use [Select] function key to confirm the set values and to leave the edit mode.  
OR:  
Use [Back] function key to reset the set values and to leave the edit mode.
- > The binary field displays the current value (binary and hexadecimal).

## 4.4 Remote access

### Contents

|                             |    |
|-----------------------------|----|
| General.....                | 34 |
| Recommended browsers.....   | 34 |
| Operating instructions..... | 35 |

7068

The device has an integrated web server. It generates a web interface which allows remote access to all device functions via an web browser. The web-interface allows the operator to easily configure, parameterise and monitor the device in permanent operation via an ethernet-based network.

### 4.4.1 General

7069

The operating concept of the web interface follows the same philosophy as the operating concept of the local display. The web interface uses the same menu items, the same menu structure and the same symbols as the graphic user interface of the local display.



Observe notes regarding the additional functionality of the web interface: → **Additional functions** (→ p. [39](#))

### 4.4.2 Recommended browsers

7070

Use one of the following Internet browsers to correctly display the HTML pages of the web interface:

- Microsoft Internet Explorer (from version 8.0)
- Mozilla Firefox (from version 3.5)

## 4.4.3 Operating instructions

### Web interface: Access

10283

- ▶ PC / Laptop / mobile device: Start Internet browser.
- ▶ Internet browser: Enter IP address of the device in the address line (e.g. 192.168.82.2)
- > Internet browser displays the start page of the web interface.

### Web interface: Navigation

14193

In the web interface, the pointing device (e.g. mouse, touchpad) is used instead of the following key functions:

- Navigation functions of the arrow keys [▼], [▲], [▶], [◀]
- Selecting functions of the function keys [Select] and [Back]

Example:

To select  > :

- ▶ Place the cursor on symbol [AS-i 1] in the main navigation bar.
- > symbol [AS-i 1] has the focus.
- > Subnavigation bar appears.
- > Navigation trail shows actual position in the menu tree:  
AS-i 1
- ▶ Place the cursor on symbol [Diagnosis] in the subnavigation bar.
- > symbol [Diagnosis] has the focus.
- > Navigation trail shows actual position in the menu tree:  
AS-i 1 > Diagnosis
- ▶ Click on symbol [Diagnosis]
- > Web browser shows menu page [Diagnosis]

AS-i 1



AS-i 1 > Diagnostics



## Web interface: Password protection

14187

The web server has a basic password protection to prevent unwanted or unauthorised changes to the device settings via the web interface.

When the web interface is accessed, a status bar at the top shows if the user is logged in or logged out:

 Status: logged in

User is logged in:

- Full access to device settings
- Full access to diagnostics and information data

 Status: logged out

User is logged out:

- No access to device settings
- Access to diagnostics and information data



The password is: CAFE

The password protection cannot be deactivated! The password cannot be changed!

## Web interface login

14221

- ▶ Go to the web interface (→ **Operating instructions** (→ p. 35)).
- > At the top of the web interface, the status bar displays the following status message:
  -  Status: logged out
- ▶ Enter the fixed password in the [Password:] field.
- ▶ Click [Login] to log in to the web interface.
- > The status bar displays the changed status:
  -  Status: logged in
- > The operator has unlimited access to all menus and functions of the web interface.



The operator remains logged in if one of the following actions is carried out:

- the web browser is closed and reopened
- the PC/laptop is restarted
- AC1433/34 is restarted

To prevent unauthorised access to the device settings:

- ▶ Manually log off before you leave the web interface! (→ **Disconnect from web interface** (→ p. 37))
- ▶ Remember to turn off the "Save password" function of your web browser before accessing the web interface!
- ▶ If the "Save password" function of your web browser is not turned off: delete the stored passwords in your browser settings!

## Disconnect from web interface

14276

To log out of the web interface:

- ▶ Start web interface
- > Status line with status message is displayed at the top of the web interface:  
 Status: logged in
- ▶ Log out of the web interface by clicking [Logout]
- > Status bar shows changed status  
 Status: logged out
- > User can only access menus in the web interface containing diagnostic and information data.
- > An error message is displayed when a user in the web interface accesses a menu with device settings.



The user stays logged into the web interface even when the web browser is closed and then restarted.

To prevent unauthorised access to the device settings:

- ▶ After finishing the access via the web browser manually log out of the device web interface!
- ▶ When password memory function of the web browser is not deactivated: Delete all saved passwords in the browser settings!

## 5 Menu

### Contents

|                            |    |
|----------------------------|----|
| Start screen .....         | 38 |
| Menu functions .....       | 39 |
| Quick setup .....          | 40 |
| AS-i 1 / AS-i 2 .....      | 49 |
| System .....               | 61 |
| Interfaces .....           | 83 |
| ifm system solutions ..... | 92 |

18788

This chapter describes the menu functions of the device's graphical user interface.

### 5.1 Start screen

6999

When starting the device, the start screen of the graphical user interface appears (special case: system start after initial commissioning or firmware update: → **Start screen 'Basic settings'** (→ p. [100](#))). The start screen displays the status information of important system components. The start screen is also the starting point for access to the menu functions of the AC1433/34.

Please press a button



- ① AS-i master 1 operation mode  
→ **Operating mode of the AS-i master** (→ p. [110](#))
- ② Operating mode of the AS-i master 2  
→ **Operating mode of the AS-i master** (→ p. [110](#))  
(only available for devices with 2 AS-i masters)
- ③ Control instance of the AS-i slave outputs  
→ **Control instance of the AS-i outputs**  
(→ p. [110](#))
- ④ State of the EtherCAT connection  
→ **EtherCAT: fieldbus status** (→ p. [110](#))
- ⑤ Error status of the field bus  
→ **EtherCAT: Error status** (→ p. [111](#))

► Change to the menu with [Menu] function key (→ **Menu functions** (→ p. [39](#))).

OR:

► Display the online support centre with [OSC] function key (→ **Online Support Center (OSC)** (→ p. [113](#))).

## 5.2 Menu functions

1977

The main navigation bar of the AC1433/34 provides access to the following menus:

| Symbol                                                                              | Description                                                                                                                            |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
|    | Access to the most important device functions<br>→ <b>System</b> (→ p. <a href="#">61</a> )                                            |
|    | Configuration and diagnostics of the AS-i 1 network (AS-i master, AS-i slaves)<br>→ <b>AS-i 1 / AS-i 2</b> (→ p. <a href="#">49</a> )  |
|    | Configuration and diagnostics of the AS-i 2 network (AS-i master, AS-i slaves)*<br>→ <b>AS-i 1 / AS-i 2</b> (→ p. <a href="#">49</a> ) |
|    | Configuration and diagnostics of the device, control of the device-internal PLC<br>→ <b>System</b> (→ p. <a href="#">61</a> )          |
|    | Configuration and diagnostics of the interfaces (EtherCAT, Configuration interface)<br>→ <b>Interfaces</b> (→ p. <a href="#">83</a> )  |
|    | Online Support Centre**<br>→ <b>Online Support Center (OSC)</b> (→ p. <a href="#">113</a> )                                            |
|  | Control and administration of the ifm system solutions (ifm apps)**<br>→ <b>ifm system solutions</b> (→ p. <a href="#">92</a> )        |

\* ... only available for devices with 2 AS-i masters

\*\* ... only available via the web interface of the device

### 5.2.1 Additional functions

7236

Compared to the user interface of the display, the web interface offers the following additional functions:

- Download device description file  
(→ **Download ESI file** (→ p. [89](#)))
- Adopt date and time of a PC/laptop  
(→ **Adopt the system time of the PC** (→ p. [77](#)))
- Store diagnostic protocol  
(→ **Store diagnostic protocol** (→ p. [81](#)))
- Use ifm system solutions  
(→ **ifm system solutions** (→ p. [92](#)))
- Diagnostics display  
(→ **Start screen: Status LEDs** (→ p. [110](#)))

## 5.3 Quick setup

13869

The [Quick-Setup] menu provides fast access to the most important device functions.

| Navigation path                                                                   | Functions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <ul style="list-style-type: none"> <li>→ Quick setup: Project AS-i networks (→ p. <a href="#">41</a>)</li> <li>→ Quick setup: Configure the operating mode of the AS-i masters (→ p. <a href="#">42</a>)</li> <li>→ Quick setup: Configure the output access (→ p. <a href="#">43</a>)</li> <li>→ Quick setup: Access the device via QR code (→ p. <a href="#">43</a>)</li> <li>→ Quick setup: Configure the EtherCAT interface (→ p. <a href="#">44</a>)</li> <li>→ Quick setup: Set the Configuration interface 1 (→ p. <a href="#">45</a>)</li> <li>→ Quick setup: Set the configuration interface 2 (→ p. <a href="#">46</a>)</li> <li>→ Quick setup: Address the AS-i slaves connected to AS-i master 1 (→ p. <a href="#">47</a>)</li> <li>→ Quick setup: Address the AS-i slaves connected to AS-i master 2 (→ p. <a href="#">48</a>)</li> </ul> |



## 5.3.1 Quick setup: Project AS-i networks

8973

During projection adaptation, the AS-i master carries out the following actions:

- The configuration data of all detected AS-i slaves (LDS) is saved
- The detected AS-i slaves are added to the list of projected slaves (LPS)



During a project a projection adaptation all output parameters of the unconnected AS-i slaves are reset to their default value in the AS-i master (single /A slaves = 0xF, B slaves = 0x7).

To carry out the projection adaptation on AS-i master 1 and/or AS-i master 2:

### 1 Select menu page



- ▶ Select tab **Project all**.

### 2 Select the AS-i master for projection adaptation

- ▶ Set the following parameters as required:

| Parameter       | Description                                                                                        | Possible values                     |                                                  |
|-----------------|----------------------------------------------------------------------------------------------------|-------------------------------------|--------------------------------------------------|
| [AS-i Master 1] | Select AS-i master 1 for projection adaptation                                                     | <input type="checkbox"/>            | Exclude AS-i master 1 from projection adaptation |
|                 |                                                                                                    | <input checked="" type="checkbox"/> | Include AS-i master 1 in projection adaptation   |
| [AS-i Master 2] | Select AS-i master 2 for projection adaptation<br>(only available for devices with 2 AS-i masters) | <input type="checkbox"/>            | Exclude AS-i master 2 from projection adaptation |
|                 |                                                                                                    | <input checked="" type="checkbox"/> | Include AS-i master 2 in projection adaptation   |

### 3 Start the projection adaptation

- ▶ Activate the button **Start projection process**.
  - > The selected AS-i masters go into the "projection mode".
  - > A projection adaptation is carried out on the selected AS-i masters.
  - > After projection adaptation, the selected AS-i masters go into the "protected mode".

## 5.3.2 Quick setup: Configure the operating mode of the AS-i masters

8974



Information regarding the operating modes of an AS-i master:→ **Operating modes of the AS-i master** (→ p. [123](#))

To configure the operating modes of the AS-i masters:

### 1 Select the menu page



- ▶ Select **[Operation modes]** tab.

### 2 Configure the operating mode of AS-i master 1 and the behaviour of the connected AS-i slaves

- > In group [AS-i master 1], set the following parameters as required:

| Parameter         | Meaning                                                       | Possible values                                                                                                                                                                                                                                                                                               |
|-------------------|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [Projection mode] | Active operating mode of the AS-i master                      | <input type="checkbox"/> Projection mode inactive:<br>AS-i network runs in protected mode (normal mode)                                                                                                                                                                                                       |
|                   |                                                               | <input checked="" type="checkbox"/> Projection mode active:<br>AS-i network can be projected.<br>(→ <b>Quick setup: Address the AS-i slaves connected to AS-i master 1</b> (→ p. <a href="#">47</a> ) or → <b>Quick setup: Address the AS-i slaves connected to AS-i master 2</b> (→ p. <a href="#">48</a> )) |
| [No slave reset]  | Behaviour of the AS-i slaves when changing the operating mode | <input type="checkbox"/> Slave is reset when changing the operating mode:<br>When changing the operating mode, the AS-i slaves will be reset for a short moment (reset or offline phase).                                                                                                                     |
|                   |                                                               | <input checked="" type="checkbox"/> Slave is not reset when changing the operating mode:<br>When changing the operating mode, the AS-i slaves continue to operate without interruption.                                                                                                                       |

- > Selected values are applied.

### 3 Optional: set the operating mode of AS-i master 2 and the behaviour of the AS-i slaves

- ▶ Repeat step 2 for the group [AS-i master 2].

### 5.3.3 Quick setup: Configure the output access

17867

Only one control instance at a time can have write access to the outputs of the connected AS-i slaves. The operator configures the control instance with the parameter [Output access].

To configure the control instance of the AS-i slave outputs:

#### 1 Select the menu page



- ▶ Select [Operation modes] tab.

#### 2 Set the control instance for the outputs of the AS-i slaves

- ▶ From the list [Output access], select the desired value:

| Parameter       | Meaning                                    | Possible values |                                                                                        |
|-----------------|--------------------------------------------|-----------------|----------------------------------------------------------------------------------------|
| [Output access] | Control instance of the AS-i slave outputs | [Gateway]       | A higher-level PLC controls the outputs of the AS-i slaves.                            |
|                 |                                            | [Manual]        | The operator controls the outputs of the AS-i slaves via the graphical user interface. |
|                 |                                            | [PLC]           | The device-internal PLC controls the outputs of the AS-i slaves.                       |

#### 3 Save the changes

- ▶ Press [Accept selection] to save the changes.
- > The selected instance controls the outputs of the AS-i slaves.

### 5.3.4 Quick setup: Access the device via QR code

11764

The QR code (Quick Response Code) allows the operator to access the web interface of the device from a smartphone or tablet PC.

#### Requirements:

- The AS-i device must be connected to a wireless LAN router with switch functionality.  
(→ **Connection via Ethernet network** (→ p. 121))
- The smartphone/tablet PC is connected to the wireless LAN router.
- The smartphone/tablet PC provides a camera function.
- The smartphone/tablet PC has a QR-code reader installed.

#### 1 Select menu page



- ▶ Select the [QR-Code] tab.
- > The display shows the QR code.

#### 2 Read the QR code

- ▶ Start the QR code reading app and scan the QR code.
- > The smartphone displays the web interface of the device (→ **Remote access** (→ p. 34)).

### 5.3.5 Quick setup: Configure the EtherCAT interface

14613

To configure the EtherCAT interface:

#### 1 Select menu page



- ▶ Select tab **EtherCAT**.

#### 2 Set the EtherCAT address of the device

- ▶ Set the following parameters as required:

| Parameter | Description                    | Possible values   |                                                     |
|-----------|--------------------------------|-------------------|-----------------------------------------------------|
| [ID]      | EtherCAT address of the device | 1<br>...<br>65535 | EtherCAT address 1<br>...<br>EtherCAT address 65535 |

- ▶ Click on **Übernehmen** to save the changes.

### 5.3.6 Quick setup: Set the Configuration interface 1

8991

The device provides the following options for configuration of the Ethernet Configuration interface 1:

- Manual = The operator sets the interface parameters (IP address, network mask, gateway address) manually.
- Automatic = The interface parameters are set automatically. The operator can choose between these protocols:
  - Dynamic Host Configuration Protocol (DHCP)
  - Zero Configuration Networking (Zeroconf)



The device must be connected to a DHCP server to automatically receive the interface parameters via DHCP.

- ▶ Connect the configuration interface (X3) to a DHCP server.

To configure the IP parameters of the configuration interface:

#### 1 Select the menu page



- ▶ Select [Config. interface X3] tab.

#### 2 Show the active settings

- > The parameters below show the active settings:

| Parameter                  | Meaning                                                         | Possible values                     |                                                                     |
|----------------------------|-----------------------------------------------------------------|-------------------------------------|---------------------------------------------------------------------|
| [Obtain IP address autom.] | Active method for the configuration of the interface parameters | <input type="checkbox"/>            | Manual assignment of the interface parameters through the operator  |
|                            |                                                                 | <input checked="" type="checkbox"/> | Automatic assignment of the interface parameters                    |
| [IP status]                | Configuration protocol used                                     | [Static]                            | The operator sets the IP parameters manually.                       |
|                            |                                                                 | [DHCP]                              | The IP parameters are set by a DHCP server.                         |
|                            |                                                                 | [Zeroconfig]                        | The IP parameters are set automatically with the Zeroconf protocol. |
| [IP address]               | IP address of the interface                                     | e.g. 192.168.0.100                  |                                                                     |
| [Subnet mask]              | Network mask of the network segment                             | e.g. 255.255.255.0                  |                                                                     |
| [Gateway address]          | IP address of the network gateway                               | e.g. 192.168.0.1                    |                                                                     |

- ▶ Take one of the following actions:
  - Configure the IP parameters manually: continue with → step 3
  - Configure the IP parameters automatically: continue with → step 4

#### 3 Configure the IP parameters manually

- ▶ Uncheck [Obtain IP address autom].
- ▶ Set the following parameters as required:
  - [IP address]
  - [Subnet mask]
  - [Gateway address]
- ▶ Press [Accept] to save the changes.
- ▶ Continue with → step 5

#### 4 Configure the IP parameters automatically

- ▶ Check [Obtain IP address autom].
- ▶ Press **Accept** to save the changes.
- > The device tries to obtain IP parameters from a DHCP server.
- > If the IP parameter configuration via DHCP server fails, the device will generate the IP parameters by means of the Zeroconf protocol.



The automatic configuration of the interface takes approx. 10 seconds.

#### 5 Show the current settings

- > The parameters (→ step 2) show the active IP settings of the Configuration interface 1.

### 5.3.7 Quick setup: Set the configuration interface 2

7105



Configuration interface 2 (X8) has the same configuration options as configuration interface 1 (X3).

→ **Quick setup: Set the Configuration interface 1** (→ p. [45](#))

To configure configuration interface 2 (X8):

#### 1 Select menu page



- ▶ Select tab **Config interface X8**.

#### 2 Configure interface

- ▶ Set the interface as required.

## 5.3.8 Quick setup: Address the AS-i slaves connected to AS-i master 1

8992

To change the address of an AS-i slave connected to AS-i master 1:

### 1 Select the menu page



- ▶ Select **[Addressing AS-i 1]** tab.

### 2 Select the AS-i slave

- > The page provides an overview of the current addressing and status of the AS-i slaves on the selected AS-i master (→ figure)  
Notes on colour codes: → **Overview of slave states** (→ p. 27)
- ▶ Select the AS-i slave of which want to change the address.
- ▶ Use [Select] to activate the selected AS-i slave.

|        | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|--------|---|---|---|---|---|---|---|---|---|---|
| 0x A B |   |   |   |   |   |   |   |   |   |   |
| 1x A B |   |   |   |   |   |   |   |   |   |   |
| 2x A B |   |   |   |   |   |   |   |   |   |   |
| 3x A B |   |   |   |   |   |   |   |   |   |   |

Slave active

### 3 Select a new AS-i address

- > The page provides an overview of the free AS-i addresses (→ figure)  
Notes on colour codes: → **Overview of free slave addresses** (→ p. 29)
- ▶ Select the address to be assigned to the AS-i slave.
- ▶ Assign the selected address with [Select].
- > The confirmation prompt appears.
- ▶ Confirm the message with [OK].
- > The AS-i slave has new address.
- > The page provides an overview of the current addressing and configuration errors (→ figure)

|        | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|--------|---|---|---|---|---|---|---|---|---|---|
| 0x A B |   |   |   |   |   |   |   |   |   |   |
| 1x A B |   |   |   |   |   |   |   |   |   |   |
| 2x A B |   |   |   |   |   |   |   |   |   |   |
| 3x A B |   |   |   |   |   |   |   |   |   |   |

Free

|        | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|--------|---|---|---|---|---|---|---|---|---|---|
| 0x A B |   |   |   |   |   |   |   |   |   |   |
| 1x A B |   |   |   |   |   |   |   |   |   |   |
| 2x A B |   |   |   |   |   |   |   |   |   |   |
| 3x A B |   |   |   |   |   |   |   |   |   |   |

Not projected

### 4 Address additional AS-i slaves (optional)

- ▶ Repeat steps 2 and 3 to address additional AS-i slaves.



After the address change, the present configuration no longer corresponds to the stored configuration.

- > The slave status indicates a configuration error.

To eliminate the configuration error:

- ▶ Start a projection adaptation (→ **Quick setup: Project AS-i networks** (→ p. 41)).

### 5.3.9 Quick setup: Address the AS-i slaves connected to AS-i master 2

11671



The procedure for addressing the AS-i slaves connected to AS-i master 2 is the same as for addressing the AS-i slaves connected to AS-i master 1 (→ **Quick setup: Address the AS-i slaves connected to AS-i master 1** (→ p. [47](#))).

To change the address of an AS-i slave connected to AS-i master 2

#### 1 Select the menu page



- ▶ Select **Addressing AS-i 2** tab.

#### 2 Change the AS-i slave address

- ▶ Address AS-i slaves.



## 5.4 AS-i 1 / AS-i 2

14197

The [AS-i 1] and [AS-i 2] menus provide access to configuration functions of the AS-i networks.



The [AS-i 2] menu is only available for devices with two AS-i masters!

| Navigation path                                                                                                                                                        | Content                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | <p>AS-i master settings</p> <ul style="list-style-type: none"> <li>→ <b>Set the operating mode of the AS-i master</b> (→ p. <a href="#">50</a>)</li> <li>→ <b>Carry out a projection adaptation</b> (→ p. <a href="#">51</a>)</li> <li>→ <b>Set the monitoring functions of the AS-i master</b> (→ p. <a href="#">51</a>)</li> </ul>                                                                                                                                                                                                                                                                                                                                  |
|      | <p>AS-i network diagnosis</p> <ul style="list-style-type: none"> <li>→ <b>Display and reset the error counters</b> (→ p. <a href="#">52</a>)</li> <li>→ <b>Display the error statistics of the AS-i slaves</b> (→ p. <a href="#">52</a>)</li> <li>→ <b>Display the voltage supply analysis</b> (→ p. <a href="#">53</a>)</li> <li>→ <b>Display and reset performance data</b> (→ p. <a href="#">53</a>)</li> </ul>                                                                                                                                                                                                                                                    |
|   | <p>AS-i slave settings</p> <ul style="list-style-type: none"> <li>→ <b>Display the input/output data of the AS-i slave</b> (→ p. <a href="#">54</a>)</li> <li>→ <b>Change the digital output values manually</b> (→ p. <a href="#">57</a>)</li> <li>→ <b>Change the analogue output values manually</b> (→ p. <a href="#">57</a>)</li> <li>→ <b>Show AS-i slave information</b> (→ p. <a href="#">58</a>)</li> <li>→ <b>Change an AS-i slave address</b> (→ p. <a href="#">59</a>)</li> <li>→ <b>Change an AS-i slave parameter output</b> (→ p. <a href="#">59</a>)</li> <li>→ <b>Change the Extended ID1 of the AS-i slave</b> (→ p. <a href="#">60</a>)</li> </ul> |

## 5.4.1 AS-i 1 / AS-i 2: Master setup

8996

The menu item [Master setup] provides access to the configuration options of the selected AS-i master.

### Set the operating mode of the AS-i master


15877



More information on the operating modes of the AS-i master: → **Operating modes of the AS-i master** (→ p. [123](#))

To set the operating mode of the AS-i master:

#### 1 Select the menu page



#### 2 Set the operating mode of AS-i master 1 and the behaviour of the connected AS-i slaves

> Set the following parameters as required:

| Parameter         | Description                                                   | Possible values                     |                                                                                                                                                                  |
|-------------------|---------------------------------------------------------------|-------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [Projection mode] | Active operating mode of the AS-i master                      | <input type="checkbox"/>            | Projection mode inactive:<br>AS-i network operates in protected mode (normal mode)                                                                               |
|                   |                                                               | <input checked="" type="checkbox"/> | Projection mode active:<br>AS-i network can be projected.                                                                                                        |
| [No slave reset]  | Behaviour of the AS-i slaves when changing the operating mode | <input type="checkbox"/>            | Slave is reset when changing the operating mode:<br>When changing the operating mode, the AS-i slaves will be reset for a short moment (reset or offline phase). |
|                   |                                                               | <input checked="" type="checkbox"/> | Slave is not reset when changing the operating mode:<br>When changing the operating mode, the AS-i slaves continue to operate without interruption.              |

> Selected values are applied.

## Carry out a projection adaptation

8938

During projection adaptation, the AS-i master stores the configuration of all AS-i slaves currently found on the AS-i network in its memory and assigns a valid AS-i address to each of them.




The projection adaptation can only be carried out in projection mode:

- ▶ [Projection mode] must be checked (→ **Set the operating mode of the AS-i master** (→ p. 50)).
- ▶ During a Projection process all output parameter of not connected AS- slaves in the AS-i master will be reset to their default values (single / A slaves = 0xF, B slaves = 0x7).

To launch the projection adaptation:

### 1 Select the menu page



### 2 Carry out a projection adaptation

- ▶ Press **[Start projection process]** button.
- > The projection adaptation is carried out.

If successful:

- > All slaves on the AS-i master are projected.

If not successful:


- > The Online Support Center displays an error message.
- ▶ Remove the error and repeat the process.

## Set the monitoring functions of the AS-i master

11728

To set the monitoring functions of the selected AS-i master:

### 1 Select the menu page



### 2 Set the monitoring functions of the AS-i master

- ▶ Set the following parameters as required:

| Parameter                  | Description                                                              | Possible values                     |                                                 |
|----------------------------|--------------------------------------------------------------------------|-------------------------------------|-------------------------------------------------|
| [Automatic addressing]     | Behaviour if AS-i slave is replaced (→ <b>Protected mode</b> (→ p. 123)) | <input type="checkbox"/>            | Automatic addressing disabled                   |
|                            |                                                                          | <input checked="" type="checkbox"/> | Automatic addressing enabled                    |
| [Earth fault detection]    | Detection of earth faults                                                | <input type="checkbox"/>            | Do not detect earth faults in the AS-i system   |
|                            |                                                                          | <input checked="" type="checkbox"/> | Detect earth faults in the AS-i system          |
| [Double address detection] | Double address detection                                                 | <input type="checkbox"/>            | Do not detect AS-i slaves with the same address |
|                            |                                                                          | <input checked="" type="checkbox"/> | Detect AS-i slaves with the same address        |

- > Selected values are applied.

## 5.4.2 AS-i 1 / AS-i 2: Diagnosis

9039

The [Diagnosis] menu provides access to the diagnostic data of the selected AS-i network.

### Display and reset the error counters

9042

To display and reset the AS-i error counters:

#### 1 Select the menu page

- ▶  >  or  > 
- ▶ Select **[Error counters]** tab.

#### 2 Display the error counters

- > Page shows the following information:

| Name              | Description                                  |
|-------------------|----------------------------------------------|
| [Telegrams]       | Number of message errors that occurred       |
| [Configuration]   | Number of configuration errors that occurred |
| [Voltage < 22.5V] | Number of voltage errors < 22.5 V            |
| [Voltage < 19.0V] | Number of voltage errors < 19.0 V            |
| [Earth fault]     | Number of detected earth faults              |

#### 3 Optional: reset the error counters

- ▶ Press [Reset] button.
- > All error counters are reset to 0.

### Display the error statistics of the AS-i slaves

9087

To display the error messages of the AS-i slaves on the selected AS-i master:

#### 1 Select the menu page

- ▶  >  or  > 
- ▶ Select **[Errors / slave]** tab.

#### 2 Display the error statistics of the AS-i slaves

- > Page shows the following information:

| Column header | Description                                               |
|---------------|-----------------------------------------------------------|
| [Address]     | Address of the AS-i slave                                 |
| [S/A]         | Number of errors of the single or A slave at this address |
| [B]           | Number of errors of the B slave at this address           |

- ▶ Use [▲] / [▼] to scroll through the table.

## Display the voltage supply analysis

9088

To display the voltage supply analysis:

### 1 Select the menu page



► Select **[Power supply]** tab.

### 2 Display the voltage supply analysis

> Page shows the following information:


| Name             | Description                        | Possible values                                       |                                                                  |
|------------------|------------------------------------|-------------------------------------------------------|------------------------------------------------------------------|
| [Power supply]   | Method of voltage supply           | [Aux]                                                 | Voltage is supplied separately by the AS-i network and AUX 24 V. |
|                  |                                    | [AS-i]                                                | Voltage is only supplied by the AS-i network.                    |
|                  |                                    | [Power24]                                             | Voltage is supplied by data decoupling module.                   |
| [AS-i voltage]   | AS-i voltage measured (in [V])     | e.g. 30.3 V                                           |                                                                  |
| [DC earth fault] | Evaluation of the network symmetry |                                                       | AS-i network is symmetrical                                      |
|                  |                                    |                                                       | AS-i network is asymmetrical                                     |
|                  |                                    |                                                       | AS-i network has earth fault                                     |
|                  |                                    | Graphical representation of the network symmetry:<br> |                                                                  |

## Display and reset performance data

9089

To display the performance statistics of the selected AS-i master:

### 1 Select the menu page



► Select **[Performance]** tab.

### 2 Display performance data

> Page shows the following information:

| Designation            | Description                                      |
|------------------------|--------------------------------------------------|
| [Activated slaves]     | Number of active AS-i slaves on the AS-i network |
| [AS-i cycle time [ms]] | AS-i cycle time (value in [ms])                  |
| ▪ [minimum]            | shortest cycle time                              |
| ▪ [maximum]            | longest cycle time                               |
| ▪ [current]            | current cycle time                               |

### 3 Optional: reset the performance data

► Press **[Reset]** button.

> The saved statistic data for minimum and maximum cycle times are deleted.

## 5.4.3 AS-i 1 / AS-i 2: AS-i slaves

9037

The [AS-i Slaves] menu provides access to information and configuration options of the AS-i slaves.



The scope of configuration options shown ([Data] and [Setup] tab) varies according to the status of the selected AS-i slaves.

### Display the input/output data of the AS-i slave

10934

To display the input/output data or the parameter output of the selected AS-i slaves:

#### 1 Select the menu page

- ▶  >  or  > 
- ▶ Select an AS-i slave (→ **Slave selector** (→ p. 26)).
- ▶ Select [Data] tab.

#### 2 Display input/output data

- > Depending on the profile of the selected AS-i slave, the page displays the following data:

#### Digital input

15972

| Name     | Description                                                                  | Example / Possible values                                                                                                                             |
|----------|------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| [Inputs] | Current values of the digital inputs (binary and hexadecimal representation) | <div> <b>Input:</b><br/>  </div>                                  |
|          |                                                                              | <div>  = Data bit is switched off (0 / OFF)                 </div> |
|          |                                                                              | <div>  = Data bit is switched on (1 / ON)                 </div>   |

#### Analogue input

15973

| Name         | Description                                                                       | Example / Possible values                                                                                                                                                                                                                                           |
|--------------|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [Inputs]     | Current values of the analogue input channels and information about their status  | <div> <b>Input:</b><br/>  </div>                                                                                                                                                |
| ▪ [Valid]    | The Valid bit indicates whether the displayed value is valid.                     | <div>  Invalid value<br/>  Valid value                 </div>                                 |
| ▪ [Overflow] | The Overflow bit indicates whether the displayed value is within the value range. | <div>  Value within valid value range<br/>  Valid value range exceeded                 </div> |


© ifm electronic gmbh



www.ifm.com


## Digital output

15974

| Designation  | Description                                                                                 | Example / Possible values                                                                                                                                                                      |
|--------------|---------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [Outputs]    | Current values of the digital outputs (binary and hexadecimal representation)               |                                                                                                              |
|              |                                                                                             |  Data bit is switched off (0 / OFF)                                                                           |
|              |                                                                                             |  Data bit is switched on (1 / ON)                                                                             |
| ▪ [Jog mode] | The parameter controls the behaviour of the outputs in the event of a changed output value. |  Jog mode disabled ("switch mode")<br>> The changes do not affect the output until you quit the editing mode. |
|              |                                                                                             |  Jog mode enabled ("momentary switch mode")<br>> The changes immediately affect the output.                   |

## Analogue output

15975

| Name                | Description                                                                                       | Example / Possible values                                                                                                                                                                |
|---------------------|---------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [Outputs]           | Current values of the analogue output channels and information about their status                 |                                                                                                      |
| ▪ [Analogue status] | Current status of the analogue outputs                                                            |  Not O.K.<br> O.K. |
| ▪ [Channel x]       | Current value of the analogue output channel x (x = 1...n; n = number of channels per AS-i slave) | per digit:<br>0 ... 9                                                                                                                                                                    |

## Parameter input

15843

| Name              | Description                                                                  | Example / Possible values                                                                                              |
|-------------------|------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|
| [Parameter input] | Current value of the parameter input (binary and hexadecimal representation) |                                    |
|                   |                                                                              |  Data bit is switched off (0 / OFF) |
|                   |                                                                              |  Data bit is switched on (1 / ON)   |



## Change the digital output values manually

10939

### **WARNING**

Risk of personal injury! Risk of material damage to the machine/plant!

The operator is responsible for any consequences caused by the manual change of the digital output values!

- ▶ Secure the concerned area.
- ▶ Only trained personnel is allowed to set outputs manually.

If the jog mode is deactivated:

After changing the slave outputs the output values remain on the changed values.

- ▶ Change the inverted outputs again immediately to the original values after the end of the test!

To change the digital output values of an AS-i slave manually:

#### 1 Enable manual access to the outputs

- ▶ Set [Output access] parameter = Manual (→ **Set the output access** (→ p. 69)).

#### 2 Select the menu page

- ▶  >  or  > 

- ▶ Select an AS-i slave (→ **Slave selector** (→ p. 26)).
- ▶ Select **[Data]** tab.

#### 3 Set the digital output values manually

- > The group [Outputs] displays the current value of the digital output (binary and hexadecimal representation).
- ▶ Set [Jog mode] as required. (→ **Digital output** (→ p. 56))
- ▶ Change the desired output value bit by bit.
- > Selected value is applied.

## Change the analogue output values manually

10940

To change the analogue output values of an AS-i slave manually:

#### 1 Enable manual access to the outputs

- ▶ Set [Output access] parameter = Manual (→ **Set the output access** (→ p. 69)).

#### 2 Select the menu page

- ▶  >  or  > 

- ▶ Select an AS-i slave (→ **Slave selector** (→ p. 26)).
- ▶ Select **[Data]** tab.

#### 3 Set the analogue output values manually

- > [Outputs] group shows the current value of the analogue output.
- ▶ Change the value of the requested channel one digit at a time (→ **Numerical field** (→ p. 32)).
- > Selected value is applied.
- ▶ Optional: repeat step 3 to change further channels.

## Show AS-i slave information

10935

To display information about an AS-i slave:

### 1 Select the menu page



► Select an AS-i slave (→ **Slave selector** (→ p. 26)).

► Select **[Information]** tab.

### 2 Display information about the AS-i slave

> Page shows the following information:

| Name                 | Description                                                                                        | Possible values                                                                                                                |                       |
|----------------------|----------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|-----------------------|
| [AS-i slave address] | Current address of the AS-i slave                                                                  | e.g. 13B                                                                                                                       |                       |
| [Slave status]       | Current status of the AS-i slave                                                                   |                                               | AS-i slave is active  |
|                      |                                                                                                    |                                               | AS-i slave is missing |
|                      |                                                                                                    |                                               | Not projected         |
|                      |                                                                                                    |                                               | Double address error  |
|                      |                                                                                                    |                                               | Periphery fault       |
| [AS-i slave profile] | Current (= Current) and expected (= Preset) slave profile (IO, ID, ID2, ID1) in hexadecimal format | <div><div>AS-i slave profile:</div><div><div>IOIDID2(ID1)</div><div>Current: 3ff(f)</div><div>Preset: 3ff(f)</div></div></div> |                       |

► Use [▲] / [▼] for page navigation.

## Change an AS-i slave address

10944

To change the address of an AS-i slave:

### 1 Select the menu page



- ▶ Select an AS-i slave (→ **Slave selector** (→ p. 26)).
- ▶ Select **[Setup]** tab.

### 2 Change the address of the AS-i slave

- ▶ Press the **[Change slave address]** button.
  - > The page displays an overview of the free AS-i addresses (→ **Overview of free slave addresses** (→ p. 29)).
- ▶ Select the address to be assigned to the AS-i slave and confirm with [Select] function key.
  - > Security prompt appears.
- ▶ Press [OK] to confirm the security prompt.
  - > The AS-i slave has a new address.
  - > The page displays an overview of the AS-i slave states (→ **Overview of slave states** (→ p. 27)).

### 3 Optional: change further AS-i addresses.

- ▶ Repeat step 2 to change further AS-i slave addresses.



After the address change, the present configuration (LDS) no longer corresponds to the stored configuration (LPS).

- > The OSC displays a configuration error.

To remove the configuration error:

- ▶ start a projection adaptation (→ **Carry out a projection adaptation** (→ p. 51)).

## Change an AS-i slave parameter output

10945

To change the parameter output of an AS-i slave:

### 1 Enable manual access to the outputs

- ▶ Set [Output access] parameter = Manual (→ **Set the output access** (→ p. 69))

### 2 Select the menu page



- ▶ Select an AS-i slave (→ **Slave selector** (→ p. 26)).
- ▶ Select **[Setup]** tab.

### 3 Change the parameter output of the AS-i slave

- > The [Parameter output] group displays the current assignment of the parameter output (binary and hexadecimal representation).
- ▶ Adjust the desired output value one position at a time.
- > Selected value is applied.

## Change the Extended ID1 of the AS-i slave

10952

To set the Extended ID1 of an AS-i slave:

### 1 Select the menu page



- ▶ Select an AS-i slave (→ **Slave selector** (→ p. [26](#))).
- ▶ Select **[Setup]** tab.

### 2 Set the Extended ID1

- > The [ID1] list displays the current Extended ID1 value (hexadecimal format).
- ▶ Select the desired value for Extended ID1 from the [ID1] list.
- > Selected value is applied.



After changing the Extended ID1, the existing configuration no longer corresponds to the stored configuration:

- > An error message appears (configuration error).
- ▶ Start a projection adaptation (→ **Carry out a projection adaptation** (→ p. [51](#))).

## 5.5 System

8957

The [System] menu provides access to functions that allow configuration of the system and the device-internal PLC.

| Navigation path                                                                                                                                                           | Functions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  >      | Device-internal PLC<br>→ <b>System: Programmable Logic Controller (PLC)</b> (→ p. <a href="#">62</a> )                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|  >      | System information<br>→ <b>Show version information</b> (→ p. <a href="#">68</a> )                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|  >      | System settings<br>→ <b>Set the output access</b> (→ p. <a href="#">69</a> )<br>→ <b>Enable/Disable the device-internal PLC</b> (→ p. <a href="#">70</a> )<br>→ <b>Set the device cycle</b> (→ p. <a href="#">71</a> )<br>→ <b>Switch the menu language</b> (→ p. <a href="#">72</a> )<br>→ <b>Set the behaviour of the display</b> (→ p. <a href="#">73</a> )<br>→ <b>Set the system time manually</b> (→ p. <a href="#">75</a> )<br>→ <b>Synchronise the system time with an NTP server</b> (→ p. <a href="#">76</a> )<br>→ <b>Adopt the system time of the PC</b> (→ p. <a href="#">77</a> )<br>→ <b>Export device configuration</b> (→ p. <a href="#">79</a> )<br>→ <b>Import device configuration</b> (→ p. <a href="#">80</a> )<br>→ <b>System reset</b> (→ p. <a href="#">81</a> )<br>→ <b>Store diagnostic protocol</b> (→ p. <a href="#">81</a> ) |
|  >  | System diagnostics<br>→ <b>Display diagnostic data</b> (→ p. <a href="#">82</a> )                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

## 5.5.1 System: Programmable Logic Controller (PLC)

8955

The [PLC] menu provides access to the device-internal PLC.

| Navigation path                                                                                                                                                                                                                                           | Functions                                                                                                                                                                                                             |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  >  >  | PLC information:<br>→ <b>Display the status of the CODESYS PLC</b> (→ p. <a href="#">63</a> )<br>→ <b>Display information about PLC projects</b> (→ p. <a href="#">63</a> )                                           |
|  >  >  | PLC settings<br>→ <b>Control a single PLC application</b> (→ p. <a href="#">64</a> )<br>→ <b>Control PLC applications</b> (→ p. <a href="#">65</a> )<br>→ <b>Show target visualisation</b> (→ p. <a href="#">66</a> ) |
|  >  >  | PLC diagnosis<br>→ <b>Show memory used</b> (→ p. <a href="#">67</a> )                                                                                                                                                 |



For information about the programming of the device-internal PLC with CODESYS, please refer to the programming manual:  
 → [www.ifm.com](http://www.ifm.com) > product page > [Downloads]

## PLC: Information

11778

The [Information] menu item provides access to the PLC status and project information.

### Display the status of the CODESYS PLC

14841

To display information about the current status of the device-internal PLC:

#### 1 Select the menu page



▶ Select **Status** tab.

#### 2 Display the status of the CODESYS PLC

> Page shows the following information:

| Name        | Description                       | Possible values                                                                                                |
|-------------|-----------------------------------|----------------------------------------------------------------------------------------------------------------|
| Status LED  | Status of the device-internal PLC |  The CODESYS PLC is disabled. |
|             |                                   |  The CODESYS PLC is enabled.  |
| [Version]   | CODESYS version                   | e.g. 3.5.3.60                                                                                                  |
| [Node name] | Name of device in CODESYS project | e.g. ifm_SmartPLC_DataLine                                                                                     |

### Display information about PLC projects

14842

To obtain information about the CODESYS project stored on the device-internal PLC:

#### 1 Select the menu page



▶ Select **Project** tab.

#### 2 Display information about PLC projects

> Page shows the following information:

| Name      | Description                           |
|-----------|---------------------------------------|
| [Project] | Name of the CODESYS project file      |
| [Title]   | Name of the CODESYS project           |
| [Version] | Version number of the CODESYS project |
| [Author]  | Author of the CODESYS project         |


## PLC: Settings

16217

The [Settings] menu item provides access to the PLC applications (apps) on the device.

### Control a single PLC application

14846



- ① [App x/y]
  - x ... number of the app displayed
  - y ... total number of apps stored
- ② Status and name of the application
  - = application has been stopped
  - = application has been started
- ③ Information concerning the application
  - date and time of creation
  - author
  - version of application
  - size

To control a single PLC application stored on the device:

#### 1 Select the menu page

- ▶ > >
- ▶ Select **Applications** tab.

#### 2 Select an application

- ▶ Use [▼] to select the message field.
- > The focus (orange frame) is on the message field.
- ▶ Use [▼] / [▲] to select the requested application.
- ▶ Perform one of the following actions:
  - Launch a single PLC application: continue with → step 3
  - Stop a single PLC application: continue with → step 4

#### 3 Launch a single PLC application

- ▶ Press [Start] to launch the selected PLC application.
- > The confirmation prompt appears.
- ▶ Press [OK] to confirm the prompt.
- > The PLC application is started.
- ▶ Continue with → step 5

#### 4 Stop a single PLC application

- ▶ Press [Stop] to stop the selected application.
- > The confirmation prompt appears.
- ▶ Press [OK] to confirm the prompt.
- > The application is stopped.

#### 5 Display information about the PLC application

- > The status display of the PLC application is updated



## Control PLC applications

14847

To control all PLC applications stored on the device:

### 1 Select the menu page



- ▶ Select **[All applications]** tab.

### 2 Display status information about the PLC applications

- > Page shows the following information:

| Designation | Meaning                                     |
|-------------|---------------------------------------------|
| [Total]     | Number of applications stored on the device |
| [Started]   | Number of applications running              |

- ▶ Perform one of the following actions:
  - Launch all PLC applications: continue with → step 3
  - Stop all PLC applications: continue with → step 4
  - Reset all PLC applications: continue with → step 5

### 3 Launch all PLC applications

- ▶ Press **[Starten]** button.
- > The confirmation prompt appears.
- ▶ Press [OK] to confirm the prompt.
- > All PLC applications are started.
- ▶ Continue with → step 6

### 4 Stop all PLC applications

- ▶ Press **[Stop]** button.
- > The confirmation prompt appears
- ▶ Press [OK] to confirm the prompt.
- > All PLC applications are stopped.
- ▶ Continue with → step 6

### 5 Reset all PLC applications

- ▶ Press **[Reset]** button.
- > The confirmation prompt appears.
- ▶ Press [OK] to confirm the prompt.
- > All PLC applications are reset and stopped.

### 6 Display the status of the PLC applications

- > The page shows updated information about the stored PLC applications.
- > The status of the **[Start]**, **[Stop]** and **[Reset]** buttons is updated.

## Show target visualisation

9055

Using the CODESYS programming system, the user can optionally program a target visualisation to create an application-specific user interface for the display of AC1433/34. The target visualisation is loaded onto the device together with the CODESYS project, but it must be activated manually.



If no valid target visualisation is stored on the device, a green screen appears after activating the **[Activate Target-Visu]** button

To exit the target visualisation and return to the menu page:

- ▶ Press [**◀**] and [**▶**] simultaneously.

If the device does not react when entering [**◀**] + [**▶**], the key combination is deactivated.

- ▶ Activate the key combination using the system command "Show target visualisation" (→ Device Manual Supplement, **Command 0x0110 – Display target visualisation**)!

To activate the target visualisation:

### 1 Select menu page



- ▶ Select the **[Activate TargetVisu]** tab.

### 2 Start the target visualisation

- ▶ Press **[Activate Target-Visu]** button.
- > The confirmation message appears.
- ▶ Press **[OK]** button to confirm the message.
- > The display shows the target visualisation.

## PLC: Diagnosis

10936

The [Diagnosis] menu item provides access to diagnostic data of the device-internal PLC.

### Show memory used

14845

To display information about the memory capacity currently used:

#### 1 Select the menu page



► Select [Memory] tab.

#### 2 Show memory used

> Page shows the following information:

| Name      | Description                                          |
|-----------|------------------------------------------------------|
| [CODESYS] | Memory capacity occupied by CODESYS data (in Kbytes) |
| [free]    | Free memory (in Kbytes)                              |



The current usage of memory space is read out once when calling up the menu page. These values are not refreshed while the menu page is displayed. Any changes regarding the memory capacity (e.g. through download of a new CODESYS project) will therefore not be reflected in the displayed values.

To update the displayed values:

- Quit the [Diagnosis] menu page.
- Access the [Diagnosis] menu page again.
- > The menu page displays the current memory usage of device.

## 5.5.2 System: Information

7281

The [Information] menu item provides access to the version information about the system components.

### Show version information

11774

To display information about the hardware and software components of the device:

#### 1 Select the menu page



▶ Select **[Version]** tab.

#### 2 Show version information

> Page shows the following information:

| Name         | Description                              | Possible values   |
|--------------|------------------------------------------|-------------------|
| [Modell]     | Article number of the device             | e.g. AC1433/34    |
| [SN]         | Serial number of the device              | e.g. 000000113034 |
| [Build]      | Version number of the installed firmware | e.g. 4.2.x        |
| [HW version] | Version number of the device main board  | e.g. AA           |

## 5.5.3 System: Setup

7274

The [Setup] menu item provides access to the configuration options of the system.

### Set the output access

9100

To set the control instance for the outputs of the AS-i slaves:

#### 1 Select the menu page



- ▶ Select **[System settings]** tab.

#### 2 Configure the control instance for the outputs of the AS-i slaves

- ▶ Set the following parameters as required:

| Name            | Description                                | Possible values |                                                                                        |
|-----------------|--------------------------------------------|-----------------|----------------------------------------------------------------------------------------|
| [Output access] | Control instance of the AS-i slave outputs | [Gateway]       | A higher-level PLC controls the outputs of the AS-i slaves.                            |
|                 |                                            | [Manual]        | The operator controls the outputs of the AS-i slaves via the graphical user interface. |
|                 |                                            | [PLC]           | The device-internal PLC controls the outputs of the AS-i slaves.                       |

#### 3 Save the changes

- ▶ Press **[Accept selection]** to save the changes.
- > The selected instance controls the outputs of the AS-i slaves.



If the value PLC is selected, the system will automatically enable the device-internal PLC (→ **Enable/Disable the device-internal PLC** (→ p. [70](#))).

## Enable/Disable the device-internal PLC

15841

### NOTICE

Risk of material damage to the machine/plant!

When disabling the device-internal PLC, all running PLC applications will be stopped. This could have undesirable effects on the controlled process if the PLC figures as the control unit for the AS-i slave outputs.

- ▶ The PLC application should be terminated in a controlled manner before disabling the device-internal PLC!

(→ **Control PLC applications** (→ p. 65))

- ▶ Implement a safe state when programming the PLC applications!

When activating the device-internal PLC, PLC applications stored on the device are started automatically.

- ▶ Implement a safe start state when programming the PLC applications!

To set the internal Programmable Logic Controller (PLC):

#### 1 Select the menu page



- ▶ Select **[System settings]** tab.

#### 2 Enable/Disable the device-internal PLC

- > Set the following parameters as required:

| Parameter | Meaning                                  | Possible values                     |                                  |
|-----------|------------------------------------------|-------------------------------------|----------------------------------|
| [Use PLC] | State of the device-internal CODESYS PLC | <input type="checkbox"/>            | Device-internal PLC is disabled. |
|           |                                          | <input checked="" type="checkbox"/> | Device-internal PLC is enabled.  |

- > Selected value is applied.

## Set the device cycle

11780

### NOTICE

Risk of material damage to the machine/plant!

A device cycle that is too short can have undesirable effects on the correct transmission of the process and control data between the PLC and peripheral devices (higher-level PLC, AS-i slaves).

- Ensure a sufficiently long cycle time!



If the PLC is disabled, the device operates with a fixed cycle time of 0.7 ms.

To set the device cycle:

#### 1 Select the menu page



- Select **System settings** tab.

#### 2 Set the device cycle

- Set the following parameters as required:

| Parameter      | Description           | Possible values |                  |
|----------------|-----------------------|-----------------|------------------|
| [Device cycle] | Active → device cycle | [1.5 ms]        | 1.5 milliseconds |
|                |                       | [2.0 ms]        | 2.0 milliseconds |
|                |                       | [2.5 ms]        | 2.5 milliseconds |
|                |                       | [3.0 ms]        | 3.0 milliseconds |

#### 3 Save the changes

- Press **Accept selection** button.
- > Selected value is applied.

## Switch the menu language

7088

To select the language of the GUI texts:

### 1 Select the menu page



- ▶ Select [System settings] tab.

### 2 Select the menu language

- > The [Language] list shows the active language in which the GUI texts are displayed.
- ▶ Set the following parameters as required:

| Parameter  | Description                                   | Possible values |            |
|------------|-----------------------------------------------|-----------------|------------|
| [Language] | Language in which the GUI texts are displayed | [Deutsch]       | German     |
|            |                                               | [English]       | English    |
|            |                                               | [Français]      | French     |
|            |                                               | [Español]       | Spanish    |
|            |                                               | [Italiano]      | Italian    |
|            |                                               | [Português]     | Portuguese |

### 3 Save the changes

- ▶ Press [Accept selection] button.
- > GUI elements are displayed in the requested language.

## Optional: switch the language with a key combination

15834

The languages available on the device are saved in an ordered list:

- German
- English
- French
- Spanish
- Italian
- Portuguese

To switch the language with a key combination (from the active language):

- ▶ Press [▶] + [▲] to select the previous language in the list.

OR:

- ▶ Press [▶] + [▼] to select the next language in the list.
- > GUI elements are displayed in the requested language.



The key combination allows you to change the language from any menu page.



## Set the behaviour of the display

9107

To set the display behaviour (screen saver, behaviour in case of inactivity):

### 1 Select the menu page



- ▶ Select **System settings** tab.

### 2 Set the behaviour of the display

- ▶ Set the following parameters as required:

| Parameter                | Description                                                     | Possible values                     |                                                                                       |
|--------------------------|-----------------------------------------------------------------|-------------------------------------|---------------------------------------------------------------------------------------|
| [Screen saver]           | Status of the screen saver                                      | <input type="checkbox"/>            | Screen saver is inactive:<br>Display remains permanently switched on.                 |
|                          |                                                                 | <input checked="" type="checkbox"/> | Screen saver is active:<br>Display is switched off after 10 minutes of inactivity.    |
| [Return to start screen] | Display behaviour in case of extended period of user inactivity | <input type="checkbox"/>            | The currently selected menu page stays on the screen.                                 |
|                          |                                                                 | <input checked="" type="checkbox"/> | When the set time has elapsed, the display automatically changes to the start screen. |

- > Selected values are applied.

## Set the system time

10954

The system time consists of date and time. The device provides the following options for setting the system time:

- **Manual:** The operator sets the date and time manually.
- **Via NTP server:** The device has an NTP client. The system time can be synchronised with an NTP server.
- **Apply the system time of a PC/laptop:** The device adopts the system time of a PC/laptop (only available via the web interface of the device)

To set the system time:

### 1 Select the menu page



► Select **[Clock]** tab.

### 2 Display the current system time settings

> The following parameters display the current system time settings:

| Parameter      | Description                                              | Possible values                                                                                                                          |
|----------------|----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| [Activate NTP] | Activate the NTP client of the device                    | <input type="checkbox"/> NTP client is deactivated:<br>Device adopts the manually set values for [Time] and [Date].                      |
|                |                                                          | <input checked="" type="checkbox"/> NTP client is not active:<br>From an NTP server, the device adopts the values for [Time] and [Date]. |
| Status LED     | Status of NTP client and synchronisation with NTP server | [NTP not active ] NTP client is deactivated:<br>Applicable are the manually set values for [Time] and [Date].                            |
|                |                                                          | [NTP waiting ] NTP client is active:<br>Device waits for messages from NTP server.                                                       |
|                |                                                          | [NTP successful ] NTP client is active:<br>Time synchronisation with NTP server was successful.                                          |
| [Time]         | System time<br>(format [hh:mm:ss])                       | e.g. 12:23:56                                                                                                                            |
| [Date]         | System date<br>(format [yyyy-mm-dd])                     | e.g. 2014-04-23                                                                                                                          |

### 3 Select the configuration method

- Select one of the following:
- **Set the system time manually** (→ p. [75](#))
  - **Synchronise the system time with an NTP server** (→ p. [76](#))
  - **Adopt the system time of the PC** (→ p. [77](#))

## Set the system time manually

10963

To set the system time manually:

### 1 Select the menu page



- ▶ Select **[Clock]** tab.

### 2 Deactivate the NTP client of the device

- ▶ Uncheck [Activate NTP] (→ **Set the system time** (→ p. 74)).
- ▶ Press **[Accept selection]** button.
- > The changes become effective.
- > NTP status: [NTP not active 

### 3 Set the system time manually

- ▶ Set [Time] and [Date] (Operating notes: → **Numerical field** (→ p. 32))
- > Selected values are applied.



Seconds cannot be changed manually. When leaving the edit mode, the seconds will be automatically set to 0.

## Synchronise the system time with an NTP server

10969

To synchronise the system time with an NTP server:



To synchronise the system time and date via Network Time Protocol (NTP), connect the configuration interface of the device to an NTP server directly or over a network.

### 1 Select the menu page



- ▶ Select **[Clock]** tab.

### 2 Deactivate the NTP client

- ▶ Uncheck **[Activate NTP]** (→ **Set the system time** (→ p. 74)).
- > The IP address field and the **[NTP-Offset]** list can be edited.

### 3 Set the IP address of the NTP server and NTP offset

- ▶ Set the following parameters as required:

| Parameter                  | Description                                                      | Possible values                   |                                                                                                 |
|----------------------------|------------------------------------------------------------------|-----------------------------------|-------------------------------------------------------------------------------------------------|
| IP address field           | IP address of the NTP server                                     | e.g. 192.168.0.100                |                                                                                                 |
| [NTP-Offset]<br>(optional) | Time zone of the NTP server in UTC (Universal Coordinated Time). | [no offset]                       | System time is taken from NTP server without offset                                             |
|                            |                                                                  | [UTC -12:00<br>...<br>UTC +12:00] | Adopt time zones according to UTC division (displayed number of hours will be added/subtracted) |

- ▶ Press **[Accept selection]** button.
- ▶ The device tries to synchronise the system time with the NTP server.
- > NTP status: **[NTP waiting]**

In case of a successful synchronisation:

- > NTP status: **[NTP successful]**
- > **[Time]** and **[Date]** show the synchronised values.

In case of a failed synchronisation:

- ▶ Check the settings of the IP parameters of the configuration interface.
- ▶ Check the IP address of the NTP server.
- ▶ Repeat the process.

## Adopt the system time of the PC

15756

To adopt the date and time of a PC/laptop:



This function is only available via the web-interface of the device (→ **Remote access** (→ p. [34](#))).

### Requirements:

- ▶ Connect the device with PC/laptop (→ **Configuration interfaces: Connection concepts** (→ p. [120](#))).
- ▶ Start the web browser and open the web interface of the device (→ **Recommended browsers** (→ p. [34](#))).



This function can only be executed via the web interface of the device.

### 1 Select the menu page



- ▶ Select the **Clock** tab.

### 2 Adopt the system time of the PC/laptop

- ▶ Uncheck [Activate NTP] (→ **Set the system time** (→ p. [74](#))).
- ▶ In group [Apply Time and Date from the PC]: Press [OK] button.
  - > The device applies the date and time of the PC/laptop.
  - > [Date] and [Time] display the system time.

## Clone device configuration

7087



This function is only available via the local user interface of the device!

The device makes it possible to create an image of the current device configuration, to transfer it to another device and activate it there (clone). The export and import of the configuration file takes place via an SD card.

A device configuration consists of the following settings:

- System settings
- AS-i 1/AS-i 2 settings
- EtherCAT settings
- PLC applications (incl. PLC task configuration, variables and data)



Cloning a device configuration is only possible if the following conditions are met.

- The firmware versions of the source device and the target device are compatible (compatible = versions are identical in the major release and minor release, e.g. V3.2. is compatible with V3.2.2, but: V3.2.1 is incompatible with V3.3.1).
- Source and target device have the same article number.

## Export device configuration

16199

### NOTICE

Risk of undesired system behaviour

During the export the control functions of the device are not available.

- ▶ Do not export the device configuration during operation of the plant!

### NOTICE

Risk of data loss

An interruption of the export can lead to a faulty export file.

- ▶ Do not disconnect the device during the export.
- ▶ Only start the export after the boot application has been successfully generated.
- ▶ Do not remove the SD card from the device before the export is completed.



The SD card has to be formatted with the FAT32 file system. SD cards with other file systems are not recognised by the AC1433/34.

To allow identification of the saved configuration the export file is saved using the following name convention:

ifm\_DevID\_XXXXXXXXXX\_YYYYMMDDhhmmss.iconf

- DevID Article number of the device
- XXXXXXXXXXXX Serial number of the device
- YYYYMMDDhhmmss Timestamp of the saved file  
(YYYY = year, MM = month, DD = day, hh = hours, mm = minutes, ss = seconds)

To save the current device configuration on an SD card:

#### 1 Select menu page



- > Select **Configuration** tab.

#### 2 Save the device configuration

- ▶ Insert an empty, formatted SD card in the SD card slot of the device.
- ▶ Activate the **Export configuration** button.
- > The device saves the current configuration on the SD card. The device stores the current configuration on the SD card.

## Import device configuration

16200

### NOTICE

Risk of undesired system behaviour

During the import the control functions of the device are not available. During the import the device reboots.

- ▶ Do not import the device configuration during operation of the plant!

### NOTICE

Risk of data loss

An interruption of the import can lead to a faulty device configuration.

- ▶ Do not disconnect the device during the import.
- ▶ Do not remove the SD card from the device before the import is completed.



To avoid that a wrong device configuration is restored:

- ▶ Check before the import if the required device configuration is saved on the SD card (identification of the saved device configuration: → **Export device configuration** (→ p. 79)).
- ▶ Save only the device configuration to be imported in the root directory of the SD card.

To transfer a stored device configuration to the device:

#### 1 Select menu page



- ▶ Select **[Configuration]** tab.

#### 2 Restore the device configuration

- ▶ Insert an SD card with the stored device configuration in the SD card slot.
- ▶ Activate the **[Import configuration]** button.
  - > A warning appears.
- ▶ Confirm prompt with [OK].
  - > The device configuration is loaded and saved onto the device.
  - > The device reboots.



## System reset

8977

To reset the device:

### 1 Select the menu page



- ▶ Select **[Reset]** tab.

### 2 Carry out a system reset

- ▶ Press **[Restart]** button.
- > A safety query is displayed..
- ▶ Press [OK] to confirm the security prompt.
- > The device reboots.

## Store diagnostic protocol

7040

Using the diagnostic protocol, the user can archive the current device configuration or provide all relevant information to the service staff via the device settings.

The diagnostic protocol contains the following information in the selected user language:

- AS-i configuration
- EtherCAT configuration
- System settings
- CODESYS information
- OSC history



This function is only available via the web-interface of the device (→ **Remote access** (→ p. [34](#))).

### Requirements:

- ▶ Connect the device with PC/laptop (→ **Configuration interfaces: Connection concepts** (→ p. [120](#))).
- ▶ Start the web browser and open the web interface of the device (→ **Recommended browsers** (→ p. [34](#))).

### 1 Select menu page



- ▶ Select the [Diagnostic protocol] tab.

### 2 Store diagnostic protocol

- ▶ Press the [Generate diagnostic protocol] button.
- > AC1433/34 generates diagnostic protocol.
- > The progress bar indicates the status of the process.
- > A dialogue window appears.
- ▶ Select file name and memory location and press [OK] to confirm.
- > The diagnostic protocol is stored as an HTML file at the selected location.

## 5.5.4 System: Diagnosis

9053:

The [Diagnosis] menu item provides access to the diagnostic data of the device.

### Display diagnostic data

15827

To display the diagnostic data of the device:

#### 1 Select menu page



#### 2 Display diagnostic data

> Page shows the following information:

| Name                             | Description                                      | Possible values                                                                                        |                                                              |
|----------------------------------|--------------------------------------------------|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------|
| [Betriebszeit<br>[JJ-TTT SS:MM]] | Operating time of system and components          | All times indicated in [JJ-TTT-SS-MM] format:<br>YY = years<br>DD = days<br>hh = hours<br>mm = minutes |                                                              |
| ▪ [gesamt]                       | Operating time of device                         |                                                                                                        |                                                              |
| ▪ [aktuell]                      | Operating time of device since last system start |                                                                                                        |                                                              |
| ▪ [LCD]                          | Operating time of LCD                            |                                                                                                        |                                                              |
| ▪ [SPS]                          | Operating time of controller                     |                                                                                                        |                                                              |
| [Temperatur]                     | Current device temperature                       | Indications in [°C] (→ Note)                                                                           |                                                              |
| [Versorgt durch]                 | Voltage supply of device                         | [Aux]                                                                                                  | Voltage is supplied separately by AS-i network and AUX 24 V. |
|                                  |                                                  | [AS-i]                                                                                                 | Voltage is only supplied by the AS-i network.                |
|                                  |                                                  | [Power Modul]                                                                                          | Voltage is supplied by data decoupling module.               |



The temperature monitoring continuously checks the system temperature of the device. The following temperature ranges apply:

- Normal range: < 79.9 °C
- Limit range: 80 °C ... 84.9 °C
- Critical range: >= 85 °C

If the system temperature reaches the critical zone, a warning is displayed in the → **Online Support Center (OSC)** (→ p. [113](#)). The warning only disappears when the device temperature is again in the normal range.

## 5.6 Interfaces

7106

The [Schnittstellen] menu provides access to the configuration options of the device's interfaces.

| Navigation path                                                                   | Functions                                                                                                                                                                                                                                               |
|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Configuration interface 1<br>→ <b>Configure the IP parameters manually</b> (→ p. <a href="#">85</a> )<br>→ <b>Configure the IP parameters automatically</b> (→ p. <a href="#">85</a> )<br>→ <b>Show Ethernet information</b> (→ p. <a href="#">86</a> ) |
|  | Configuration interface 2<br>→ <b>Interfaces: Configuration interface 2</b> (→ p. <a href="#">86</a> )                                                                                                                                                  |
|  | EtherCAT interface<br>→ <b>Interfaces: EtherCAT interface</b> (→ p. <a href="#">87</a> )                                                                                                                                                                |

## 5.6.1 Interfaces: Configuration interface 1

7279

The [Configuration interface 1] menu provides access to the settings of the Ethernet Configuration interface 1 (port X3).

### Notes on IP settings

14856

The device provides the following options for configuration of the Ethernet Configuration interface 1:

- Manual = The operator sets the interface parameters (IP address, network mask, gateway address) manually.
- Automatic = The interface parameters are set automatically. The operator can choose between these protocols:
  - Dynamic Host Configuration Protocol (DHCP)
  - Zero Configuration Networking (Zeroconf)

To display the current configuration method and the active IP parameters of the configuration interface:

#### 1 Select the menu page



- ▶ Select **[IP setup]** tab.

#### 2 Show the active settings

- > The parameters below show the active settings:

| Parameter                  | Meaning                                                         | Possible values                     |                                                                     |
|----------------------------|-----------------------------------------------------------------|-------------------------------------|---------------------------------------------------------------------|
| [Obtain IP address autom.] | Active method for the configuration of the interface parameters | <input type="checkbox"/>            | Manual assignment of interface parameters through operator          |
|                            |                                                                 | <input checked="" type="checkbox"/> | Automatic assignment of interface parameters                        |
| [IP status]                | Configuration protocol used                                     | [Static]                            | The operator sets the IP parameters manually.                       |
|                            |                                                                 | [DHCP]                              | The IP parameters are set by a DHCP server.                         |
|                            |                                                                 | [Zeroconf]                          | The IP parameters are set automatically with the Zeroconf protocol. |
| [IP address]               | IP address of the interface                                     | e.g. 192.168.0.100                  |                                                                     |
| [Subnet mask]              | Network mask of the network segment                             | e.g. 255.255.255.0                  |                                                                     |
| [Gateway address]          | IP address of the network gateway                               | e.g. 192.168.0.1                    |                                                                     |

- ▶ Select one of the following options:
  - **Configure the IP parameters manually** (→ p. [85](#))
  - **Configure the IP parameters automatically** (→ p. [85](#))

## Configure the IP parameters manually

14860

To configure the IP parameters of the configuration interface manually:

### 1 Select the menu page



- ▶ Select **[IP setup]** tab.

### 2 Deactivate the NTP client

- ▶ Uncheck [Obtain IP address autom.] (→ **Notes on IP settings** (→ p. 84)).
- > The IP address fields [IP address], [Subnet mask] and [Gateway address] can be edited.

### 3 Configure the IP parameters

- ▶ Configure the following parameters as required (→ **Notes on IP settings** (→ p. 84)):
  - [IP address]
  - [Subnet mask]
  - [Gateway address]

### 4 Save the changes

- ▶ Press [Accept] button.
- > Selected values are applied.
- > [IP status] displays the active configuration method: [Static]

## Configure the IP parameters automatically

14859



The device must be connected to a DHCP server to automatically receive the interface parameters via DHCP.

- ▶ Connect the configuration interface (X3) to a DHCP server.

To configure the IP parameters of the configuration interface automatically:

### 1 Select the menu page



- ▶ Select **[IP setup]** tab.

### 2 Enable the NTP client

- ▶ Activate the [Obtain IP address autom.] (→ **Notes on IP settings** (→ p. 84))

### 3 Save the changes

- ▶ Press **[Accept]** button.
- > The device tries to obtain the IP parameters from a DHCP server.
- > If the configuration of IP parameters via DHCP server fails, the device will generate the IP parameters with the Zeroconf protocol.
- > [IP address], [Subnet mask] and [Gateway address] display the set IP parameters.
- > Selected values are applied.
- > [IP status] displays the active configuration method: DHCP or Zeroconf.



The automatic configuration of the IP parameters takes approx. 10 seconds.

## Show Ethernet information

14857

To show Ethernet information regarding the configuration interface:

### 1 Select the menu page



- ▶ Select **Ethernet information** tab.

### 2 Show Ethernet information

- > Page shows the following information:

| Name     | Description                                |
|----------|--------------------------------------------|
| [MAC ID] | MAC identification number of the interface |

## 5.6.2 Interfaces: Configuration interface 2

7234

The [Konfigurationsschnittstelle 2] menu provides access to the settings of the Ethernet configuration interface 2 (port X2).



The Ethernet configuration interfaces 1 (X3) and 2 (X8) must not be participants of the same EtherNet subnet. Non-compliance may lead to connection problems under CODESYS.

- ▶ Configure IP settings so that interfaces X3 and X8 are part of different Ethernet subnets.



The menu functions correspond to the functions of the menu [Configuration interface 1].

For information regarding the menu functions: → **Interfaces: Configuration interface 1** (→ p. [84](#))

- ▶ For the selection of the menu page replace the symbol  by  !

### 5.6.3 Interfaces: EtherCAT interface

13870

The [EtherCAT] menu provides access to information, settings and diagnostic data regarding the EtherCAT interface.

| Navigation path                                                                                                                                                                                                                                           | Functions                                                                                                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  >  >  | EtherCAT information<br>→ <b>Show information</b> (→ p. <a href="#">88</a> )<br>→ <b>Display EtherCAT parameters</b> (→ p. <a href="#">88</a> )<br>→ <b>Display the module configuration</b> (→ p. <a href="#">89</a> )<br>→ <b>Download ESI file</b> (→ p. <a href="#">89</a> ) |
|  >  >  | EtherCAT settings<br>→ <b>Configure the EtherCAT interface</b> (→ p. <a href="#">90</a> )                                                                                                                                                                                        |
|  >  >  | EtherCAT diagnostics<br>→ <b>Display diagnostic data</b> (→ p. <a href="#">91</a> )                                                                                                                                                                                              |

## EtherCAT: Information

11781

The menu item [Information] provides access to information regarding the EtherCAT interface.

### Show information

11513

To display information about the EtherCAT module AC1433/34:

#### 1 Select menu page



▶ Select tab **[ID object]**

#### 2 Show information

> Page shows the following information:

| Name                | Description                    | Possible values |
|---------------------|--------------------------------|-----------------|
| [Device type]       | EtherCAT ID of the device type | 5001            |
| [Device name]       | Article number of the device   | AC1433/34       |
| [Device revision]   | Hardware version of the device | e.g. AA         |
| [Software revision] | Software version of the device | e.g. 4.2.2      |
| [Vendor ID]         | Manufacturer ID                | 0x0622          |
| [Product code]      | Product code of the device     | e.g. 0xAC432    |
| [Revisions-Nr.]     | Revision number of the device  | e.g. 0x0001     |
| [S. no.]            | Serial number of the device    | e.g. 4206659    |

## Display EtherCAT parameters

6994

To display the current settings of the EtherCAT parameters

#### 1 Select menu page



▶ Select tab **[EtherCAT data]**

#### 2 Display EtherCAT parameters

> Page displays current settings of the following EtherCAT parameters (→ **Device-specific parameters** (→ p. 136)):

- [Failsafe value]
- [Parameter Download]



## Display the module configuration

11009

To display the current module configuration:

### 1 Select the menu page



- ▶ Select **[Module configuration]** tab.

### 2 Display the module configuration

- > The page shows the active module configuration of the EtherCAT slots. (→ **Profibus modules**)



The fieldbus slots can only be configured in the EtherCAT projection software.

## Download ESI file

11493



This function is only available via the web interface of the device (→ **Remote access** (→ p. [34](#))).

To download the ESI file:

### Requirements:

- ▶ Connect the device to the PC/laptop (→ **Configuration interfaces: Connection concepts** (→ p. [120](#))).
- ▶ Start web browser and activate device web interface (→ **Recommended browsers** (→ p. [34](#))).

### 1 Select menu page



- ▶ Select tab [Datei-Download].
- > Menu screen [Datei-Download] appears.

### 2 Download ESI file

- ▶ Click on [Download ESI-Datei] to download the device description.

## EtherCAT: Setup

16196

The [Setup] menu item provides access to the configuration options of the EtherCAT interface.

### Configure the EtherCAT interface

11481

To configure the EtherCAT interface:

#### 1 Select menu page



- ▶ Select tab **EtherCAT settings**.

#### 2 Set the EtherCAT address of the device

- ▶ Set the following parameters as required:

| Parameter | Description                    | Possible values   |                                                     |
|-----------|--------------------------------|-------------------|-----------------------------------------------------|
| [ID]      | EtherCAT address of the device | 1<br>...<br>65535 | EtherCAT address 1<br>...<br>EtherCAT address 65535 |

- ▶ Click on **Accept** to save the changes.

## EtherCAT: Diagnosis

9126

The menu item [Diagnosis] provides access to the diagnostic data of the EtherCAT interface:

### Display diagnostic data

14605


To display the diagnostic EtherCAT data:

#### 1 Select menu page



#### 2 Display diagnostic data

> Page shows the following information:

| Parameter      | Description                          | Possible values                                                                      |                                               |                                          |
|----------------|--------------------------------------|--------------------------------------------------------------------------------------|-----------------------------------------------|------------------------------------------|
| [EtherCAT RUN] | status of the EtherCAT state machine |     | OFF                                           | INIT                                     |
|                |                                      |    |                                               | PRE-OPERATIONAL                          |
|                |                                      |    |                                               | SAFE-OPERATIONAL                         |
|                |                                      |    | EIN                                           | OPERATIONAL                              |
|                |                                      |   |                                               |                                          |
| [EtherCAT ERR] | Error status                         |    | OFF                                           | no error                                 |
|                |                                      |  |                                               | invalid configuration                    |
|                |                                      |  |                                               | local error / unexpected state of change |
|                |                                      |  |                                               | watchdog error                           |
|                |                                      |  |                                               |                                          |
| [Status X6]    | connection status port X6            |   | no connection to the EtherCAT controller      |                                          |
|                |                                      |   | connection to fieldbus controller established |                                          |
| [Status X7]    | connection status port X7            |   | no connection to the EtherCAT controller      |                                          |
|                |                                      |   | connection to fieldbus controller established |                                          |

## 5.7 ifm system solutions

7065



This menu is only available via the web interface of AC1433/34.  
→ **Remote access** (→ p. [34](#))

The [ifm system solutions] menu provides access to information and installation options for ifm system solutions.

| Navigation path                                                                   | Functions                                                                                                                                                                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | ifm system solutions:<br>→ <b>Show information about installed ifm apps</b> (→ p. <a href="#">94</a> )<br>→ <b>Install single/basic app</b> (→ p. <a href="#">95</a> )<br>→ <b>Install multi app</b> (→ p. <a href="#">96</a> )<br>→ <b>Update ifm apps</b> (→ p. <a href="#">97</a> )<br>→ <b>Uninstall ifm apps</b> (→ p. <a href="#">97</a> ) |

## 5.7.1 Notes on ifm system solutions

12229

With the AC1433/34, ifm electronic offers different system solutions for the simple implementation of typical applications. System solutions consist of applications which are processed by the device-internal CODESYS PLC.



ifm system solutions and user-created applications must not be stored and run simultaneously on the AC1433/34!

- ▶ Delete all CODESYS system solutions stored on the device before installing new ifm system solutions or user applications!

ifm system solutions can only be installed and run if the device-internal PLC is activated.

- ▶ Activate the PLC of the AC1433/34 (→ **Enable/Disable the device-internal PLC** (→ p. 70))!



Users can download the available ifm system solutions from ifm's website.

→ [www.ifm.com](http://www.ifm.com) > Service > Download > Industrial communication


## Types of ifm system solutions

8682

There are 2 types of ifm system solutions:


- **Single apps**

Single apps provide the user with a CODESYS-based solution. Single apps directly access the I/O mechanisms of the CODESYS PLC. Only one single app must be stored and executed on the device.



- **Basic app + multi apps**

Multi apps provide the user with the possibility to execute different CODESYS-based solutions in parallel. The multi apps use the services of the basic app in order to be able to access the inputs and outputs of AC1433/34 at the same time. They operate as a pure communication layer between the I/O mechanisms of the CODESYS PLC and the connected multi apps. Maximum 5 multi apps at a time can be stored and executed in parallel on the device.



## 5.7.2 Show information about installed ifm apps

9041

In order to display information about the ifm system solutions installed on the device:

### 1 Select menu page



- ▶ Select the [Information] tab.

### 2 Show information about installed ifm apps

- > The browser window displays an overview of the installed ifm apps. The following information is displayed for each ifm app:

| Information                           | Meaning                                                                         |
|---------------------------------------|---------------------------------------------------------------------------------|
| [Name]                                | Designation of the ifm system solution app                                      |
| [Version]                             | Version number of the ifm system solution app                                   |
| [Type]                                | Type of ifm app (single, basic, multi)                                          |
| [Description]                         | Description of the functionality of the ifm system solution app                 |
| [Licence information]                 | Licence information about the ifm system solution in the selected user language |
| [Link to the ifm system solution app] | Hyperlink for web visualisation of the ifm system solution app                  |

## 5.7.3 Install single/basic app

7092



Only one single app, basic app or CODESYS PLC application must be stored on the device. When installing a single/basic app, all ifm system solutions and CODESYS PLC applications stored on the device are deleted.

To install a single or basic app on the device:

### 1 Select menu page



- ▶ Select the [Installation] tab.

### 2 Select single/basic app

- ▶ Activate the [Search] button.
- > A dialogue window appears.
- ▶ Select the requested single/basic app (\*.ifmapp) and click [Open] to load it.
- > The file name of the selected single/basic app is displayed.

### 3 Transfer the single/basic app to the device

- ▶ Click on [Transfer file] button to transfer the selected single/basic app to the device.
- > The progress bar indicates the status of the process.
- > After successful transfer: The window shows information about the copied single/basic app.
- ▶ Optional: Click on [Cancel] to stop the download process.

### 4 Install the single/basic app

- ▶ Activate the [Start installation] button.
- > CODESYS PLC is stopped.
- > All ifm system solutions and CODESYS PLC applications on the device are deleted.
- > The selected single/basic app is installed.
- > The progress bar indicates the status of the installation process.
- > CODESYS PLC is started.
- > The installed single/basic app is automatically started (RUN state).

## 5.7.4 Install multi app

6954



Maximum 5 multi apps must be stored on the device simultaneously.

To install a multi app on the device:

### Requirements:

- > The basic app is installed and started (RUN state) (→ **Install single/basic app** (→ p. [95](#)))

### 1 Select menu page



- ▶ Select the [Installation] tab.

### 2 Select multi app

- ▶ Activate the [Search] button.
- > A dialogue window appears.
- ▶ Select the requested multi app (\*.ifmapp) and click the [Open] button to load it.
- > The file name of the selected multi app is displayed.

### 3 Transfer the multi app onto the device

- ▶ Click on [Transfer file] to transfer the selected multi app onto the device.
- > The progress bar indicates the status of the process.
- > After successful transfer: The window shows information about the copied multi app.
- ▶ Optional: Click on [Cancel] to stop the download process.

### 4 Install multi app

- ▶ Activate the [Start installation] button.
- > CODESYS PLC is stopped.
- > The selected multi app is installed.
- > The progress bar indicates the status of the installation process.
- > CODESYS PLC is started.
- > The installed multi app is automatically started (RUN state).
- ▶ Optional: Repeat steps 2 to 4 to install further multi apps.



## 5.7.5 Update ifm apps

6925

The user can update an ifm system solution installed on the device by overwriting it with the new version of the ifm system solution.

Naming convention for ifm apps:

AppName\_x.y.z.ifmapp

AppName = name of the ifm app  
x.y.z = version number of the ifm app  
ifmapp = file extension of an ifm app

To update an ifm system solution:

### Requirements:

- > The name of the new ifm app and the installed ifm app must be identical.
- > The version number of the ifm app must be greater than that of the installed ifm app.



To determine the version of the installed ifm app: → **Show information about installed ifm apps** (→ p. [94](#))

### 1 Download new ifm app

- Download new version of the ifm system solution (→ **Notes on ifm system solutions** (→ p. [93](#))).

### 2 Update the installed ifm app

- Install the new ifm system solution
  - Single/basic app: → **Install single/basic app** (→ p. [95](#))
  - multi app: → **Install multi app** (→ p. [96](#))

## 5.7.6 Uninstall ifm apps

7014



When a basic app is uninstalled, all dependent multi apps are uninstalled, too.  
Before uninstalling an ifm app, the CODESYS PLC of AC1433/34 is stopped. After successful uninstallation, the CODESYS PLC is started again.

To uninstall an ifm system solution installed on the device:

### 1 Display installed ifm apps

- **Show information about installed ifm apps** (→ p. [94](#))

### 2 Uninstall ifm app

- In the section of the respective ifm app:  
Activate the [Uninstall app] button.
- > CODESYS PLC is stopped.
- > The selected ifm app is uninstalled.
- > CODESYS PLC is started.



## 6 Setup

### Contents

|                                             |     |
|---------------------------------------------|-----|
| Connect the device to the periphery.....    | 99  |
| Start screen 'Basic settings'.....          | 100 |
| Update the firmware of the device.....      | 102 |
| Connect and address AS-i slaves .....       | 106 |
| Configure EtherCAT interface .....          | 106 |
| Set Ethernet configuration interfaces ..... | 106 |
| Exchange AS-i slave .....                   | 107 |

15844

This section provides information for setting up the device following mounting, electrical installation and connection to AS-i network components.



Observe the notes on mounting and electrical connection of the device!  
→ Operating instructions (supplied with the device)

### 6.1 Connect the device to the periphery

9000

#### 6.1.1 EtherCAT interface

14615

If AC1433/34 is to be operated as EtherCAT slave:

- ▶ Connect EtherCAT IN (X7) to the EtherCAT master or the previous EtherCAT slave
- ▶ Optional: Connect EtherCAT OUT (X6) with the next EtherCAT slave.

#### 6.1.2 Ethernet configuration interfaces

3859

To access the web interface or the programming interface of the device-internal PLC of the device:

- ▶ Connect the device to the Ethernet network or the PC/laptop via the configuration interface 1 (X3) or 2 (X8)  
(→ **Configuration interfaces: Connection concepts** (→ p. [120](#))).

If AC1433/34 is to be operated as EtherCAT master:

- ▶ Connect the device to the EtherCAT network via the configuration interface 1 (X3) or 2 (X8).

## 6.2 Start screen 'Basic settings'

11226

The 'Basic settings' start screen appears after the following actions/events:

- initial setup
- firmware update
- data loss due to battery failure

The basic settings provide access to the GUI texts, system time, etc.



The same operating notes as for the page view apply for the 'Basic settings' start screen (→ **Page view** (→ p. [21](#))).

### 6.2.1 Change the basic settings of the device

18511


To change the basic settings of the device:

#### 1 Start the device

- ▶ Connect the device to a circuit.
- > The device starts.
- > The display shows the start screen "Basic settings" (screenshot).

#### 2 Set the language of the GUI texts


- ▶ List shows the active language.
- ▶ Use [▼] / [▲] to mark the list.
- > The focus (= orange frame) is on the marked list.
- ▶ Open the list with the left function key [Select].
- ▶ Use [▼] / [▲] to mark the desired language and press [Select] to activate it.
- > The GUI texts appear in the selected language.
- ▶ Go to the next page with [Next](#).



### 3 Set the system time


#### Option 1: Set the system time manually

- ▶ [Uhrzeit] and [Datum] indicate the current system time.
- ▶ Deactivate the checkbox [NT aktivieren].
- > Status LED = 
- ▶ In the group [Uhrzeit], set the desired clock time one position at a time.
- ▶ In the group [Datum], set the desired date one position at a time.
- ▶ Save the changes with [Fertigstellen] and go to the standard start screen.



#### Option 2. Synchronise the system time with an NTP server

- ▶ Activate the checkbox [NTP aktivieren].
- > Status LED = 
- ▶ Enter the IP address of the NTP server in the IP address field.
- ▶ Pick the time zone of the NTP server from the list (UTC format).
- > The NTP client of the device synchronises the system time with the selected NTP server.
- ▶ Wait until status LED = 
- > [Datum] and [Uhrzeit] show the synchronised values.
- ▶ Save the changes with [Fertigstellen] and go to the standard start screen.



## 6.3 Update the firmware of the device

18399

### NOTICE

Risk of data loss!

Interrupting a firmware update leads to a loss of the current system and fieldbus settings.

- ▶ Secure the device settings before carrying out a firmware update! (→ **Export device configuration** (→ p. [79](#)))
- ▶ Ensure an uninterrupted voltage supply during the firmware update!

To update the firmware of the device:

- ▶ Select one of the following options:
  - **Firmware update from SD card** (→ p. [103](#))
  - **Firmware update via the web interface** (→ p. [104](#))

### 6.3.1 Behaviour of the settings upon firmware update

17058

The following settings/data records remain valid upon a firmware update:

| Setting / data record                        | Path to the menu page                                 |
|----------------------------------------------|-------------------------------------------------------|
| User language of the GUI                     | [System] > [Setup] > [System settings]                |
| Display settings (screen saver, return)      | [System] > [Setup] > [System settings]                |
| System time (date/time)                      | [System] > [Setup] > [Clock]                          |
| NTP settings                                 | [System] > [Setup] > [Clock]                          |
| Operating hours counter                      | [System] > [Diagnosis]                                |
| AS-i master settings and configuration data  | [AS-i 1] / [AS-i 2] > [Master setup]                  |
| IP parameters of the configuration interface | [Interfaces] > [Configuration interface] > [IP-Setup] |
| Fieldbus settings                            | [Interfaces] > [EtherCAT] > [Setup]                   |

The following settings/data records are reinitialised with their default values upon firmware update:

| Setting / data record  | Reset value            | Path to the menu page                  |
|------------------------|------------------------|----------------------------------------|
| Control of the outputs | Gateway                | [System] > [Setup] > [System settings] |
| Activate CODESYS PLC   | deactivated            | [System] > [Setup] > [System settings] |
| Device cycle           | 0.7 ms                 | [System] > [Setup] > [System settings] |
| OSC                    | Delete system messages | Start page > [OSC]                     |
| Retain variables       | 0x00                   | --                                     |

## 6.3.2 Firmware update from SD card

18400




Pay attention to notes on memory behaviour (→ **Behaviour of the settings upon firmware update** (→ p. [102](#)))!

### 1 Preparations

- ▶ Download the new firmware file from the **ifm** website.
- ▶ Copy the firmware file into the root directory of an SD card.
- ▶ Insert the SD card containing the firmware file in the SD card slot (→ **SD card slot** (→ p. [14](#))).


### 2 Start the recovery mode

- ▶ Separate the device from the circuit.
- ▶ Perform the following actions simultaneously:
  - Press the left function key and the arrow keys [▲] and [▼] simultaneously and keep them pressed (→ picture).
  - Connect the device to a circuit.
- ▶ Keep the keys pressed until the screen [ifm Recovery] appears (approx. 10 s).



### 3 Update the firmware

- ▶ Use the arrow keys [▲] / [▼] to select the menu item [Install from SD] (→ picture).
- ▶ Press [OK] using the left function key.
  - > The updating process starts.
  - > The display shows the progress of the firmware update.
  - > A status message appears once the firmware has been updated successfully.



### 4 Reboot the device

- ▶ Use the arrow keys [▲] / [▼] to select the [Reboot] button.
- ▶ Press [OK] to reboot the device.
  - > The device reboots with the current firmware.
  - > The start screen "Basic settings" appears (→ **Start screen 'Basic settings'** (→ p. [100](#))).

### 6.3.3 Firmware update via the web interface

18401



Pay attention to notes on memory behaviour (→ **Behaviour of the settings upon firmware update** (→ p. [102](#)))!

#### 1 Preparations

- ▶ Download the new firmware file from the **ifm** website.
- ▶ Connect the PC/laptop to the configuration interface (X3) of the device.  
(→ **Configuration interfaces: Connection concepts** (→ p. [120](#)))

#### 2 Start the recovery mode

- ▶ Separate the device from the circuit.
- ▶ Perform the following actions simultaneously:
  - Press the left function key and the arrow keys [▲] and [▼] simultaneously and keep them pressed (→ picture).
  - Connect the device to a circuit.
- ▶ Keep the keys pressed until the screen [ifm Recovery] appears (approx. 10 s).




#### 3 Optional: adjust the IP parameters

- ▶ Use the arrow keys [▲] / [▼] to select the menu item [Network Setup].
- ▶ Press [OK] to go to the network setup.
- > The display shows the page [Network Setup] (→ picture).
- > The page shows the current IP address of the device.

##### Option 1: obtain the IP parameters from a DHCP server


- ▶ Connect the configuration interface to the DHCP server.
- ▶ Use the arrow keys [▲] / [▼] to select the menu item [DHCP].
- ▶ Press [OK] to activate the DHCP client of the device.
- > The device obtains the IP parameters from the DHCP server.
- > If not successful, the device will create the IP parameters by means of the Zeroconf protocol.
- > The display shows the [Network Setup] page with the new IP address.
- ▶ Leave the network setup with [Back].
- > The display shows the [ifm Recovery] page.





**Option 2: configure the IP parameters manually**

- ▶ Use the arrow keys [▲] / [▼] to select the menu item [Manual Setup].
- ▶ Activate the manual setup with [OK].
- > The display shows the [Static IP setup] page (→ picture)
- ▶ Use the arrow keys [▲] / [▼] to select the following menu items one after the other and set them as required:
  - [IP Address]
  - [Network Mask]
  - [Default gateway]
- ▶ Press [Apply] to save the set values.
- > The display shows the [Network Setup] page with the new IP address.
- ▶ Leave the network setup with [Back].
- > The display shows the [ifm Recovery] page.

**4 Update the firmware**

- ▶ Access the web interface of the device.
- > The web interface of the recovery mode appears:



- ▶ Press the [Search ...] button.
- > The file explorer appears.
- ▶ Select the firmware file and press [Open].
- > The field [Select image to upload] shows the file path and name of the firmware file.
- ▶ Press [send] to start the updating process.
- > The display and web interface show the progress of the firmware update.
- > A status message appears once the firmware has been updated successfully.

**5 Reboot the device**

- ▶ Click on the tab [Reboot]
- > The device reboots with the current firmware.
- > The start screen "Basic settings" appears (→ **Start screen 'Basic settings'** (→ p. [100](#))).

## 6.4 Connect and address AS-i slaves

9004

To integrate AS-i slaves into an AS-i network that is controlled by one of the AS-i masters of the device:

### 1 Connect and address the AS-i slave

- ▶ Connect ONE AS-i slave to be addressed to the requested AS-i network (AS-i 1 or AS-i 2) as described in the corresponding installation instructions.
- ▶ Assign the desired address to the AS-i slave  
(→ **Quick setup: Address the AS-i slaves connected to AS-i master 1** (→ p. 47) or → **Quick setup: Address the AS-i slaves connected to AS-i master 2** (→ p. 48)).
- ▶ Optional: Repeat step 1 to connect and address further AS-i slaves.

### 2 Project the AS-i network

- ▶ Carry out a projection adaptation on the AS-i master with the newly addressed AS-i slaves  
(→ **Quick setup: Project AS-i networks** (→ p. 41)).
- > The AS-i master adds the detected slaves (LDS) to the list of the projected slaves (LPS).
- > The AS-i slaves have a valid address and are integrated in the AS-i network.

## 6.5 Configure EtherCAT interface

14614

If AC1433/34 is to be operated as EtherCAT slave:

- ▶ Set device ID (→ **Configure the EtherCAT interface** (→ p. 90))
- ▶ In the EtherCAT projection software:
  1. Integrate the AC1433/34 into the EtherCAT project.
  2. Optional: AC1433/34 is added to a hot-connect group.
  3. Configure EtherCAT slots of the AC1433/34 (→ **Cyclic data** (→ p. 139)).



If the AC1433/34 is to be operated as EtherCAT master:

- ▶ Add and configure EtherCAT master stack (→ Programming manual)

## 6.6 Set Ethernet configuration interfaces

13346

To configure the Ethernet configuration interfaces 1 (X3) and 2 (X8):

- Ethernet configuration interface 1 (X3):

- ▶  >
- ▶ Select **[IP setup]**.
- ▶ Set interface parameters (→ **Notes on IP settings** (→ p. 84)).

- Ethernet configuration interface 2 (X8):

- ▶  >
- ▶ Select **[IP setup]**.
- ▶ Set interface parameters (→ **Notes on IP settings** (→ p. 84)).

## 6.7 Exchange AS-i slave

10249

AC1433/34 makes it possible to replace an AS-i slave by a new AS-i slave in the operating mode "protected mode".

### Requirements:

- > The new and the old AS-i slave have the same device profile (→ **Profiles of AS-i slaves** (→ p. [126](#))).
- > The new AS-i slave has the address 0.
- > Parameter [Automat. addressing] is activated (→ **Set the monitoring functions of the AS-i master** (→ p. [51](#))).

### 1 Remove old AS-i slave

- ▶ Disconnect the AS-i slave to be replaced from the AS-i network
- > AC1433/34 detects a configuration error and generates a corresponding OSC message.

### 2 Install new AS-i slave

- ▶ Connect the new AS-i slave to the AS-i network.
- > AC1433/34 detects the new AS-i slave and automatically assigns the address of the old AS-i slave.
- > The OSC error message disappears.
- > The new AS-i slave is operational.

# 7 Troubleshooting

## Contents

|                                   |     |
|-----------------------------------|-----|
| Status LED .....                  | 108 |
| Start screen: Status LEDs .....   | 110 |
| Online diagnosis function .....   | 112 |
| Online Support Center (OSC) ..... | 113 |

7288

This chapter offers information regarding fault detection and troubleshooting.

## 7.1 Status LED

7094

The status LEDs of the device provide information about the current state of system components.



Position of the status LED on device: → **Overview** (→ p. [12](#))

### 7.1.1 Status LED: Basic device

6950

| Status LED |        |                | Description                                     |
|------------|--------|----------------|-------------------------------------------------|
| H1         | green  | on             | Device has started, warnings or error messages. |
|            | yellow | flashes 0.5 Hz | There is a warning but not an error message.    |
|            | red    | flashes 2 Hz   | There is an error message.                      |

### 7.1.2 Status LED: Fieldbus EtherCAT

12115

| Status LED |        |         | Description            |
|------------|--------|---------|------------------------|
| H2         | yellow | off     | no data transmission   |
|            |        | flashes | Reception of data      |
| H3         | green  | off     | no physical connection |
|            |        | on      | Physical connection OK |
| H4         | yellow | off     | no data transmission   |
|            |        | flashes | Reception of data      |
| H5         | green  | off     | no physical connection |
|            |        | on      | Physical connection OK |

### 7.1.3 Status LED: Configuration interface 2 (X8)

12794

| Status LED |        |         | Description            |
|------------|--------|---------|------------------------|
| H6         | yellow | off     | no data transmission   |
|            |        | flashes | Reception of data      |
| H7         | green  | off     | no physical connection |
|            |        | on      | Physical connection OK |

## 7.2 Start screen: Status LEDs

7777

The start screen of the graphic user interface proves the following status information (→ **Start screen** (→ p. 38)):

### 7.2.1 Status of the web interface

20766

| Status LED           |       |    | Description |
|----------------------|-------|----|-------------|
| Web interface status | red   | on | offline     |
|                      | green | on | online      |



This function is only available via the web interface of the device (→ **Remote access** (→ p. 34)).

### 7.2.2 Operating mode of the AS-i master

7780

| Status LED              |        |    | Description     |
|-------------------------|--------|----|-----------------|
| AS-i 1 2 operating mode | yellow | on | projection mode |
|                         | green  | on | protected mode  |

### 7.2.3 Control instance of the AS-i outputs

7783

| Status LED     |        |    | Description                 |
|----------------|--------|----|-----------------------------|
| Output control | yellow | on | manually   manually via PLC |
|                | green  | on | gateway   gateway with PLC  |
|                | blue   | on | PLC                         |


### 7.2.4 EtherCAT: fieldbus status

7839

| Status LED |       |                                                                                                                         | Description      |
|------------|-------|-------------------------------------------------------------------------------------------------------------------------|------------------|
| ECAT RUN   | green | off                                                                                                                     | INIT             |
|            |       | flashes (200 ms on, 200 ms off)<br>  | PRE-OPERATIONAL  |
|            |       | flashes (200 ms on, 1000 ms off)<br> | SAFE-OPERATIONAL |
|            |       | on                                                                                                                      | OPERATIONAL      |

## 7.2.5 EtherCAT: Error status

7840

| Status LED |     |                                                                                                                                              | Description                               |
|------------|-----|----------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------|
| ECAT ERR   | red | off                                                                                                                                          | no error                                  |
|            |     | flashes (200 ms on, 200 ms off)<br>                         | invalid configuration                     |
|            |     | flashes (200 ms on, 1000 ms off)<br>                        | local error / unexpected change of status |
|            |     | flashes (200 ms on, 200 ms off, 200 ms on, 1000 ms off)<br> | watchdog error                            |

## 7.3 Online diagnosis function

7055

The device offers an online diagnosis function. It helps the user to find and eliminate the source of occurring failures and errors.

### 7.3.1 Message types

18986

The online diagnostic function of AC1433/34 distinguishes 3 types of messages:

| Symbol                                                                            | Message type | Meaning                                                                                                                                                    |
|-----------------------------------------------------------------------------------|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Error        | <ul style="list-style-type: none"> <li>An error occurred; proper operation of the device is disturbed.</li> <li>User action absolutely required</li> </ul> |
|  | Warning      | <ul style="list-style-type: none"> <li>An irregularity has occurred</li> <li>User action required</li> </ul>                                               |
|  | Event        | <ul style="list-style-type: none"> <li>An uncritical event has occurred</li> <li>No user action required</li> </ul>                                        |

### 7.3.2 Locate error sources

7063

The online diagnosis function helps the operator to locate the source of occurring warning and error messages. The menu symbols of the navigation path leading to the menu page, which generates a message, are overlain by a warning / error symbol. Thus, the operator can easily locate the error source.

Example:



- > The following menu symbols are overlain by an error symbol:
  - Main navigation bar: [AS-i 1]
  - Sub navigation bar: [Slaves]
- > Error source on menu page [AS-i 1] > [Slaves]



If a function unit of the device causes a warning and an error message at the same time, then the error symbol is displayed.




## 7.4 Online Support Center (OSC)

7058

The Online Support Center (OSC) displays detailed information about occurring events, failures and errors.

The OSC has the following appearance:



- ① List to select a filter and name of the selected filter
- ② Message  
An message consists of error symbol, timestamp and detailed information about the errors
- ③ Number of the message displayed and total number of messages
- ④ Tabs to select a view  
[Current]: → **OSC: View current error messages**  
(→ p. [114](#))  
[History]: → **OSC: Show message history**  
(→ p. [115](#))

## 7.4.1 OSC: View current error messages

15842

The [Current] tab lists all current messages. The messages are in chronological order. All messages regarding warnings and errors are displayed.



Information about the different types of messages: → **Message types** (→ p. [112](#))  
 Overview of possible OSC messages of the device: → **OSC messages** (→ p. [166](#))

To view the error messages that are currently active:

### 1 Select the menu page

- ▶ On the start screen: Select [OSC]
- ▶ Select **[Current]** tab.

### 2 Show current messages

- > The page shows the error messages that are currently active.
- ▶ Press [▼] to select the message field.
- > The focus (orange frame) is on the message field.
- ▶ Use [▲]/[▼] to go through the error messages.

### 3 Optional: filter messages

- ▶ Set the following parameters as required:

| Parameter | Description                                 | Possible values |                                                                                                        |
|-----------|---------------------------------------------|-----------------|--------------------------------------------------------------------------------------------------------|
| [Filter]  | System component the message was created in | [All]           | Display all messages in chronological order of their occurrence (= preset).                            |
|           |                                             | [AS-i 1]        | Display messages that were created in AS-i master 1.                                                   |
|           |                                             | [AS-i 2]        | Display messages that were created in AS-i master 2 (only selectable for devices with 2 AS-i masters). |
|           |                                             | [System]        | Display messages that were created in the system.                                                      |

- > Page shows filtered messages.

## 7.4.2 OSC: Show message history

11775

The [History] tab lists all messages which occurred during the operating time of the device. The messages are shown in chronological order. The device displays messages regarding events, warnings and errors.



The messages are stored in a ring buffer. The ring buffer can store 2000 messages. If full, the device overwrites the oldest message(s) (time stamp).

There is a message pair for each failure (warning, error). It indicates the time of occurrence of the failure and the time at which the cause of the failure was rectified. The symbols of the messages are correspondingly marked.

Example: Error message



= Time at which the error occurred



= Time at which the cause of the fault was rectified.

To display the history of messages created so far again:

### 1 Select menu page

- ▶ On the start screen: Select [OSC].
- ▶ Select [History] tab.

### 2 Display all messages

- > The page shows all previously generated error messages.
- ▶ Press [▼] to select the message field.
- > The focus (orange frame) is on the message field.
- ▶ Use [▲]/[▼] to go through the error messages.

### 3 Optional: Filter messages

- ▶ Set the following parameters as required:

| Parameter | Description                                 | Possible values |                                                                                                        |
|-----------|---------------------------------------------|-----------------|--------------------------------------------------------------------------------------------------------|
| [Filter]  | System component the message was created in | [All]           | Display all messages in chronological order of their occurrence (= preset).                            |
|           |                                             | [AS-i 1]        | Display messages that were created in AS-i master 1.                                                   |
|           |                                             | [AS-i 2]        | Display messages that were created in AS-i master 2 (only selectable for devices with 2 AS-i masters). |
|           |                                             | [System]        | Display messages that were created in the system.                                                      |

- > Page shows filtered messages.

## 8 Appendix

### Contents

|                                                    |     |
|----------------------------------------------------|-----|
| Approval tests / certifications.....               | 116 |
| Technical data .....                               | 117 |
| Address assignment in Ethernet networks .....      | 119 |
| Configuration interfaces: Connection concepts..... | 120 |
| AS-i master .....                                  | 122 |
| AS-i slaves.....                                   | 125 |
| Fieldbus EtherCAT .....                            | 135 |
| OSC messages .....                                 | 166 |

7156

### 8.1 Approval tests / certifications

7239

Software-relevant certifications:

- AS-i master profile M4 according to AS-i specification 3.0
- Fieldbus certification: compliant with EtherCat specification



## 8.2 Technical data

### Contents

|                                           |     |
|-------------------------------------------|-----|
| Housing.....                              | 117 |
| Display elements .....                    | 117 |
| Operation .....                           | 117 |
| Power supply connections.....             | 118 |
| Interface.....                            | 118 |
| Programmable Logic Controller (PLC) ..... | 118 |

9011

### 8.2.1 Housing

9044

| Housing                     |                                  |
|-----------------------------|----------------------------------|
| Degrees of protection       | IP20                             |
| Material                    | Aluminium, steel sheet, Makrolon |
| Dimensions (W x H x D) [mm] | 93 x 128,2 x 106,2               |

### 8.2.2 Display elements

9045

| Display      |                                      |
|--------------|--------------------------------------|
| Technology   | LCD, colour                          |
| Size         | 35 x 28 mm (1.8")                    |
| Resolution   | 220 x 176 pixels                     |
| Colour depth | 18 bits (= 262 144 possible colours) |

| LED              |                    |
|------------------|--------------------|
| Possible colours | red, green, yellow |

### 8.2.3 Operation

9046

| Membrane keys                |    |
|------------------------------|----|
| Function keys                | 2x |
| Navigation keys / arrow keys | 4x |

## 8.2.4 Power supply connections

9047

| Power supply connections |                            |
|--------------------------|----------------------------|
| AS-i 1, AS-i 2, FE       | plug-in, 6 poles, Combicon |
| 24 V Power supply        | plug-in, 2 poles, Combicon |

## 8.2.5 Interface

8368

| Ethernet configuration interface |                   |
|----------------------------------|-------------------|
| Connection                       | 2x RJ45           |
| Transfer                         | 10/100 Mbits/s    |
| Protocol                         | HTTP, FTP, Telnet |

8597

| EtherCAT interface |                |
|--------------------|----------------|
| Connection         | 2x RJ45        |
| Protocol           | EtherCAT slave |
| Transfer           | 10/100 Mbits/s |

11072

| SD card slot           |                                  |
|------------------------|----------------------------------|
| Media                  | SD memory cards (max. 32 Gbytes) |
| Format                 | SDHC format is supported         |
| Supported file formats | FAT32                            |

## 8.2.6 Programmable Logic Controller (PLC)

14849

| Programmable Logic Controller (PLC)                      |                                                                         |
|----------------------------------------------------------|-------------------------------------------------------------------------|
| Type                                                     | CODESYS Control Runtime System<br>(incl. CODESYS WebVisu)               |
| Programming system                                       | CODESYS Development System (version 3.5 SP9 Patch 7 Hotfix 3 or higher) |
| Programming languages                                    | FBD, SFC, CFC, IL, LD, ST                                               |
| Available memory for PLC applications / RETAIN variables | approx. 10 MB / 4072 bytes                                              |

## 8.3 Address assignment in Ethernet networks

14436



In the Ethernet network every IP address **MUST** be unique.

The following IP addresses are reserved for network-internal purposes and are therefore not allowed as an address for participants: nnn.nnn.nnn.0 | nnn.nnn.nnn.255.

Only network participants whose subnet mask is identical and whose IP addresses are identical with respect to the subnet mask can communicate with each other.

### Rule:

If part of the subnet mask = 255, the corresponding IP address parts must be identical.

If part of the subnet mask = 0, the corresponding IP address parts must be different.

If the subnet mask = 255.255.255.0, 254 participants communicating with each other are possible in the network.

If the subnet mask = 255.255.0.0, 256x254 = 65 024 participants communicating with each other are possible in the network.

In the same physical network different subnet masks of the participants are allowed. They form different groups of participants which cannot communicate with groups of participants having other subnet masks.



In case of doubt or problems please contact your system administrator.

### Examples:

| Participant A<br>IP address | Participant A<br>Subnet mask | Participant B<br>IP address | Participant B<br>Subnet mask | Communication of<br>participants possible?                                                      |
|-----------------------------|------------------------------|-----------------------------|------------------------------|-------------------------------------------------------------------------------------------------|
| 192.168.82.247              | 255.255.255.0                | 192.168.82.10               | 255.255.255.0                | Yes, 254 participants possible                                                                  |
| 192.168.82. <b>247</b>      | 255.255.255.0                | 192.168.82. <b>247</b>      | 255.255.255.0                | No (same IP address)                                                                            |
| 192.168.82.247              | 255.255. <b>255</b> .0       | 192.168.82.10               | 255.255. <b>0</b> .0         | No (different subnet mask)                                                                      |
| 192.168. <b>82</b> .247     | 255.255.255.0                | 192.168. <b>116</b> .10     | 255.255.255.0                | No (different IP address range:<br>82 vs. 116)                                                  |
| 192.168.222.213             | 255.255.0.0                  | 192.168.222.123             | 255.255.0.0                  | Yes, 65 024 participants<br>possible                                                            |
| 192.168.111.213             | 255.255.0.0                  | 192.168.222.123             | 255.255.0.0                  | Yes, 65 024 participants<br>possible                                                            |
| 192.168.82.247              | 255.255.255.0                | 192.168.82. <b>0</b>        | 255.255.255.0                | No; the whole network is<br>disturbed because the IP<br>address xxx.xxx.xxx.0 is not<br>allowed |

## 8.4 Configuration interfaces: Connection concepts

### Contents

|                                       |     |
|---------------------------------------|-----|
| Direct connection .....               | 120 |
| Connection via Ethernet network ..... | 121 |

1970


The device has 2 configuration interfaces X3 and X8 (→ **Ethernet configuration interfaces** (→ p. 14)).

To use the interface functions configuration interface X3 or X8 has to be connected to the necessary IT infrastructure. The device supports the following connection types:

- **Direct connection** (→ p. 120)
- **Connection via Ethernet network** (→ p. 121)

### 8.4.1 Direct connection

2305



- ▶ Connect either configuration interface 1 (X3) or 2 (X8) to the PC/laptop via Ethernet cable.
  - ▶ Set the IP parameters of the configuration interface according to the requirements. (→ **Address assignment in Ethernet networks** (→ p. 119))
  - > User can access the web interface and/or programming interface of the device.




The selected configuration interface must not be used as EtherCAT master!



## 8.4.2 Connection via Ethernet network

1978



- ①
  - ▶ Connect either configuration interface 1 (X3) or 2 (X8) to switch / WiFi router via Ethernet cable.
  - ▶ Set IP parameters of the configuration interface and the switch / WiFi router so that the data exchange between both devices is ensured. (→ **Address assignment in Ethernet networks** (→ p. 119))
- ②
  - ▶ Connect the PC/laptop to the switch using an Ethernet cable.
  - > User can access the web interface and/or programming interface of the device.

OR:
- ③
  - ▶ Establish wireless connection of PC/laptop/mobile device to the WiFi router.
  - > User can access the web interface and/or programming interface of the device.



The selected configuration interface must not be used as EtherCAT master!

## 8.5 AS-i master

### Contents

|                                          |     |
|------------------------------------------|-----|
| Operating modes of the AS-i master ..... | 123 |
| Master flags .....                       | 124 |

8900

Master = Handles the complete organisation on the bus. The master decides on the bus access time and polls the →slaves cyclically.

## 8.5.1 Operating modes of the AS-i master

### Contents

|                              |     |
|------------------------------|-----|
| Protected mode .....         | 123 |
| Projection mode .....        | 123 |
| Switch operating modes ..... | 124 |

8934

The AS-i master can be operated in one of the following operating modes:

### Protected mode

14833

In the operating mode "Protected mode" (= normal mode), the AS-i master only communicates with AS-i slaves that are entered in the list of projected slaves (LPS) and where current and target configuration match.

The AS-i master automatically detects the following actions and signals a configuration error:

- an AS-i slave is added to the AS-i network (error message: Slave not projected)
- an AS-i slave is removed from the AS-i network (error message: Slave not present)

Optionally, the operator can activate/deactivate the following monitoring functions (→ **Set the monitoring functions of the AS-i master** (→ p. [51](#))):

|                               |                                                                                                                                                                                                                                                                                                                                         |
|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| • Automatic addressing:       | When a defective slave is replaced, the AS-i master controls the addressing. The new AS-i slave obtains the same address as the old AS-i slave if the following conditions are met: <ul style="list-style-type: none"> <li>▪ The new AS-i slave has the address 0.</li> <li>▪ Both AS-i slaves have the same device profile.</li> </ul> |
| • Double address recognition: | The AS-i master recognises whether one or several AS-i slaves have the same address (error message: Double address error).                                                                                                                                                                                                              |
| • Earth-fault detection:      | The AS-i master detects any earth faults.                                                                                                                                                                                                                                                                                               |

In the operating mode "Protected mode", the operator can control the PLC applications stored on the device (start, stop, reset).

### Projection mode

14848

In the operating mode "Projection mode", the AS-i master communicates with all AS-i slaves that are connected to the AS-i line and do not have the address 0. Missing AS-i slaves are not detected by the AS-i master.

In projection mode a projection adaptation can be carried out. The AS-i master reads the configuration data of all detected AS-i slaves and saves it permanently.

## Switch operating modes

5487

The operator / programmer can switch the operating modes of the AS-i master as follows:

- per GUI / web interface (→ **Set the operating mode of the AS-i master** (→ p. [50](#)))
- per function block Set\_Mode (→ programming manual: **Set\_Mode**)



If an AS-i slave with the address 0 is connected, then the AS-i master cannot switch from "projection mode" into "protected mode" !

- ▶ Address the AS-i slave correctly.
- ▶ Switch the operating mode.

## 8.5.2 Master flags

16936

The master flags contain information about the status of the AS-i master and the fieldbus host.

The master flags are transmitted along with the input data of the digital AS-i slaves in the acyclic data set DS2 (→ Device Manual Supplement - Acyclic datasets and command interface).

## 8.6 AS-i slaves

### Contents

|                              |     |
|------------------------------|-----|
| Profiles of AS-i slaves..... | 126 |
|------------------------------|-----|

8893

Slave = Passive participant on the bus, only replies on request of the →master. Slaves have a clearly defined and unique →address in the bus.

## 8.6.1 Profiles of AS-i slaves

### Contents

|                                                                                                   |     |
|---------------------------------------------------------------------------------------------------|-----|
| Configuration data (CDI) of the slaves (slave profiles).....                                      | 127 |
| Slave profiles for slaves with combined transaction.....                                          | 133 |
| Combined transaction – Use of analogue channels in the gateway depending on the slave profile ... | 133 |

8902

## Configuration data (CDI) of the slaves (slave profiles)

### Contents

|                                                                 |     |
|-----------------------------------------------------------------|-----|
| Structure of the slave profile .....                            | 127 |
| Description of the IO code for digital slaves .....             | 128 |
| Description of the ID code (selection) .....                    | 128 |
| Description of the extended ID code 1 .....                     | 129 |
| Description of the extended ID code 2 .....                     | 129 |
| Valid combinations IO code / ID code / extended ID code 2 ..... | 130 |

5346

The configuration data CDI (= **C**onfiguration **D**ata **I**mage) for single, A and B slaves is stored in a data word. The structure is shown below and is the same for all slaves.

### Structure of the slave profile

5347

The slave profile has the following structure: S-[IO code].[ID code].[ext. ID code2]

| Bits 15...12                                                                                   | Bits 11...8                                                                                                                               | Bits 7...4                                            | Bits 3...0                                                      |
|------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------|-----------------------------------------------------------------|
| XID2<br>extended ID code 2<br>3rd figure in the slave profile<br><br>(AS-i slave v2.0 = 0xF *) | XID1<br>extended ID code 1<br>is <u>no</u> part of the slave profile<br>can be changed by the user<br>(AS-i slave v2.0 = 0xF *)           | ID code<br>ID code<br>2nd figure in the slave profile | IO code<br>I/O configuration<br>1st figure in the slave profile |
| <b>Example:</b>                                                                                | AC2255<br>4 digital inputs, 2 digital outputs<br>AS-i profile = S-7.A.E<br>This results in the following configuration data of the slave: |                                                       |                                                                 |
| 0b1110 = 0xE                                                                                   | (e.g.) 0b0111 = 0x7                                                                                                                       | 0b1010 = 0xA                                          | 0b0111 = 0x7                                                    |
| The corresponding CDI data word is: 11100111 10100111 = 0xE7A7                                 |                                                                                                                                           |                                                       |                                                                 |

\*) AS-i slaves according to the AS-i specification 2.0 and older do not support the extended ID codes 1 and 2. In the master 0xF is stored for this configuration data.

## Description of the IO code for digital slaves

5349

Structure slave profile = S-[IO-Code].x.x

| IO code<br>[hex] | IO code (bits<br>3...0) | Function of the periphery bit |                |                |                |
|------------------|-------------------------|-------------------------------|----------------|----------------|----------------|
|                  |                         | D3                            | D2             | D1             | D0             |
| 0                | 0000                    | input                         | input          | input          | input          |
| 1                | 0001                    | output                        | input          | input          | input          |
| 2                | 0010                    | input / output                | input          | input          | input          |
| 3                | 0011                    | output                        | output         | input          | input          |
| 4                | 0100                    | input / output                | input / output | input          | input          |
| 5                | 0101                    | output                        | output         | output         | input          |
| 6                | 0110                    | input / output                | input / output | input / output | input          |
| 7                | 0111                    | input / output                | input / output | input / output | input / output |
| 8                | 1000                    | output                        | output         | output         | output         |
| 9                | 1001                    | input                         | output         | output         | output         |
| A                | 1010                    | input / output                | output         | output         | output         |
| B                | 1011                    | input                         | input          | output         | output         |
| C                | 1100                    | input / output                | input / output | output         | output         |
| D                | 1101                    | input                         | input          | input          | output         |
| E                | 1110                    | input / output                | input / output | input / output | output         |
| F                | 1111                    | not allowed                   |                |                |                |

## Description of the ID code (selection)

5351

Structure slave profile = S-x.[ID-Code].x

| ID code<br>[hex] | ID code (Bits<br>3...0) | Description                                                                              |
|------------------|-------------------------|------------------------------------------------------------------------------------------|
| 0                | 0000                    | 4 I/O connections for binary sensors and/or actuators with 1 signal each                 |
| 1                | 0001                    | 2 dual-signal I/O connections for binary sensors and/or actuators with 2 signals each    |
| A                | 1010                    | slave operates in the extended addressing mode (B slave or A/B slave)                    |
| B                | 1011                    | slave corresponds to Safety-at-Work                                                      |
| F                | 1111                    | manufacturer-specific device (cannot be replaced with products from other manufacturers) |



### Description of the extended ID code 1

5353

Can be changed by the user, however not a part of the slave profile.

Default value:

0xF for single slaves

0x7 for A/B slaves

The value is evaluated and checked by the master. The user can make an additional distinction between slaves which do not differ in the AS-i system, e.g. slaves with different ranges for current, voltage or frequency. This prevents damage when replacing slaves with a wrong performance range.

### Description of the extended ID code 2

5355

#### Extended ID code 2 for analogue slaves with profile 7.3.x

5357

The extended ID code 2 is used to specify complex slaves.

Structure slave profile = S-7.3.[ext.ID code2]

| Bit 3 | Bit 2 | Bit 1 | Bit 0 | Description                                        |
|-------|-------|-------|-------|----------------------------------------------------|
|       |       | 0     | 0     | 1-channel slave                                    |
|       |       | 0     | 1     | 2-channel slave                                    |
|       |       | 1     | 0     | 4-channel slave                                    |
|       |       | 1     | 1     | 4-channel slave (if slave has no extended ID code) |
|       | 0     |       |       | transparent data exchange = binary bits            |
|       | 1     |       |       | analogue value transmission                        |
| 0     |       |       |       | output slave                                       |
| 1     |       |       |       | input slave                                        |

The ID code 2 results from a combination of the options stated above.

**Extended ID code 2 for analogue slaves with profile 7.4.x**

5358

The extended ID code 2 is used to specify complex slaves.

Structure slave profile = S-7.3.[ext. ID code2]

| Bit 3 | Bit 2 | Bit 1 | Bit 0 | Description                                        |
|-------|-------|-------|-------|----------------------------------------------------|
|       |       | 0     | 0     | 1-channel slave                                    |
|       |       | 0     | 1     | 2-channel slave                                    |
|       |       | 1     | 0     | 4-channel slave                                    |
|       |       | 1     | 1     | 4-channel slave (if slave has no extended ID code) |
| 0     | 0     | 0     | 0     | 4 binary inputs + 4 binary outputs                 |
| 0     |       |       |       | output slave                                       |
| 1     |       |       |       | input slave                                        |

The ID code 2 results from a combination of the options stated above.

**Valid combinations IO code / ID code / extended ID code 2**

5359

Structure slave profile = S-[IO code].[ID code].[ext. ID code2]

| IO code<br>[hex]      | ID code<br>[hex] | Ext.<br>ID code 2<br>[hex] | Meaning                                                                                                     |
|-----------------------|------------------|----------------------------|-------------------------------------------------------------------------------------------------------------|
| 0...E<br>not: 9, B, D | 0                | x                          | binary I/O connections for sensors and actuators                                                            |
| 0, 3, 8               | 1                | x                          | 1 or 2 binary sensors or actuators with 2 signals each (dual-signal devices)                                |
| 0                     | 1                | x                          | 4 binary inputs for 2 dual-signal sensors                                                                   |
| 0...E<br>not: 2A      | A                | x                          | slave operates in the "extended addressing mode" (B slave or A/B slave)                                     |
| 0                     | A                | E                          | slave with extended address function:<br>4 binary inputs for 2 dual-signal sensors (e.g. I/O module AC2250) |
| 0                     | B                | x                          | slave corresponds to Safety-at-Work                                                                         |
| 0...E                 | F                | x                          | manufacturer-specific device (cannot be replaced by other products)                                         |
| 1                     | 1                | x                          | single sensor with remote setting:<br>3 binary inputs + 1 binary output (e.g. sensor OC5226)                |
| 3                     | 1                | x                          | 2 binary inputs for 1 dual-signal sensor AND<br>2 binary outputs for 1 dual-signal actuator                 |
| 3                     | A                | x                          | slave with extended address function                                                                        |
| 3                     | A                | 1                          | slave with extended address function:<br>2 binary inputs + 1 binary output                                  |
| 3                     | A                | 2                          | slave with extended address function:<br>4 binary inputs                                                    |
| 6                     | 0                | x                          | quick combined transaction type 5 of 8, 12 or 16 data bits by using 2, 3 or 4 slave addresses in a slave    |
| 7                     | 0                | F                          | motor starter 2I + 2O (e.g. ZB0032)                                                                         |

| IO code<br>[hex] | ID code<br>[hex] | Ext.<br>ID code 2<br>[hex] | Meaning                                                                                                                                                                                                                                          |
|------------------|------------------|----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 7                | 0                | E                          | 4 binary inputs + 4 binary outputs (e.g. I/O module AC2251)                                                                                                                                                                                      |
| 7                | 1                | x                          | interface for the transmission of 6...18-bit signals;<br>analogue profile for combined transaction type 1;<br>was replaced by S-7.3                                                                                                              |
| 7                | 2                | x                          | extended slave profile for the transmission of 6...18-bit signals;<br>extended analogue profile for combined transaction type 1;<br>was replaced by S-7.4                                                                                        |
| 7                | 3                | x                          | slave profile for 16-bit transmission with integrated support in the master;<br>integrated analogue profile for combined transaction type 1<br>(→ <b>Extended ID code 2 for analogue slaves with profile 7.3.x</b> (→ p. 129))                   |
| 7                | 3                | 5                          | 2 analogue outputs of 16 bits each (e.g. I/O module AC2618)                                                                                                                                                                                      |
| 7                | 3                | 6                          | 4 analogue outputs of 16 bits each (e.g. I/O module AC2518)                                                                                                                                                                                      |
| 7                | 3                | C                          | 1 analogue input of 16 bits (e.g. sensor PPA020)                                                                                                                                                                                                 |
| 7                | 3                | D                          | 2 analogue inputs of 16 bits each (e.g. I/O module AC2616)                                                                                                                                                                                       |
| 7                | 3                | E                          | 4 analogue inputs of 16 bits each (e.g. I/O module AC2516)                                                                                                                                                                                       |
| 7                | 4                | x                          | extended slave profile for 16-bit transmission with integrated support in the master;<br>integrated extended analogue profile for combined transaction type 1<br>(→ <b>Extended ID code 2 for analogue slaves with profile 7.4.x</b> (→ p. 130)) |
| 7                | 4                | C                          | RFID identification system for writing and reading RFID tags<br>15-bit data + 1-bit messages (e.g. DTA100)                                                                                                                                       |
| 7                | A                | x                          | slave operates in the "extended addressing mode" (B slave or A/B slave)                                                                                                                                                                          |
| 7                | A                | 5                          | slave operates in the "extended addressing mode" (B slave or A/B slave)<br>combined slave; supports combined transaction type 2                                                                                                                  |
| 7                | A                | 7                          | slave operates in the "extended addressing mode" (B slave or A/B slave)<br>4 binary inputs + 4 binary outputs                                                                                                                                    |
| 7                | A                | 8                          | slave operates in the "extended addressing mode" (B slave or A/B slave)<br>1 channel for combined transaction type 4                                                                                                                             |
| 7                | A                | 9                          | slave operates in the "extended addressing mode" (B slave or A/B slave)<br>dual channel for combined transaction type 4                                                                                                                          |
| 7                | A                | A                          | slave operates in the "extended addressing mode" (B slave or A/B slave)<br>8 binary inputs + 8 binary outputs                                                                                                                                    |
| 7                | A                | E                          | slave operates in the "extended addressing mode" (B slave or A/B slave);<br>dual sensor with actuator interface (e.g. sensor AC2317);<br>2 binary inputs + 2 binary outputs                                                                      |
| 7                | B                | x                          | safety slave with non-safe outputs                                                                                                                                                                                                               |
| 7                | B                | 0                          | safety slave with non-safe outputs;<br>2 safe binary inputs (e.g. I/O module AC005S)                                                                                                                                                             |
| 7                | B                | E                          | safety sensor with non-safe outputs;<br>2 safe binary inputs AND<br>2 safe binary outputs AND<br>2 non-safe (relay) outputs (e.g. I/O module AC009S)                                                                                             |
| 7                | D                | x                          | device for motor control (electromechanical)                                                                                                                                                                                                     |
| 7                | D                | 0                          | electromechanical motor control with open sub-profile                                                                                                                                                                                            |
| 7                | D                | 1                          | electromechanical direct starter                                                                                                                                                                                                                 |
| 7                | D                | 2                          | electromechanical reverser                                                                                                                                                                                                                       |
| 7                | D                | 3                          | electromechanical direct starter with brake                                                                                                                                                                                                      |
| 7                | D                | 4                          | electromechanical reverser with brake                                                                                                                                                                                                            |

| IO code<br>[hex] | ID code<br>[hex] | Ext.<br>ID code 2<br>[hex] | Meaning                                                                                                                             |
|------------------|------------------|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| 7                | D                | 5                          | electromechanical direct starter with accessories                                                                                   |
| 7                | D                | 6                          | electromechanical reverser with accessories                                                                                         |
| 7                | E                | x                          | device for motor control (electronic)                                                                                               |
| 7                | E                | 0                          | electronic motor control with open sub-profile                                                                                      |
| 7                | E                | 1                          | electronic direct starter                                                                                                           |
| 7                | E                | 2                          | electronic reverser                                                                                                                 |
| 7                | E                | 3                          | electronic direct starter with brake                                                                                                |
| 7                | E                | 4                          | electronic reverser with brake                                                                                                      |
| 7                | E                | 5                          | electronic direct starter with accessories                                                                                          |
| 7                | E                | 6                          | electronic reverser with accessories                                                                                                |
| 8                | 1                | x                          | 4 binary outputs for 2 dual-signal actuators                                                                                        |
| B                | 1                | x                          | dual-signal actuator with feedback:<br>2 binary outputs + 2 binary inputs                                                           |
| B                | A                | 5                          | slave operates in the "extended addressing mode" (B slave or A/B slave);<br>supports combined transaction type 2                    |
| B                | A                | E                          | slave operates in the "extended addressing mode" (B slave or A/B slave);<br>2 binary outputs + 2 binary inputs (e.g. AC2086 module) |
| D                | 1                | x                          | single actuator with monitoring:<br>1 binary output + 3 binary inputs                                                               |

x = any value (0...F)

Devices with M4 master profile enable connection of slaves with more than 4 digital inputs/outputs. The transmission is combined: Part of the data transmission is carried out via the digital bits D0...D3, another part via the "analogue" channels.



The more data is transmitted, the longer it takes until all data of a slave has been transmitted.

Cycle time single slave = 5 ms

Cycle time A/B slave (if address is only assigned to A or B slave) = 5 ms

Cycle time A/B slave (if address is assigned to A and B slave) = 10 ms

The cycle time for CTT transmission is a multiple of these values for individual data.

CTT = Combined Transaction Type

## Slave profiles for slaves with combined transaction

5362

Structure slave profile = S-[IO-Code].[ID-Code].[ext.ID-Code2]

| Slave profile | Master profile | Assignment analogue channels in the device |                                                                                               | Bits D0...D3           | Additional acyclic string data transaction | Combined transaction CTT |
|---------------|----------------|--------------------------------------------|-----------------------------------------------------------------------------------------------|------------------------|--------------------------------------------|--------------------------|
|               |                | Number of channels                         | Use analogue / digital                                                                        |                        |                                            |                          |
| S-6.0         | M4             | 1 I and 1 O                                | 2/3/4 x 4 binary inputs and 2/3/4 x 4 binary outputs                                          | —                      | no                                         | type 5                   |
| S-7.3         | M3             | 1/2/4 I or 1/2/4 O                         | 1/2/4 analogue inputs or 1/2/4 binary outputs                                                 | —                      | no                                         | type 1                   |
| S-7.4         | M3             | 1/2/4 I or 1/2/4 O                         | 1/2/4 analogue inputs or 1/2/4 binary outputs                                                 | 4 inputs or 4 outputs  | yes                                        | type 1                   |
| S-7.5.5       | M4             | 0...4 I and 0...4 O                        | 0...4 analogue inputs or < 65 binary inputs and 0...4 analogue outputs or < 65 binary outputs | 2 inputs and 2 outputs | yes                                        | type 2                   |
| S-7.A.5       | M4             | 0...2 I and 0...2 O                        | 0...2 analogue inputs or < 33 binary inputs and 0...2 analogue outputs or < 33 binary outputs | 2 inputs and 1 output  | yes                                        | type 2                   |
| S-7.A.7       | M4             | —                                          | —                                                                                             | 4 inputs and 4 outputs | no                                         | type 3                   |
| S-7.A.8       | M4             | 1 I                                        | 1 analogue input or < 17 binary inputs                                                        | 1 output               | no                                         | type 4                   |
| S-7.A.9       | M4             | 2 I                                        | 2 analogue inputs or < 33 binary inputs                                                       | —                      | no                                         | type 4                   |
| S-7.A.A       | M4             | 1 I and 1 O                                | 8 binary inputs and 8 binary outputs                                                          | —                      | no                                         | type 3                   |
| S-B.A.5       | M4             | 0...2 I and 0...2 O                        | 0...2 analogue inputs or < 33 binary inputs and 0...2 analogue outputs or < 33 binary outputs | —                      | yes                                        | type 2                   |

Legend colour pattern:

binary inputs

binary outputs

analogue inputs

analogue outputs

## Combined transaction – Use of analogue channels in the gateway depending on the slave profile

5366

| Transaction | Slave profile | Slave type | Number channels | Analogue input channels |     |     |     |        | Analogue output channels |             |     |     |        |   |   |   |   |
|-------------|---------------|------------|-----------------|-------------------------|-----|-----|-----|--------|--------------------------|-------------|-----|-----|--------|---|---|---|---|
|             |               |            |                 | CH3                     | CH2 | CH1 | CH0 | Trans. | CH3                      | CH2         | CH1 | CH0 | Trans. |   |   |   |   |
| CTT5        | 6.0.x         | S          | 1               | -                       | -   | -   | b   | -      | -                        | -           | -   | b   | -      |   |   |   |   |
| CTT1        | 7.3.C         | S          | 1               | -                       | -   | -   | a   | -      | -                        | -           | -   | -   | -      |   |   |   |   |
|             | 7.3.D         | S          | 2               | -                       | -   | a   | a   | -      | -                        | -           | -   | -   | -      |   |   |   |   |
|             | 7.3.E         | S          | 4               | a                       | a   | a   | a   | -      | -                        | -           | -   | -   | -      |   |   |   |   |
|             | 7.3.4         | S          | 1               | -                       | -   | -   | -   | -      | -                        | -           | -   | a   | -      |   |   |   |   |
|             | 7.3.5         | S          | 2               | -                       | -   | -   | -   | -      | -                        | -           | a   | a   | -      |   |   |   |   |
|             | 7.3.6         | S          | 4               | -                       | -   | -   | -   | -      | a                        | a           | a   | a   | -      |   |   |   |   |
|             | 7.3.C         | S          | 1               | -                       | -   | -   | a   | -      | -                        | -           | -   | -   | -      |   |   |   |   |
|             | 7.3.D         | S          | 2               | -                       | -   | a   | a   | -      | -                        | -           | -   | -   | -      |   |   |   |   |
|             | 7.3.E         | S          | 4               | a                       | a   | a   | a   | -      | -                        | -           | -   | -   | -      |   |   |   |   |
|             | 7.3.4         | S          | 1               | -                       | -   | -   | -   | -      | -                        | -           | -   | a   | -      |   |   |   |   |
|             | 7.3.5         | S          | 2               | -                       | -   | -   | -   | -      | -                        | -           | a   | a   | -      |   |   |   |   |
|             | 7.3.6         | S          | 4               | -                       | -   | -   | -   | -      | a                        | a           | a   | a   | -      |   |   |   |   |
| CTT1        | 7.4.4         | S          | 1               | -                       | -   | -   | -   | -      | -                        | -           | -   | a   | X      |   |   |   |   |
|             | 7.4.5         | S          | 2               | -                       | -   | -   | -   | -      | -                        | -           | a   | a   | X      |   |   |   |   |
|             | 7.4.6         | S          | 4               | -                       | -   | -   | -   | -      | a                        | a           | a   | a   | X      |   |   |   |   |
|             | 7.4.C         | S          | 1               | -                       | -   | -   | a   | X      | -                        | -           | -   | -   | -      |   |   |   |   |
|             | 7.4.D         | S          | 2               | -                       | -   | a   | a   | X      | -                        | -           | -   | -   | -      |   |   |   |   |
|             | 7.4.E         | S          | 4               | a                       | a   | a   | a   | X      | -                        | -           | -   | -   | -      |   |   |   |   |
| CTT2        | 7.5.5         | S          | 0...4           | a                       | b   | a   | b   | a      | b                        | X           | a   | b   | a      | b | a | b | X |
| CTT2        | 7.A.5         | A          | 0...2           | -                       | -   | a   | b   | a      | b                        | X           | -   | -   | a      | b | a | b | X |
|             | 7.A.5         | B          | 0...2           | a                       | b   | a   | b   | -      | -                        | X           | a   | b   | a      | b | - | - | X |
| CTT3        | 7.A.7         | A          | -               | only binary             |     |     |     |        | -                        | only binary |     |     |        |   | - |   |   |
|             |               | B          | -               |                         |     |     |     |        | -                        |             |     |     |        |   | - |   |   |
| CTT4        | 7.A.8         | A          | 1               | -                       | -   | -   | a   | b      | -                        | -           | -   | -   | -      | - | - |   |   |
|             |               | B          | 1               | -                       | a   | b   | -   | -      | -                        | -           | -   | -   | -      | - |   |   |   |
| CTT4        | 7.A.9         | A          | 2               | -                       | -   | a   | b   | a      | b                        | -           | -   | -   | -      | - | - |   |   |
|             |               | B          | 2               | a                       | b   | a   | b   | -      | -                        | -           | -   | -   | -      | - |   |   |   |
| CTT3        | 7.A.A         | A          | 1               | -                       | -   | -   | b   | -      | -                        | -           | -   | -   | b      | - |   |   |   |
|             |               | B          | 1               | -                       | b   | -   | -   | -      | -                        | b           | -   | -   | -      |   |   |   |   |
| CTT2        | B.A.5         | A          | 0...2           | -                       | -   | a   | b   | a      | b                        | X           | -   | -   | a      | b | a | b | X |
|             | B.A.5         | B          | 0...2           | a                       | b   | a   | b   | -      | -                        | X           | a   | b   | a      | b | - | - | X |

CHn = channel  
Trans. = transparent mode

S = single slave  
A = A slave  
B = B slave

a = analogue inputs/outputs (word)  
b = binary inputs/outputs (bits)  
- = not used

X = additional acyclic transaction of strings for device, parameters, diagnosis

Legend colour pattern:

 binary inputs

 binary outputs

 analogue inputs

 analogue outputs

## 8.7 Fieldbus EtherCAT

### Contents

|                                                        |     |
|--------------------------------------------------------|-----|
| Parameter data .....                                   | 136 |
| Cyclic data .....                                      | 139 |
| Acyclic data .....                                     | 152 |
| EtherCAT projection software: Programmers' notes ..... | 157 |

11574

## 8.7.1 Parameter data

### Contents

|                                  |     |
|----------------------------------|-----|
| Fieldbus parameters .....        | 136 |
| Device-specific parameters ..... | 136 |
| ESI file .....                   | 138 |

1568

### Fieldbus parameters

11570

The fieldbus parameters provide information for the integration of the device into the EtherCAT network.

| Name | Description                        | Possible values |
|------|------------------------------------|-----------------|
| [ID] | "Explicit Device ID" of the device | 0...65535       |

### Device-specific parameters

12938

The device-specific parameters allow you to make individual adjustments to the system.



The device only supports the top down configuration via the EtherCAT projection software.

| Parameter                                                                                                                                                                                                                                                                                                    | Description                                                                                                                                         | Values                                                        |                                                                                                                                                                             |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Failsafe state                                                                                                                                                                                                                                                                                               | Behaviour of the slave outputs if an interrupted fieldbus connection is detected                                                                    | Clear outputs* =                                              | All AS-i outputs are switched off in case of an interrupted EtherCAT connection (value = 0).                                                                                |
|                                                                                                                                                                                                                                                                                                              |                                                                                                                                                     | Hold outputs =                                                | The outputs are held in the last valid state that existed before the interrupted connection was detected.                                                                   |
| AS-i param. download                                                                                                                                                                                                                                                                                         | Transmission of the slave parameters when downloading a configuration from the EtherCAT projection software.                                        | Disable* =                                                    | The following slave parameter data are NOT downloaded to the device. The parameters set in the device apply.                                                                |
|                                                                                                                                                                                                                                                                                                              |                                                                                                                                                     | Enable =                                                      | Each time the EtherCAT connection is established, the following slave parameter data are downloaded to the device, activated in the AS-i slaves, and stored non-volatilely. |
| Param. slave 1(A) AS-i master 1<br>...<br>Param. slave 31(A) AS-i master 1<br>Param. slave 1B AS-i master 1<br>...<br>Param. slave 31B AS-i master 1<br>Param. slave 1(A) AS-i master 2<br>...<br>Param. slave 31(A) AS-i master 2<br>Param. slave 1B AS-i master 2<br>...<br>Param. slave 31B AS-i master 2 | Parameter data of the AS-i slaves.<br><br>The set values are only activated when the parameter "AS-i param. download" is set to the value "Enable". | P3..P0 =<br>P3..P0 =<br>...<br>P3..P0** =<br>...<br>P3..P0* = | 2#0000 / 16#0<br>2#0001 / 16#1<br>...<br>2#0111 / 16#7<br>...<br>2#1111 / 16#F                                                                                              |



© ifm electronic gmbh



www.ifm.com

## ESI file

13868

To represent the AC1433/34 in a field bus projection software ifm electronic provides an ESI file.

The ESI file is saved in the device. It can be downloaded to the PC with the EtherCAT projection software via the web interface (→ **Download ESI file** (→ p. [89](#))). In the ESI file, all parameters, process data and their valid value ranges are defined.

## 8.7.2 Cyclic data

### Contents

|                                                                              |     |
|------------------------------------------------------------------------------|-----|
| Overview: EtherCAT modules .....                                             | 139 |
| Slot 1 – Digital inputs/outputs of the single/A slaves to AS-i master 1..... | 140 |
| Slot 2 – Digital inputs/outputs of the single/A slaves to AS-i master 2..... | 140 |
| Slot 3 – Digital inputs/outputs of the B slaves to AS-i master 1 .....       | 141 |
| Slot 4 – Digital inputs/outputs of the B slaves to AS-i master 2 .....       | 141 |
| Slot 5 ... 66 – Analogue slaves to AS-i master 1 and AS-i master 2 .....     | 143 |
| Slot 67 – Inputs of AC14 PLC .....                                           | 144 |
| Slot 68 – Outputs to AC14 PLC .....                                          | 145 |
| Slot 69 – Diagnostic data.....                                               | 146 |

22429

### Overview: EtherCAT modules

11500

The following tables show the available EtherCAT modules.

| Slot location | Description                                                                  | Detailed information                                                                                       |
|---------------|------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| 1             | Digital inputs/outputs of single or A slaves, connected to <AS-i1>           | <b>Slot 1 – Digital inputs/outputs of the single/A slaves to AS-i master 1</b> (→ p. <a href="#">140</a> ) |
| 2             | Digital inputs/outputs of single or A slaves, connected to <AS-i2>           | <b>Slot 2 – Digital inputs/outputs of the single/A slaves to AS-i master 2</b> (→ p. <a href="#">140</a> ) |
| 3             | Digital inputs/outputs of the B slaves, connected to AS-i master 1           | <b>Slot 3 – Digital inputs/outputs of the B slaves to AS-i master 1</b> (→ p. <a href="#">141</a> )        |
| 4             | Digital inputs/outputs of the B slaves, connected to AS-i master 2           | <b>Slot 4 – Digital inputs/outputs of the B slaves to AS-i master 2</b> (→ p. <a href="#">141</a> )        |
| 5...66        | Analogue inputs/outputs of the AS-i slaves, connected to AS-i master 1 and 2 | <b>Slot 5 ... 66 – Analogue slaves to AS-i master 1 and AS-i master 2</b> (→ p. <a href="#">143</a> )      |
| 67            | Data from the device-internal PLC to the EtherCAT PLC                        | <b>Slot 67 – Inputs of AC14 PLC</b> (→ p. <a href="#">144</a> )                                            |
| 68            | Data from the EtherCAT PLC to the device-internal PLC                        | <b>Slot 68 – Outputs to AC14 PLC</b> (→ p. <a href="#">145</a> )                                           |
| 69            | Diagnostic data sent to the EtherCAT master                                  | <b>Slot 69 – Diagnostic data</b> (→ p. <a href="#">146</a> )                                               |

## Slot 1 – Digital inputs/outputs of the single/A slaves to AS-i master 1

11490

| Slot location | Description                                                        | Value range                                             | Length [Bytes] |
|---------------|--------------------------------------------------------------------|---------------------------------------------------------|----------------|
| 1             | Digital inputs/outputs of single or A slaves, connected to <AS-i1> | Empty module = module is deactivated                    | 0              |
|               |                                                                    | all S/A slaves AS-i 1 = all S/A slaves of AS-i master 1 | 16             |

→ Mapping: digital input / output data (TxPDO/RxPDO) (→ p. [142](#))

## Slot 2 – Digital inputs/outputs of the single/A slaves to AS-i master 2

11488

| Slot location | Description                                                        | Value range                                             | Length [Bytes] |
|---------------|--------------------------------------------------------------------|---------------------------------------------------------|----------------|
| 2             | Digital inputs/outputs of single or A slaves, connected to <AS-i2> | Empty module = module is deactivated                    | 0              |
|               |                                                                    | all S/A slaves AS-i 2 = all S/A slaves of AS-i master 2 | 16             |

→ Mapping: digital input / output data (TxPDO/RxPDO) (→ p. [142](#))

### Slot 3 – Digital inputs/outputs of the B slaves to AS-i master 1

14602

| Slot location | Description                                                        | Value range                                         | Length [Bytes] |
|---------------|--------------------------------------------------------------------|-----------------------------------------------------|----------------|
| 3             | Digital inputs/outputs of the B slaves, connected to AS-i master 1 | Empty module = module is deactivated                | 0              |
|               |                                                                    | all B slaves AS-i 1 = all B slaves of AS-i master 1 | 16             |

→ Mapping: digital input / output data (TxPDO/RxPDO) (→ p. [142](#))

### Slot 4 – Digital inputs/outputs of the B slaves to AS-i master 2

14061

| Slot location | Description                                                        | Value range                                         | Length [Bytes] |
|---------------|--------------------------------------------------------------------|-----------------------------------------------------|----------------|
| 4             | Digital inputs/outputs of the B slaves, connected to AS-i master 2 | Empty module = module is deactivated                | 0              |
|               |                                                                    | all B slaves AS-i 2 = all B slaves of AS-i master 2 | 16             |

→ Mapping: digital input / output data (TxPDO/RxPDO) (→ p. [142](#))

**Mapping: digital input / output data (TxPDO/RxPDO)**

15783

TxPDO:

| Byte | Bit                           |   |   |   |                                             |   |   |   |
|------|-------------------------------|---|---|---|---------------------------------------------|---|---|---|
|      | 7                             | 6 | 5 | 4 | 3                                           | 2 | 1 | 0 |
| 1    | slave 1(A) or 1B: DI3...DI0   |   |   |   | <b>master flags</b> (→ p. 142) or reserved* |   |   |   |
| 2    | slave 3(A) or 3B: DI3...DI0   |   |   |   | slave 2(A) or 2B: DI3...DI0                 |   |   |   |
| 3    | slave 5(A) or 5B: DI3...DI0   |   |   |   | slave 4(A) or 4B: DI3...DI0                 |   |   |   |
| ...  | ...                           |   |   |   | ...                                         |   |   |   |
| 15   | slave 29(A) or 29B: DI3...DI0 |   |   |   | slave 28(A) or 28B: DI3...DI0               |   |   |   |
| 16   | slave 31(A) or 31B: DI3...DI0 |   |   |   | slave 30(A) or 30B: DI3...DI0               |   |   |   |

\* ... Master flags are only transferred in slots 1 and 2, in slots 3 and 4 bits 0...4 of the 1st byte remain empty.

RxPDO:

| Byte | Bit                           |   |   |   |                               |   |   |   |
|------|-------------------------------|---|---|---|-------------------------------|---|---|---|
|      | 7                             | 6 | 5 | 4 | 3                             | 2 | 1 | 0 |
| 1    | slave 1(A) or 1B: DO3...DO0   |   |   |   | reserved                      |   |   |   |
| 2    | slave 3(A) or 3B: DO3...DO0   |   |   |   | slave 2(A) or 2B: DO3...DO0   |   |   |   |
| 3    | slave 5(A) or 5B: DO3...DO0   |   |   |   | slave 4(A) or 4B: DO3...DO0   |   |   |   |
| ...  | ...                           |   |   |   | ...                           |   |   |   |
| 15   | slave 29(A) or 29B: DO3...DO0 |   |   |   | slave 28(A) or 28B: DO3...DO0 |   |   |   |
| 16   | slave 31(A) or 31B: DO3...DO0 |   |   |   | slave 30(A) or 30B: DO3...DO0 |   |   |   |

**master flags**

1975

The master flags are transferred together with the digital input data of the single/A slaves (→ **Mapping: digital input / output data (TxPDO/RxPDO)** (→ p. 142)). They provide information about the operating status of the AS-i master.

| Bit 3                  | Bit 2                                   | Bit 1                  | Bit 0            |
|------------------------|-----------------------------------------|------------------------|------------------|
| AS-i power fail (19 V) | Configuration error in the AS-i circuit | AS-i master is offline | Peripheral fault |

## Slot 5 ... 66 – Analogue slaves to AS-i master 1 and AS-i master 2

11482

| Slot location | Description                                                                                    | Value range                                                                          | Length [Word] |
|---------------|------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|---------------|
| 5...66        | Input and output values of the analogue slaves connected to an AS-i master 1 and AS-i master 2 | Empty module = module is deactivated                                                 | 0             |
|               |                                                                                                | IN 1 word A or S = 1-word input data, single or A slave                              | 1             |
|               |                                                                                                | IN 1 word B = 1-word input data, B slave                                             | 1             |
|               |                                                                                                | IN 2 word A or S = 2-word input data, single or A slave                              | 2             |
|               |                                                                                                | IN 2 word B = 2-word input data, B slave                                             | 2             |
|               |                                                                                                | IN 4 word A+B or S = 4-word input data, A and B slaves or single slave               | 4             |
|               |                                                                                                | IN/OUT 1 word A or S = 1-word input and output data, single or A slave               | 1             |
|               |                                                                                                | IN/OUT 1 word B = 1-word input and output data, B slave                              | 1             |
|               |                                                                                                | IN/OUT 2 word A or S = 2-word input and output data, single or A slave               | 2             |
|               |                                                                                                | IN/OUT 2-word B = 2-word input and output data, B slave                              | 2             |
|               |                                                                                                | IN/OUT 4-word A+B or S = 4-word input and output data, A and B slave or single slave | 4             |
|               |                                                                                                | OUT 1-word A or S = 1-word output data, single or A slave                            | 1             |
|               |                                                                                                | OUT 1-word B = 1-word output data, B slave                                           | 1             |
|               |                                                                                                | OUT 2-word A or S = 2-word output data, single or A slave                            | 2             |
|               |                                                                                                | OUT 2-word B = 2-word output data, B slave                                           | 2             |
|               |                                                                                                | OUT 4-word A+B or S = 4-word output data, A and B slave or single slave              | 4             |

## Slot 67 – Inputs of AC14 PLC

11509

| Slot location | Description                                           | Value range                                                 | Length [Worte] |
|---------------|-------------------------------------------------------|-------------------------------------------------------------|----------------|
| 67            | Data from the device-internal PLC to the EtherCAT PLC | Empty module = module is deactivated                        | 0              |
|               |                                                       | PLC IN, 004 words = 4 words AC1433/34 PLC >> fieldbus PLC   | 4              |
|               |                                                       | PLC IN, 008 words = 8 words AC1433/34 PLC >> fieldbus PLC   | 8              |
|               |                                                       | PLC IN, 012 words = 12 words AC1433/34 PLC >> fieldbus PLC  | 12             |
|               |                                                       | PLC IN, 016 words = 16 words AC1433/34 PLC >> fieldbus PLC  | 16             |
|               |                                                       | PLC IN, 020 words = 20 words AC1433/34 PLC >> fieldbus PLC  | 20             |
|               |                                                       | PLC IN, 024 words = 24 words AC1433/34 PLC >> fieldbus PLC  | 24             |
|               |                                                       | PLC IN, 028 words = 28 words AC1433/34 PLC >> fieldbus PLC  | 28             |
|               |                                                       | PLC IN, 032 words = 32 words AC1433/34 PLC >> fieldbus PLC  | 32             |
|               |                                                       | PLC IN, 036 words = 36 words AC1433/34 PLC >> fieldbus PLC  | 36             |
|               |                                                       | PLC IN, 040 words = 40 words AC1433/34 PLC >> fieldbus PLC  | 40             |
|               |                                                       | PLC IN, 044 words = 44 words AC1433/34 PLC >> fieldbus PLC  | 44             |
|               |                                                       | PLC IN, 048 words = 48 words AC1433/34 PLC >> fieldbus PLC  | 48             |
|               |                                                       | PLC IN, 052 words = 52 words AC1433/34 PLC >> fieldbus PLC  | 52             |
|               |                                                       | PLC IN, 056 words = 56 words AC1433/34 PLC >> fieldbus PLC  | 56             |
|               |                                                       | PLC IN, 060 words = 60 words AC1433/34 PLC >> fieldbus PLC  | 60             |
|               |                                                       | PLC IN, 076 words = 76 words AC1433/34 PLC >> fieldbus PLC  | 76             |
|               |                                                       | PLC IN, 092 words = 92 words AC1433/34 PLC >> fieldbus PLC  | 92             |
|               |                                                       | PLC IN, 108 words = 108 words AC1433/34 PLC >> fieldbus PLC | 108            |
|               |                                                       | PLC IN, 120 words = 120 words AC1433/34 PLC >> fieldbus PLC | 120            |



## Slot 68 – Outputs to AC14 PLC

11498

| Slot location | Description                                           | Value range                                                  | Length [Worte] |
|---------------|-------------------------------------------------------|--------------------------------------------------------------|----------------|
| 68            | Data from the EtherCAT PLC to the device-internal PLC | Empty module = module is deactivated                         | 0              |
|               |                                                       | PLC OUT, 004 words = 4 words fieldbus PLC >> AC1433/34 PLC   | 4              |
|               |                                                       | PLC OUT, 008 words = 8 words fieldbus PLC >> AC1433/34 PLC   | 8              |
|               |                                                       | PLC OUT, 012 words = 12 words fieldbus PLC >> AC1433/34 PLC  | 12             |
|               |                                                       | PLC OUT, 016 words = 16 words fieldbus PLC >> AC1433/34 PLC  | 16             |
|               |                                                       | PLC OUT, 020 words = 20 words fieldbus PLC >> AC1433/34 PLC  | 20             |
|               |                                                       | PLC OUT, 024 words = 24 words fieldbus PLC >> AC1433/34 PLC  | 24             |
|               |                                                       | PLC OUT, 028 words = 28 words fieldbus PLC >> AC1433/34 PLC  | 28             |
|               |                                                       | PLC OUT, 032 words = 32 words fieldbus PLC >> AC1433/34 PLC  | 32             |
|               |                                                       | PLC OUT, 036 words = 36 words fieldbus PLC >> AC1433/34 PLC  | 36             |
|               |                                                       | PLC OUT, 040 words = 40 words fieldbus PLC >> AC1433/34 PLC  | 40             |
|               |                                                       | PLC OUT, 044 words = 44 words fieldbus PLC >> AC1433/34 PLC  | 44             |
|               |                                                       | PLC OUT, 048 words = 48 words fieldbus PLC >> AC1433/34 PLC  | 48             |
|               |                                                       | PLC OUT, 052 words = 52 words fieldbus PLC >> AC1433/34 PLC  | 52             |
|               |                                                       | PLC OUT, 056 words = 56 words fieldbus PLC >> AC1433/34 PLC  | 56             |
|               |                                                       | PLC OUT, 060 words = 60 words fieldbus PLC >> AC1433/34 PLC  | 60             |
|               |                                                       | PLC OUT, 076 words = 76 words fieldbus PLC >> AC1433/34 PLC  | 76             |
|               |                                                       | PLC OUT, 092 words = 92 words fieldbus PLC >> AC1433/34 PLC  | 92             |
|               |                                                       | PLC OUT, 108 words = 108 words fieldbus PLC >> AC1433/34 PLC | 108            |
|               |                                                       | PLC OUT, 120 words = 120 words fieldbus PLC >> AC1433/34 PLC | 120            |

## Slot 69 – Diagnostic data

11476

The diagnostic data comprise max. 9 words.

| Slot location | Description                                 | Value range                                                              | Data length [Worte] |
|---------------|---------------------------------------------|--------------------------------------------------------------------------|---------------------|
| 69            | Diagnostic data sent to the EtherCAT master | Empty module                                                             | 0                   |
|               |                                             | AC1433 (→ <b>Module: AC1433 diagnostics</b> (→ p. <a href="#">147</a> )) | 25                  |
|               |                                             | AC1434 (→ <b>Module: AC1434 diagnostics</b> (→ p. <a href="#">147</a> )) | 49                  |

**Module: AC1433 diagnostics**

11496

| Word    | Description                                            | Details                                                                                        |
|---------|--------------------------------------------------------|------------------------------------------------------------------------------------------------|
| 1       | System diagnostics                                     | → <b>Diagnosis - System diagnosis</b> (→ p. <a href="#">148</a> )                              |
| 2...5   | AS-i master 1: AS-i diagnostics                        | → <b>Diagnosis - AS-i diagnosis</b> (→ p. <a href="#">148</a> )                                |
| 6...9   | AS-i master 1: List of missing slaves                  | → <b>Diagnosis - List of missing slaves (LCMES)</b> (→ p. <a href="#">149</a> )                |
| 10...13 | AS-i master 1: List of non-projected slaves            | → <b>Diagnosis - List of non-projected slaves (LCAES)</b> (→ p. <a href="#">149</a> )          |
| 14...17 | AS-i master 1: List of slaves with wrong slave profile | → <b>Diagnosis - List of slaves with wrong slave profile (LCE)</b> (→ p. <a href="#">150</a> ) |
| 18...21 | AS-i master 1: List of peripheral faults               | → <b>Diagnosis - List of peripheral faults (LPF)</b> (→ p. <a href="#">150</a> )               |
| 22...25 | AS-i master 1: List of slaves addressed several times  | → <b>Diagnosis - List of double addressed slaves (LDAS)</b> (→ p. <a href="#">151</a> )        |

**Module: AC1434 diagnostics**

11523

| Word    | Description                                            | Details                                                                                        |
|---------|--------------------------------------------------------|------------------------------------------------------------------------------------------------|
| 1       | System diagnostics                                     | → <b>Diagnosis - System diagnosis</b> (→ p. <a href="#">148</a> )                              |
| 2...5   | AS-i master 1: AS-i diagnostics                        | → <b>Diagnosis - AS-i diagnosis</b> (→ p. <a href="#">148</a> )                                |
| 6...9   | AS-i master 1: List of missing slaves                  | → <b>Diagnosis - List of missing slaves (LCMES)</b> (→ p. <a href="#">149</a> )                |
| 10...13 | AS-i master 1: List of non-projected slaves            | → <b>Diagnosis - List of non-projected slaves (LCAES)</b> (→ p. <a href="#">149</a> )          |
| 14...17 | AS-i master 1: List of slaves with wrong slave profile | → <b>Diagnosis - List of slaves with wrong slave profile (LCE)</b> (→ p. <a href="#">150</a> ) |
| 18...21 | AS-i master 1: List of peripheral faults               | → <b>Diagnosis - List of peripheral faults (LPF)</b> (→ p. <a href="#">150</a> )               |
| 22...25 | AS-i master 1: List of slaves addressed several times  | → <b>Diagnosis - List of double addressed slaves (LDAS)</b> (→ p. <a href="#">151</a> )        |
| 26...29 | AS-i master 2: AS-i diagnostics                        | → <b>Diagnosis - AS-i diagnosis</b> (→ p. <a href="#">148</a> )                                |
| 30...33 | AS-i master 2: List of missing slaves                  | → <b>Diagnosis - List of missing slaves (LCMES)</b> (→ p. <a href="#">149</a> )                |
| 34...37 | AS-i master 2: List of non-projected slaves            | → <b>Diagnosis - List of non-projected slaves (LCAES)</b> (→ p. <a href="#">149</a> )          |
| 38...41 | AS-i master 2: List of slaves with wrong slave profile | → <b>Diagnosis - List of slaves with wrong slave profile (LCE)</b> (→ p. <a href="#">150</a> ) |
| 42...45 | AS-i master 2: List of peripheral faults               | → <b>Diagnosis - List of peripheral faults (LPF)</b> (→ p. <a href="#">150</a> )               |
| 46...49 | AS-i master 2: List of slaves addressed several times  | → <b>Diagnosis - List of double addressed slaves (LDAS)</b> (→ p. <a href="#">151</a> )        |

## Diagnosis - System diagnosis

12657

| Offset<br>Word no. | Bit |    |    |    |    |    |   |   |   |   |   |   |    |    |    |     |
|--------------------|-----|----|----|----|----|----|---|---|---|---|---|---|----|----|----|-----|
|                    | 15  | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3  | 2  | 1  | 0   |
| n                  | -   | -  | -  | -  | -  | -  | - | - | - | - | - | - | PS | GI | OT | ISE |

Legend:

| Flag | Description                                                                                         |
|------|-----------------------------------------------------------------------------------------------------|
| ISE  | Internal System Error Interner Systemfehler                                                         |
| OT   | over temperature: temperature inside the device has exceeded the permissible max. temperature value |
| GI   | gateway inactive: the gateway mode was deactivated                                                  |
| PS   | PLC stop: The controller was stopped                                                                |

## Diagnosis - AS-i diagnosis

12658

| Offset<br>Word no. | bit                             |    |      |        |    |    |    |     |   |   |   |     |    |      |      |      |
|--------------------|---------------------------------|----|------|--------|----|----|----|-----|---|---|---|-----|----|------|------|------|
|                    | 15                              | 14 | 13   | 12     | 11 | 10 | 9  | 8   | 7 | 6 | 5 | 4   | 3  | 2    | 1    | 0    |
| n                  | -                               | -  | PF19 | PF22.5 | EF | S0 | PM | IME | - | - | - | DAE | PE | CEIP | CEAS | CEMS |
| n+1                | Voltage AS-i+ to AS-i- in mV    |    |      |        |    |    |    |     |   |   |   |     |    |      |      |      |
| n+2                | Voltage FE to AS-i in mV        |    |      |        |    |    |    |     |   |   |   |     |    |      |      |      |
| n+3                | Symmetry in % (-100% ... +100%) |    |      |        |    |    |    |     |   |   |   |     |    |      |      |      |

Legend:

| Flag   | Description                                                                                                                                            |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| IME    | internal master error: Internal system error of an AS-i master                                                                                         |
| PM     | projection mode: AS-i master was set to the projection mode.                                                                                           |
| S0     | slave 0 detected: New slave 0 was detected.                                                                                                            |
| EF     | earth fault: Earth fault was detected                                                                                                                  |
| PF22.5 | 22.5V AS-i Power-Fail (classic AS-i Power) was detected.                                                                                               |
| PF19   | 19 AS-i Power-Fail (Power24) was detected.                                                                                                             |
| CEMS   | Configuration Error – Missing Slave: AS-i configuration error, one or several slaves are projected, but not available.                                 |
| CEAS   | Configuration Error – Additional Slave: AS-i configuration error, one or several slaves are available, but not projected.                              |
| CEIP   | Configuration Error – Invalid Profile: AS-i configuration error, the slave profiles of one or several slaves differ from the projected slave profiles. |
| PE     | periphery error: One or several AS-i slaves have a periphery error.                                                                                    |
| DAE    | duplicate address error: One or several multiple-addressing faults occurred.                                                                           |

**Diagnosis - List of detected slaves (LDS)**

12675

| Offset<br>Word no. | Bit   |       |       |       |       |       |       |       |       |       |       |       |       |       |       |       |
|--------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
|                    | 15    | 14    | 13    | 12    | 11    | 10    | 9     | 8     | 7     | 6     | 5     | 4     | 3     | 2     | 1     | 0     |
| <b>n</b>           | 15(A) | 14(A) | 13(A) | 12(A) | 11(A) | 10(A) | 9(A)  | 8(A)  | 7(A)  | 6(A)  | 5(A)  | 4(A)  | 3(A)  | 2(A)  | 1(A)  | 0     |
| <b>n+1</b>         | 31(A) | 30(A) | 29(A) | 28(A) | 27(A) | 26(A) | 25(A) | 24(A) | 23(A) | 22(A) | 21(A) | 20(A) | 19(A) | 18(A) | 17(A) | 16(A) |
| <b>n+2</b>         | 15B   | 14B   | 13B   | 12B   | 11B   | 10B   | 9B    | 8B    | 7B    | 6B    | 5B    | 4B    | 3B    | 2B    | 1B    | n.a.  |
| <b>n+3</b>         | 31B   | 30B   | 29B   | 28B   | 27B   | 26B   | 25B   | 24B   | 23B   | 22B   | 21B   | 20B   | 19B   | 18B   | 17B   | 16B   |

Possible value of slave fields:

0 ... no slave detected

1.... slave detected

**Diagnosis - List of missing slaves (LCMES)**

2659

| Offset<br>Word no. | Bit   |       |       |       |       |       |       |       |       |       |       |       |       |       |       |       |
|--------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
|                    | 15    | 14    | 13    | 12    | 11    | 10    | 9     | 8     | 7     | 6     | 5     | 4     | 3     | 2     | 1     | 0     |
| <b>n</b>           | 15(A) | 14(A) | 13(A) | 12(A) | 11(A) | 10(A) | 9(A)  | 8(A)  | 7(A)  | 6(A)  | 5(A)  | 4(A)  | 3(A)  | 2(A)  | 1(A)  | 0     |
| <b>n+1</b>         | 31(A) | 30(A) | 29(A) | 28(A) | 27(A) | 26(A) | 25(A) | 24(A) | 23(A) | 22(A) | 21(A) | 20(A) | 19(A) | 18(A) | 17(A) | 16(A) |
| <b>n+2</b>         | 15B   | 14B   | 13B   | 12B   | 11B   | 10B   | 9B    | 8B    | 7B    | 6B    | 5B    | 4B    | 3B    | 2B    | 1B    | n.a.  |
| <b>n+3</b>         | 31B   | 30B   | 29B   | 28B   | 27B   | 26B   | 25B   | 24B   | 23B   | 22B   | 21B   | 20B   | 19B   | 18B   | 17B   | 16B   |

Possible values of slave fields:

0 ... no error

1.... slave is projected, but is missing



If at least 1 bit is set in this list, the bit for CEMS is also set.

(→ **Diagnosis - AS-i diagnosis** (→ p. [148](#)))**Diagnosis - List of non-projected slaves (LCAES)**

12660

| Offset<br>Word no. | Bit   |       |       |       |       |       |       |       |       |       |       |       |       |       |       |       |
|--------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
|                    | 15    | 14    | 13    | 12    | 11    | 10    | 9     | 8     | 7     | 6     | 5     | 4     | 3     | 2     | 1     | 0     |
| <b>n</b>           | 15(A) | 14(A) | 13(A) | 12(A) | 11(A) | 10(A) | 9(A)  | 8(A)  | 7(A)  | 6(A)  | 5(A)  | 4(A)  | 3(A)  | 2(A)  | 1(A)  | 0     |
| <b>n+1</b>         | 31(A) | 30(A) | 29(A) | 28(A) | 27(A) | 26(A) | 25(A) | 24(A) | 23(A) | 22(A) | 21(A) | 20(A) | 19(A) | 18(A) | 17(A) | 16(A) |
| <b>n+2</b>         | 15B   | 14B   | 13B   | 12B   | 11B   | 10B   | 9B    | 8B    | 7B    | 6B    | 5B    | 4B    | 3B    | 2B    | 1B    | n.a.  |
| <b>n+3</b>         | 31B   | 30B   | 29B   | 28B   | 27B   | 26B   | 25B   | 24B   | 23B   | 22B   | 21B   | 20B   | 19B   | 18B   | 17B   | 16B   |

Possible values of slave fields:

0 ... no error

1.... slave is detected, but not yet projected



If at least 1 bit is set in this list, the bit for CEAS is also set.

(→ **Diagnosis - AS-i diagnosis** (→ p. [148](#)))

**Diagnosis - List of slaves with wrong slave profile (LCE)**

12663

| Offset<br>Word no. | Bit   |       |       |       |       |       |       |       |       |       |       |       |       |       |       |       |
|--------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
|                    | 15    | 14    | 13    | 12    | 11    | 10    | 9     | 8     | 7     | 6     | 5     | 4     | 3     | 2     | 1     | 0     |
| <b>14</b>          | 15(A) | 14(A) | 13(A) | 12(A) | 11(A) | 10(A) | 9(A)  | 8(A)  | 7(A)  | 6(A)  | 5(A)  | 4(A)  | 3(A)  | 2(A)  | 1(A)  | 0     |
| <b>15</b>          | 31(A) | 30(A) | 29(A) | 28(A) | 27(A) | 26(A) | 25(A) | 24(A) | 23(A) | 22(A) | 21(A) | 20(A) | 19(A) | 18(A) | 17(A) | 16(A) |
| <b>16</b>          | 15B   | 14B   | 13B   | 12B   | 11B   | 10B   | 9B    | 8B    | 7B    | 6B    | 5B    | 4B    | 3B    | 2B    | 1B    | n.a.  |
| <b>17</b>          | 31B   | 30B   | 29B   | 28B   | 27B   | 26B   | 25B   | 24B   | 23B   | 22B   | 21B   | 20B   | 19B   | 18B   | 17B   | 16B   |

Possible values of slave fields:

0 ... no error

1.... Slave is detected, but has wrong profile



If at least 1 bit is set in this list, the bit for CEIP is also set.  
 (→ **Diagnosis - AS-i diagnosis** (→ p. [148](#)))

**Diagnosis - List of peripheral faults (LPF)**

2664

| Offset<br>Word no. | Bit   |       |       |       |       |       |       |       |       |       |       |       |       |       |       |       |
|--------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
|                    | 15    | 14    | 13    | 12    | 11    | 10    | 9     | 8     | 7     | 6     | 5     | 4     | 3     | 2     | 1     | 0     |
| <b>n</b>           | 15(A) | 14(A) | 13(A) | 12(A) | 11(A) | 10(A) | 9(A)  | 8(A)  | 7(A)  | 6(A)  | 5(A)  | 4(A)  | 3(A)  | 2(A)  | 1(A)  | 0     |
| <b>n+1</b>         | 31(A) | 30(A) | 29(A) | 28(A) | 27(A) | 26(A) | 25(A) | 24(A) | 23(A) | 22(A) | 21(A) | 20(A) | 19(A) | 18(A) | 17(A) | 16(A) |
| <b>n+2</b>         | 15B   | 14B   | 13B   | 12B   | 11B   | 10B   | 9B    | 8B    | 7B    | 6B    | 5B    | 4B    | 3B    | 2B    | 1B    | n.a.  |
| <b>n+3</b>         | 31B   | 30B   | 29B   | 28B   | 27B   | 26B   | 25B   | 24B   | 23B   | 22B   | 21B   | 20B   | 19B   | 18B   | 17B   | 16B   |

Possible values of slave fields:

0 ... no error

1.... peripheral fault at the slave



If at least 1 bit is set in this list, the bit for PE is also set.  
 (→ **Diagnosis - AS-i diagnosis** (→ p. [148](#)))

## Diagnosis - List of double addressed slaves (LDAS)

12665

| Offset<br>Word no. | Bit   |       |       |       |       |       |       |       |       |       |       |       |       |       |       |       |
|--------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
|                    | 15    | 14    | 13    | 12    | 11    | 10    | 9     | 8     | 7     | 6     | 5     | 4     | 3     | 2     | 1     | 0     |
| <b>n</b>           | 15(A) | 14(A) | 13(A) | 12(A) | 11(A) | 10(A) | 9(A)  | 8(A)  | 7(A)  | 6(A)  | 5(A)  | 4(A)  | 3(A)  | 2(A)  | 1(A)  | 0     |
| <b>n+1</b>         | 31(A) | 30(A) | 29(A) | 28(A) | 27(A) | 26(A) | 25(A) | 24(A) | 23(A) | 22(A) | 21(A) | 20(A) | 19(A) | 18(A) | 17(A) | 16(A) |
| <b>n+2</b>         | 15B   | 14B   | 13B   | 12B   | 11B   | 10B   | 9B    | 8B    | 7B    | 6B    | 5B    | 4B    | 3B    | 2B    | 1B    | n.a.  |
| <b>n+3</b>         | 31B   | 30B   | 29B   | 28B   | 27B   | 26B   | 25B   | 24B   | 23B   | 22B   | 21B   | 20B   | 19B   | 18B   | 17B   | 16B   |

Possible values of slave fields:

0 ... no error

1.... Double address error detected



If at least 1 bit is set in this list, the bit for DAE is also set.  
 (→ **Diagnosis - AS-i diagnosis** (→ p. [148](#))).

## 8.7.3 Acyclic data

### Contents

|                                         |     |
|-----------------------------------------|-----|
| Fieldbus objects.....                   | 152 |
| Overview: acyclic data sets (DSx) ..... | 153 |
| Overview: System commands .....         | 154 |
| Overview: AS-i master commands .....    | 155 |

7164

### Fieldbus objects

1974

The device uses the following fieldbus objects for acyclic communication:

- Access to the command channels:

| Command channel | Fieldbus object |          | Description                                 |
|-----------------|-----------------|----------|---------------------------------------------|
|                 | Index           | Subindex |                                             |
| System          | 0x2010          | 01       | request channel for system commands         |
|                 |                 | 03       | response channel for system commands        |
| AS-i master 1   | 0x2011          | 01       | request channel for AS-i master 1 commands  |
|                 |                 | 03       | response channel for AS-i master 1 commands |
| AS-i master 2   | 0x2012          | 01       | request channel for AS-i master 2 commands  |
|                 |                 | 03       | response channel for AS-i master 2 commands |

- Access to acyclic data sets (DS)

| Command            | Fieldbus object |          | Description                                      |
|--------------------|-----------------|----------|--------------------------------------------------|
|                    | Index           | Subindex |                                                  |
| Read / write calls | 0x2013          | xx       | acyclic read or write call for a data set (DSxx) |

xx ... number of the requested data set (DSxx)



## Overview: acyclic data sets (DSx)

17035

| Data record | Content                                                                                                                      | Access<br>r = read<br>w = write | Words |
|-------------|------------------------------------------------------------------------------------------------------------------------------|---------------------------------|-------|
| DS1         | System information                                                                                                           | r                               | 26    |
| DS2         | Digital inputs of slaves 1(A)...31(A) and 1B...31B and master flags (Status AS-i master and exec.-ctl. flags and host flags) | r                               | 36    |
| DS3         | Analogue inputs of slaves 1(A)...15(B)                                                                                       | r                               | 75    |
| DS4         | Analogue inputs of slaves 16(A)...31(B)                                                                                      | r                               | 80    |
| DS5         | Digital outputs of slaves 1(A)...31(A) and 1B...31B                                                                          | r/w                             | 32    |
| DS6         | Analogue outputs of slaves 1(A)...15(B)                                                                                      | r/w                             | 60    |
| DS7         | Analogue outputs of slaves 16(A)...31(B)                                                                                     | r/w                             | 64    |
| DS8         | Status flags of analogue output data of slaves 1(A)...31(A) and 1B...31B                                                     | r                               | 32    |
| DS9         | Slave lists LAS, LDS, LPF, LCE                                                                                               | r                               | 16    |
| DS10        | Slave list LPS                                                                                                               | r                               | 4     |
| DS11        | Actual Configuration data (CDI)                                                                                              | r                               | 64    |
| DS12        | Projected Configuration data (PCD)                                                                                           | r                               | 64    |
| DS13        | Image of input parameter                                                                                                     | r                               | 32    |
| DS14        | Image of output parameter                                                                                                    | r/w                             | 32    |
| DS15        | Slave error counter, configuration error counter, AS-i cycle counter                                                         | r                               | 72    |
| DS16        | n.a.                                                                                                                         | –                               | –     |
| DS17        | AS-i master: Error lists LCEMS, LCEAS, LDAE                                                                                  | r                               | 12    |
| DS18        | Fieldbus information (only available via CODESYS)                                                                            | r                               | 19    |
| DS19        | n.a.                                                                                                                         | –                               | –     |
| DS20        | n.a.                                                                                                                         | –                               | –     |



Detailed information about the acyclic data sets and the command interface is given in the supplement to the device manual of the SmartPLC DataLine with EtherNet/IP device interface (→ **Overview: User documentation for AC1433/34** (→ p. [6](#))).

## Overview: System commands

11078

| Comm. no.<br>[hex] | Comm. no.<br>[dec] | Description                                                  |
|--------------------|--------------------|--------------------------------------------------------------|
| 0101               | 257                | Quick setup AS-i master 1/2                                  |
| 0103               | 259                | Change the user language                                     |
| 0104               | 260                | Change the display settings                                  |
| 0105               | 261                | Set output control                                           |
| 0106               | 262                | Set the PLC operating mode                                   |
| 0109               | 265                | Set the date / time                                          |
| 010A               | 266                | Configure the NTP server settings                            |
| 010B               | 267                | Read date / time / NTP settings                              |
| 010C               | 268                | Reboot the system                                            |
| 010D               | 269                | Read fieldbus information (can only be executed in CODESYS!) |
| 010F               | 271                | Read text of an OSC entry                                    |
| 0110               | 272                | Display target visualisation                                 |



Detailed information about the acyclic data sets and the command interface is given in the supplement to the device manual of the SmartPLC DataLine with EtherNet/IP device interface (→ **Overview: User documentation for AC1433/34** (→ p. [6](#))).

## Overview: AS-i master commands

7250

| Comm. no.<br>[hex] | Comm. no.<br>[dec] | Description                                                                                                                                                                                                                               | Note                                                                      |
|--------------------|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| 0001               | 1                  | Write parameters to a connected AS-i slave                                                                                                                                                                                                |                                                                           |
| 0003               | 3                  | Adopt and save currently connected AS-i slaves in the configuration<br> With this command the fieldbus connection is reset. The device must be rebooted! | ConfDataInput Slave<br>→ Projected<br>Configuration Data and<br>LDS → LPS |
| 0004               | 4                  | Change the list of projected AS-i slaves (LPS)                                                                                                                                                                                            |                                                                           |
| 0005               | 5                  | set the operating mode of the AS-i master                                                                                                                                                                                                 |                                                                           |
| 0006               | 6                  | readdress a connected AS-i slave                                                                                                                                                                                                          |                                                                           |
| 0007               | 7                  | set the auto addressing mode of the AS-i master                                                                                                                                                                                           |                                                                           |
| 0009               | 9                  | change the extended ID code 1 in the connected AS-i slave                                                                                                                                                                                 |                                                                           |
| 000A               | 10                 | change PCD                                                                                                                                                                                                                                |                                                                           |
| 000D               | 13                 | AS-i master supply voltage, symmetry, earth fault                                                                                                                                                                                         |                                                                           |
| 0015               | 21                 | read ID string of an AS-i slave with profile S-7.4                                                                                                                                                                                        | slave profile S-7.4                                                       |
| 001A               | 26                 | read AS-i master info                                                                                                                                                                                                                     |                                                                           |
| 001C               | 28                 | deactivation of the slave reset when changing to the protected mode                                                                                                                                                                       |                                                                           |
| 0021               | 33                 | read diagnostic string of an AS-i slave with profile S-7.4                                                                                                                                                                                | slave profile S-7.4                                                       |
| 0022               | 34                 | read parameter string of an AS-i slave with profile S-7.4                                                                                                                                                                                 | slave profile S-7.4                                                       |
| 0023               | 35                 | write parameter string of an AS-i slave with profile S-7.4                                                                                                                                                                                | slave profile S-7.4                                                       |
| 0024               | 36                 | CTT2 standard read:<br>acyclic standard read call of an AS-i slave with CTT2 profile                                                                                                                                                      | CTT2 slave profile *)                                                     |
| 0025               | 37                 | CTT2 standard write:<br>acyclic standard write call of an AS-i slave with CTT2 profile                                                                                                                                                    | CTT2 slave profile *)                                                     |
| 0026               | 38                 | CTT2 vendor specific read:<br>acyclic manufacturer-specific read call of an AS-i slave with CTT2 profile                                                                                                                                  | CTT2 slave profile *)                                                     |
| 0027               | 39                 | CTT2 vendor specific write:<br>acyclic manufacturer-specific write call of an AS-i slave with CTT2 profile                                                                                                                                | CTT2 slave profile *)                                                     |
| 0040               | 64                 | CTT2 device group read:<br>acyclic manufacturer-specific read call of an AS-i slave with CTT2 profile                                                                                                                                     | CTT2 slave profile *)                                                     |
| 0041               | 65                 | CTT2 device group write:<br>acyclic device group write call of an AS-i slave with CTT2 profile                                                                                                                                            | CTT2 slave profile *)                                                     |
| 0042               | 66                 | CTT2 vendor specific selective read from buffer:<br>selective standard read call of an AS-i slave with CTT2 profile                                                                                                                       | CTT2 slave profile *)                                                     |
| 0043               | 67                 | CTT2 vendor specific selective write from buffer:<br>selective standard write call of an AS-i slave with CTT2 profile                                                                                                                     | CTT2 slave profile *)                                                     |
| 0044               | 68                 | CTT2 vendor specific selective read:<br>selective manufacturer-specific read call of an AS-i slave with CTT2 profile                                                                                                                      | CTT2 slave profile *)                                                     |
| 0045               | 69                 | CTT2 vendor specific selective write:<br>selective manufacturer-specific write call of an AS-i slave with CTT2 profile                                                                                                                    | CTT2 slave profile *)                                                     |
| 0046               | 70                 | CTT2 device group selective read:<br>selective device group read call of an AS-i slave with CTT2 profile                                                                                                                                  | CTT2 slave profile *)                                                     |
| 0047               | 71                 | CTT2 device group selective write:<br>selective device group write call of an AS-i slave with CTT2 profile                                                                                                                                | CTT2 slave profile *)                                                     |

| Comm. no.<br>[hex] | Comm. no.<br>[dec] | Description                                                                                                                 | Note                  |
|--------------------|--------------------|-----------------------------------------------------------------------------------------------------------------------------|-----------------------|
| 0049               | 73                 | CTT2 vendor specific exchange:<br>manufacturer-specific data exchange with an AS-i slave with CTT2 profile                  | CTT2 slave profile *) |
| 004A               | 74                 | CTT2 device group exchange:<br>device group data exchange with an AS-i slave with CTT2 profile                              | CTT2 slave profile *) |
| 004B               | 75                 | CTT2 device group selective read from buffer:<br>manufacturer-specific read / write call of an AS-i slave with CTT2 profile | CTT2 slave profile *) |
| 004C               | 76                 | CTT2 device group selective write from buffer:<br>device group read / write call of an AS-i slave with CTT2 profile         | CTT2 slave profile *) |
| 0050               | 80                 | set AS-i master settings                                                                                                    |                       |
| 0051               | 81                 | Reset the error counters                                                                                                    |                       |

Legend:

\*) ... CTT2 profiles = S-7.5.5, S-7.A.5 or S-B.A.5

CTT → **Combined transaction – Use of analogue channels in the gateway depending on the slave profile** (→ p. [133](#))



Detailed information about the acyclic data sets and the command interface is given in the supplement to the device manual of the SmartPLC DataLine with EtherNet/IP device interface (→ **Overview: User documentation for AC1433/34** (→ p. [6](#))).

## 8.7.4 EtherCAT projection software: Programmers' notes

### Contents

|                                                   |     |
|---------------------------------------------------|-----|
| Integrate the device into a TwinCAT project ..... | 158 |
| Read cyclical data .....                          | 158 |
| Use acyclic services .....                        | 159 |

23804

## Integrate the device into a TwinCAT project

2314

To integrate the device into a TwinCAT project:

### 1 Integrate ESI file

- ▶ Download device ESI file of the device (→ **Download ESI file** (→ p. [89](#))).
- ▶ Copy downloaded file to the following subdirectory of the TwinCAT installation directory:  
.. \3.1 \Config \Io \EtherCAT
- ▶ Start TwinCAT.
- > TwinCAT loads the device description to the device catalogue.

### 2 Integrate the device into the TwinCat project

- ▶ Open a project or create a new project.
- ▶ Add device as sub-device to the requested EtherCAT master.
- ▶ Set EtherCAT address of the device (→ **Configure the EtherCAT interface** (→ p. [90](#))).
- ▶ Optional: Add the device to a hot connect group.

### 3 Configure cyclical data

- ▶ Configure fieldbus slots (→ **Read cyclical data** (→ p. [158](#))).
- ▶ Load the configuration to the device.

## Read cyclical data

2313

To access the cyclical process data of the device the user has to configure the fieldbus slots of the device.

- ▶ In the Solutions Explorer: Double click on the device icon.
- > The editor window shows the configuration options of the device.
- ▶ Select the tab [Slots].
- > Table shows device slots and available fieldbus modules.
- ▶ Configure slots as requested.
- ▶ Optional: Map the configured cyclical data to variables.
- ▶ Save the project to apply changes.
- ▶ Download device configuration to activate the changes.

## Use acyclic services

1972

To access acyclic services from a TwinCAT application the user can use the following function blocks:

- FB\_EcCoESdoRead: read SDO of an EtherCAT slave
- FB\_EcCoESdoWrite: write SDO of an EtherCAT slave



To use both function blocks the function library Tc2\_EtherCAT.lib has to be added to the project.

Description of the function blocks: → Help function of TwinCAT

## Read acyclic data records

15785

To access acyclic data sets of the device the user can use the TwinCAT function block FB\_EcCoESdoRead. The functions block is part of the TwinCAT library Tc2\_EtherCAT.lib (→ TwinCAT documentation).

The user has to configure the parameters of the function block:

| Input      | Description                                                                                  | Possible values                                                                              |
|------------|----------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| sNetId     | AMS net ID of the device                                                                     | depends on the project, e.g. 172.16.2.131.2.1                                                |
| nSlaveAddr | EtherCAT address of the device                                                               | depends on the project, e.g. 1006                                                            |
| nIndex     | index of the field bus object                                                                | 0x2013 read/write an acyclic data set                                                        |
| nSubIndex  | subindex of the fieldbus object                                                              | xx number of the data set DSxx<br>(→ <b>Overview: acyclic data sets (DSx)</b><br>(→ p. 153)) |
| pDstBuf    | pointer to the structure variable (e.g. arRxData) to which the read data set DSxx is written | address of the structure variable, e.g. ADR(arTxData)                                        |
| cbBufLen   | maximum size of the data buffer (number of the words)                                        | depending on the command, e.g. 8                                                             |

### Example: Read list of projected slaves (LPS)

15784

**Task:** Read list of projected AS-i slaves on AS-i master 2

**Solution:** Read acyclic data set DS10 of the device

#### Preparations

- Create empty array for return values of the data set (e.g. arRxData):

| Word | Value | Description                                                            |
|------|-------|------------------------------------------------------------------------|
| 1    | blank | user ID (UID)                                                          |
| 2    | blank | reflected command number                                               |
| 3    | blank | command status                                                         |
| 4    | blank | command error code                                                     |
| 5    | blank | List of projected slaves (LPS):<br>→ <b>Details of the slave lists</b> |
| 6    | blank |                                                                        |
| 7    | blank |                                                                        |
| 8    | blank |                                                                        |



The words 1...4 contain the administration information of the command. The user data is stored as from the 5th word in the array. (→ Principle of the command channels)

#### 1 Read data set

- Execute function block FB\_EcCoESdoRead with the following input values:

| Input      | Value                  | Description                                                    |
|------------|------------------------|----------------------------------------------------------------|
| nNetId     | depends on the project | AMS network ID of the EtherCAT master                          |
| nSlaveAddr | depends on the project | EtherCAT address of the device                                 |
| nSubIndex  | 0x0A                   | subindex of the fieldbus object (number of the data set)       |
| nIndex     | 0x2013                 | Index of the field bus object (read/write an acyclic data set) |
| pSrcBuf    | ADR(arTxData)          | address of the buffer storage for return values                |
| cbBufLen   | SIZEOF(arTxData)       | Number of words to be transferred                              |

#### 2 Evaluate return values

- After faultless function block processing: Evaluate the command status (word 3) and command error code (word 4) in the buffer storage.
- > If successful: Words 5...8 of the buffer storage contain the list of projected slaves (LPS).



## Use acyclic commands

15786

Since request and response are paired, the following partial steps always have to be executed sequentially in the program code:

1. Send command to the device (write)
2. Check if command was successfully executed (read)
3. If successful receive the reply data (read)

To access the device command interface in reading or writing the user has to define the following inputs of the TwinCAT function blocks:

| Input      | Description                                                        | Possible values                                                   |
|------------|--------------------------------------------------------------------|-------------------------------------------------------------------|
| sNetId     | AMS net ID of the EtherCAT master to which the device is connected | depends on the project<br>e.g. 172.16.2.131.2.1                   |
| nSlaveAddr | EtherCAT address of the device                                     | depends on the project<br>e.g. 1006                               |
| nIndex     | index of the field bus object                                      | 0x2010 System command                                             |
|            |                                                                    | 0x2011 AS-i master 1 command                                      |
|            |                                                                    | 0x2012 AS-i master 2 command                                      |
| nSubIndex  | subindex of the fieldbus object                                    | 0x01 command request                                              |
|            |                                                                    | 0x02 status of the command execution                              |
|            |                                                                    | 0x03 command response                                             |
| pDstBuf    | pointer to the array to be sent/received                           | e.g. ADR(arTxData)<br>(= address of the transmit buffer arTxData) |
| cbBufLen   | maximum size of the data buffer (number of the words)              | depending on the command<br>e.g. 8                                |

### Example: Set the operating mode of AS-i master 2 to "Projection mode"

1971

**Task:** Set the operating mode of AS-i master 2 to "Projection mode"

**Solution:** Execute command 0x0005

#### Preparations

- Create data structure for values to be transferred to the device (arTxData):

| Word | Value  | Description                                                                              |
|------|--------|------------------------------------------------------------------------------------------|
| 1    | UID    | User ID (value between 0 and 65535 to mark the request)                                  |
| 2    | 0x0005 | Command number<br>→ <b>Command 0x0005 – Change the operating mode of the AS-i master</b> |
| 3    | 0x0001 | 0x01 = projection mode                                                                   |

- Create empty data structure for status message of the command processing (bRxStatus)

| Byte | Value | Description                                       |
|------|-------|---------------------------------------------------|
| 1    | blank | Status message of command processing (index 0x02) |

- Create empty data structure for values of the command response (arRxData):

| Word | Value | Description                                       |
|------|-------|---------------------------------------------------|
| 1    | blank | UID value between 0 and 65535 to mark the request |
| 2    | blank | reflected command number                          |
| 3    | blank | MSB = reserved, LSB = command status              |
| 4    | blank | Command error code                                |

#### 1 Send command request to the device

- Execute function block FB\_EcCoESdoWrite with the following input values:

| Input      | Value                  | Description                                                   |
|------------|------------------------|---------------------------------------------------------------|
| nNetId     | depends on the project | AMS network ID of the EtherCAT master                         |
| nSlaveAddr | depends on the project | EtherCAT address of the device                                |
| nSubIndex  | 0x01                   | subindex of the fieldbus object (command request)             |
| nIndex     | 0x2012                 | Index of the fieldbus object (AS-i master 2 command)          |
| pSrcBuf    | ADR(arTxData)          | address of the buffer storage with the data to be transmitted |
| cbBufLen   | SIZEOF(arTxData)       | Number of words to be transferred                             |

## 2 Evaluate command status

- Execute function block FB\_EcCoESdoRead with the following input values:

| Input      | Value                  | Description                                          |
|------------|------------------------|------------------------------------------------------|
| nNetId     | depends on the project | AMS network ID of the EtherCAT master                |
| nSlaveAddr | depends on the project | EtherCAT address of the device                       |
| nSubIndex  | 0x02                   | subindex of the fieldbus object (status message)     |
| nIndex     | 0x2012                 | Index of the fieldbus object (AS-i master 2 command) |
| pSrcBuf    | ADR(bRxStatus)         | Buffer storage for data to be transmitted            |
| cbBufLen   | SIZEOF(bRxStatus)      | Number of words to be transferred                    |

- Evaluate the status of the command processing (bRxStatus).

## 3 Receive command response from the device

- After faultless function block processing: Execute function block FB\_EcCoESdoRead with the following input values:

| Input      | Value                  | Description                                          |
|------------|------------------------|------------------------------------------------------|
| nNetId     | depends on the project | AMS network ID of the EtherCAT master                |
| nSlaveAddr | depends on the project | EtherCAT address of the device                       |
| nSubIndex  | 0x03                   | subindex of the fieldbus object (command response)   |
| nIndex     | 0x2012                 | Index of the fieldbus object (AS-i master 2 command) |
| pSrcBuf    | ADR(arRxData)          | Buffer storage for data to be transmitted            |
| cbBufLen   | SIZEOF(arRxData)       | Number of words to be transferred                    |

- Evaluate the command status (word 3) and command error code (word 4) in the buffer storage.
- > If successful: AS-i master 2 is in the projection mode.

**Example: Read date / time / NTP settings**

1633

**Task:** Read date / time / NTP settings of the device**Solution:** Execute command 0x010B**Preparations**

- Create data structure for values to be transferred to the device (arTxData):

| Word | Value  | Description                                                                 |
|------|--------|-----------------------------------------------------------------------------|
| 1    | UID    | User ID (value between 0 and 65535 to mark the request)                     |
| 2    | 0x010B | Command number<br>→ <b>Command 0x010B – Read date / time / NTP settings</b> |
| 3    | 0x4F42 | Boot sequence 1 (0x4F = O, 0x42 = B)                                        |
| 4    | 0x544F | Boot sequence 2 (0x54 = T, 0x4F = O)                                        |

- Create empty data structure for status message of the command processing (bRxStatus)

| Byte | Value | Description                                       |
|------|-------|---------------------------------------------------|
| 1    | blank | Status message of command processing (index 0x02) |

- Create empty data structure for values of the command response (arRxData):

| Word | Value | Description                                                                             |
|------|-------|-----------------------------------------------------------------------------------------|
| 1    | blank | UID value between 0 and 65535 to mark the request                                       |
| 2    | blank | reflected command number                                                                |
| 3    | blank | MSB = reserved, LSB = command status                                                    |
| 4    | blank | Command error code                                                                      |
| 5    | blank | Date / time / NTP settings<br>→ <b>Command 0x010B – Read date / time / NTP settings</b> |
| ...  | ...   |                                                                                         |
| 11   | blank |                                                                                         |

**1 Send command request to the device**

- Execute function block FB\_EcCoESdoWrite with the following input values:

| Input      | Value                  | Description                                                   |
|------------|------------------------|---------------------------------------------------------------|
| nNetId     | depends on the project | AMS network ID of the EtherCAT master                         |
| nSlaveAddr | depends on the project | EtherCAT address of the device                                |
| nSubIndex  | 0x01                   | subindex of the fieldbus object (command request)             |
| nIndex     | 0x2010                 | Index of the fieldbus object (system command)                 |
| pSrcBuf    | ADR(arTxData)          | address of the buffer storage with the data to be transmitted |
| cbBufLen   | SIZEOF(arTxData)       | Number of words to be transferred                             |

## 2 Evaluate command status

- Execute function block FB\_EcCoESdoRead with the following input values:

| Input      | Value                  | Description                                      |
|------------|------------------------|--------------------------------------------------|
| nNetId     | depends on the project | AMS network ID of the EtherCAT master            |
| nSlaveAddr | depends on the project | EtherCAT address of the device                   |
| nSubIndex  | 0x02                   | subindex of the fieldbus object (status message) |
| nIndex     | 0x2010                 | Index of the fieldbus object (system command)    |
| pSrcBuf    | ADR(bRxStatus)         | Buffer storage for data to be transmitted        |
| cbBufLen   | SIZEOF(bRxStatus)      | Number of words to be transferred                |

- Evaluate the status of the command processing (bRxStatus).

## 3 Command response received from the device

- After faultless command processing: Execute FB\_EcCoESdoRead with the following input values:

| Input      | Value                  | Description                                        |
|------------|------------------------|----------------------------------------------------|
| nNetId     | depends on the project | AMS network ID of the EtherCAT master              |
| nSlaveAddr | depends on the project | EtherCAT address of the device                     |
| nSubIndex  | 0x03                   | subindex of the fieldbus object (command response) |
| nIndex     | 0x2010                 | Index of the fieldbus object (system command)      |
| pSrcBuf    | ADR(arRxData)          | Buffer storage for data to be transmitted          |
| cbBufLen   | SIZEOF(arRxData)       | Number of words to be transferred                  |

- Evaluate the command status (word 3) and command error code (word 4).
- > If successful: words 5...11 contain the date / time / NTP settings.

## 8.8 OSC messages

### Contents

|                                    |     |
|------------------------------------|-----|
| OSC messages: System .....         | 166 |
| OSC messages: AS-i 1 / AS-i 2..... | 167 |

18959

This section contains information about the messages for events, warnings and faults of the AC1433/34.

### 8.8.1 OSC messages: System

14284

| Message                                                                              | Type    | Corrective measures                                   |
|--------------------------------------------------------------------------------------|---------|-------------------------------------------------------|
| An internal device error was detected<br><Fehlernummer>                              | Error   | ► Note the message and contact the ifm service center |
| Permitted temperature limit value inside the device was exceeded (<xxx.x> °C)        | Warning | ► Check thermal conditions of the system environment  |
| First operation after delivery                                                       | Event   | not necessary                                         |
| The output control was set to<br><Gateway,manuell,SPS>                               | Event   | not necessary                                         |
| System power-up completed, <SW-Version>                                              | Event   | not necessary                                         |
| A system reset was requested manually                                                | Event   | not necessary                                         |
| The user-specific message history was deleted.                                       | Event   | not necessary                                         |
| The device was reset to factory settings via<br><HMI, Feldbus>.                      | Event   | not necessary                                         |
| PLC used for more than 10 hours.                                                     | Event   | not necessary                                         |
| The project <Name> was loaded.                                                       | Event   | not necessary                                         |
| The PLC was set to the operating mode<br><Projektierungsmodus, geschützter Betrieb>. | Event   | not necessary                                         |
| The firmware was updated from <FW-Version> to<br>version <FW-Version>.               | Event   | not necessary                                         |
| The settings of the fieldbus interface were<br>modified                              | Event   | not necessary                                         |
| The fieldbus connection was established                                              | Event   | not necessary                                         |
| The fieldbus connection was aborted                                                  | Event   | not necessary                                         |
| The IP settings of the configuration interface<br>were changed                       | Event   | not necessary                                         |

## 8.8.2 OSC messages: AS-i 1 / AS-i 2

16029

| Message                                                                                                           | Type    | Corrective measures                                                                                                                                                                                                            |
|-------------------------------------------------------------------------------------------------------------------|---------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| System errors: AS-i master <1,2>                                                                                  | Error   | <ul style="list-style-type: none"> <li>▶ Reboot the device</li> <li>If the error occurs again:</li> <li>▶ Note the message and contact the ifm service center!</li> </ul>                                                      |
| Earth fault: AS-i <1,2>                                                                                           | Error   | <ul style="list-style-type: none"> <li>▶ Check for earth fault of AC1433/34</li> </ul>                                                                                                                                         |
| Incorrect profile: AS-i <1,2>, slave <1(A)..31(A), 1B..31B> with profile <S-x.x.x> expected, but <S-y.y.y> found. | Error   | <ul style="list-style-type: none"> <li>▶ Check profile of the AS-i slave</li> </ul>                                                                                                                                            |
| Config error: AS-i <1,2>, slave <1(A)..31(A), 1B..31B> with the profile <S-x.x.x> missing                         | Error   | <ul style="list-style-type: none"> <li>▶ Check connections of the AS-i slave</li> <li>▶ Reconnect AS-i slave</li> </ul>                                                                                                        |
| Config error: AS-i <1,2>, slave <1(A)..31(A), 1B..31B> with the profile <S-x.x.x> is available but not projected  | Error   | <ul style="list-style-type: none"> <li>▶ Carry out projection process ([Quick setup] &gt; [Project all])</li> </ul>                                                                                                            |
| Protocol error: AS-i <1, 2>, slave <1(A)..31(A), 1B..31B> no data transmission                                    | Error   | <ul style="list-style-type: none"> <li>▶ Improve the transmission quality on the AS-i line</li> </ul>                                                                                                                          |
| Double address detected: AS-i <1, 2>, slave <1(A)..31(A), 1B..31B>                                                | Error   | <ul style="list-style-type: none"> <li>▶ Remove an AS-i slave with a double address from the AS-i network</li> <li>▶ Readdress the remaining AS-i slave</li> <li>▶ Reconnect removed AS-i slave to the AS-i network</li> </ul> |
| The automatic addressing is not activated for AS-i <1,2>.                                                         | Warning | <ul style="list-style-type: none"> <li>▶ Activate automatic addressing ([AS-i1]/[AS-i2] &gt; [Master setup])</li> </ul>                                                                                                        |
| A voltage drop of 19.0 V was detected on AS-i master <1,2>                                                        | Warning | <ul style="list-style-type: none"> <li>▶ Check voltage supply of the device and replace if necessary</li> </ul>                                                                                                                |
| A voltage drop of 22.5 V was detected on AS-i master <1,2>                                                        | Warning | <ul style="list-style-type: none"> <li>▶ Check voltage supply of the device and replace if necessary</li> </ul>                                                                                                                |
| Increased message error rate: AS-i <1, 2>, slave <1(A)..31(A), 1B..31B>                                           | Warning | <ul style="list-style-type: none"> <li>▶ Improve the transmission quality on the AS-i line</li> </ul>                                                                                                                          |
| Peripheral fault: AS-i <1, 2>, slave <1(A)..31(A), 1B..31B>                                                       | Warning | <ul style="list-style-type: none"> <li>▶ Check displayed AS-i slave</li> </ul>                                                                                                                                                 |
| AS-i slave with address 0 cannot be automatically readdressed (wrong profile)                                     | Warning | <ul style="list-style-type: none"> <li>▶ Activate automatic addressing ([AS-i1]/[AS-i2] &gt; [Master setup])</li> </ul>                                                                                                        |
| Manual output change: AS-i <1, 2>, slave <1(A)..31(A), 1B..31B>, value: <0..F, 0..32768>                          | Event   | not necessary                                                                                                                                                                                                                  |
| Manual parameter change: AS-i <1, 2>, slave <1(A)..31(A), 1B..31B>, value: <0..F, 0..32768>                       | Event   | not necessary                                                                                                                                                                                                                  |
| AS-i master <1,2> was switched to the <geschützten Betrieb, Projektierungsmodus>                                  | Event   | not necessary                                                                                                                                                                                                                  |
| AS-i projection process was carried out.                                                                          | Event   | not necessary                                                                                                                                                                                                                  |
| AS-i slave with the address 0 was detected                                                                        | Event   | not necessary                                                                                                                                                                                                                  |

# 9 Index

## A

|                                               |     |
|-----------------------------------------------|-----|
| Acyclic data .....                            | 152 |
| Acyclic process data .....                    | 152 |
| Additional functions .....                    | 39  |
| Address assignment in Ethernet networks ..... | 119 |
| Address assignment of the outputs .....       | 106 |
| Adopt the system time of the PC .....         | 77  |
| Analogue input .....                          | 54  |
| Analogue output .....                         | 56  |
| Appendix .....                                | 116 |
| Approval tests / certifications .....         | 116 |
| Arrow and function keys .....                 | 12  |
| Arrow keys .....                              | 16  |
| AS-i 1 / AS-i 2 .....                         | 49  |
| AS-i slaves .....                             | 54  |
| Diagnosis .....                               | 52  |
| Master setup .....                            | 50  |
| AS-i master .....                             | 122 |
| AS-i slaves .....                             | 125 |

## B

|                                                      |     |
|------------------------------------------------------|-----|
| Behaviour of the settings upon firmware update ..... | 102 |
| Binary field .....                                   | 33  |
| Button .....                                         | 24  |

## C

|                                                                                                     |     |
|-----------------------------------------------------------------------------------------------------|-----|
| Carry out a projection adaptation .....                                                             | 51  |
| Change an AS-i slave address .....                                                                  | 59  |
| Change an AS-i slave parameter output .....                                                         | 59  |
| Change the analogue output values manually .....                                                    | 57  |
| Change the basic settings of the device .....                                                       | 100 |
| Change the digital output values manually .....                                                     | 57  |
| Change the Extended ID1 of the AS-i slave .....                                                     | 60  |
| Checkbox .....                                                                                      | 24  |
| Clone device configuration .....                                                                    | 78  |
| CODESYS PLC .....                                                                                   | 12  |
| Combined transaction .....                                                                          | 133 |
| Combined transaction – Use of analogue channels in the gateway depending on the slave profile ..... | 133 |
| Configuration data (CDI) of the slaves (slave profiles) .....                                       | 127 |
| Configuration interfaces .....                                                                      |     |
| Connection concepts .....                                                                           | 120 |
| Configure EtherCAT interface .....                                                                  | 106 |
| Configure the EtherCAT interface .....                                                              | 90  |
| Configure the IP parameters automatically .....                                                     | 85  |
| Configure the IP parameters manually .....                                                          | 85  |
| Confirmation message .....                                                                          | 31  |
| Connect and address AS-i slaves .....                                                               | 106 |
| Connect the device to the periphery .....                                                           | 99  |
| Connection via Ethernet network .....                                                               | 121 |
| Control a single PLC application .....                                                              | 64  |
| Control instance of the AS-i outputs .....                                                          | 110 |
| Control of the graphical user interface .....                                                       | 15  |
| Control PLC applications .....                                                                      | 65  |
| Cyclic data .....                                                                                   | 139 |

## D

|                                                                 |         |
|-----------------------------------------------------------------|---------|
| Description of the control elements .....                       | 22      |
| Description of the extended ID code 1 .....                     | 129     |
| Description of the extended ID code 2 .....                     | 129     |
| Description of the ID code (selection) .....                    | 128     |
| Description of the IO code for digital slaves .....             | 128     |
| Device temperature .....                                        | 82      |
| Device-specific parameters .....                                | 136     |
| Diagnosis - AS-i diagnosis .....                                | 148     |
| Diagnosis - List of detected slaves (LDS) .....                 | 149     |
| Diagnosis - List of double addressed slaves (LDAS) .....        | 151     |
| Diagnosis - List of missing slaves (LCMES) .....                | 149     |
| Diagnosis - List of non-projected slaves (LCAES) .....          | 149     |
| Diagnosis - List of peripheral faults (LPF) .....               | 150     |
| Diagnosis - List of slaves with wrong slave profile (LCE) ..... | 150     |
| Diagnosis - System diagnosis .....                              | 148     |
| Digital input .....                                             | 54      |
| Digital output .....                                            | 56      |
| Direct connection .....                                         | 120     |
| Disconnect from web interface .....                             | 37      |
| Display .....                                                   | 12      |
| Display and reset performance data .....                        | 53      |
| Display and reset the error counters .....                      | 52      |
| Display diagnostic data .....                                   | 82, 91  |
| Display elements .....                                          | 12, 117 |
| Display EtherCAT parameters .....                               | 88      |
| Display information about PLC projects .....                    | 63      |
| Display power-on time .....                                     | 82      |
| Display the error statistics of the AS-i slaves .....           | 52      |
| Display the input/output data of the AS-i slave .....           | 54      |
| Display the module configuration .....                          | 89      |
| Display the status of the CODESYS PLC .....                     | 63      |
| Display the voltage supply analysis .....                       | 53      |
| Download ESI file .....                                         | 89      |

## E

|                                                                 |        |
|-----------------------------------------------------------------|--------|
| Enable/Disable the device-internal PLC .....                    | 70     |
| ESI file .....                                                  | 138    |
| EtherCAT .....                                                  |        |
| Diagnosis .....                                                 | 91     |
| Error status .....                                              | 111    |
| fieldbus status .....                                           | 110    |
| Information .....                                               | 88     |
| Setup .....                                                     | 90     |
| EtherCAT fieldbus interface .....                               | 13     |
| EtherCAT interface .....                                        | 99     |
| EtherCAT projection software .....                              |        |
| Programmers' notes .....                                        | 157    |
| Ethernet configuration interfaces .....                         | 13, 99 |
| Example .....                                                   | 19     |
| Read date / time / NTP settings .....                           | 164    |
| Read list of projected slaves (LPS) .....                       | 160    |
| Set the operating mode of AS-i master 2 to .....                | 162    |
| Exchange AS-i slave .....                                       | 107    |
| Export device configuration .....                               | 79     |
| Extended ID code 2 for analogue slaves with profile 7.3.x ..... | 129    |
| Extended ID code 2 for analogue slaves with profile 7.4.x ..... | 130    |
| Extended ID-Code 1 .....                                        | 129    |
| Extended ID-Code 2 .....                                        | 129    |



## Index

### F

|                                             |     |
|---------------------------------------------|-----|
| Fieldbus EtherCAT .....                     | 135 |
| Fieldbus objects .....                      | 152 |
| Fieldbus parameters .....                   | 136 |
| Firmware update from SD card .....          | 103 |
| Firmware update via the web interface ..... | 104 |
| Free slave addresses                        |     |
| colour code + symbols .....                 | 30  |
| Free slave addresses, overview .....        | 29  |
| Function keys .....                         | 16  |

### G

|                                   |    |
|-----------------------------------|----|
| General .....                     | 34 |
| General safety instructions ..... | 7  |

### H

|               |     |
|---------------|-----|
| Housing ..... | 117 |
|---------------|-----|

### I

|                                                                     |        |
|---------------------------------------------------------------------|--------|
| ID code .....                                                       | 128    |
| ifm system solutions .....                                          | 92     |
| ifm weltweit • ifm worldwide • ifm à l'échelle internationale ..... | 171    |
| Import device configuration .....                                   | 80     |
| Information concerning the device .....                             | 11     |
| Install multi app .....                                             | 96     |
| Install single/basic app .....                                      | 95     |
| Integrate the device into a TwinCAT project .....                   | 158    |
| Intended use .....                                                  | 10     |
| Interface .....                                                     | 118    |
| Interfaces .....                                                    | 13, 83 |
| Configuration interface 1 .....                                     | 84     |
| Configuration interface 2 .....                                     | 86     |
| EtherCAT interface .....                                            | 87     |
| IO code .....                                                       | 128    |

### L

|                                       |     |
|---------------------------------------|-----|
| Legal and copyright information ..... | 5   |
| List .....                            | 25  |
| Locate error sources .....            | 112 |

### M

|                                                 |     |
|-------------------------------------------------|-----|
| Mapping                                         |     |
| digital input / output data (TxPDO/RxPDO) ..... | 142 |
| master flags .....                              | 142 |
| Master flags .....                              | 124 |
| Meaning of the colour combinations .....        | 30  |
| Meaning of the colour combinations (example     |     |
| configuration error type 2) .....               | 28  |
| Menu .....                                      | 38  |
| Menu functions .....                            | 39  |
| Menu navigation .....                           | 18  |
| Menu view .....                                 | 17  |
| Message types .....                             | 112 |
| Modification history .....                      | 6   |
| Module                                          |     |
| AC1433 diagnostics .....                        | 147 |
| AC1434 diagnostics .....                        | 147 |

### N

|                                     |    |
|-------------------------------------|----|
| Navigate on a page .....            | 20 |
| Navigation aids .....               | 18 |
| Notes on ifm system solutions ..... | 93 |
| Notes on IP settings .....          | 84 |
| Numerical field .....               | 32 |

### O

|                                                  |         |
|--------------------------------------------------|---------|
| Online diagnosis function .....                  | 112     |
| Online Support Center (OSC) .....                | 113     |
| Operating elements .....                         | 12      |
| Operating instructions .....                     | 35      |
| Operating mode of the AS-i master .....          | 110     |
| Operating modes of the AS-i master .....         | 123     |
| Operation .....                                  | 15, 117 |
| Optional                                         |         |
| adjust the IP parameters .....                   | 104     |
| switch the language with a key combination ..... | 72      |
| OSC                                              |         |
| Show message history .....                       | 115     |
| View current error messages .....                | 114     |
| OSC messages .....                               | 166     |
| AS-i 1 / AS-i 2 .....                            | 167     |
| System .....                                     | 166     |
| Overview .....                                   | 11      |
| acyclic data sets (DSx) .....                    | 153     |
| AS-i master commands .....                       | 155     |
| EtherCAT modules .....                           | 139     |
| System commands .....                            | 154     |
| User documentation for AC1433/34 .....           | 6       |
| Overview of free slave addresses .....           | 29      |
| Overview of slave states .....                   | 27      |

### P

|                                           |          |
|-------------------------------------------|----------|
| P controller .....                        | 164      |
| Page view .....                           | 20       |
| Parameter data .....                      | 136      |
| Parameter input .....                     | 56       |
| Permitted use .....                       | 10       |
| PI controller .....                       | 5        |
| PLC                                       |          |
| Diagnosis .....                           | 67       |
| Information .....                         | 63       |
| Settings .....                            | 64       |
| Power supply connections .....            | 118      |
| Preliminary note .....                    | 5        |
| Preparations .....                        | 103, 104 |
| Profiles of AS-i slaves .....             | 126      |
| Programmable Logic Controller (PLC) ..... | 118      |
| Prohibited use .....                      | 10       |
| Projection mode .....                     | 123      |
| Protected mode .....                      | 123      |
| Purpose of the document .....             | 5        |

### Q

|                                                          |    |
|----------------------------------------------------------|----|
| Quick setup .....                                        | 40 |
| Access the device via QR code .....                      | 43 |
| Address the AS-i slaves connected to AS-i master 1 ..... | 47 |
| Address the AS-i slaves connected to AS-i master 2 ..... | 48 |
| Configure the EtherCAT interface .....                   | 44 |

## Index

|                                                                             |          |                                                                 |          |
|-----------------------------------------------------------------------------|----------|-----------------------------------------------------------------|----------|
| Configure the operating mode of the AS-i masters .....                      | 42       | Status of the web interface .....                               | 110      |
| Configure the output access .....                                           | 43       | Store diagnostic protocol .....                                 | 81       |
| Project AS-i networks .....                                                 | 41       | Structure of the slave profile .....                            | 127      |
| Set the Configuration interface 1 .....                                     | 45       | Switch operating modes .....                                    | 124      |
| Set the configuration interface 2 .....                                     | 46       | Switch the menu language .....                                  | 72       |
| <b>R</b>                                                                    |          | Symbols                                                         |          |
| Read acyclic data records .....                                             | 159      | free slave addresses .....                                      | 29       |
| Read cyclical data .....                                                    | 158      | slave status .....                                              | 27       |
| Reboot the device .....                                                     | 103, 105 | Symbols and styles used .....                                   | 6        |
| Recommended browsers .....                                                  | 34       | Synchronise the system time with an NTP server .....            | 76       |
| Remote access .....                                                         | 34       | System .....                                                    | 61       |
| Required accessories .....                                                  | 14       | Diagnosis .....                                                 | 82       |
| Required background knowledge .....                                         | 7        | Information .....                                               | 68       |
|                                                                             |          | Programmable Logic Controller (PLC) .....                       | 62       |
|                                                                             |          | Setup .....                                                     | 69       |
|                                                                             |          | System description .....                                        | 9        |
|                                                                             |          | System reset .....                                              | 81       |
| <b>S</b>                                                                    |          | <b>T</b>                                                        |          |
| Safety instructions .....                                                   | 7        | Tab menu/Tab .....                                              | 23       |
| SD card slot .....                                                          | 13       | Tampering with the unit .....                                   | 8        |
| Set Ethernet configuration interfaces .....                                 | 106      | Technical data .....                                            | 117      |
| Set the behaviour of the display .....                                      | 73       | Troubleshooting .....                                           | 108      |
| Set the device cycle .....                                                  | 71       | Types of ifm system solutions .....                             | 93       |
| Set the monitoring functions of the AS-i master .....                       | 51       | <b>U</b>                                                        |          |
| Set the operating mode of the AS-i master .....                             | 50       | Uninstall ifm apps .....                                        | 97       |
| Set the output access .....                                                 | 69       | Update ifm apps .....                                           | 97       |
| Set the system time .....                                                   | 74       | Update the firmware .....                                       | 103, 105 |
| Set the system time manually .....                                          | 75       | Update the firmware of the device .....                         | 102      |
| Setting RTC .....                                                           | 74       | Use acyclic commands .....                                      | 161      |
| Setup .....                                                                 | 99       | Use acyclic services .....                                      | 159      |
| Show AS-i slave information .....                                           | 58       | Use navigation aids .....                                       | 20       |
| Show Ethernet information .....                                             | 86       | <b>V</b>                                                        |          |
| Show information .....                                                      | 88       | Valid combinations IO code / ID code / extended ID code 2 ..... | 130      |
| Show information about installed ifm apps .....                             | 94       | <b>W</b>                                                        |          |
| Show memory used .....                                                      | 67       | Warnings used .....                                             | 8        |
| Show target visualisation .....                                             | 66       | Web interface                                                   |          |
| Show version information .....                                              | 68       | Access .....                                                    | 35       |
| Slave addresses, free .....                                                 | 29       | Navigation .....                                                | 35       |
| Slave profile .....                                                         | 127      | Password protection .....                                       | 36       |
| Slave profiles for slaves with combined transaction .....                   | 133      | Web interface login .....                                       | 36       |
| Slave selector .....                                                        | 26       |                                                                 |          |
| Slave status                                                                |          |                                                                 |          |
| colour code + symbols .....                                                 | 28       |                                                                 |          |
| overview .....                                                              | 27       |                                                                 |          |
| Overview .....                                                              | 27       |                                                                 |          |
| Slot 1 – Digital inputs/outputs of the single/A slaves to AS-i master ..... | 1140     |                                                                 |          |
| Slot 2 – Digital inputs/outputs of the single/A slaves to AS-i master ..... | 2140     |                                                                 |          |
| Slot 3 – Digital inputs/outputs of the B slaves to AS-i master 1 .....      | 141      |                                                                 |          |
| Slot 4 – Digital inputs/outputs of the B slaves to AS-i master 2 .....      | 141      |                                                                 |          |
| Slot 5 ... 66 – Analogue slaves to AS-i master 1 and AS-i master 2 .....    | 143      |                                                                 |          |
| Slot 67 – Inputs of AC14 PLC .....                                          | 144      |                                                                 |          |
| Slot 68 – Outputs to AC14 PLC .....                                         | 145      |                                                                 |          |
| Slot 69 – Diagnostic data .....                                             | 146      |                                                                 |          |
| Start screen .....                                                          | 38       |                                                                 |          |
| Status LEDs .....                                                           | 110      |                                                                 |          |
| Start screen 'Basic settings' .....                                         | 100      |                                                                 |          |
| Start the recovery mode .....                                               | 103, 104 |                                                                 |          |
| Status LED .....                                                            | 108      |                                                                 |          |
| Basic device .....                                                          | 108      |                                                                 |          |
| Configuration interface 2 (X8) .....                                        | 109      |                                                                 |          |
| Fieldbus EtherCAT .....                                                     | 108      |                                                                 |          |
| Status LEDs .....                                                           | 12       |                                                                 |          |

# 10 ifm weltweit • ifm worldwide • ifm à l'échelle internationale

Version: 2017-12-18

8310

ifm electronic gmbh • Friedrichstraße 1 • 45128 Essen

[www.ifm.com](http://www.ifm.com) • Email: [info@ifm.com](mailto:info@ifm.com)

Service hotline: 0800 / 16 16 16 (only Germany, Mo-Fr 07.00...18.00 h)

## ifm Niederlassungen • Sales offices • Agences

|    |                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| D  | Niederlassung Nord • 31135 Hildesheim • Tel. 05121 7667-0<br>Niederlassung West • 45128 Essen • Tel. 0201 36475 -0<br>Niederlassung Mitte-West • 58511 Lüdenscheid • Tel. 02351 4301-0<br>Niederlassung Süd-West • 64646 Heppenheim • Tel. 06252 7905-0<br>Niederlassung Baden-Württemberg • 73230 Kirchheim • Tel. 07021 8086-0<br>Niederlassung Bayern • 82178 Puchheim • Tel. 089 80091-0<br>Niederlassung Ost • 07639 Tautenhain • Tel. 036601 771-0 |
| AE | ifm electronic FZC • Saif Zone, Sharjah • phone +971- 6-5573601                                                                                                                                                                                                                                                                                                                                                                                          |
| AR | ifm electronic s.r.l. • 1107 Buenos Aires • phone +54 11 5353-3436                                                                                                                                                                                                                                                                                                                                                                                       |
| AT | ifm electronic gmbh • 1120 Wien • phone +43 / 1 / 617 45 00                                                                                                                                                                                                                                                                                                                                                                                              |
| AU | ifm efector pty ltd. • Mulgrave Vic 3170 • phone +61 1300 365 088                                                                                                                                                                                                                                                                                                                                                                                        |
| BE | ifm electronic n.v./s.a. • 1731 Zellik • phone +32 2 481 0220                                                                                                                                                                                                                                                                                                                                                                                            |
| BG | ifm electronic eood • 1202 Sofia • phone +359 2 807 59 69                                                                                                                                                                                                                                                                                                                                                                                                |
| BR | ifm electronic Ltda. • 03337-000 Sao Paulo / SP • phone +55-11-2672-1730                                                                                                                                                                                                                                                                                                                                                                                 |
| CA | ifm efector Canada inc. • Mississauga, ON L5N 2X7 • phone +1 855-436-2262                                                                                                                                                                                                                                                                                                                                                                                |
| CH | ifm electronic ag • 4624 Härkingen • phone +41 / 800 88 80 33                                                                                                                                                                                                                                                                                                                                                                                            |
| CL | ifm electronic SpA • Oficina 5041 Comuna de Conchalí • phone +56-2-32239282                                                                                                                                                                                                                                                                                                                                                                              |
| CN | ifm electronic (Shanghai) Co. Ltd. • 201203 Shanghai • phone +86 21 3813 4800                                                                                                                                                                                                                                                                                                                                                                            |
| CZ | ifm electronic, spol. s.r.o. • 140 00 Praha 4 • phone +420 267 990 211                                                                                                                                                                                                                                                                                                                                                                                   |
| DK | ifm electronic a/s • 2605 Brøndby • phone +45 70 20 11 08                                                                                                                                                                                                                                                                                                                                                                                                |
| ES | ifm electronic s.a. • 08820 El Prat de Llobregat • phone +34 93 479 30 80                                                                                                                                                                                                                                                                                                                                                                                |
| FI | ifm electronic oy • 00440 Helsinki • phone +358 75 329 5000                                                                                                                                                                                                                                                                                                                                                                                              |
| FR | ifm electronic s.a. • 93192 Noisy-le-Grand Cedex • phone +33 0820 22 30 01                                                                                                                                                                                                                                                                                                                                                                               |
| GB | ifm electronic Ltd. • Hampton, Middlesex TW12 2HD • phone +44 / 20 / 8213 0000                                                                                                                                                                                                                                                                                                                                                                           |
| GR | ifm electronic monoprosofi E.P.E. • 15125 Amaroussio • phone +30 210 61 800 90                                                                                                                                                                                                                                                                                                                                                                           |
| HU | ifm electronic kft. • 9028 Győr • phone +36-96 / 518-397                                                                                                                                                                                                                                                                                                                                                                                                 |
| IN | ifm electronic India Private Limited • Kolhapur, 416234 • phone +91 / 231 / 267 27 70                                                                                                                                                                                                                                                                                                                                                                    |
| IE | ifm electronic (Ireland) Ltd. • Dublin 22 • phone +353 / 1 / 461 32 00                                                                                                                                                                                                                                                                                                                                                                                   |
| IT | ifm electronic s.r.l. • 20864 Agrate Brianza (MB) • phone +39 39-6899982                                                                                                                                                                                                                                                                                                                                                                                 |
| JP | efector co., ltd. • Chiba-shi, Chiba 261-7118 • phone +81 043-299-2070                                                                                                                                                                                                                                                                                                                                                                                   |
| KR | ifm electronic Ltd. • 04420 Seoul • phone +82 2-790-5610                                                                                                                                                                                                                                                                                                                                                                                                 |
| MX | ifm efector S. de R.L. de C.V. • San Pedro Garza Garcia, N.L. 66269 • phone +52-81-8040-3535                                                                                                                                                                                                                                                                                                                                                             |
| MY | ifm electronic Pte. Ltd • 47100 Puchong, Selangor • phone +603 8066 9853                                                                                                                                                                                                                                                                                                                                                                                 |
| NA | ifm electronic (pty) Ltd • 25 Dr. W. Kulz Street Windhoek • phone +264 61 300984                                                                                                                                                                                                                                                                                                                                                                         |
| NL | ifm electronic b.v. • 3843 GA Harderwijk • phone +31 341-438 438                                                                                                                                                                                                                                                                                                                                                                                         |
| NZ | ifm efector pty ltd • 930 Great South Road Penrose, Auckland • phone +64 / 95 79 69 91                                                                                                                                                                                                                                                                                                                                                                   |
| PL | ifm electronic sp. z o.o. • 40-106 Katowice • phone +48 32 70 56 400                                                                                                                                                                                                                                                                                                                                                                                     |
| PT | ifm electronic s.a. • 4410-137 São Félix da Marinha • phone +351 223 71 71 08                                                                                                                                                                                                                                                                                                                                                                            |
| RO | ifm electronic s.r.l. • Sibiu 557260 • phone +40 269 224 550                                                                                                                                                                                                                                                                                                                                                                                             |
| RU | ifm electronic • 105318 Moscow • phone +7 495 921-44-14                                                                                                                                                                                                                                                                                                                                                                                                  |
| SG | ifm electronic Pte Ltd • 609 916 Singapore • phone +65 6562 8661                                                                                                                                                                                                                                                                                                                                                                                         |
| SK | ifm electronic s.r.o. • 831 06 Bratislava • phone +421 244 872 329                                                                                                                                                                                                                                                                                                                                                                                       |
| SE | ifm electronic ab • 412 50 Göteborg • phone +46 31-750 23 00                                                                                                                                                                                                                                                                                                                                                                                             |
| TR | ifm electronic Ltd. Sti. • 34381 Sisli, Istanbul • phone +90 212 210 50 80                                                                                                                                                                                                                                                                                                                                                                               |
| TW | ifm electronic • Kaohsiung City, 806, Taiwan R.O.C. • phone +886 7 3357778                                                                                                                                                                                                                                                                                                                                                                               |
| UA | TOV ifm electronic • 02660 Kiev • phone +380 44 501-85-43                                                                                                                                                                                                                                                                                                                                                                                                |
| US | ifm efector inc. • Malvern, PA 19355 • phone +1 800-441-8246                                                                                                                                                                                                                                                                                                                                                                                             |
| VN | ifm electronic Vietnam Co., Ltd. • 700000 Ho Chi Minh City • phone +84-28-2253.6715                                                                                                                                                                                                                                                                                                                                                                      |
| ZA | ifm electronic (Pty) Ltd. • 0157 Pretoria • phone +27 12 450 0412                                                                                                                                                                                                                                                                                                                                                                                        |

Technische Änderungen behalten wir uns ohne vorherige Ankündigung vor.

We reserve the right to make technical alterations without prior notice.

Nous nous réservons le droit de modifier les données techniques sans préavis.