



^{8.} Check the wire type and response frequency when extending wire because of distortion of waveform or residual voltage increment etc by line resistance or capacity between lines.

Temperature Controllers Temperature/Humidity Transducers SSR/Power Controllers Counters Timers Panel Meters Tachometer/Pulse (Rate) Meters Display Units Autonics Corporation Sensor Controllers http://www.autonics.com HEADQUARTERS 18, Bansong-ro 513 beon-gil, Haeundae-gu, Busan, South Korea, 48002 TEL: 82-51-519-3232 E-mail: sales@autonics.com

DRW171368AC