٠

1



Pepperl+Fuchs Group www.pepperl-fuchs.com

Date of issue: 2010-11-20 086585\_ENG.xml

2010-11-20 16:11

Release date:

1

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

## NJ1,5-F2-E0-V1

## Installation hint

The inductive proximity sensor with plugin acknowledgement elements is designed for applications where the simple installation of an adjustable mechanical stop with electronic acknowledgement is required. Heavy duty fine threaded stop screws serve as finely adjustable end stops. The state of the acknowledgement element is indicated by the built-in LED on the proximity sensor.

Accessories:

Stop screws (Acknowledgement elements)



	Туре	A	В	L	L1	L2	Load
0	Coding						F max.
AS	6 08/15	M 8 x 1	6	15	3,5	2	2 000 N
A	S 08/40	M 8 x 1	6	40	3,5	2	2 000 N
A	S 10/50	M 10 x 1	7	50	2,5	1	9 500 N
A	S 12/60	M 12 x 1	9	60	2	0,5	20 500 N
A	S 12/80	M 12 x 1	9	80	2	0,5	20 500 N



Subject to modifications without notice

