



Mounting instructions  
for clamp fitting


**E30018**

**E30025**

**UK**


701310 / 02 05 / 1999

Fig. 1



- Insert the fitting (A) into the process connection and tighten it.

Fig. 2




Temperature sensor TT:

- Slip the coupling nut (B) and the suitable closed gasket (C) onto the sensor (D) from the bottom.

Temperature sensor TS:

- Slip the coupling nut (B) onto the sensor from the bottom.
- Bend the slotted gasket (C) open and snap it onto the sensor cable (D).

Fig. 3



- Adjust the sensor to the required installation depth and tighten the coupling nut (B).

UK



Permitted overpressure: max. 1 bar.