

Universal distance sensor, measurement to reflector, IO-Link interface, measuring method PRT, 50 m detection range, red laser light, laser class 1, push-pull output, analog output, terminal block



# Function

The VDM28 distance measurement device employs Pulse Ranging Technology (PRT). It has a repeat accuracy of 5 mm with an operating range of 0.5 ... 50 m and an absolute accuracy of 25 mm.

# Safety Information



Refer to "General Notes Relating to Pepperl+Fuchs Product Information"



#### **Dimensions**



# **Technical Data**

General specifications	
Device type	GUBW1.D.OS-VDM28-50-R1
Measurement range	0.5 50 m
Reference target	OFR-100/100
Light source	laser diode typ. service life 85,000 h at Ta = +25 °C
Light type	modulated visible red light
Laser nominal ratings	
Note	LASER LIGHT , DO NOT STARE INTO BEAM
Laser class	1
Wave length	660 nm
Beam divergence	< 1.5 mrad
Pulse length	approx. 4 ns
Repetition rate	250 kHz
max. pulse energy	< 1.5 nJ
Angle deviation	max. ± 2°
Measuring method	Pulse Ranging Technology (PRT)
Diameter of the light spot	< 50 mm at a distance of 50 m at 20 °C
Ambient light limit	50000 Lux
Temperature influence	typ. ≤ 0.25 mm/K
Functional safety related parameters	
MTTF <sub>d</sub>	200 a
Mission Time (T <sub>M</sub> )	10 a
Diagnostic Coverage (DC)	0 %
Indicators/operating means	
Operation indicator	LED green
Function indicator	2 LEDs yellow for switching state

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Release date: 2020-07-13 Date of issue: 2020-07-13 Filename: 300497\_eng.pdf

# VDM28-50-R1-IO/110/116/122-Ex

## **Distance sensor**

**Technical Data** 

Teach-In indicator		Teach-In: LED green/yellow equiphase flashing; 2.5 Hz Teach Error:LED green/yellow non equiphase flashing; 8.0 Hz
Control elements		5-step rotary switch for operating modes selection (threshold setting and operating modes)
Control elements		Switch for setting the threshold values
Electrical specifications		
Operating voltage	UB	10 30 V DC / when operating in IO-Link mode: 18 30 V
Ripple		10 % within the supply tolerance
No-load supply current	I <sub>0</sub>	$\leq$ 70 mA / 24 V DC
Time delay before availability	t <sub>v</sub>	1.5 s
Interface		
Interface type		IO-Link
Protocol		IO-Link V1.0
Cycle time		min. 2.3 ms
Mode		COM 2 (38.4 kBaud)
Process data width		16 bit
SIO mode support		yes
Output		
Signal output		Push-pull output, short-circuit protected, reverse polarity protected
Switching voltage		max. 30 V DC
Switching current		max. 100 mA
Measurement output		1 analog output 4 20 mA, short-circuit/overload protected
Switching frequency	f	50 Hz
Response time		10 ms
Conformity		
Product standard		EN 60947-5-2
Laser safety		IEC 60825-1:2007
Measurement accuracy		
Absolute accuracy		± 25 mm
Repeat accuracy		< 5 mm
Approvals and certificates		
IECEx approval		IECEx INE 14.0042X
ATEX approval		INERIS 14 ATEX 0035X
Marking		ⓑ II 2 GD Ex db IIC T6 Gb Ex tb IIIC T85°C Db
Ambient conditions		
Ambient temperature		-30 45 °C (-22 113 °F)
Storage temperature		-30 70 °C (-22 158 °F)
Mechanical specifications		
Cable gland		Clamping range 3 8.5 mm
Enclosure cover		threaded round cover
Cover fixing		flamepath thread
Flamepath grease		petroleum jelly
Degree of protection		IP66
Connection		Connection terminals, max. wire cross-section 2.5 mm <sup>2</sup>
Material		
Enclosure		aluminum alloy
Glass		thermo-resistant tempered glass
Finish		epoxy coated RAL 7005 (grey)
Mass		approx. 6.6 kg

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 Get

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

1

2

3

4

# **Connection Assignment**



2

analog Ο

O = Light on= Dark on

# Assembly



1	Operating display green		
2	Signal display yellow		
3	TEACH-IN button		
4	Mode rotary switch		
5	Laser output		

# Accessories

PACTware*	PACTware 4.1	FDT Framework
<u>O</u> tr	VDM28 IODD	IODD for communication with VDM28-IO-Link sensors
<u>O</u> r	VDM28-IO-Link DTM	Device DTM for communication with VDM28-IO-Link sensors
	IO-Link-Master02-USB	IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection
<u>O</u> hn	IO-Link-Master-USB DTM	Communication DTM for use of IO-Link-Master
	REF-MH82	Reflector with Micro-structure, rectangular 82 mm x 60 mm, mounting holes
	REF-MH50	Reflector with Micro-structure, rectangular 50.9 mm x 50.9 mm, mounting holes, fixing strap
	REF-MH78	Reflector with Micro-structure, hexagonal 78 mm x 61 mm, mounting holes
	OFR-100/100	Reflective tape 100 mm x 100 mm

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Release date: 2020-07-13 Date of issue: 2020-07-13 Filename: 300497\_eng.pdf

4

## **Teach-In**

You can use the rotary switch to select the relevant switching threshold A and/or B for teaching in for switching output **Q1**. The yellow LEDs indicate the current state of the selected output.

To store a switching threshold (distance measured value), press and hold the "SET" button until the yellow and green LEDs flash in phase (approx. 2 s). Teach-In starts when the "SET" button is released.

Successful Teach-In is indicated by alternating flashing (2.5 Hz) of the yellow and green LEDs.

An unsuccessful Teach-In is indicated by rapidly alternating flashing (8 Hz) of the yellow and green LEDs.

After an unsuccessful Teach-In, the sensor continues to operate with the previous valid setting after the relevant visual fault signal is issued.

Different switching modes can be defined by teaching in the relevant distance measured values for the switching thresholds A and B:



Every taught-in switching threshold can be retaught (overwritten) by pressing the SET button again.

Pressing and holding the "SET" button for > 5 s completely deletes the taught-in value. The yellow and green LEDs go out simultaneously to indicate that this procedure has been completed.

Minimum and maximum values for the analog output **Q2** are taught in in the same way as those for the switching output: The following values apply: A = 4 mA

B = 20 mA

This provides three different options for operation:



• Short circuit: In the event of a short circuit at the sensor output, the green LED flashes with a frequency of approx. 4 Hz.

fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 Germany: +49 621 776 1111

fa-info@us.pepperl-fuchs.com

www.pepperl-fuchs.com

### Distance sensor

# VDM28-50-R1-IO/110/116/122-Ex

• Teach error: In the event of a teach error, the yellow and green LEDs flash alternately with a frequency of approx. 8 Hz.



#### Note!

The difference in the taught-in distance measured values for switching thresholds A and B must be greater than 20 mm.

If the difference in the taught-in measured values is the same as or smaller than the set switching hysteresis, the sensor will visually signal an unsuccessful Teach-In. The last distance measured value that was taught in will not be adopted by the sensor.

Select a new distance measured value for switching threshold A or B with a greater difference between the switching thresholds.

Teach in this distance measured value on the sensor again.

Switching threshold A can be deleted or set to a value of zero.

(E.g., when setting the "zero start point" curve).

However, switching threshold B can neither be deleted nor set to a value of zero.

# Application

- Object identification or classification
- Positioning
- Level measurement
- Collision avoidance/distance measurement
- Compartment occupied checks
- Rack fine positioning
- Stack height control
- Coil measurement
- Dip monitoring
- Lift height checks
- · Opening impulse sensor and closing edge monitoring on automatic doors, industrial gates and barrier systems
- Vehicle detection for traffic engineering purposes (e.g. monitoring of individual parking spaces)
- · Height measurement in tunnels and entranceways
- Anti-collision protection on automated transport systems

## **Safety Information**

Laser Class 1 Information

The irradiation can lead to irritation especially in a dark environment. Do not point at people!

Maintenance and repairs should only be carried out by authorized service personnel!

Attach the device so that the warning is clearly visible and readable.

Caution – Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

6