

Model Number

UB300-18GM40-E5-V1-Y287031

Single head system

Features

- Short design, 40 mm
- Switch output
- 5 different output functions can be . set
- **Program input**
- Temperature compensation ٠

Diagrams

Characteristic response curve



Technical data		
General specifications		
Sensing range		
Adjustment range		
Dead band		
Standard target plate		
Transducer frequency		
Response delay		
Electrical specifications		
Operating voltage U _B		
No-load supply current I0		
Input		
Input type		
Output		
Output type		
Rated operating current I _e		
Default setting		
Voltage drop U _d		
Repeat accuracy		
Switching frequency f		
Range hysteresis H		
Temperature influence		
Ambient conditions		
Ambient temperature		
Storage temperature		
Mechanical specifications		
Connection type		
Degree of protection		
Material		
Housing		
Transducer		
Mass		
Compliance with standards and directives		
Standard conformity		

Standard conformity Standards

Approvals and certificates

UL approval CSA approval CCC approval

Stainless steel 1.4305 / AISI 303 epoxy resin/hollow glass sphere mixture; foam polyurethane, cover PBT . 25 g

EN 60947-5-2:2007 + A1:2012 IEC 60947-5-2:2007 + A1:2012

cULus Listed, General Purpose cCSAus Listed, General Purpose CCC approval / marking not required for products rated ≤36 V

Dimensions



35 ... 300 mm 50 ... 300 mm 0 ... 35 mm

100 mm x 100 mm approx. 390 kHz approx. 50 ms

10 ... 30 V DC , ripple 10 $\%_{\rm SS}$ \leq 20 mA

1 program input operating distance 1: -U_B ... +1 V, operating distance 2: +6 V ... +U_B input impedance: > 4,7 k Ω program pulse: ≥ 1 s

1 switching output E5, PNP NO/NC, programmable 200 mA , short-circuit/overload protected Switch point A1: 50 mm Switch point A2: 300 mm \leq 3 V ≤1 %

 \leq 13 Hz 1 % of the set operating distance ± 1.5 % of full-scale value

-25 ... 70 °C (-13 ... 158 °F) -40 ... 85 °C (-40 ... 185 °F)

Connector M12 x 1 , 4-pin , metal IP67

UB300-18GM40-E5-V1-Y287031

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Electrical Connection

Standard symbol/Connections: (version E5, pnp)

	(())	
u ∲	1 (<u>BN)</u> 2 (WH)	 + U_B Teach input
	4 (BK) 3 (BU)	Switch outp
		- 0

Core colours in accordance with EN 60947-5-2.

Switch output

Pinout

Connector V1

Accessories

UB-PROG2 Programming unit

OMH-04

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

BF 18 Mounting flange, 18 mm

BF 18-F Mounting flange with dead stop, 18 mm

BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

V1-G-2M-PVC Female cordset, M12, 4-pin, PVC cable

V1-W-2M-PUR Female cordset, M12, 4-pin, PUR cable

Adjusting the switching points

The ultrasonic sensor features a switch output with two teachable switching points. These are set by applying the supply voltage -U_B or +U_B to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s.

Five different output functions can be set

- 1. Window mode, normally-open function
- 2. Window mode, normally-closed function
- 3. one switching point, normally-open function
- 4. one switching point, normally-closed function
- 5. Detection of object presence

TEACH-IN window mode, normally-open function

- Set target to near switching point
- TEACH-IN switching point A1 with -UB
- Set target to far switching point
- TEACH-IN switching point A2 with +UB

TEACH-IN window mode, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A2 with +U_B
- Set target to far switching point
- TEACH-IN switching point A1 with -U_B

TEACH-IN switching point, normally-open function

- Set target to near switching point
- TEACH-IN switching point A2 with +UB
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -U_B

TEACH-IN switching point, normally-closed function

- Set target to near switching point

www.pepperl-fuchs.com

- TEACH-IN switching point A1 with -UB
 - Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

UB300-18GM40-E5-V1-Y287031

Additional Information

Programmable output modes



5. A1 -> ∞ , A2 -> ∞ : Object presence detection mode Object detected: Switch output closed No object detected: Switch output open

PEPPERL+FUCHS

- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A2 with +UB

TEACH-IN detection of objects presence

- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -U_B
- TEACH-IN switching point A2 with +UB

Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF18, BF18-F or BF 5-30 must be used.

In case of direct mounting of the sensor in a through hole using the steel nuts, it has to be fixed at the middle of the housing thread. If a fixation at the front end of the threaded housing is required, plastic nuts with centering ring (accessories) must be used.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group USA: www.pepperl-fuchs.com fa-info@u

