# Safety control unit module

#### **Dimensions**





#### **Model Number**

### SB4 Module 6C

Safety control unit module Module for Evaluation unit SafeBox - series SB4

#### **Features**

- Sensor module ٠
- 6 sensor channels ٠
- Single module for safety thru-beam sensors SLA12 and SLA29 and for 2 channel safety devices (emergency off)
- Operating mode can be selected by ٠ means of DIP switches

00.5 80.3



### **Electrical connection**

0000	Terminal	Function
	1	Transmitter 1 output
0000	2	Transmitter 2 output
13 14 15 16 9 10 11 12	3	Transmitter 3 output
R5 R6	4	Transmitter 13 +U
☆ ☆	5	Transmitter 4 output
R3 R4	6	Transmitter 5 output
R3 R4	7	Transmitter 6 output
R3 R4 芬 芬 R1 R2 芬 芬	8	Transmitter 46 +U
	9	Receiver 1 input
1 2 3 4 5 6 7 8	10	Receiver 2 input
0000	11	Receiver 3 input
	12	Receiver 13 +U
0000	13	Receiver 4 input
	14	Receiver 5 input
	15	Receiver 6 input
	16	Receiver 46 +U

## **Technical data**

General specifications	
Operating mode	simultaneousness, antivalence
Functional safety related parameters	
Safety Integrity Level (SIL)	SIL 3
Performance level (PL)	PL e
Category	Cat. 4
Mission Time (T <sub>M</sub> )	20 a
Туре	4
Indicators/operating means	
Function indicator	LED yellow (6x): indicator lamp channel 1 6
Pre-fault indicator	LED yellow flashing: Indicator lamp channel 1 6
Control elements	DIP-switch
Electrical specifications	
Operating voltage U <sub>B</sub>	24 V DC $\pm$ 20 % , via SB4 Housing
Input	
Activation current	approx. 7 mA
Conformity	
Functional safety	ISO 13849-1 ; EN 61508 part1-4
Product standard	EN 61496-1
Ambient conditions	
Ambient temperature	0 50 °C (32 122 °F)
Storage temperature	-20 70 °C (-4 158 °F)
Mechanical specifications	
Degree of protection	IP20
Connection	screw terminals , lead cross section 0.2 2 mm <sup>2</sup>

www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

### Safety control unit module

Housing	Polyamide (PA)	
Mass	approx. 150 g	
Approvals and certificates		
CE conformity	CE	
UL approval	cULus	
TÜV approval	ΤÜV	

The operation of this module is possible only within a control unit of the type SafeBox SB4.

The operating instruction of the SafeBox has to be observed.

# Function

The 6-channel sensor card module SB4-6C makes it possible to connect light barriers or light grids or contact safety sensors in a one or two-channel version.

When the system is switched on, the software determines whether a light barrier or a contact safety sensor is switched on at a channel and monitors its presence during operation. Safety sensors with switching contacts, which are connected to the Safe-Box, must operate in the switching mode "normally closed". An open contact means "safe status".

The channels 1 and 2, 3 and 4 as well as 5 and 6 can be monitored for simultaneousness or antivalence. If simultaneousness monitoring is activated, 2 channel safety equipment is monitored for simultaneous opening or changing of the signals. The monitoring time is 2 s.

Antivalence monitoring expects the normally closed contact at channel 1, 3 or 5 and the normally open contact at channel 2, 4 or 6. If antivalence monitoring is performed without simultaneousness monitoring, an incorrect contact position causes a switch-off and the error message 7 after approx. 60 s.

## **Operation types**

The assembly contains 4 DIP switches for selecting the simultaneousness functions of neighbouring channels (1 and 2, 3 and 4, 5 and 6) and for an antivalent evaluation of neighbouring channels (1 and 2, 3 and 4, 5 and 6). For selecting functions, 2 selector switches must always be actuated. The functions are not effective if light barriers are connected.

#### Position of the DIP switches



Switch	Position	Operation type
1 and 3	OFF	No antivalent evaluation
	ON	Antivalent evaluation active
2 and 4	OFF	No simultaneousness evaluation
	ON	Simultaneousness evalu- ation active

## Display

For each channel, there is a yellow LED on the front panel of the module.

Display LED Meaning		LED	Meaning
	R1 - R6	yellow	Status of light barrier 1 6
			Off: light beam interrupted On: light beam released
			Flashing (2.5 Hz): light beam released, function reserve fallen short of
			Flashing (5 Hz): error

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group USA: +1 330 www.pepperl-fuchs.com fa-info@us.pepp

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



SB4 Module 6C