HRTU 420

Ultrasonic scanners with background suppression

Dimensioned drawing



- Various opening angles and sound cone geometries
- Switching behavior largely independent of surface properties
- Precise switching point adjustment through • teach-in on the device and via a cable
- Protection against erroneous operation by automatically locking teach button



Accessories:

(available separately)

- M8 connectors (D M8...)
- Ready-made cables (K-D ...)



Active surface Α

В Green indicator diode

Electrical connection



[**|**•>>))

((((

•

Leuze electronic GmbH + Co. KG info@leuze.de • www.leuze.com

▲ Leuze electronic

HRTU 420

1000

400

Specifications				Tables
Ultrasonic data Scanning range Adjustment range of the switching point Opening angle Sound frequency Repeatability Temperature drift Hysteresis	10 200mm 30 200mm narrow	o the switching point)	HRTU 420/L 100 1000mm 100 1000mm wide 240 kHz	1 100 100 2 40 400 3 10 200 1 HRTU 420/L 2 2 HRTU 420/S
Timing Switching frequency Response time Decay time Delay before start-up		20Hz ≤ 25ms ≤ 25ms	10Hz ≤ 50ms ≤ 50ms	Scanning range [mm]
/4NC /2NO	$\begin{array}{l} 12 \hdown & 30 \mbox{VDC} \hdown & I0\% \\ \leq 10\% \hdown & I0\% \\ \leq 35 \mbox{mA} \\ pin 4: \hdown & PNP \hdown & Insistor \\ pin 4: \hdown & PNP \hdown & Insistor \\ pin 4: \hdown & Insistor \\ pin 4: \hdown & Insistor \\ \leq 100 \hdown & Insistor \\ C_{max} & = 10 \hdown & Insistor \\ C_{max} & = 10 \hdown & Insistor \\ Pin 2: \hdown & Insistor \\ \geq (U_R - 2V) / \leq 2V \end{array}$, make-contact (NO) , break-contact (NC) , make-contact (NO) , break-contact (NC)	residual ripple	Diagrams HRTU 420/S Typ. response behavior (object 15 x15mm)
Indicators Green LED Green LED slowly flashing Green LED quickly flashing	switching state (on = teach event active teaching error	object detected)		B -6 → y1 -12 -15 50 100 150 20 Distance x [mm]
Mechanical data Housing Active surface Standard measurement object ²⁾ Attachment Weight Connection type	plastic (PE), color: red plastic (PC) 15 x15mm through holes for 2 x approx. 10g M8 connector, 4-pin	30 x30mm	30 x30mm	HRTU 420/ Typ. response behavior (object 30 x30mm)
Environmental data Ambient temp. (operation/storage) Protective circuit ³⁾ VDE safety class Protection class Standards applied Certifications	-10°C +60°C/-40° 1, 2, 3 III IP 67 IEC/EN 60947-5-2 UL 508	°C +85°C		HRTU 420/L
1) Observe the safety regulations and instal		ng power supply and wir	ing;	Typ. response behavior (object 30 x30 mm)

for UL applications: only for use in "Class 2" circuits acc. to NEC
Aligned perpendicular to sensor reference axis
1=polarity reversal protection, 2=short circuit protection, 3=overload protection for all outputs

Remarks

• Approved purpose:

This product may only be used by qualified personnel and must only be used for the approved purpose. This sensor is not a safety sensor and is not to be used for the protection of persons.



T

HRTU 420

Ultrasonic scanners with background suppression

Type key

		H R T U 4 2 0 / 4 N 0 . 2 - S - S 8
Operating	principle / construction	
HRTU	Ultrasonic scanner (proximity switch) with background suppression	
Series		
420	Small cubic construction with housing width of 20 mm	
Output fun	ction	
4NO	PNP transistor, make-contact (NO)	
4NC	PNP transistor, break-contact (NC)	
2NO	NPN transistor, make-contact (NO)	
2NC	NPN transistor, break-contact (NC)	
Equipment		
2	Teach input	
Sound con	e geometry	
N/A	Sound cone with standard opening angle	
·S	Sound cone with narrow opening angle	
-L	Sound cone with wide opening angle	
Electrical o	connection	
S8	M8 connector, 4-pin, axial	

Order guide

The sensors listed here are preferred types; current information at www.leuze.com.

Opening angle of the ultrasonic cone	Designation	Part No.
Narrow	HRTU 420/4N0.2-S-S8 HRTU 420/4NC.2-S-S8 HRTU 420/2N0.2-S-S8 HRTU 420/2NC.2-S-S8	50113992 50113989 50113986 50113983
Standard	HRTU 420/4N0.2-S8 HRTU 420/4NC.2-S8 HRTU 420/2N0.2-S8 HRTU 420/2NC.2-S8	50113991 50113988 50113985 50113982
Wide	HRTU 420/4N0.2-L-S8 HRTU 420/4NC.2-L-S8 HRTU 420/2N0.2-L-S8 HRTU 420/2NC.2-L-S8	50113990 50113987 50113984 50113981

HRTU 420

Switching point adjustment via teach-in

Teach button	Teach-in input PIN 2		
1 Activate teach-in			
Press the teach button for approx. 2s until the LED flashes - then release the button. (2) Place the object at the desired switching position			
and conclude the teach event			
LED flashes. Once the object is at the desired switching position, briefly press the teach button once again. The teach event ends after 2s, the sensor detects the object at this position and the LED is on. If the object is removed, the LED must switch off.	Position object U _B briefly, ends teach event; LED on		

Teaching error

If the object is located outside of the scanning range during the teach event, a teaching error occurs. The LED flashes quickly and the switching output is reset to the factory setting (switching point at the max. scanning range).

Resetting the sensor to factory setting

Teach button	Teach-in input PIN 2
Restoring the factory setting	
Press the teach button for at least 6s until the LED flashes quickly - then release the button. The sensor setting now corresponds to the factory setting (switching point at the max. scanning range).	U _B for at least 6s, LED flashes quickly

Locking the teach button

The sensor automatically locks the teach button after either 5 min. after power-on or 5 min. after the last teach event is ended. A new teach event is only possible after disconnecting the sensor from voltage.



If the **Teach-IN** input is not used, it must be connected to GND!