HTU418B

STANDARD ultrasonic sensors with 1 switching output

Dimensioned drawing



- Small dead zone at long range
- Adjustment of the switching point can be taught
- NO/NC function reversible
- 1 switching output (PNP)
- Extra short construction
- NEW Stable all-metal design



Accessories:

(available separately)

- Mounting systems
- Mounting adapter M18-M30: BTX-D18M-D30 (Part no. 50125860)
- Cables with M12 connector (KD ...)
- Teach adapter PA1/XTSX-M12 (Part no. 50124709)





- A Indicator diodes
- B Active sensor surface

Electrical connection



HTU418B

Specifications

Ultrasonic specifications

Scanning range 1) Adjustment range Ultrasonic frequency Typ. opening angle Resolution switching output Direction of beam Reproducibility Switching hysteresis Temperature drift

Timing Switching frequency Response time Delay before start-up

Electrical data

Operating voltage U_B⁶⁾ Residual ripple Open-circuit current Switching output Function Output current Switching range adjustment

Changeover NO/NC 7)

Indicators

Yellow LED Yellow LED, flashing Green LED

Mechanical data

Housing Weight Ultrasonic transducer Connection type Fitting position

Environmental data

Ambient temperature (operation/storage) Protective circuit ⁹⁾ VDE safety class Degree of protection Standards applied Certifications

At 20°C 1)

Target: plate 20mm x 20mm 2)

3) Target: plate 100mm x 100mm Target: plate 100mm x 100mm

4) 5 Of full scale value

For UL applications: for use in class 2 circuits according to NEC only 6)

Not applicable for Type HTU418B-1000 / 4TX-M12P2 (50130241)

The ceramic material of the ultrasonic transducer contains lead zirconium titanate (PZT) 8)

1=short-circuit and overload protection, 2=polarity reversal protection, 3=wire break and inductive protection 9 10) These proximity switches shall be used with UL Listed Cable assemblies rated 30V, 0.5A min, in the field installation, or equivalent (categories: CYJV/CYJV7 or PVVA/PVVA7)

11)Ambient temperature 85°C. Use same supply source for all circuits

Deviating Specifications for HTU418B-1000 / 4TX-M12P2

Customer-specific parameterization with the following characteristics:

Dead zone:	350mm
------------	-------

- Switching point: set to 560mm on delivery ۰
- Switching hysteresis: 25mm
- Switch-on/Switch-off delay: 1.8s
- No adjustment of the switching function (NC/NO) via the teach input

Remarks

Operate in accordance with intended use!

by This product is not a safety sensor and is not intended as personnel protection.

She product may only be put into operation by competent persons.

Solve the product in accordance with the intended use



8Hz

62 ms

< 300ms

200kHz 16° 1mm axial ± 0.15% ^{1) 5)} 10mm ¹⁾ 0.17%/K 8Hz

62 ms < 300ms

150 ..



OUT1: object detected teach-in / teaching error object within scanning range

25 ... 400 mm ²

400mm

25

310kHz

0.5mm

5 mm 1)

0.17%/K

± 0.15%^{1) 5)}

axial

7Hz

71 ms

< 300ms

all-metal brass, nickel-plated 50g piezoceramic 8) M12 connector, 5-pin any

-25°C ... +70°C/-30°C ... +85°C

1, 2, 3 ШÍ IP 67 and IP 68 EN 60947-5-2 UL 508, C22.2 No.14-13 6) 10) 11)





y2

v1







Object distance [mm]

HTU418B

STANDARD ultrasonic sensors with 1 switching output

Part number code

H T U 4 1 8 B - 1 0 0 0 . X 3 / 4 T X - M 1 2 P x

Operat	ing principle	
HTU	Ultrasonic sensor, scanning principle, with background suppression	
DMU	Ultrasonic sensor, distance measurement	
Series		
418B	418B Series, cylindrical M18 construction	
Scanni	ng range in mm	
400	25 400	
700	100 700	
1000	150 1000	
	nent (optional)	
X	"Advanced" design	
3	Teach button on the sensor	
Pin ass	signment of connector pin 4 / black cable wire (OUT1)	
4	PNP output, NO contact preset	
P	PNP output, NC contact preset	
L	IO-Link communication or push-pull (SIO)	
Pin ass	signment of connector pin 2 / white cable wire (Teach-IN)	
Т	teach input	
	signment of connector pin 5 / gray cable wire (OUT2)	
4 D	PNP output, NO contact preset	
P	PNP output, NC contact preset	
V	Analog voltage output 1 10V	
C	Analog current output 4 20 mA	
X	Connection not assigned (n. c not connected)	
Conne	ction technology	
M12	M12 connector, 5-pin	
. .		
Specia	l devices	

Px	Special device version $x = 1 \dots 9$
free	Standard device

Order guide

The sensors listed here are preferred types; current information at www.leuze.com.

	Designation	Part no.	Remark
Scanning range			
25 400 mm	HTU418B-400/4TX-M12	50124269	
100 700mm	HTU418B-700/4TX-M12	50131020	
150 1000mm	HTU418B-1000/4TX-M12	50124270	
350 1000 mm	HTU418B-1000/4TX-M12P2	50130241	customer specific parameterization

▲ Leuze electronic

HTU418B

Device functions and indicators

All sensor settings are taught via the **Teach-IN** input. Device status and switching states are indicated by a green and a yellow LED as follows:



Adjusting the switching point via the teach input

The switching point of the sensor is set to 400mm, 700mm or 1000mm on delivery.

By means of a simple teach event, the switching point can be taught to an arbitrary distance within the scanning range. The Leuze **PA1/XTSX-M12** teach adapter can be used for this purpose. The adapter can also be used to easily switch the output function from NO contact to NC contact.

1-point teach				
1. Place object at desired switching distance.				
2. For the adjustment of output OUT1, connect input Teach-IN to GND for 2 7s (Leuze teach adapter: position "Teach-GND").				
The current state of output OUT1 is frozen during the teach event.				
3. The yellow LED flashes at 3Hz and then remains on.				
The current object distance has been taught as the new switching point.				
4. Error-free teach: LED states and switching behavior according to the diagram shown above.				
Faulty teach (object may be too close or too far away – please note scanning range):				
yellow LED flashes at 5Hz until an error-free teach event is performed.				
The output OUT1 is inactive as long as there is a teach error.				

Adjusting the switching function (NC/NO) via the teach input ¹⁾

The switching function of the sensor is set to normally open (NO) on delivery.

If the switching function is changed, the switching output is changed to the opposite state (toggled).

Changeover of the switching function

1. To change the switching function, connect input Teach-IN to U_B for 2 ... 7s (Leuze teach adapter: position "Teach-U_B").

The current state of output **OUT1** remains frozen while the adjustment is performed.

- 2. The green and yellow LED flash alternately at 2Hz.
- The switching function has been reversed.

The switching behavior corresponds to the diagram shown above.



Notice!

Please note that pin 2 and pin 5 are connected internally. The switching point is taught when GND is connected, and the output function is reversed when U_B is connected due to the configuration of the input.

If no sensor action is desired, pin 2 and pin 5 must remain unconnected!

¹⁾ Not applicable for Type HTU418B-1000 / 4TX-M12P2 (50130241)