Safety control unit module

Dimensions





Model Number

SB4 Module 4CO

Safety control unit module Module for Evaluation unit SafeBox - series SB4

Features

- Sensor module ٠
- 4 sensor channels ٠
- Single module for safety thru-beam sensors SLA12 and SLA29 and for 2 channel safety devices (emergency off)
- Operating mode can be selected by • means of DIP switches

00.5 80.3



Electrical connection





LSE = receiver of light barrier)

Technical data

General specifications	
Operating mode	ODER-Function
Functional safety related parameters	
Safety Integrity Level (SIL)	SIL 3
Performance level (PL)	PL e
Category	Cat. 4
Mission Time (T _M)	20 a
Туре	4
Indicators/operating means	
Function indicator	LED yellow (4x): indicator lamp channel 1 4
Pre-fault indicator	LED yellow flashing: Indicator lamp channel 1 4
Control elements	DIP-switch
Electrical specifications	
Operating voltage U _B	24 V DC \pm 20 % , via SB4 Housing
Input	
Activation current	approx. 7 mA
Conformity	
Functional safety	ISO 13849-1 ; EN 61508 part1-4
Product standard	EN 61496-1
Ambient conditions	
Ambient temperature	0 50 °C (32 122 °F)
Storage temperature	-20 70 °C (-4 158 °F)
Mechanical specifications	
Degree of protection	IP20
Connection	screw terminals , lead cross section 0.2 2 mm ²
Material	

www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

Safety control unit module

Housing	Polyamide (PA)
Mass	approx. 150 g
Approvals and certificates	
CE conformity	CE
UL approval	cULus
TÜV approval	TÜV

This module can only be operated within an evaluation device of the SafeBox SB4 type.

The SafeBox instruction manual should be observed.

Function

The 4-channel sensor card module SB4-4CO makes it possible to connect light barriers or light grids or contact safety sensors in a one-channel version.

When the system is switched on, the software determines whether a light barrier or a contact safety sensor is switched on at a channel and monitors its presence during operation.

Contact safety sensors, which are connected to the SafeBox, must work according to the normally closed principle. An open contact indicates "safe state".

The channels 1 and 2 as well as 3 and 4 can be combined via an OR function when using light barriers.



When using this function, it must be ensured that the effectiveness of the fusing is maintained. This must be checked on installation and commissioning

Operating modes

The assembly has 4 DIP switches for selecting the OR-operation of neighbouring channels (1 OR 2 and 3 OR 4). For selecting functions, 2 selector switches must always be actuated. The functions are only effective if light barriers are connected.

Position of the DIP switches



Switch	Position	Operation type
1 and 3	OFF	No OR-operation channel 1 and 2
T and 0	ON	OR-operation chan- nel 1 and 2
2 and 4	OFF	No OR-operation channel 3 and 4
	ON	OR-operation chan- nel 3 and 4

Displays

For each channel, there is a yellow LED on the front panel of the module.

Display	LED	Meaning
R1 - R4	yellow	Status of light barrier 1 4
		Off: light beam interrupted On: light beam released
		Flashing: light beam released, function reserve fallen short of (frequency approx. 2.5 Hz)
		Flashing fast: error (frequency approx. 5 Hz)

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001

Pepperl+Fuchs Group www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

