# **ODSL 96**

### **Optical laser distance sensors**

# **Dimensioned drawing**







- Α Green indicator diode
- в Indicator diode yellow
- С Transmitter
- D Receiver
- Е Optical axis
- F Device plug M12x1
- Countersinking for SK nut M5, 4.2mm deep G
- н Teach button

# CE k IEC 60947 IEC 60947 **Accessories:**

(available separately)

- Mounting systems
- Cable with M12 connector (K-D ...)

# **Electrical connection**



hudu

10 - 30 V

DC

information

•

 150 ... 2300mm

Reflection-independent distance

• 2 teachable switching outputs (push-pull) · Easy alignment through visible red light

info@leuze.com • www.leuze.com

		OD3L 90
Specifications		Tables
Optical data         Measurement range <sup>1)</sup> Resolution <sup>2)</sup> Hysteresis <sup>2)</sup> Light source         Wavelength         Max. output power         Pulse duration         Light spot         Error limits (relative to measurement accuracy <sup>1)</sup> Repeatability <sup>3)</sup> B/W detection thresh. (6 90% rem.         Temperature drift         Timing         Measurement time         Response time         Delay before start-up         Electrical data         Operating voltage UB         Residual ripple         Open-circuit current         Switching output/function <sup>4</sup> )         Signal voltage high/low         Indicators         Green LED       continuous light flashing (no teach) off         Yellow LED       continuous light flashing (no teach) off         Mechanical data         Housing	$\pm 3\%$ $\pm 2\%$ ) ≤ 1% ≤ 0.1%/°C 2 7ms ≤ 20ms ≤ 300ms 10 30VDC (incl. residual ripple) ≤ 15% of U <sub>B</sub> ≤ 150mA 2 push-pull switching outputs pin 2: Q2, PNP light switching, NPN dark switching pin 4: Q1, PNP light switching, NPN dark switching ≥ (U <sub>B</sub> -2 V)/≤ 2V ready fault, teach values were not applied no voltage object within teach-in measurement distance (output Q1 <sup>5</sup> )) teach values were not applied object outside teach-in measurement distance (output Q1 <sup>4</sup> )	Diagrams
	plastic plastic 140g M12 connector -20°C +40°C/-30°C +70 C 1, 2, 3 II, all-insulated IP 67 2 (acc. to EN 60825-1) IEC 60947-5-2	
<ol> <li>Luminosity coefficient 6% 90%, at 2'</li> <li>Minimum and maximum value depend c</li> <li>Same object, identical environmental cc</li> <li>The push-pull switching outputs must ne</li> <li>No display for output Q2</li> </ol>	0°C, measurement object $\ge$ 50x50mm <sup>2</sup> on measurement distance inditions, measurement object $\ge$ 50x50mm <sup>2</sup>	Remarks Intended use: The ODSL 96 distance sensors are optoelectronic sensors for the optical, contactless measurement of distance to objects.
Characteristic curve of switching outp	A Hysteresis B Switching point Q1 (teach point) C Switching point Q2 (teach point) D Measurement distance	<ul> <li>Operate in accordance with intended use!</li> <li>This product is not a safety sensor and is not intended as personnel protection.</li> <li>The product may only be put into operation by competent persons.</li> <li>Only use the product in accordance with the intended use.</li> <li>Measurement time depends on the reflectivity of the measurement object and on the measurement mode.</li> </ul>
	Designation Part no.	
With M12 connector		

0DSL 96K/66-2300-S12

501 01882

and 2 switching outputs

# **ODSL 96**

### **Optical laser distance sensors**

### Laser safety notices

#### ATTENTION, LASER RADIATION - LASER CLASS 2

#### Never look directly into the beam!

The device fulfills the EN 60825-1:2008-05 (IEC 60825-1:2007) safety regulations for a product in **laser class 2** as well as the U.S. 21 CFR 1040.10 regulations with deviations corresponding to "Laser Notice No. 50" from June 24th, 2007.

- between the laser beam or in the direction of reflecting laser beams!
- If you look into the beam path over a longer time period, there is a risk of injury to the retina.
- ♦ Do not point the laser beam of the device at persons!
- 🗞 Intercept the laser beam with an opaque, non-reflective object if the laser beam is accidentally directed towards a person.
- rightarrow When mounting and aligning the device, avoid reflections of the laser beam off reflective surfaces!
- CAUTION! Use of controls or adjustments or performance of procedures other than specified herein may result in hazardous light exposure.
  - The use of optical instruments or devices (e.g., magnifying glasses, binoculars) with the product will increase eye hazard.
- Adhere to the applicable legal and local regulations regarding protection from laser beams acc. to EN 60825 (IEC 60825) in its latest version.
- ✤ The device must not be tampered with and must not be changed in any way. There are no user-serviceable parts inside the device. Repairs must only be performed by Leuze electronic GmbH + Co. KG.

#### NOTICE

#### Affix laser information and warning signs!

Laser information and warning signs are affixed to the device(see ①). In addition, self-adhesive laser information and warning signs (stick-on labels) are supplied in several languages (see ②).

- Affix the laser information sheet with the language appropriate for the place of use to the device.
- When using the device in the US, use the stick-on label with the "Complies with 21 CFR 1040.10" notice.
- Affix the laser information and warning signs near the device if no signs are attached to the device (e.g. because the device is too small) or if the attached laser information and warning signs are concealed due to the installation position. Affix the laser information and warning signs so that they are legible without exposing the reader to the laser radiation of the device or other optical radiation.



# Leuze electronic

# ODSL 96

# T<sub>I</sub> teach-in with teach button

- 1. Position measurement object at the desired measurement distance (
- 2. The respective teach function is activated by operating the teach button (2) for different amounts of time. The activated teach function is signaled by a flashing of the LEDs.

Teach function	Duration of teach button operation	Green LED	Yellow LED
Switching output Q1	2 4s	Flash synchr	onously
Switching output Q2	4 6s	Flash alternatingly	

**3.** Release teach button (②) and wait for optical confirmation by end of flashing signal (green LED on).

# T<sub>I</sub> teach-in via input

1. Position measurement object at the desired measurement distance.

2. The respective teach function is activated by applying +U<sub>B</sub> to teach input (pin 5). The teach event is signaled by flashing of the LEDs.

Teach function	Duration of the teach signal	Green LED	Yellow LED
Switching output Q1	2 4s	Flash synchronously	
Switching output Q2	4 6s	Flash alternatingly	

**3.** To finish the teach event, disconnect the teach input from  $+U_B$  or switch it to 0V after the desired time.

4.A successful teach event is signaled by the end of the flashing (green LED on)

# Error messages

Continuously flashing LEDs signal an unsuccessful teach event (sensor not ready):

Green LED	Yellow LED	Error
Flash synchronously		Teach switching output Q1 unsuccessful
Flash alternatingly		Teach switching output Q1 unsuccessful

Remedy:

- Repeat teach event or
- Press teach button for more than 10s or
- Disconnect sensor from voltage to restore the old values.



### **ODSL 96**

### **Optical laser distance sensors**

# Typical areas of application of optical distance sensors



### Installation instructions

Mounting systems are available which have to be ordered separately at Leuze electronic. Apart from this, the drilled-through holes and threaded holes are suitable for the individual mounting of the ODSL 96, depending on the area in which it is used. When mounting, avoid application of excessive force on the housing.



#### Preferred mounting in connection to objects with structured surface



#### View through a chase

If the ODSL 96 has to be installed behind a cover, the chase has to have at least the size of the optical glass cover. Otherwise, a correct measurement is not possible or can not be guaranteed.



#### Alignment to measurement objects with reflecting surfaces

If the measurement object to be detected has a reflecting surface, a measurement may not be possible depending on the angle in which the light is reflected by the measurement object's surface. Adjust the angle between the sensor and the measurement object such that the sensor can reliably detect the measurement object.





# ▲ Leuze electronic

ODSL 96