



Model Number

PSE4-SC-01

Safety control unit Safety control unit from the PSE4 series

Features

- Safety control unit •
- For evaluating safety thru-beam ٠ sensors PSE4-SL
- Safety category 4 according to • EN61496-1
- 24 V DC supply voltage •
- 2 safe output contacts ٠
- Performance level PLe (EN13849-1) • is attainable
- Component of PSE4 modular system

Product information

In its entirety, the PSE4 safety edge system consists of the control interface, sensors, a rubber sensor strip, and an optional aluminum mounting strip. The system can be used within a temperature range of 5 $^{\circ}\text{C}$ to 55 °C.

The control interface analyzes the signal from the sensors and is designed to be installed in a switch cabinet. The safety contact of the control interface is released by actuating the safety edge. The system as a whole can be used in applications up to Cat. 4/PL e as defined in EN ISO 13849-1.



Electrical connection

Dimensions



USA: +1 330 486 0001

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com ⁵ PEPPERL+FUCHS

1

		= /			n	
г	Э	- 4	5	U -	U	

Other suitable accessories can be found at

www.pepperl-fuchs.com

mit data					
Permissible cable length		200 m			
Functional safety related parameter	eters				
Performance level (PL)		PLe			
Category		Cat. 4			
MTTFd		166 a			
Mission Time (T _M)		20 a			
Diagnostic Coverage (DC)		99 %			
ndicators/operating means					
Operation indicator		LED green: Power on			
Function indicator		LED green			
Electrical specifications					
Operating voltage	UB	24 V DC +20/-10 %			
Power consumption	P ₀	< 4 W			
Dutput					
Signal output		relay, 2 NO			
Switching voltage		max. 250 V AC/DC			
Switching current		max. 4 A			
Switching power		1000 VA			
Response time		32 ms			
Conformity					
Functional safety		ISO 13849-1			
Product standard		EN 12978 ; ISO 13856-2			
Ambient conditions					
Ambient temperature		5 55 °C (41 131 °F)			
Pollution degree		2			
Mechanical specifications					
Degree of protection		IP20			
Connection		screw terminals , Cable cross-section 0.2 2.5 mm ²			
Material		Polyethylene (PE)			
Mass		approx. 200 g			
Approvals and certificates					
UL approval		cULus Listed File no: NRNT.E344450			
TÜV approval		TÜV Rheinland 968/M 301.00/11			



Notes

The modular PSE system comprises the following components: PSE4-SL safety thru-beam sensors:

The plug electronics are fully encapsulated in the housing to achieve a high level of resistance to environmental influences such as water, dust, and moisture. Degree of protection IP68 is achieved.

Rubber profiles PSE4-RUB and PSE4-ROI:

The rubber profile is designed as a double-chamber profile. The emitter and receiver are inserted in the round hollow chamber at the top. When the profile is actuated, the optical channel is interrupted and the enable circuits on the control unit open. When actuated near the end, the emitter and/or receiver dip into the lower chamber. This ensures that the beam of light is broken. However, the forces required are high, meaning the end areas are inactive areas in line with EN 1760-2.

PSE safety control units:

www.pepperl-fuchs.com

Controller for the emitter/receiver system.

Date of issue: 2019-12-18 233900_eng.xml

Release date: 2019-12-18 11:23

2

PSE4-ALU aluminum rails:

The aluminum rails are available in various lengths and can be used as an option.

Functional Principle

The emitter transmits pulses of infrared light, which are detected by the receiver. When the emitter light is detected, the receiver turns off the emitter via a control input. The "luminous flux" stops. The receiver also detects this status and the emitter is then switched on again after a specified time. This coupling produces a dynamic signal that is conveyed, in principle, to a charge pump. The pump's charge state is analyzed in the evaluation.

Any errors in the emitter/receiver system affect the optical or electrical signal, which results in the absence of a dynamic signal.



Note:

Safety edges must be fully installed to comply with the EC-Type Examination Certificate for the PSE4 series.

Possible combinations

	PSE4-ALU-*	PSE4-ALU-3009-*	PSE4-ROI-*	PSE4-RUB-*	PSE4-RUB-30EPDM58-*	PSE2-SC-*	PSE4-SC-*	PSE4-SL-*
PSE4-ALU-*			Х	Х	-	Х	Х	Х
PSE4-ALU-3009-*			-	-	Х	Х	Х	Х
PSE4-ROI-*	Х	-				Х	Х	Х
PSE4-RUB-*	Х	-				Х	Х	Х
PSE4-RUB-30EPDM58-*	-	Х				Х	Х	Х
PSE2-SC-*	Х	Х	Х	Х	Х			Х
PSE4-SC-*	Х	Х	Х	Х	Х			Х
PSE4-SL-*	Х	Х	Х	Х	Х	Х	Х	

Sensor strip PSE4-RUB-XX or PSE4-ROI-XX and accompanying aluminum mounting strip Cut PSE4-ALU-XX to the required length. Slide the emitter and receiver into the upper chamber. Guide the emitter cable through the lower chamber to the receiver side.

Mounting or replacing the sensors

Pepperl+Fuchs Group

www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001

fa-info@us.pepperl-fuchs.com

fa-info@de.pepperl-fuchs.com

Germany: +49 621 776 1111

fa-info@sg.pepperl-fuchs.com

Singapore: +65 6779 9091