

Installation Instructions Electronic pressure sensor

efectorsod PX32xx

PX32XX PX34XX UK

CE



1 Safety instructions

- Please read the product description prior to installing the unit. Ensure that the product is suitable for your application without any restrictions.
- If the operating instructions or the technical data are not adhered to, personal injury and/or damage to property may occur.
- Please check for all applications that the product materials (see Technical data) are compatible with the media to be measured.

For units with cULus approval and the scope of validity cULus: \rightarrow 6 Technical data.

2 Function and features

The pressure sensor detects the system pressure and converts it into an analog output signal (4...20 mA).

2.1 Applications

• Type of pressure: relative pressure

Order no.	Measuring range	Permissible overload pressure	Bursting pressure	
PX3233	0250 PSI	2 175 PSI	5 075 PSI	
PX3234	0200 PSI	1 087 PSI	2 175 PSI	
PX3254	0100 PSI	1 087 PSI	2 175 PSI	
PX3438	0100 inH2O	4 015 inH2O	12 043 inH2O	



Static and dynamic overpressures exceeding the indicated overload pressure are to be avoided by taking appropriate measures.

The indicated bursting pressure must not be exceeded. Even if the bursting pressure is exceeded only for a short time, the unit can be destroyed. NOTE: Risk of injury!

3 Installation



Before mounting and removing the sensor, make sure that no pressure is applied to the system.

- ► Insert the unit in suitable process connection (see type label "Port Size").
- ► Tighten firmly. Tightening torque 25 Nm.

4 Electrical connection

The unit must only be connected by an electrician. The national and international regulations for the installation of electrical equipment must be observed. Voltage supply to EN50178, SELV, PELV.

- ► Disconnect power.
- Connect the unit as follows:



Core colours of ifm sockets:

1 = BN (brown), 2 = WH (white), 3 = BU (blue), 4 = BK (black), n.c. = not connected.

5 Scale drawing



Dimensions are in millimeters

1: ventilation

6 Technical data

Operating voltage [V]						
Step response time analogue output [ms]						
PX3233		PX3234	PX3254		PX3438	
3		3	500		6	
Characteristics deviation [% of the span]						
PX3233	PX3233 PX		PX3254		PX3438	
< ± 0.35 (BFSL) / < ± 0.75 (LS)						
Repeatability [% of the span]						
PX3233	PX3234		PX3254		PX3438	
0.1		0.1	0.15		0.1	
Long-term stability [% of value of measuring range / 6 months]						
PX3233			PX3254		PX3438	
< ± 0.05						
Temperature coefficients (TEMPCO) in the compensated temperature range 0 80°C (in% of the span/10K)						
		PX3233	PX3234	PX3	3254	PX3438
greatest TEMPCO of the zero point		0.2	0.15	0	.2	0.2
greatest TEMPCO of the span		0.3	0.2	0	.3	0.3

Housing materialstainless steel (316S12); FPM (Viton); PA Materials (wetted parts)stainless steel (303S22) Operating temperature [°C] Medium temperature [°C] Storage temperature [°C] Protection Protection class Insulation resistance [MΩ] Shock resistance [g] 20 (DIN / IE)	; ceramics; FPM (Viton) -25 +80 -25 +90 -40 +100 IP 65 III -25 +90 -40 +100 IP 65 III -25 +90 -40 +100 N / IEC 68-2-27, 11 ms)
EN 61000-4-2 ESD:	
EN 61000-4-3 HF radiated:	
EN 61000-4-4 Burst:	
EN 61000-4-6 HF conducted:	
radiation of interference according to the automotive directive 2	
noise immunityaccording to the automotive directive 2004	4/104/EC / ISO 11452-2
HF radiated	100 V/m
pulse resistanceaccording to ISO	
¹⁾ to EN50178, SELV, PELV	

BFSL = Best Fit Straight Line / LS = Limit Value Setting

For units with cULus approval and the scope of validity cULus:

The device shall be supplied from an isolating transformer having a secondary Listed fuse rated as noted in the following table.

Overcurrent protection				
Control-circuit wire size		Maximum protective device rating		
AWG	(mm²)	Ampere		
26	(0.13)	1		
24	(0.20)	2		
22	(0.32)	3		
20	(0.52)	5		
18	(0.82)	7		
16	(1.3)	10		

The Sensor shall be connected only by using any R/C (CYJV2) cord, having suitable ratings.

More information at www.ifm.com