



Model Number

UC500-30GM70-IE2R2-K-V15

Ultrasonic diffuse sensor with separate transducer

Features

- Analog output 4 ... 20 mA
- 1 switch output
- Synchronization options
- Temperature compensation
- Can be parameterized via the ULT-RA-PROG-IR software and interface (accessories)

Diagrams

Characteristic response curve



Technical data				
General specifications				
Sensing range				
Adjustment range Dead band				
Standard target plate				
Transducer frequency				
Response delay				
Nominal ratings				
Temperature drift				
Time delay before availability t _v Limit data				
Permissible cable length				
Indicators/operating means				
LED yellow				
LED green/yellow				
Potentiometer				
Electrical specifications				
Rated operating voltage Ue				
Operating voltage UB				
Ripple				
No-load supply current I ₀				
Interface type				
Mode				
Input/Output				
Input/output type				
0 Level				
1 Level				
Input impedance				
Number of sensors				
Switching output				
Output type				
Default setting Repeat accuracy R				
Operating current I				
Switching frequency				
Switching hysteresis				
Voltage drop				
Off-state current				
Analog output Output type				
Default setting				
Load resistor				
Ambient conditions				
Ambient temperature				
Storage temperature				
Shock resistance Vibration resistance				
Mechanical specifications				
Connection type				
Degree of protection				
Material				
Housing Cable				
Transducer				
Installation position				
Mass				
Construction type				
Cable length				
Compliance with standards and directives				
Standard conformity				
Standards				
Approvals and certificates				
UL approval				
CSA approval				

45 ... 500 mm 50 ... 500 mm 0 ... 45 mm 100 mm x 100 mm approx. 300 kHz ≤ 60 ms $\leq \pm 1.5$ % of full-scale value ≤ 85 ms max. 300 m switching state switch output yellow: object in evaluation range green: Teach-In switch output adjustable 24 V DC 20 ... 30 V DC (including ripple) ≤ 10 % ≤ 50 mA Infrared point-to-point connection 1 synchronization connection, bidirectional (Factory setting: synchronized mode) / Teach-In input $\leq 3 V$ $\geq 15 \text{ V}$ typ. 900 Ω max. 10 1 switch output PNP, NO (NC contact programmable) 50 ... 500 mm (adjustable via potentiometer) ± 0.5 mm 300 mA , short-circuit/overload protected \leq 5 Hz 5 mm (programmable) \leq 3 V $\leq 10 \ \mu A$ 1 current output 4 ... 20 mA , ascending/descending programmable rising ramp ; evaluation limit A1: 50 mm ; evaluation limit A2: 500 mm \leq 500 Ω -25 ... 70 °C (-13 ... 158 °F) -40 ... 85 °C (-40 ... 185 °F) 30 g , 11 ms period $10 \hdots 55 \mbox{ Hz}$, Amplitude $\pm 1 \mbox{ mm}$ Connector M12 x 1 , 5-pin IP65 brass, nickel-plated PVC epoxy resin/hollow glass sphere mixture; polyurethane foam any position 190 g Cylindrical 165 cm EN 60947-5-2:2007 + A1:2012 IEC 60947-5-2:2007 + A1:2012 EN 60947-5-7:2003 IEC 60947-5-7:2003

cULus Listed, General Purpose cCSAus Listed, General Purpose CCC approval / marking not required for products rated ≤36 V

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

CCC approval

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Dimensions

M30 x 1.5

M12 x 1

Additional Information

Analog output operating mode



Switching output operating mode

M18 x 1

26.7

1

3.3



Electrical Connection

10.



74.4

88.5

Pinout



Wire colors in accordance with EN 60947-5-2

1 2 3 4	BN WH BU BK	(brown) (white) (blue) (black)
4	BK	(black)
5	GY	(gray)

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Accessories

BF 30

Mounting flange, 30 mm

BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

V15-G-2M-PUR Female cordset, M12, 5-pin, PUR cable

UC-18/30GM-IR Interface cable

ULTRA-PROG-IR

Configuration software for ultrasonic sensors

BF 18 Mounting flange, 18 mm

Description of Sensor Functions

Displays and Controls

The sensor has two potentiometers and two display LEDs.

LED 1 (yellow)	On/off: Switching state of switching output Flashing: Error when setting the switching points (switching point 2 < switching point 1). This state only occurs in window function operating mode (2 switching points).	LED 1 potentiometer 2 connector
LED 2 (yellow)	On/off: Object between evaluation limit A1 and evaluation limit A2 in the analog evaluation range.	
LED 2 (green)	approx. 500 ms on: Range limit taught in Off: Normal mode	
Potentiometer 1	Setting for switching point 1 of the switching output.	
Potentiometer 2	Setting for switching point 2 of the switching output	potentiometer 1 LED 2 temperature yellow / green sensor

The potentiometer function described illustrates the default function. The function of the potentiometer can be altered using the ULTRA-PROG-IR software. As soon as a configuration has been changed, the potentiometer function selected using ULTRA-PROG-IR is activated.

Setting the Sensor Using the Potentiometers

The sensor is equipped with two potentiometers. These potentiometers are assigned to the switching output by default. The switching output operates in window mode by default (2 switching points). Potentiometer 1 is used to set the near switching point of the switching window. Potentiometer 2 is used to set the distant switching point of the switching window. Note:

The function of the potentiometer can be altered using the ULTRA-PROG-IR software. As soon as a configuration has been changed, the potentiometer function selected using ULTRA-PROG-IR is activated.

Parameterization via ULTRA-PROG-IR

In order to be able to set the sensor parameters and adjust the sensor to the respective application, the sensor is able to communicate with a PC via the integrated infrared interface. The UC-18/30GM-IR interface cable is required to allow communication via this method. This cable is connected to an unused USB port on the PC.



The ULTRA-PROG-IR parameterization software is also required for setting the sensor parameters. The ULTRA-PROG-IR software can be downloaded for free from the **www.pepperl-fuchs.com** website. The software allows all open parameters to be set, including:

- All trip points and switching hystereses
- Output modes and behaviors
- Delay times
- Settings and setting ranges of the potentiometer
- Settings for teach-in and synchronization
- Definition of blind zones
- Sensor modes and measurement methods
- Filtering measurement values

The following service functions are also available:

- Observing and recording measurement values
- Diagnosing interference reflections

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Teach-in

The sensor is equipped with a function input (XI). In order to teach in a limit value, this sensor must be parameterized as the Teach-in input using the ULTRA-PROG-IR parameterization software. This parameterization software allows you to specify what limit value is taught in. **Note:**

The Teach-in function is not activated when the sensor is delivered.

- Description of the Teach-in process:
- 1. Position an object at the required distance.
- 2. Connect the Teach-in input to L-.
 - The green LED lights up briefly after approx. 3 seconds. This indicates that the required distance has been successfully saved.
- 3. Disconnect the Teach-in input from L-.

Note:

If the Teach-in input remains connected to L-, the Teach-in process is repeated every 3 seconds.

Synchronization

The sensor features a function input (XI). Using the ULTRA-PROG-IR parameterization software, this function input can be configured as a synchronization input to suppress mutual interference from external ultrasonic signals. This is illustrated in the following description. If the synchronization input is not connected, the sensor operates with internally generated cycle pulses.

External synchronization

The sensor can be synchronized by applying external rectangular pulses. The pulse duration must be \geq 100 µs. Each rising pulse edge sends an individual ultrasonic pulse. If the signal at the synchronization input is high, the sensor reverts to the normal, unsynchronized operating mode. If a low signal is applied to the synchronization input, the sensor switches to standby. In this operating mode, the last recorded output statuses are retained.

Internal synchronization

Common mode operation

Up to ten sensors can be synchronized with each other. To do this, the synchronization inputs of the individual sensors are connected to each other. When configured in this state, all of the sensors send the ultrasonic signals together at the same time. The cycle rate corresponds to the cycle rate of the sensor with the lowest rate.

Multiplex mode

Up to ten sensors can work in multiplex mode; i.e. the sensors send their ultrasonic signals in succession. This prevents the sensor signals interfering with each other. In multiplex mode, the synchronization inputs of all sensors are connected to each other. An address must also be assigned to each sensor using the ULTRA-PROG-IR parameterization software, and the number of sensors to be synchronized must be determined. To start multiplex mode, all sensors are commissioned together by switching on the power supply.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

