	Technical data		
	General specifications		
· ···	Sensing range	50 800 mm	
E E	Adjustment range	70 800 mm	
N	Dead band	0 50 mm	
	Standard target plate	100 mm x 100 mm	
	Transducer frequency	approx. 255 kHz	
A STANAN AND A STANAN	Response delay Indicators/operating means	approx. 100 ms	
	LED green	Power on	
	LED yellow	indication of the switching state	
	,	flashing: program function object detected	
	LED red	solid red: Error	
		red, flashing: program function, object not detected	
	Electrical specifications	10 20 V DC ripple 10 %	
	Operating voltage U _B No-load supply current I ₀	10 30 V DC , ripple 10 % _{SS} ≤ 20 mA	
	Input	2 20 11/4	
	Input type	1 program input	
		operating distance 1: -U _B +1 V, operating distance 2: +6 V	
		+U _B	
	Output	input impedance: > 4,7 k Ω program pulse: ≥ 1 s	
odel Number	Output type	1 switching output E5, PNP NO/NC, programmable	
	Rated operating current I _e	200 mA, short-circuit/overload protected	
3800-18GM60-E5-V1-M	Default setting	Switch point A1: 70 mm Switch point A2: 800 mm	
ngle head system	Voltage drop U _d	≤ 3 V	
.g.ee.a eyetetti	Repeat accuracy	≤1 %	
atures	Switching frequency f	≤ 4 Hz	
	Range hysteresis H	1 % of the set operating distance	
Short version: 55 mm	Temperature influence	± 1.5 % of full-scale value	
Function indicators visible from all	Ambient conditions Ambient temperature	-25 70 °C (-13 158 °F)	
directions	Storage temperature	-40 85 °C (-40 185 °F)	
Switch output	Mechanical specifications		
•	Connection type	Connector M12 x 1, 4-pin	
5 different output functions can be	Degree of protection	IP67	
set	Material		
Program input	Housing	brass, nickel-plated	
• •	Transducer	epoxy resin/hollow glass sphere mixture; foam polyurethane, cover PBT	
Temperature compensation	Mass	31 g	
E1-Type approval	Compliance with standards and	org	
	directives		
agrams	Standard conformity		
agranis	Standards	EN 60947-5-2:2007 + A1:2012	
		IEC 60947-5-2:2007 + A1:2012	
aracteristic response curve	Approvals and certificates		
	UL approval CSA approval	cULus Listed, General Purpose cCSAus Listed, General Purpose	
ce Y [mm] 00	CCC approval	CCC approval / marking not required for products rated ≤36 \	
50	UN/ECE Regulation No. 10 (E1)	Type-approval number: 10R-058090	
	Dimensions		
50			
0 2 1			
50		an a	
)		
50			
00	M18 × 1		
0 200 400 600 800 1000 1200 1400	M ST	║┣┨╢┨║│║┷━╜┦┤	
Distance X [mm]			
X			
curve 1: flat surface 100 mm x 100 mm curve 2: round bar, Ø 25 mm			
a vo L. IVAIIA DAI, O LJ IIIII			

 Pefer to "General Notes Relating to Pepperl+Fuchs Product Information".

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 G

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com

Curve 1: flat surface 100 mm x 100 mm Curve 2: round bar, Ø 25 mm

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



51 62.3 UB800-18GM60-E5-V1-M

1

A1

object distance

Additional Information

Programmable output modes

1. Window mode, normally open mode

A1

2. Window mode, normally closed mode

A2

3. One switch point, normally open mode

A2 4. One switch point, normally closed mode

A1

5. A1 -> ∞, A2 -> ∞: Object presence detection mode Object detected: Switch output closed No object detected: Switch output open

A1 < A2:

A2 < A1:

A1 -> ∞:

A2 -> ∞:

Electrical Connection

Standard symbol/Connections: (version E5, pnp)



Core colours in accordance with EN 60947-5-2.

Pinout

Wire colors in accordance with EN 60947-5-2

BN	(brown)
WH	(white)
BU	(blue)
BK	(black)
	BU

Accessories

UB-PROG2 Programming unit

OMH-04

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

BF 18

Mounting flange, 18 mm

BF 18-F Mounting flange with dead stop, 18 mm

BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

V1-G-2M-PVC Female cordset, M12, 4-pin, PVC cable

V1-W-2M-PUR Female cordset, M12, 4-pin, PUR cable

Adjusting the switching points

The ultrasonic sensor features a switch output with two teachable switching points. These are set by applying the supply voltage $-U_B$ or $+U_B$ to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. Switching point A1 is taught with $-U_B$, A2 with $+U_B$.

fa-info@us.pepperl-fuchs.com

Five different output functions can be set

- 1. Window mode, normally-open function
- 2. Window mode, normally-closed function
- 3. one switching point, normally-open function
- 4. one switching point, normally-closed function
- 5. Detection of object presence

TEACH-IN window mode, normally-open function

- Set target to near switching point
- TEACH-IN switching point A1 with -U_B
- Set target to far switching point

www.pepperl-fuchs.com

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 G

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Date of issue: 2016-10-10 288382_eng.xml

Release date: 2016-10-10 10:54

2

- TEACH-IN switching point A2 with +UB

TEACH-IN window mode, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A2 with +U_B
- Set target to far switching point
- TEACH-IN switching point A1 with -U_B

TEACH-IN switching point, normally-open function

- Set target to near switching point
- TEACH-IN switching point A2 with +UB
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -U_B

TEACH-IN switching point, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A1 with -UB
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A2 with +U_B

TEACH-IN detection of objects presence

- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -UB
- TEACH-IN switching point A2 with +UB

LED Displays

Displays in dependence on operating mode	Red LED	Yellow LED
TEACH-IN switching point:		
Object detected	off	flashes
No object detected	flashes	off
Object uncertain (TEACH-IN invalid)	On	off
Normal operation	off	Switching state
Fault	on	Previous state

Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF18, BF18-F or BF 5-30 must be used.

In case of direct mounting of the sensor in a through hole using the steel nuts, it has to be fixed at the middle of the housing thread. If a fixation at the front end of the threaded housing is required, plastic nuts with centering ring (accessories) must be used.

