Retroreflective sensor

Dimensions



c(Ul CE 🚷 IO-Link US

Model Number

OBR7000-R100-2EP-IO-1R-IR

Retroreflective sensor with fixed cable

Features

- Miniature design with versatile • mounting options
- Extended temperature range ٠ -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and • process data

Product information

The R100 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.



Electrical connection



Indicators/operating means



Light-on/Dark-on changeover switch 1 2 Sensitivity adjuster 3 Operating indicator / dark on 4 Signal indicator 5 Operating indicator / light on

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Pepperl+Fuchs Group

www.pepperl-fuchs.com

Retroreflective sensor

Technical data

General specifications Effective detection range Reflector distance Threshold detection range Reference target Light source Light type LED risk group labelling Polarization filter Diameter of the light spot Angle of divergence Ambient light limit Functional safety related parameters MTTF_d Mission Time (T_M)

Diagnostic Coverage (DC) Indicators/operating means Operation indicator

Function indicator

Control elements Control elements Parameterization indicator

Electrical specifications
Operating voltage
Ripple
No-load supply current

Protection class Interface Interface type Transfer rate IO-Link Revision

Min. cycle time Process data witdh SIO mode support Device ID

Compatible master port type
Output

Switching type

Signal output

Switching voltage Switching current Usage category Voltage drop

Switching frequency Response time

Conformity Communication interface

Product standard

Ambient conditions Ambient temperature

Storage temperature Mechanical specifications

Housing width Housing height Housing depth Degree of protection Connection Material Housing

Optical face

www.pepperl-fuchs.com

Mass

0 ... 7 m 0.03 ... 7 m 10 m H85-2 reflector LED modulated infrared light 850 nm exempt group no approx. 100 mm at a distance of 1 m 5.4 ° EN 60947-5-2

724 a 20 a 0 %

UB

In

 U_{d}

LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode Yellow LED: Permanently lit - light path clear Permanently off - object detected Flashing (4 Hz) - insufficient operating reserve Light-on/dark-on changeover switch sensitivity adjustment IO link communication: green LED goes out briefly (1 Hz)

10 ... 30 V DC max. 10 % < 25 mA at 24 V supply voltage III

IO-Link (via C/Q = pin 4) COM 2 (38.4 kBaud) 1.1 2.3 ms Process data input 2 Bit Process data output 2 Bit yes 0x110201 (1114625) A

The switching type of the sensor is adjustable. The default setting is: C/Q - BK: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link /Q - WH: NPN normally closed / light-on, PNP normally open / dark-on 2 push-pull (4 in 1)outputs, short-circuit protected, reverse polarity protected, overvoltage protected max. 30 V DC max. 100 mA . resistive load DC-12 and DC-13 < 1.5 V DC 1000 Hz 0.5 ms IEC 61131-9 EN 60947-5-2 -40 ... 60 °C (-40 ... 140 °F) , fixed cable -25 ... 60 °C (-13 ... 140 °F), movable cable not appropriate for conveyor chains -40 ... 70 °C (-40 ... 158 °F) 11 mm 37.1 mm 21.5 mm IP67 / IP69 / IP69K 2 m fixed cable

OBR7000-R100-2EP-IO-1R-IR

Accessories

IO-Link-Master02-USB IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

OMH-R10X-01 Mounting bracket

OMH-R10X-02 Mounting bracket

OMH-R10X-04 Mounting bracket

OMH-R10X-10 Mounting bracket

OMH-ML100-03 Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

OMH-ML100-031 Mounting aid for round steel ø 10 ... 14 mm or sheet 1 mm ... 5 mm

REF-H85-2 Reflector, rectangular 84.5 mm x 84.5 mm, mounting holes

REF-H50 Reflector, rectangular 51 mm x 61 mm, mounting holes, fixing strap

OFR-100/100 Reflective tape 100 mm x 100 mm

REF-H33 Reflector with screw fixing

REF-VR10 Reflector, rectangular 60 mm x 19 mm, mounting holes

Other suitable accessories can be found at www.pepperl-fuchs.com

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 G

USA: +1 330 486 0001 Germa fa-info@us.pepperl-fuchs.com fa-info@

PC (Polycarbonate)

PMMA

approx. 36 g

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Cable length

2 m

Approvals and certificates

UL approval

E87056, cULus Listed, class 2 power supply, type rating 1

Curves/Diagrams





Functions and Operation



- 1 Light-on / dark-on changeover switch
- 2 Sensing range / sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

R

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".	
Pepperl+Fuchs Group USA: +1 330 486 0001 www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com	Germany: +49 621 5 fa-info@de.pepperl-f



3

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range /sensitivity adjuster for more than 180 degrees.

4

