### Safety control unit module

#### **Dimensions**





#### **Model Number**

#### SB4 Module 4C/165

Safety control unit module Module for Evaluation unit SafeBox - series SB4

#### **Features**

- ٠ Sensor module
- 4 sensor channels ٠
- Single module for safety thru-beam sensors SLA12 and SLA29 and for 2 channel safety devices (emergency off)
- Operating mode can be selected by • means of DIP switches
- · Screw terminals or spring terminals

#### Accessories

SB4 Cape cover sheet

SB4 Housing 2 Empty housing for Evaluation unit SB4

SB4 Housing 3 Empty housing for Evaluation unit SB4

SB4 Housing 4 Empty housing for Evaluation unit SB4

SB4 Housing 5 Empty housing for Evaluation unit SB4

SB4 Housing 6 Empty housing for Evaluation unit SB4

SB4 Housing 8 Empty housing for Evaluation unit SB4





### **Electrical connection**

14 1

-∰ B4

₩R3

∰ R2

-₩-R1

23





(LSS = transmitter of light barrier; LSE = receiver of light barrier)

### **Technical data**

| General specifications              |   |
|-------------------------------------|---|
| Operating mode                      | simultaneousness, antivalence   |
| Functional safety related parameter | rs  |
| Safety Integrity Level (SIL)        | SIL 3   |
| Performance level (PL)              | PL e  |
| Category                            | Cat. 4  |
| Mission Time (T <sub>M</sub> )      | 20 a  |
| Туре                                | 4   |
| Indicators/operating means          |   |
| Function indicator                  | LED yellow (4x): indicator lamp channel 1 4                                 |
| Pre-fault indicator                 | LED yellow flashing: Indicator lamp channel 1 4                             |
| Control elements                    | DIP-switch  |
| Electrical specifications           |   |
| Operating voltage U                 | $_{\rm B}$ 24 V DC ± 20 % , via SB4 Housing                                 |
| Input                               |   |
| Activation current                  | approx. 7 mA  |
| Conformity                          |   |
| Functional safety                   | ISO 13849-1 ; EN 61508 part1-4  |
| Product standard                    | EN 61496-1  |
| Ambient conditions                  |   |
| Ambient temperature                 | 0 50 °C (32 122 °F)   |
| Storage temperature                 | -20 70 °C (-4 158 °F)   |
| Mechanical specifications           |   |
| Degree of protection                | IP20  |
| Connection                          | Cage tension spring terminals , Cable cross-section 0.2 1.5 mm <sup>2</sup> |
| Material                            |   |

206757\_eng.xml Date of issue: 2017-12-05 Release date: 2017-12-05 15:19

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



### Safety control unit module

| Housing                    | Polyamide (PA) |  |  |
|----------------------------|----------------|--|--|
| Mass                       | approx. 150 g  |  |  |
| Approvals and certificates |                |  |  |
| CE conformity              | CE             |  |  |
| UL approval                | cULus          |  |  |
| TÜV approval               | TÜV            |  |  |
|                            |                |  |  |

The operation of this module is possible only within a control unit of the type SafeBox SB4.

The operating instruction of the SafeBox has to be observed.

# Function

The 4-channel sensor card module SB4-4C makes it possible to connect light barriers or light grids or contact safety sensors in a one or two-channel version.

When the system is switched on, the software determines whether a light barrier or a contact safety sensor is switched on at a channel and monitors its presence during operation. Safety sensors with switching contacts, which are connected to the Safe-Box, must operate in the switching mode "normally closed". An open contact means "safe status".

The channels 1 and 2 as well as 3 and 4 can be monitored for simultaneousness or antivalence. If simultaneousness monitoring is activated, 2 channel safety equipment is monitored for simultaneous opening or changing of the signals. The monitoring time is 2 s.

Antivalence monitoring expects the normally closed contact at channel 1 or 3 and the normally open contact at channel 2 or 4. If antivalence monitoring is performed without simultaneousness monitoring, an incorrect contact position causes a switch-off and the error message 7 after approx. 60 s.

## **Operation types**

The assembly contains 4 DIP switches for selecting the simultaneousness functions of neighbouring channels (1 and 2, 3 and 4) and for an antivalent evaluation of neighbouring channels (1 and 2, 3 and 4). For selecting functions, 2 selector switches must always be actuated. The functions are not effective if light barriers are connected.

### Position of the DIP switches



| Switch  | Position | Operation type                          |
|---------|----------|---|
| Switch  | FUSILION | Operation type                          |
| 1 and 3 | OFF      | No antivalent evaluation                |
|         | ON       | Antivalent evaluation active            |
| 2 and 4 | OFF      | No simultaneousness evaluation          |
|         | ON       | Simultaneousness eva-<br>luation active |

### Display

For each channel, there is a yellow LED on the front panel of the module.

| Display | LED    | Meaning  |
|---------|--------|--|
| R1 - R4 | yellow | Status of light barrier 1 4  |
|         |        | Off: light beam interrupted<br>On: light beam released                   |
|         |        | Flashing (2.5 Hz): light beam released, function reserve fallen short of |
|         |        | Flashing (5 Hz): error   |

Release date: 2017-12-05 15:19 Date of issue: 2017-12-05 206757\_eng.xml

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group USA: +1 3 www.pepperl-fuchs.com fa-info@us.pe



2

SB4 Module 4C/165