

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"
Pepperl+Fuchs Group
USA: +1 330 486 0001
G

www.pepperl-fuchs.com fa-inf

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

76 4411 Singapor uchs.com fa-info@sg.p

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com 

# UB500-18GM75-E23-V15

1

# UB500-18GM75-E23-V15

## Dimensions



# **Electrical Connection**



Core colours in accordance with EN 60947-5-2.

## Pinout



#### Wire colors in accordance with EN 60947-5-2

1 2	BN WH	(brown) (white)
3	BU	(blue)
4	BK	(black)
5	GY	(gray)

# Additional Information

# Programmed switching output function

Switch output 1 (N.O.)	Object range	
Switch output 2 (N.C.)		
Switch point 1 -> ∞:	Switch output 1, (N.O.) Detection of object presence	
Switch point 2 -> $\infty$ :	Switch output 2, (N.C.) Detection of object presence	



## Accessories

**UB-PROG3** Programming unit

## **OMH-04**

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

**BF 18** 

Mounting flange, 18 mm

#### **BF 18-F**

Mounting flange with dead stop, 18 mm

#### BF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

UVW90-K18 Ultrasonic -deflector

V15-G-2M-PVC Female cordset, M12, 5-pin, PVC cable

## M18K-VF

# **Description of Sensor Functions**

## Programming procedure

The sensor features two switch outputs with one programmable switch point, each. Programming the switch points is done by applying the supply voltage -U<sub>B</sub> (switch output 1) or +U<sub>B</sub> (switch output 2) to the Teach-In input. The supply voltage must be applied to the Teach-In input for at least 1 s. LEDs indicate whether the sensor has recognized the target during the programming procedure.

#### Note:

Switching points may only be specified directly after Power on. A time lock secures the adjusted switching points against unintended modification 5 minutes after Power on. To modify the switching points later, the user may specify the desired values only after a new Power On.

#### Note:

If a programming adapter UB-PROG3 is used for the programming procedure, button A1 is assigned to -U<sub>B</sub> and button A2 is assigned to +U<sub>B</sub>.

## Programming switch ouputs

#### Switch point for switch output 1

- 1. Place the target at the desired switch point position of switch output 1
- 2. Program the switch point by applying -U<sub>B</sub> to the Teach-In input (corresponding yellow LED flashes)
- 3. Disconnect the Teach-In input from -U<sub>B</sub> to save the switch point
- Switch point for switch output 2
- 1. Place the target at the desired switch point position of switch output 2
- 2. Program the switch point by applying +U<sub>B</sub> to the Teach-In input (corresponding yellow LED flashes)
- 3. Disconnect the Teach-In input from  $+U_B$  to save the switch point

## Programming detection of object presence

- 1. Cover the sensor face with hand or remove all objects from sensing range
- 2. Apply -U<sub>B</sub> to the Teach-In input (red LED flashes)
- 3. Disconnect the Teach-In input from -UB
- 4. Apply  $+U_B$  to the Teach-In input (red LED flashes)
- 5. Disconnect the Teach-In input from +UB

Note: Only one switch output can be configured for detection of presence of objects. If the sensor detects an object within the maximum detection range, the switch output switches.

#### Adjusting the sound cone characteristics:

The ultrasonic sensor enables two different shapes of the sound cone, a wide angle sound cone and a small angle sound cone.

#### 1. Small angle sound cone

- · switch off the power supply
- connect the Teach-In input wire to -UB
- switch on the power supply
- the red LED flashes once with a pause before the next.
- ÷Ř: 「 yellow LED: permanently on: indicates the presence of an object or disturbing object within the sensing range
- disconnect the Teach-In input wire from -U<sub>B</sub> and the changing is saved

### 2. Wide angle sound cone

- switch off the power supply
- connect the Teach-In input wire with +UB
- switch on the power supply
- the red LED double-flashes with a long pause before the next. ٠
- yellow LED: permanently on: indicates an object or disturbing object within the sensing range
- disconnect the Teach-In input wire from +U<sub>B</sub> and the changing is saved

# **Factory settings**

See technical data.

# Display

eng.xml

130227

Date of issue: 2016-04-13

2016-04-13 11:21

date:

Release

The sensor provides LEDs to indicate various conditions.





pause

, ĐÓ: ,

	Red LED	Yellow LED 1	Yellow LED 2
During Normal operation			
Proper operation	Off	Switching state	Switching state
		output 1	output 2
Interference (e.g. compressed air)	On	remains in previous	remains in previous
		state	state
Programming of output 1			
Object detected	Off	Flashes	Off
No object detected	Flashes	Off	Off
Object uncertain (programming invalid)	On	Off	Off
Programming of output 2			
Object detected	Off	Off	Flashes
No object detected	Flashes	Off	Off
Object uncertain (programming invalid)	On	Off	Off

## Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF18, BF18-F or BF 5-30 must be used.

In case of direct mounting of the sensor in a through hole using the steel nuts, it has to be fixed at the middle of the housing thread. If a fixation at the front end of the threaded housing is required, plastic nuts with centering ring (accessories) must be used.

