
Installation Instructions Adapter

> efectorsoo E30116

05/2011

706015/00

Mounting sensor - adapter



- ► Slightly grease the threads and sealing areas of the sensor and adapter with the lubricating paste (A).
 - The paste must be suitable and approved for the application and compatible with the elastomers used.
- ► Screw the sensor into the adapter until it is hand-tight.
- ► Clamp sensor and adapter into a clamping device (B). Tighten the clamping device only slightly so that the adapter does not warp.
- ► Tighten the sensor using a spanner (tightening torque: 20 Nm).

Technical data and further information at www.ifm.com