

Operating instructions Diffuse reflection sensor with background suppression EFECLOFECO OGH3xx OGH5xx

CE





1 Preliminary note

1.1 Symbols used

- Instruction
- > Reaction, result
- \rightarrow Cross-reference



Non-compliance can result in malfunctions or interference.

2 Functions and features

The diffuse reflection sensor detects objects and materials without contact and indicates their presence by a switching signal.

Range: (\rightarrow type label).

3 Installation



1: LED

► Align the diffuse reflection sensor to the object to be detected.

Secure it to a bracket.

Note:

The objects to be detected are to move transversely to the lens of the sensor.

In case of other directions of movement it should be tested before whether safe switching is guaranteed.



4 Electrical connection

The unit must be connected by a qualified electrician.

- The national and international regulations for the installation of electrical equipment must be adhered to.
- ► Ensure voltage supply to EN 50178.
- Disconnect power.
- ► Connect the unit as follows:

Connector



pin 1 = L+ (pin 2 = not connected) pin 3 = Lpin 4 = load

Cable



Core colours: BN = brown, BU = blue, BK = black

5 Operation

- ► Check whether the unit operates correctly.
- Dark-on switching units (OGH-DPKG): the output is switched / the yellow LED is lit when no object is detected.
- Light-on switching units (OGH-HPKG): the output is switched / the yellow LED is lit when an object is detected.

6 Maintenance, repair and disposal

- ► Keep the front lens of the sensor free from soiling.
- For cleaning do not use any solvents or cleaning agents which could damage the plastic material.

Technical data and further information at www.ifm.com