


Thru-beam sensor, 15 m detection range, infrared light, light/dark on, DC version, PNP output, sensitivity adjuster, emitter switch-off, fixed cable



Function

The ML100 series is characterized by its miniature housing with integral, all-metal threaded bushings. All versions are equipped with a visible red transmitter LED. This greatly simplifies installation and commissioning. The switching states are easily visible from all directions thanks to the highly visible LEDs.

Dimensions



Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

1

Technical Data

| System components | | |
|--------------------------------------|----------------|---|
| Emitter | | M100-6090/95/76b |
| Receiver | | MV100-6090/95/102 |
| General specifications | | |
| Effective detection range | | 0 15 m |
| Threshold detection range | | 20 m |
| Light source | | IRED |
| Light type | | modulated infrared light |
| Diameter of the light spot | | approx. 1.5 m at a distance of 20 m |
| Angle of divergence | | approx. 2 ° |
| Optical face | | frontal |
| Ambient light limit | | EN 60947-5-2 |
| Functional safety related parameters | | |
| MTTF _d | | 860 a |
| Mission Time (T _M) | | 20 a |
| Diagnostic Coverage (DC) | | 0 % |
| Indicators/operating means | | |
| Operation indicator | | LED green: power on |
| Function indicator | | Receiver: LED yellow, lights up when light beam is free, flashes when falling short of the stability control ; OFF when light beam is interrupted |
| Control elements | | sensitivity adjustment |
| Control elements | | Light-on/dark-on changeover switch |
| Electrical specifications | | |
| Operating voltage | U _B | 10 30 V DC |
| Ripple | | max. 10 % |
| No-load supply current | I ₀ | Emitter: ≤ 15 mA Receiver: ≤ 8 mA |
| Input | | |
| Test input | | emitter deactivation at +U _B |
| Output | | |
| Switching type | | The switching type of the sensor is adjustable. The default setting is: light-on |
| Signal output | | 1 PNP output, short-circuit protected, reverse polarity protected, open collector |
| Switching voltage | | max. 30 V DC |
| Switching current | | max. 100 mA , resistive load |
| Voltage drop | U_d | ≤ 1.5 V DC |
| Switching frequency | f | 250 Hz |
| Response time | | 2 ms |
| Conformity | | |
| Product standard | | EN 60947-5-2 |
| Approvals and certificates | | |
| UL approval | | cULus Listed, Class 2 Power Source or listed Power Supply with a limited voltage output with (maybe integrated) fuse (max. 3.3 A according UL248), Type 1 enclosure |
| CCC approval | | CCC approval / marking not required for products rated \leq 36 V |
| Ambient conditions | | |
| Ambient temperature | | -30 60 °C (-22 140 °F) |
| Storage temperature | | -40 70 °C (-40 158 °F) |
| Mechanical specifications | | |
| Housing width | | 11 mm |
| Housing height | | 31 mm |
| Housing depth | | 20 mm |
| | | IP67 |
| Degree of protection | | |
| Degree of protection Connection | | |
| | | 300 mm fixed cable with M12 connector, 4-pin |


Thru-beam sensor


M100/MV100-IR/76a/103/115b

Technical Data

| Optical face | PMMA | |
|-------------------------------------|-------------------------------------|--|
| Mass | approx. 40 g (emitter and receiver) | |
| Tightening torque, fastening screws | 0.6 Nm | |
| Cable length | 0.3 m | |

Connection Assignment





O = Light on

= Dark on


Connection Assignment



Wire colors in accordance with EN 60947-5-2

| 1 | BN | (brown) |
|---|----|---------|
| 2 | WH | (white) |
| 3 | BU | (blue) |
| 4 | BK | (black) |

Assembly



| 1 | Light-Dark-switching | |
|---|----------------------|--------|
| 2 | Sensitivity adjuster | |
| 3 | Signal display | yellow |
| 4 | Operating display | green |


Pepperl+Fuchs Group www.pepperl-fuchs.com


Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Characteristic Curve





Accessories

| J. | OMH-ML100-S2 | Mounting aid for ML100 series, mounting bracket |
|--|---------------|---|
| C. | OMH-ML100-09 | Mounting aid for round steel ø 12 mm or sheet 1.5 mm 3 mm |
| | OMH-ML100-01 | Mounting aid for ML100 series, mounting bracket |
| J. | OMH-ML100-02 | Mounting aid for ML100 series, mounting bracket |
| and the second s | OMH-ML100-03 | Mounting aid for round steel ø 12 mm or sheet 1.5 mm 3 mm |
| | OMH-ML100-04 | Mounting aid for ML100 series, mounting bracket |
| | OMH-ML100-05 | Mounting aid for ML100 series, mounting bracket |
| * | OMH-F10-ML100 | Mounting aid for ML100 series |

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

4

| Accessones | | | | |
|------------|--------|--------------|--|--|
| 1 1 | OMH-10 | Mounting aid | | |
| - 1 | | | | |

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 Get

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com

5

Accessories

Additional accessories can be found in the Internet.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

