

Model Number

UB300-18GM40-E5-V1-Y220359


Single head system

Features

- Short design, 40 mm •
- Function indicators visible from all directions
- . Switch output
- 5 different output functions can be • set
- **Program input** .
- Temperature compensation •

Diagrams

Characteristic response curve



Technical data
General specifications
Sensing range
Adjustment range
Dead band
Standard target plate
Transducer frequency
Response delay
Indicators/operating mea
LED green
LED yellow
LED red
Electrical specifications
Operating voltage UB
No-load supply current I0

Input Input type

Output Output type Rated operating current Ie Default setting Voltage drop U_d Repeat accuracy Switching frequency f Range hysteresis H Temperature influence Ambient conditions Ambient temperature Storage temperature Mechanical specifications Connection type Degree of protection Material

- Housing Transducer
- Mass Compliance with standards and directives Standard conformity
 - Standards

Approvals and certificates

UL approval CSA approval CCC approval

UB300-18GM40-E5-V1-Y220359

35 ... 300 mm 50 ... 300 mm 0 ... 35 mm 100 mm x 100 mm approx. 390 kHz approx. 18 ms

Power on indication of the switching state flashing: program function object detected solid red: Error red, flashing: program function, object not detected

10 ... 30 V DC , ripple 10 %_{SS} \leq 20 mA

1 program input operating distance 1: -U_B ... +1 V, operating distance 2: +6 V ... +U_B input impedance: > 4,7 kΩ program pulse: ≥ 1 s

1 switching output E5, PNP NO/NC, programmable 200 mA , short-circuit/overload protected Switch point A1: 50 mm Switch point A2: 300 mm < 3 V ≤1 % ≤ 26 Hz 1 % of the set operating distance ± 1.5 % of full-scale value

10 ... 60 °C (50 ... 140 °F) -40 ... 85 °C (-40 ... 185 °F)

Connector M12 x 1 , 4-pin IP67

brass, nickel-plated

epoxy resin/hollow glass sphere mixture; foam polyurethane, cover PBT 25 g

EN 60947-5-2:2007 + A1:2012 IEC 60947-5-2:2007 + A1:2012

cULus Listed, General Purpose cCSAus Listed, General Purpose CCC approval / marking not required for products rated ≤36 V

Date of issue: 2016-04-25 Release date: 2016-04-25 09:29

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com




220359_eng.xml

Dimensions



Electrical Connection





Core colours in accordance with EN 60947-5-2.

Pinout

Connector V1



Accessories

UB-PROG2 Programming unit

OMH-04

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

BF 18 Mounting flange, 18 mm

BF 18-F

Mounting flange with dead stop, 18 mm

BF 5-30 Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

V1-G-2M-PVC Female cordset, M12, 4-pin, PVC cable

V1-W-2M-PUR Female cordset, M12, 4-pin, PUR cable

Adjusting the switching points

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sq.pepperl-fuchs.com



Additional Information

Programmable output modes



5. A1 -> ∞ , A2 -> ∞ : Object presence detection mode Object detected: Switch output closed No object detected: Switch output open

The ultrasonic sensor features a switch output with two teachable switching points. These are set by applying the supply voltage $-U_B$ or $+U_B$ to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. Switching point A1 is taught with $-U_B$, A2 with $+U_B$.

Five different output functions can be set

- 1. Window mode, normally-open function
- 2. Window mode, normally-closed function
- 3. one switching point, normally-open function
- 4. one switching point, normally-closed function
- 5. Detection of object presence

TEACH-IN window mode, normally-open function

- Set target to near switching point
- TEACH-IN switching point A1 with -UB
- Set target to far switching point
- TEACH-IN switching point A2 with +UB

TEACH-IN window mode, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A2 with +U_B
- Set target to far switching point
- TEACH-IN switching point A1 with -UB

TEACH-IN switching point, normally-open function

- Set target to near switching point
- TEACH-IN switching point A2 with +UB
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -U_B

TEACH-IN switching point, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A1 with -UB
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A2 with +UB

TEACH-IN detection of objects presence

- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -UB
- TEACH-IN switching point A2 with +U_B

LED Displays

Displays in dependence on operating mode	Red LED	Yellow LED
TEACH-IN switching point:		
Object detected	off	flashes
No object detected	flashes	off
Object uncertain (TEACH-IN invalid)	On	off
Normal operation	off	Switching state
Fault	on	Previous state

Installation conditions

If the sensor is installed at places, where the environment temperature can fall below 0 °C, for the sensors fixation, one of the mounting flanges BF18, BF18-F or BF 5-30 must be used.

In case of direct mounting of the sensor in a through hole using the steel nuts, it has to be fixed at the middle of the housing thread. If a fixation at the front end of the threaded housing is required, plastic nuts with centering ring (accessories) must be used.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

