Dimensions





CE

Model Number

SBL-8-H-900-IR/59/65b/73/136

Background suppression sensor with 4-pin, M12 x 1 connector

Features


- Background suppression sensor for • roller conveyors
- For installation between the rollers on ٠ a roller conveyor
- Very small black-white difference .
- Adjustable detection range •
- Modern dual push-pull outputs ٠

Product information

Sensors of the SBL series are used to easily control material flow on roller conveyors in material handling and other branches.

The SBL series is a precise background suppression sensor according to the 3 element method. The sensor features superior background suppression and a very good ambient light immunity. Material and transport container of all colors and opacities are reliably detected.

The special design allows the sensor to be mounted between the rollers of a roller conveyor or any other conveying unit. Mounting between the rollers is easy and protects the sensor.



Electrical connection

Option: +UB 2 ō 3 0 V 4 Q

$$O = Light on$$


 $\bullet = Dark on$

Pinout





Indicators/operating means



	1	Signal display	yellow
	2	Sensing range adjuster	

Pepperl+Fuchs Group www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com ⁵ PEPPERL+FUCHS 1

SBL-8-H-900-IR/59/65b/73/136

Technical data			Accessories	
General specifications			OMH-SBL-01	
Detection range		40 900 mm	Mounting bracket for sensors of SBL	
Detection range min.		40 340 mm	series	
Detection range max.		40 900 mm	Series	
Adjustment range		340 900 mm	V1-G-2M-PVC	
Reference target		standard white 200 mm x 200 mm	Female cordset, M12, 4-pin, PVC cable	
Light source		IRED		
Light type		modulated infrared light , 880 nm	V1-G-5M-PVC	
Black/White difference (6 %/9) 0 %)	< 10 %	Female cordset, M12, 4-pin, PVC cable	
Diameter of the light spot		approx. 60 mm at detection range 900 mm		
Ambient light limit		continuous light 30000 Lux, Fluorescent lamp 5000 Lux	V1-W-2M-PUR	
Functional safety related part	rameters		Female cordset, M12, 4-pin, PUR cable	
MTTF _d		1100 a	V1-W-5M-PUR	
Mission Time (T _M)		20 a		
Diagnostic Coverage (DC)		0 %	Female cordset, M12, 4-pin, PUR cable	
Indicators/operating means			Schraubendreher 0,5 x 3,0 mm	
Function indicator		LED yellow: lights when object is detected	Screwdriver	
Control elements		Sensing range adjuster		
Electrical specifications			Other suitable accessories can be found a	
Operating voltage	U _B	24 VDC -20% +10%	www.pepperl-fuchs.com	
Ripple	ч	max. 10 %		
No-load supply current	I ₀	max. 20 mA		
Output	0			
Switching type		dark on		
Signal output		2 push-pull (4 in 1) outputs, short-circuit protected, reverse		
Signal output		polarity protected		
Switching voltage		max. 30 V DC		
Switching current		max. 100 mA		
Switching frequency	f	100 Hz		
Response time		5 ms		
Conformity				
Product standard		EN 60947-5-2		
Ambient conditions				
Ambient temperature		-20 50 °C (-4 122 °F)		
Storage temperature		-30 60 °C (-22 140 °F)		
Mechanical specifications				
Housing width		18 mm		
Housing height		100 mm		
Housing depth		46 mm		
Degree of protection		IP65		
Connection		4-pin, M12 x 1 connector		
Material				
Housing		plastic		
Optical face		plastic lens		
Mass		approx. 50 g		
Compliance with standards a directives	and			
Standard conformity				
Shock and impact resistanc	e	IEC / EN 60068. half-sine, 40 g in each X, Y and Z directions		
Vibration resistance		IEC / EN 60068-2-6. Sinus. 10 -1000 Hz, 10 g in each X, Y and Z directions		
Approvals and certificates				
UL approval		cULus Listed, Class 2 Power Source, Type 1 enclosure		
CCC approval		CCC approval / marking not required for products rated ≤36 V		

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

www.pepperl-fuchs.com

2


Germany: +49 621 776 1111

fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

EPPERL+FUCHS

Curves/Diagrams



Options:

Sensors with the version -V are equipped with a solenoid valve and can directly control a 3/2 way pneumatic actuator, without any-interaction of an external system controlling unit (PLC). As soon as conveyed goods are detected, the diffuse mode sensor gives an electrical-signal to the pneumatic solenoid valve, which is then activated.

Sensors with the control logic option -SL-(V) allows up to 50 diffuse mode sensors to be connected-to each other (data and power), depending on the current consumption of sensor and solenoid valve. An additional supply power and data bus cable is used to interconnect the sensors with control logic option -SL. All necessary functions for controlling the material flow of conveyed goods are supported, such as: single feed, single release, slug release, external motor and solenoid valve control. It is also possible to energize the valves of all sensors included in the cascade by slug release (VT). To do this, apply the positive supply voltage (+UB) on the input VT of the first sensor.

Sensors with timing function -Z features the adjustment of the ON- and OFF delay of the output independently. This optimizes control of the solenoid valve. A zero pressure accumulation of the conveyed goods can be realized with application of time ONand OFF delay of the output. The ON- and OFF delay to control the switching of the solenoid valve may be adjusted between 0 and 2 seconds.

Additional power supply between every 20 to 25 sensors can be realized by the use of the power in feed junction V1S-TEE-V1/ V1S in combination with a cable V1-G-...-PVC. This features to practically connect any number of SBL sensors in series. Attention should be paid to the maximum rated current of the cable and the connectors which usually is max. I = 4 A. For more details on the maximum rated current of single components, please refer to our datasheet values. For the electrical supply of the sensors the country specific standards have to be considered.

Note:

Pepperl+Fuchs Group

www.pepperl-fuchs.com

Use a screwdriver to adjust the sensing range. We strongly recommend to use the screwdriver given in the accessories section.

