

Product information

The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and

can be adapted to the application environment.



Electrical connection emitter



LLLL

Electrical connection receiver



Pinout



Wire colors in accordance with EN 60947-5-2 BN (brown) BU BK (blue) (black)

eng.xml

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com Emitter

Receiver

O

\$

Indicators/operating means Laserlabel Operating indicator CLASS 1 I ASER Ē PRODUCT ГЩП CLASS 1 LASER PRODUCT IEC 60825-1: 2007 certified. Complies with 21 CFR 1040.10 and 1040.11 except 1 Sensitivity adjustment for deviations pursuant to Laser Notice No. 50, dated June 24, 2007 2 Light-on / dark-on changeover switch Ē 3 Operating indicator / dark on 4 Signal indicator Ē 5 Operating indicator / light on CLASS 1 LASER PRODUCT IEC 60825-1: 2007 certified. Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007 Accessories IO-Link-Master02-USB IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection V3-GM-2M-PUR Female cordset single-ended, M8, 3-pin, PUR cable V3-WM-2M-PUR Female cordset single-ended, M8, 3-pin, PUR cable OMH-RL31-02 Mounting bracket narrow OMH-RL31-03 Mounting bracket narrow **OMH-RL31-04** Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm OMH-RL31-07 _eng.xml Mounting bracket including adjustment 129 **OMH-R20x-Quick-Mount** 301 Quick mounting accessory October suitable accessories can be found at www.pepperl-fuchs.com Quick mounting accessory

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

www.pepperl-fuchs.com

Technical data		
System components		
Emitter		OBE40M-R201-S-IO-0,3M-V3-L
Beceiver		OBE40M-R201-EP-IO-0,3M-V3-L
		0DE40M-R201-EF-10-0,3M-V3-E
General specifications		0 10
Effective detection range		0 40 m
Threshold detection range		50 m
Light source		laser diode
Light type		modulated visible red light
Laser nominal ratings		
Note		LASER LIGHT , DO NOT STARE INTO BEAM
Laser class		1
Wave length		680 nm
Beam divergence		> 5 mrad ; d63 < 2 mm in the range of 250 mm 750 mm
Pulse length		1.6 μs
Repetition rate		max. 17.6 kHz
max. pulse energy		9.6 nJ
Alignment aid		LED red (in receiver lens) illuminated constantly: beam is interrupted, flashes: reaching switching point, off: sufficient stability control
Diameter of the light spot		approx. 80 mm at a distance of 40 m
Angle of divergence		approx. 0.12 °
Ambient light limit		EN 60947-5-2 : 40000 Lux
Functional safety related parame	eters	
MTTF _d		440 a
Mission Time (T _M)		20 a
Diagnostic Coverage (DC)		60 %
Indicators/operating means		
Operation indicator		LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode
Function indicator		Yellow LED: Permanently lit - light path clear Permanently off - object detected Flashing (4 Hz) - insufficient operating reserve
Control elements		Receiver: light/dark switch
Control elements		Receiver: sensitivity adjustment
Electrical specifications		
Operating voltage	UB	10 30 V DC
Ripple		max. 10 %
No-load supply current	I ₀	Emitter: ≤ 13 mA
		Receiver: ≤ 15 mA at 24 V Operating voltage
Protection class		III
Interface		
Interface type		IO-Link (via C/Q = pin 4)
Device profile		Identification and diagnosis Smart Sensor: Receiver: type 2.4 Emitter: -
Transfer rate		COM 2 (38.4 kBaud)
IO-Link Revision		1.1
Min. cycle time		2.3 ms
Process data witdh		Emitter: Process data input: 0 bit Process data output: 1 bit Receiver: Process data input: 2 bit
		Process data output: 2 bit
SIO mode support Device ID		yes Emitter: 0x111412 (1119250) Receiver: 0x111312 (1118994)
Compatible master port type Input		Α
Test input		emitter deactivation at +U _B
Output		
Switching type		The switching type of the sensor is adjustable. The default setting is: C/Q - Pin4: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link
Signal output		1 push-pull (4 in 1) output, short-circuit protected, reverse polarity protected, overvoltage protected
Switching valtage		max. 30 V DC
Switching voltage		
Switching current		max. 100 mA, resistive load
Switching current Usage category	11	DC-12 and DC-13
Switching current Usage category Voltage drop	U _d	DC-12 and DC-13 ≤ 1.5 V DC
Switching current Usage category	U _d f	DC-12 and DC-13

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

0	
Conformity	
Communication interface	IEC 61131-9
Product standard	EN 60947-5-2
Laser safety	EN 60825-1:2014
Ambient conditions	
Ambient temperature	-40 60 °C (-40 140 °F) , fixed cable -20 60 °C (-4 140 °F) , movable cable not appropriate for conveyor chains
Storage temperature	-40 70 °C (-40 158 °F)
Mechanical specifications	
Housing width	15 mm
Housing height	61.7 mm
Housing depth	41.7 mm
Degree of protection	IP67 / IP69 / IP69K
Connection	300 mm fixed cable with M8 x 1, 3-pin connector
Material	
Housing	PC (Polycarbonate)
Optical face	РММА
Mass	Emitter: approx. 51 g receiver: approx. 51 g

0.3 m

Approvals and certificates

UL approval CCC approval

Cable length

FDA approval

E87056 , cULus Listed , class 2 power supply , type rating 1 CCC approval / marking not required for products rated ≤36 V IEC 60825-1:2007 Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007

Curves/Diagrams





Functions and Operation

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range /sensitivity adjuster for more than 180 degrees.

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com