





CE

Model Number

SBL-8-H-600-IR-4022

Background suppression sensor with 4-pin, M12 x 1 connector

Features

- Background suppression sensor for • roller conveyors
- For installation between the rollers on ٠ a roller conveyor
- Very small black-white difference •
- Adjustable detection range •
- Direction of plug coding offset by 90° compared to IEC 60947-5-2

Product information

Sensors of the SBL series are used to easily control material flow on roller conveyors in material handling and other branches.

The SBL series is a precise background suppression sensor according to the 3 element method. The sensor features superior background suppression and a very good ambient light immunity. Material and transport container of all colors and opacities are reliably detected.

The special design allows the sensor to be mounted between the rollers of a roller conveyor or any other conveying unit. Mounting between the rollers is easy and protects the sensor.



(brown) (white) (blue) (black)

Electrical connection



= Dark on

Pinout



Indicators/operating means



	1	Signal display	yellow
	2	Sensing range adjuster	

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com ⁵ PEPPERL+FUCHS 1

Technical data			Accessories	
General specifications				
Detection range		15 600 mm	OMH-SBL-01	
Detection range min.		15 250 mm	Mounting bracket for sensors of SBL series	
Detection range max.		15 600 mm		
•		250 600 mm		
Adjustment range Reference target		standard white 200 mm x 200 mm	V1-G-2M-PVC	
Light source		IRED	Female cordset, M12, 4-pin, PVC cable	
Light type		modulated infrared light , 880 nm	V1-G-5M-PVC	
Black/White difference (6 %/90 %)		< 15 %	Female cordset, M12, 4-pin, PVC cable	
Diameter of the light spot	, ,,,,	approx. 40 mm at detection range 600 mm		
Ambient light limit		continuous light 30000 Lux, Fluorescent lamp 5000 Lux	V1-W-2M-PUR	
Functional safety related para	ameters	·····3·····	Female cordset, M12, 4-pin, PUR cable	
MTTF _d		1100 a		
Mission Time (T _M)		20 a	V1-W-5M-PUR	
Diagnostic Coverage (DC)		0 %	Female cordset, M12, 4-pin, PUR cable	
Indicators/operating means			V1S-TEE-V1/V1S	
Function indicator		LED yellow: lights when object is detected		
Control elements		Sensing range adjuster	T-Distributor, M12 connector to M12	
Electrical specifications			socket/connector	
Operating voltage	UB	24 VDC -20% +10%	Schraubendreher 0,5 x 3,0 mm	
Ripple	OB	max. 10 %	Screwdriver	
No-load supply current	I ₀	max. 20 mA	Borewanter	
Output	10		Additional accessories can be found in the	
Switching type		dark on	Internet.	
Signal output		1 PNP, short-circuit protected, reverse polarity protected		
Switching voltage		max. 30 V DC		
Switching current		max. 200 mA		
Switching frequency	f	100 Hz		
Response time		5 ms		
Conformity				
Product standard		EN 60947-5-2		
Ambient conditions				
Ambient temperature		-20 50 °C (-4 122 °F)		
Storage temperature		-30 60 °C (-22 140 °F)		
Mechanical specifications				
Housing width		18 mm		
Housing height		100 mm		
Housing depth		46 mm		
Degree of protection		IP65		
Connection		4-pin, M12 x 1 connector		
Material		F ,		
Housing		plastic		
Optical face		plastic lens		
Mass		approx. 50 g		
Compliance with standards a directives	nd			
Standard conformity				
Shock and impact resistance	;	IEC / EN 60068. half-sine, 40 g in each X, Y and Z directions		
Vibration resistance		IEC / EN 60068-2-6. Sinus. 10 -1000 Hz, 10 g in each X, Y and Z directions		
Approvals and certificates				
UL approval		cULus Listed, Class 2 Power Source, Type 1 enclosure		
CCC approval		CCC approval / marking not required for products rated \leq 36 V		

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

2

Germany: +49 621 776 1111

fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

EPPPERL+FUCHS

Curves/Diagrams



Note:

Use a screwdriver to adjust the sensing range. We strongly recommend to use the screwdriver given in the accessories section.