Safety control unit module

Dimensions



Model Number

SB4 Module 4MD/165

Safety control unit module Module for Evaluation unit SafeBox - series SB4

Features

- Muting module ٠
- 4 sensor channels ٠
- Double muting
- Continuous muting with no time limit .
- Emergency muting for the correction ٠ of the material jam
- ٠ Operating mode can be selected by means of DIP switches

80.3

00.5



Electrical connection





Technical data

| General specifications | | |
|---------------------------------|----------------|---|
| Operating mode | | muting operating modes |
| Functional safety related param | eters | |
| Safety Integrity Level (SIL) | | SIL 3 |
| Performance level (PL) | | PL e |
| Mission Time (T _M) | | 20 a |
| Туре | | 4 |
| Indicators/operating means | | |
| Function indicator | | LED yellow (4x): indicator lamp muting sensor 1 4 LED white (2x): status muting lamp |
| Control elements | | DIP-switch |
| Electrical specifications | | |
| Operating voltage | U _B | 24 V DC \pm 20 % , 24 V DC \pm 20 % , via SB4 Housing |
| Input | | |
| Activation current | | approx. 10 mA |
| Activation time | | Override-Input 0.4 1.2 s |
| Output | | |
| Switching voltage | | 24 V |
| Switching current | | 7.5 mA 500 mA |
| Conformity | | |
| Functional safety | | ISO 13849-1 ; EN 61508 part1-4 |
| Product standard | | EN 61496-1 |
| Ambient conditions | | |
| Ambient temperature | | 0 50 °C (32 122 °F) |
| Storage temperature | | -20 70 °C (-4 158 °F) |
| | | |

Release date: 2017-12-05 15:19 Date of issue: 2017-12-05 216909_eng.xml

www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

Safety control unit module

| Mechanical specifications | |
|----------------------------|--|
| Degree of protection | IP20 |
| Connection | Cage tension spring terminals, Cable cross-section 0.2 1.5 mm ² |
| Material | |
| Housing | Polyamide (PA) |
| Mass | approx. 150 g |
| Approvals and certificates | |
| CE conformity | CE |
| UL approval | cULus |
| TÜV approval | TÜV |

This module can only be operated within an evaluation device of the SafeBox SB4 type.

The SafeBox instruction manual should be observed.

Function

The muting module realises the muting function for the sensor channels of the four to six channel sensor card module immediately to the right of the module.

The user must make sure to only connect sensors that can be muted to the sensor card that is assigned to the muting module. These are, for example, light barriers or light grids.



Emergency off push buttons must not be muted.

This muting module does not monitor the activation time of the muting sensors.

The following must be observed for the application:



The access to the protected area is completely blocked by the object which triggers muting. If the muting sensors are activated, it should not be possible to access the hazardous area via the object.

With parallel muting, an application in the category 4 is possible. With sequential muting, only a category 2 can still be reached.

The basis of the assessment of the safety category is that every muting sensor is activated at least once per day (the activation is triggered when the muting procedure is not interrupted).

A detailed description of the muting operating modes can be found in the instruction manual.

Muting sensors

Muting sensors are supposed to detect the muting objects. If an object is detected, the output of the muting sensor switches through its supply voltage. For this purpose, sensors with relay or pnp output are suitable. In a de-energised state, the output of the muting sensor must not be active. The sensor output should be capable of reliably switching a load current of 8 mA at 20 V. Muting sensors with a current consumption of a maximum of 30 mA can be supplied directly from the muting module. Sensors with a higher current consumption require an external power supply. Muting sensors must be selected such that they also work at a supply voltage of at least 12 V.

The cables to the muting sensors must be laid in such a way that no short circuits are possible between the muting sensors.

As muting sensors, the following sensors can be used, for example:

- ·Retro-reflective sensors dark on or light on (in this case reflector at the object),
- ·Photoelectric sensors (light on),
- ·Inductive sensors, mechanical switches.

Settings

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.co



Safety control unit module

The assembly has 8 DIP switches for selecting the different muting operating modes. For selecting functions, 2 selector switches must always be actuated.

Position Switch **Operation type** Position of the DIP switches OFF Muting lamp monitor-Group 1 ing inactive and 2 ON Muting lamp monitor-ing active 2 OFF Single muting 00 ------Group 1 ON Double muting Ο. and 2 0 يىتىتىتى ш Funct ۵ 3 OFF The muting sensors group 1 ۵ Group 1 can be activated and 2 without a time limit Ē ON Before protected group 2 area activation, the muting sensors can be activated without a time limit; from protected area activation, muting limited by protection beam OFF 4 Sequential muting

Displays

The muting module has a yellow display for each muting sensor. For each muting lamp there is a white display.

ON

If there is an error in the muting module, only the yellow displays on this assembly will flash.

Group 1

and 2

In the case of an error on the muting lamps, the white muting displays will flash if the muting lamp monitoring is activated.

Parallel muting

| Display | LED | Meaning |
|---------|--------|---|
| 1 - 4 | yellow | Continuous light: muting sensor activated |
| | | Flashing (5 Hz). muting sensor error |
| M1, M2 | white | Continuous light: muting activated |
| | | Flashing (5 Hz). muting lamp error |

www.pepperl-fuchs.com



3