



(€





Model Number

OBT650-R201-2EP-IO-V1

Triangulation sensor (BGS) with 4-pin, M12 x 1 connector

Features

- Medium design with versatile mounting options
- Best background suppressor in its
- Precision object detection, almost irrespective of the color
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and process data

Product information


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and can be adapted to the application environment.


Dimensions



(brown) (white)

(blue) (black)


Electrical connection



Pinout



Indicators/operating means



1	Sensitivity adjustment	
2	Light-on / dark-on changeover switch	
3	Operating indicator / dark on GN	
4	Signal indicator YE	
5	Operating indicator / light on	GN

Technical data				
General specifications		10 650 mm		
Detection range Detection range min.		10 100 mm		
•		10 650 mm		
Detection range max. Adjustment range		100 650 mm		
Reference target		standard white, 100 mm x 100 mm		
Light source		LED		
Light type		modulated visible red light		
LED risk group labelling		exempt group		
Black/White difference (6 %/90 %)		< 6 % at 650 mm		
Diameter of the light spot		approx. 20 mm x 20 mm at a distance of 650 mm		
Angle of divergence		approx. 2°		
Ambient light limit		EN 60947-5-2 : 70000 Lux		
Functional safety related parameter	tare	211 000 17 0 2 . 70000 Eux		
MTTF _d	ICI S	600 a		
Mission Time (T _M)		20 a		
Diagnostic Coverage (DC)		0%		
		0 /0		
Indicators/operating means		LED green:		
Operation indicator		constantly on - power on		
		flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode		
Function indicator		LED yellow:		
		constantly on - object detected constantly off - object not detected		
Control elements		Light-on/dark-on changeover switch		
Control elements		Sensing range adjuster		
Electrical specifications		0 0 ,		
Operating voltage	U _R	10 30 V DC		
Ripple	оВ	max. 10 %		
• • •	I _O	< 25 mA at 24 V supply voltage		
Protection class	-0	III		
Interface				
Interface type		IO-Link (via C/Q = pin 4)		
Device profile		Identification and diagnosis		
		Smart Sensor type 2.4		
Transfer rate		COM 2 (38.4 kBaud)		
IO-Link Revision		1.1		
Min. cycle time		2.3 ms		
Process data witdh		Process data input 1 Bit Process data output 2 Bit		
SIO mode support		yes		
Device ID		0x111611 (1119761)		
Compatible master port type		A		
Output				
Switching type		The switching type of the sensor is adjustable. The default		
		setting is: C/Q - Pin4: NPN normally open / light-on, PNP normally closed dark-on, IO-Link		
		/Q - Pin2: NPN normally closed / dark-on, PNP normally open / light-on		
Signal output		2 push-pull (4 in 1)outputs, short-circuit protected, reverse polarity protected, overvoltage protected		
Switching voltage		max. 30 V DC		
Switching current		max. 100 mA , resistive load		
Usage category		DC-12 and DC-13		
Voltage drop	U _d	≤ 1.5 V DC		
	f	500 Hz		
Response time		1 ms		
Conformity				
Communication interface		IEC 61131-9		
Product standard		EN 60947-5-2		
Ambient conditions				
Ambient temperature		-40 60 °C (-40 140 °F)		
Storage temperature		-40 70 °C (-40 158 °F)		
Mechanical specifications				
Housing width		15 mm		
Housing width Housing height		61.7 mm		
Housing neight Housing depth		41.7 mm		
Degree of protection		41.7 mm IP67 / IP69 / IP69K		
Connection		4-pin, M12 x 1 connector, 90° rotatable		
Material		T-pin, W112 X 1 CONTINECTOR, SU TOTATABLE		
Housing		PC (Polycarhonate)		
Optical face		PC (Polycarbonate) PMMA		
Mass				
IVIGOS		approx. 47 g		

Accessories

IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

V1-W-2M-PUR

Female cordset, M12, 4-pin, PUR cable

V1-G-2M-PUR

Female cordset, M12, 4-pin, PUR cable

OMH-RL31-02

Mounting bracket narrow

OMH-RL31-03

Mounting bracket narrow

OMH-RL31-04

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

OMH-RL31-07

Mounting bracket including adjustment

OMH-R20x-Quick-Mount


Quick mounting accessory


Other suitable accessories can be found at www.pepperl-fuchs.com


Approvals and certificates

 $\begin{tabular}{lll} UL approval & E87056 \ , \ cULus \ Listed \ , \ class \ 2 \ power \ supply \ , \ type \ rating \ 1 \\ CCC \ approval \ / \ marking \ not \ required \ for \ products \ rated \ \le 36 \ V \\ \end{tabular}$

Curves/Diagrams







To unlock the adjustment functions, rotate the sensing range/sensitivity adjuster by more than 180°.

Sensing Range/Sensitivity

To increase the sensing range/sensitivity, rotate the sensing range/sensitivity adjuster clockwise.

To reduce the sensing range/sensitivity, rotate the sensing range/sensitivity adjuster counter-clockwise.

As soon as the end of the adjustment range is reached, the signal indicator flashes at 8 Hz.

Configuring Light On/Dark On

Press the light-on/dark-on changeover switch for more than 1 second (but less than 4 seconds). "Light on/dark on" mode changes and the relevant operating indicator lights up.

If you press the light-on/dark-on changeover switch for longer than 4 seconds, the "light on/dark on" mode will switch back to the original setting. The current status is activated when the light-on/dark-on changeover switch is released.

Restoring Factory Settings

Press the light-on/dark-on changeover switch for more than 10 seconds (but less than 30 seconds) until all LEDs go out. When the light-on/dark-on changeover switch is released, the signal indicator lights up. After 5 seconds, the sensor resumes operation with the factory settings.

The adjustment functions are locked after 5 minutes of inactivity. To unlock the adjustment functions, rotate the sensing range/ sensitivity adjuster again by more than 180°.