










# **Dimensions**



# **Model Number**

## SLC14-600-S

Slave module for master slave mode

## **Features**

- Sensing range up to 5 m
- Resolution 14 mm (finger protection)
- · Protection field height up to 750 mm
- Self-monitoring (type 4 according to IEC/EN 61496-1)
- Master/Slave detection, Plug and Play
- Start/Restart disable
- Degree of protection IP67
- Integrated function display
- Pre-fault indication
- Safety outputs OSSD in potential-separated semiconductor design or with monitored, compelled connection NC-contacts
- Optional with ATEX certificates for zone 2 and 22 and degree of protection IP66 (Option 133)

# **Accessories**


# **PG SLC-600**

Protective glass panes for SLC series

# **BA SLC**

laser alignment aid for safety light cutrtains series SLC

# **Electrical connection**



www.pepperl-fuchs.com

Emitter SLC14-600-T-S SLC14-600-R-S Receiver

# **General specifications**

Effective detection range 0.2 ... 5 m IRFD Light source

Light type modulated infrared light

LED risk group labelling exempt group

IEC/EN 61496 Tests

Safety type according to IEC/EN 61496 0.2 ... 5 m Width of protected area Protection field height 600 mm Number of beams

Operating mode in the master Optical resolution 14 mm Angle of divergence < 5 °

#### Functional safety related parameters

Safety Integrity Level (SIL) SIL 3 PL e Performance level (PL) Category Cat. 4 Mission Time (T<sub>M</sub>) 20 a 2.42 E-8  $PFH_d$ Type 4

# Indicators/operating means

Operation indicator in the master Diagnostics indicator in the master Function indicator in the master Pre-fault indicator in the master Control elements in the master

### **Electrical specifications**

Operating voltage  $U_{B}$ from master No-load supply current from master Protection class

#### Input

Test input in the master Function input in the master

## Output

Safety output in the master Signal output in the master

Response time depends on height of protective field

#### Conformity

Functional safety ISO 13849-1

Product standard EN 61496-1; IEC 61496-2

### **Ambient conditions**

0 ... 55 °C (32 ... 131 °F) Ambient temperature Storage temperature -25 ... 70 °C (-13 ... 158 °F) Relative humidity max. 95 %, not condensing

# Mechanical specifications

Housing length L 710 mm IP67 Degree of protection Connection

M20 cable gland,

terminal compartment with screw terminals, lead cross-section max. 1.5 mm<sup>2</sup>

### Material

Housing extruded aluminum profile, RAL 1021 (yellow) coated

Optical face Plastic pane Per 2100 g Mass


### Approvals and certificates


CE CE conformity UL approval cULus Listed

CCC approval / marking not required for products rated ≤36 V CCC approval

TÜV approval

117585\_eng.xml





# **Notes**

# Response times of cascading units

If cascading units are set up, the response time of the entire SLC, consisting of a master and a slave, must be determined. The overall number of beams for master and slave can be determined from technical data sheets. Depending on the type of output, the resulting response time can be read from the table.

		i
	1	

Number of beams	Response time in milliseconds		
	Semiconductor output	Relay output	
8	10	30	
16	10	30	
24	12	32	
32	14	34	
40	16	36	
48	18	38	
56	20	40	
64	22	42	
72	24	44	
80	26	46	
88	28	48	
96	30	50	

Example: Master: SLC14-300/31 32 beams

Slave: SLC60-90-S+ 24 beams

56 beams

56 beams, OSSD relay --> response time = 40 ms.

#### **Notes**

#### Master slave mode

Master: SLC..-... (semiconductor)

or

SLC..-.../31 (relay)

Slave: SLC..-...-S

Using slaves makes it possible to lengthen protective fields or to form protective fields that lie in more than just one level. When you select slaves that can be connected, you should take into consideration that the maximum number of 96 light rays must not be exceeded.

There are slaves for transmitters and receivers. These may simply be connected to the master light curtain. As many as 2 slaves may be connected respectively to the transmitter and receiver unit.

## Installation:

- 1 The end cap should be screwed off for the light curtain (without cable gland).
- 2 The plug-in jumper on the connectors of the printed circuit board, which is now visible, should be removed.
- 3 The slave is designed so that the cap located on the cable connector can be plugged directly onto the open end of the light curtain with the printed circuit board.
- 4 After you have screwed on the connection cap, the system is complete.

# **System accessories**

- Mounting set SLC
- Test rods SLC14/SLC30/SLC60
- Protective glass pieces for SLC (to protect the optically functional surface)
- Lateral screwed connection SLC
- Profile alignment aid
- Laser alignment aid SLC
- Mirror for SLC (for securing hazardous areas on multiple sides)
- Ground pillar UC SLP/SLC
- Housing for pillar

Enclosure UC SLP/SLC

 Collision protector Damping UC SLP/SLC