

CE

Model Number

UB400-F77-F-V31

Ultrasonic direct detection sensor

Features

- Miniature design
- Frequency output ٠
- **Program input** .
- **Degree of protection IP67**
- Switching status indicator, yellow LED

Diagrams

Characteristic response curve



General specifications				
Sensing range				
Dead band				
Standard target plate				
Transducer frequency				
Response delay				
Nominal ratings				
Time delay before availability ty				
Limit data				
Permissible cable length				
Indicators/operating means				
LED yellow				
Electrical specifications				
Rated operating voltage U				
Operating voltage U _B				
No-load supply current I0				
Input				
Input type				
Level				
Input impedance				
Pulse length				
Output				
Output type				
Rated operating current Ie				
Voltage drop U _d				
Resolution				
Repeat accuracy				
Off-state current Ir				
Output frequency				
Temperature influence				
Ambient conditions				
Ambient temperature				
Storage temperature				
Shock resistance				
Vibration resistance				
Mechanical specifications				
Connection type				
Degree of protection				
Material				
Housing				
Transducer				
Installation position				
Mass				
Tightening torque, fastening screw				
Compliance with standards and				
directives				
Standard conformity				
Standards				
• · · · · · · · · · · · · · · · · · · ·				

Technical data

Approvals and certificates

UL approval CCC approval

Safety Note



The use of this device in applications, where the safety of persons depends from the devices function, is not allowed!

UB400-F77-F-V31

40 400 mm
0 40 mm
20 mm x 20 mm
approx. 300 kHz
≤ 75 ms
< 150 mg
≤ 150 ms
max. 300 m
object inside the scanning range
24 V DC
20 30 V DC , ripple 10 % _{SS} ; 12 20 V DC sensitivity
reduced to 90 %
≤ 20 mA
1 program input
low level : 0 0.7 V (Teach-In active)
high level : U_B or open input (Teach-In inactive) 16 k Ω
>3s
238
Frequency output, PNP
100 mA , short-circuit/overload protected
<2 V
Standard 2 Hz / mm
± 2.5 %
≤ 0.01 mA
frequency : 80 800 Hz (40 400 Hz), adjustable
+ 0.17 %/K
-25 70 °C (-13 158 °F)
-40 85 °C (-40 185 °F)
30 g , 11 ms period
10 55 Hz , Amplitude ± 1 mm
M8 x 1 connector , 4-pin
IP67
Polycarbonate
epoxy resin/hollow glass sphere mixture; polyurethane foam
any position

10 g max. 0.2 Nm

EN 60947-5-2:2007+A1:2012 IEC 60947-5-2:2007 + A1:2012

cULus Listed, General Purpose CCC approval / marking not required for products rated ≤36 V

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111

fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

EPEPPERL+FUCHS

UB400-F77-F-V31

Dimensions



Description of Sensor Function

The ultrasonic sensor transmits ultrasonic packages in quick succession and responds to their reflection off the detected object. It has a frequency output that delivers a square wave signal. The frequency of this signal changes linearly with the distance of the object. Two frequency ranges are available.

Description of the Frequency Selection

Proceed as follows to select the frequency range:

Standard frequency 80 ... 800 Hz

- 1. Connect terminal ET to +U_B or leave it open.
- 2. Switch on the operating voltage.
- 3. The sensor will be ready for operation after 3 seconds.

Low frequency 40 ... 400 Hz

- 1. Connect terminal (ET) to -U_B.
- 2. Switch on the operating voltage.
- 3. The sensor will be ready for operation after 3 seconds.

ET	unusable area	Sensing range 40 400 mm	> 400 mm or no object
Open or +U _B	Undefined	80 800 Hz	800 Hz
-U _B	Undefined	40 400 Hz	400 Hz

Note:

Switching the potential on ET during operation will not change the frequency range.

Mounting instruction

www.pepperl-fuchs.com

If the sensor is operated at temperatures below 0 °C, use the supplied distance plate. Only use the two rearmost mounting holes (located opposite to the transducer) for mounting the sensor.

Safety Note

The use of this device in applications, where the safety of persons depends from the devices function, is not allowed!

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com