

Model Number

OBR25M-R201-2EP-IO-L

Laser retroreflective sensor with fixed cable

Features

- Medium design with versatile • mounting options
- DuraBeam Laser Sensors durable ٠ and employable like an LED
- Extended temperature range • -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and process data

Product information


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.


Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and can be adapted to the application

environment.






Electrical connection



Indicators/operating means



| 1 | Sensitivity adjustment | |
|---|--------------------------------------|----|
| 2 | Light-on / dark-on changeover switch | |
| 3 | Operating indicator / dark on | GN |
| 4 | Signal indicator | YE |
| 5 | Operating indicator / light on | GN |

Pepperl+Fuchs Group

www.pepperl-fuchs.com

eng.xml

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

| Technical data | | | Laserlabel |
|--|---------------------|---|------------------------------|
| General specifications | | 0.05 | |
| Effective detection range Reflector distance | | 0 25 m 0.5 25 m | |
| Threshold detection range | | 33 m | |
| Reference target | | H85-2 reflector | |
| Light source | | laser diode | |
| Light type | | modulated visible red light | |
| Polarization filter | | Yes | |
| Laser nominal ratings | | | |
| Note | | LASER LIGHT, DO NOT STARE INTO BEAM | |
| Laser class | | 1 | |
| Wave length | | 680 nm | IEC 6 |
| Beam divergence | | > 5 mrad d63 < 2 mm in the range of 250 mm 750 mm | Com |
| Pulse length | | 1.6 µs | 1040 for d |
| Repetition rate | | max. 17.6 kHz | Lase |
| max. pulse energy | | 9.6 nJ | |
| Diameter of the light spot | | approx. 50 mm at a distance of 25 m | |
| Angle of divergence | | approx. 0.1 ° | |
| Ambient light limit | | EN 60947-5-2 : 60000 Lux | |
| Functional safety related para | meters | 270 | CLASS |
| MTTF _d | | 672 a | |
| Mission Time (T _M) Diagnostic Coverage (DC) | | 20 a 0 % | |
| • • • • • | | 0 % | IEC 60825-1 |
| Indicators/operating means | | | Complies wit |
| Operation indicator | | LED green: constantly on - power on | 1040.11 exce Laser Notice |
| | | flashing (4Hz) - short circuit | |
| | | flashing with short break (1 Hz) - IO-Link mode | |
| Function indicator | | Yellow LED: | |
| | | Permanently lit - light path clear Permanently off - object detected | Accessorie |
| | | Flashing (4 Hz) - insufficient operating reserve | Accessorie |
| Control elements | | Light-on/dark-on changeover switch | IO-Link-Mast |
| Control elements | | sensitivity adjustment | IO-Link maste |
| Electrical specifications | | | separate pow |
| Operating voltage | UB | 10 30 V DC | M12 plug for s |
| Ripple | | max. 10 % | |
| No-load supply current | I ₀ | < 15 mA at 24 V Operating voltage | OMH-RL31-0 |
| Protection class | | III | Mounting brac |
| Interface | | | OMH-RL31-0 |
| Interface type | | IO-Link (via $C/Q = BK$) | Mounting brac |
| Device profile | | Identification and diagnosis | wounting brac |
| T () | | Smart Sensor type 2.4 | OMH-RL31-0 |
| Transfer rate | | COM 2 (38.4 kBaud) | Mounting aid |
| IO-Link Revision Min. cycle time | | 1.1 2.3 ms | sheet 1.5 mm |
| Process data witdh | | Process data input 2 Bit | |
| FIDCESS data witum | | Process data output 2 Bit | OMH-RL31-0 |
| SIO mode support | | yes | Mounting brac |
| Device ID | | 0x111212 (1118738) | OMH-R20x-G |
| Compatible master port type | | A | Quick mountin |
| Output | | | Quick mountin |
| Switching type | | The switching type of the sensor is adjustable. The default | REF-H85-2 |
| | | setting is: | Reflector, rec |
| | | C/Q - BK: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link | 84.5 mm, moi |
| | | /Q - WH: NPN normally closed / light-on, PNP normally open / | |
| | | dark-on | REF-C110-2 |
| Signal output | | 2 push-pull (4 in 1)outputs, short-circuit protected, reverse | Reflector, rou |
| | | polarity protected, overvoltage protected | mounting hole |
| Switching voltage | | max. 30 V DC | |
| Switching current | | max. 100 mA, resistive load | REF-H50 |
| Usage category | | DC-12 and DC-13 | Reflector, rec |
| Voltage drop | U _d f | ≤ 1.5 V DC 2000 Hz | mounting hole |
| Switching frequency Response time | 1 | 250 μs | REF-VR10 |
| • | | -00 µ3 | Reflector, rec |
| Conformity Communication interface | | IEC 61131.0 | mounting hole |
| Product standard | | IEC 61131-9 EN 60947-5-2 | |
| Laser safety | | EN 60825-1:2014 | OFR-100/100 |
| Ambient conditions | | | Reflective tap |
| Ambient conditions | | -40 60 °C (-40 140 °F) , fixed cable | |
| . insient temperature | | $-20 \dots 60 \degree$ C ($-4 \dots 140 \degree$ F), movable cable not appropriate for | REF-MH82 |
| | | conveyor chains | Reflector with |
| Storage temperature | | -40 70 °C (-40 158 °F) | rectangular 82 |
| Mechanical specifications | | | holes |



CLASS 1 I ASER PRODUCT

ssories

nk-Master02-USB nk master, supply via USB port or ate power supply, LED indicators, olug for sensor connection

RL31-02 ting bracket narrow

RL31-03 ting bracket narrow

-RL31-04 ting aid for round steel ø 12 mm or 1.5 mm ... 3 mm

RL31-07 ting bracket including adjustment

R20x-Quick-Mount mounting accessory

H85-2 ctor, rectangular 84.5 mm x nm, mounting holes

C110-2 ctor, round ø 84 mm, central ting hole

H50 ctor, rectangular 51 mm x 61 mm, ting holes, fixing strap

VR10 ctor, rectangular 60 mm x 19 mm, ting holes

100/100 ctive tape 100 mm x 100 mm

MH82 ctor with Micro-structure, ngular 82 mm x 60 mm, mounting holes

REF-MH78

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

USA: +1 330 486 0001

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Mechanical specifications

EPPERL+FUCHS

295670-100087_eng.xml

Date of issue: 2019-10-31


Release date: 2018-05-23 09:22


| Housing width | 15 mm | | |
|----------------------------|--|--|--|
| Housing height | 61.7 mm | | |
| Housing depth | 41.7 mm | | |
| Degree of protection | IP67 / IP69 / IP69K | | |
| Connection | 2 m fixed cable | | |
| Material | | | |
| Housing | PC (Polycarbonate) | | |
| Optical face | PMMA | | |
| Mass | approx. 83 g | | |
| Cable length | 2 m | | |
| | | | |
| Approvals and certificates | | | |
| UL approval | E87056 , cULus Listed , class 2 power supply , type rating 1 | | |
| CCC approval | CCC approval / marking not required for products rated ≤36 V | | |

FDA approval

ai / marking not requ for proa IEC 60825-1:2007 Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007

Curves/Diagrams





295670-100087 eng.xml

Date of issue: 2019-10-31

Release date: 2018-05-23 09:22

Functions and Operation

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

| Refer to "General Notes Relating to Pepperl+Fuchs Product Information". | | | | | | | | | |
|---|------------------------------|------------------------------|------------------------------|--|--|--|--|--|--|
| Pepperl+Fuchs Group | USA: +1 330 486 0001 | Germany: +49 621 776 1111 | Singapore: +65 6779 9091 | | | | | | |
| www.pepperl-fuchs.com | fa-info@us.pepperl-fuchs.com | fa-info@de.pepperl-fuchs.com | fa-info@sg.pepperl-fuchs.com | | | | | | |

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range / sensitivity adjuster for more than 180 degrees.